

# MODBUSConfigurator

RESI's MODBUS Configurator V1.10.7.6 - [Unnamed]

**Local COM port settings**

Modbus unit: 255 Device: COM1 Stopbits: 1 stopbit IP-Address: \_\_\_\_\_  
Baudrate: 19200 Parity: NONE Port: \_\_\_\_\_

**Device specific**

Download config Test connection Test

RESI-DMX-SIO DMX512 to MODBUS/RTU+ASCII module for up to 512 DMX lamps  
Software version: ???? State: ???? Start DMX Stop DMX Set DMX Length Write DMX registers Read DMX registers

**MODBUS**

Address: 255 Baudrate: 57600 Parity: NONE Stopbits: 1 stopbit

Register	Value	Comment
4x0001	0x00A.10	Current value of DMX Register 1
4x0002	0x00FF.255	Current value of DMX Register 2
4x0003	0x001E.30	Current value of DMX Register 3
4x0004	0x0000.0	Current value of DMX Register 4
4x0005	0x0000.0	Current value of DMX Register 5
4x0006	0x0000.0	Current value of DMX Register 6
4x0007	0x0000.0	Current value of DMX Register 7
4x0008	0x0000.0	Current value of DMX Register 8
4x0009	0x0000.0	Current value of DMX Register 9
4x0010	0x0000.0	Current value of DMX Register 10
4x0011	0x0000.0	Current value of DMX Register 11
4x0012	0x0000.0	Current value of DMX Register 12
4x0013	0x0000.0	Current value of DMX Register 13
4x0014	0x0000.0	Current value of DMX Register 14
4x0015	0x0000.0	Current value of DMX Register 15
4x0016	0x0000.0	Current value of DMX Register 16
4x0017	0x0000.0	Current value of DMX Register 17
4x0018	0x0000.0	Current value of DMX Register 18
4x0019	0x0000.0	Current value of DMX Register 19
4x0020	0x0000.0	Current value of DMX Register 20
4x0021	0x0000.0	Current value of DMX Register 21
4x0022	0x0000.0	Current value of DMX Register 22
4x0023	0x0000.0	Current value of DMX Register 23
4x0024	0x0000.0	Current value of DMX Register 24
4x0025	0x0000.0	Current value of DMX Register 25
4x0026	0x0000.0	Current value of DMX Register 26
4x0027	0x0000.0	Current value of DMX Register 27
4x0028	0x0000.0	Current value of DMX Register 28
4x0029	0x0000.0	Current value of DMX Register 29
4x0030	0x0000.0	Current value of DMX Register 30
4x0031	0x0000.0	Current value of DMX Register 31
4x0032	0x0000.0	Current value of DMX Register 32
4x0033	0x0000.0	Current value of DMX Register 33
4x0034	0x0000.0	Current value of DMX Register 34

**Einfacher Test**  
Test aller DMX Geräte

**GRATIS**  
Kostenloser Download von [www.RESI.cc](http://www.RESI.cc)

**Windows**  
basiert