

Command NAME	ASCII command type	ASCII command structure	NEW REAL VALUE	NEW VALUE	DATA TYPE	DO WRITE
ASCII COMMANDS						
HEART BEAT	ASCII READ COMMAND	#HB<CR> Result: #HB<CR>			ASCII	
	TX	#1,HB<CR>				
	RX	#1,HB<CR>				
Sends an Heartbeat to test the communcation						
GET VERSION	ASCII READ COMMAND	#VERSION<CR> Result: #VERSION:<VersionHi>,<VersionMed>,<VersionLo><CR>			ASCII	
	TX	#1,VERSION<CR>				
	RX	#1,VERSION:1.2.00<CR>				
		Current SW version:1.2.00				
Returns the version number of the module VersionHi: Version number high (1..255) VersionMed: Version number medium (1..255) VersionLo: Version number low (1..255)						
GET TYPE	ASCII READ COMMAND	#TYPE<CR> Result: #TYPE:<Type><CR>			ASCII	
	TX	#1,TYPE<CR>				
	RX	#1,TYPE:RESI-6DI6DO4AIOX-SIO<CR>				
		Current module type:RESI-6DI6DO4AIOX-SIO				
Returns the current module type						
GET FEATURES	ASCII READ COMMAND	#FTRS<CR> Result: #FTRS:<Type><CR>			ASCII	
	TX	#1,FTRS<CR>				
	RX	#1,FTRS:RESI-6DO6DO4AIOX-SIO,RS485,DI:6,DO:6,DOIC:MAX14915,AIOX:4<CR>				
		Current module type:#1,FTRS:RESI-6DO6DO4AIOX-SIO,RS485,DI:6,DO:6,DOIC:MAX14915,AIOX:4<CR>				
Returns the current module features						
GET OWNER	ASCII READ COMMAND	#OWNER<CR> Result: #OWNER:<Owner><CR>			ASCII	
	TX	#1,OWNER<CR>				
	RX	#1,OWNER:RESI<CR>				
		Current owner:RESI				
Returns the current owner of the module						

GET CREATOR	ASCII READ COMMAND	#CREATOR<CR> Result: #CREATOR:<Creator><CR>	ASCII	
	TX	#1,CREATOR<CR>		
	RX	#1,CREATOR:DI HC SIGL,MSC<CR>		
		Current creator:DI HC SIGL,MSC		
Returns the current creator of the module				
GET COPYRIGHT	ASCII READ COMMAND	#COPYRIGHT<CR> Result: #COPYRIGHT:<Copyright><CR>	ASCII	
	TX	#1,COPYRIGHT<CR>		
	RX	#1,COPYRIGHT:2015-24 BY RESI AND DI HC SIGL,MSC WWW.RESI.CC<CR>		
		Current copyright:2015-24 BY RESI AND DI HC SIGL,MSC WWW.RESI.CC		
Returns the current copyright of the module				
GET SERIAL NUMBER	ASCII READ COMMAND	#SN<CR> Result: #SN:<Serial><CR>	ASCII	
	TX	#1,SN<CR>		
	RX	#1,SN:280029001457435535343920<CR>		
		Current serial number:280029001457435535343920		
Returns the current serial number of the module				
GET INTERNAL STATUS	ASCII READ COMMAND	#INTSTAT<CR> Result: #INTSTAT:<Status><CR>	ASCII	
	TX	#1,INTSTAT<CR>		
	RX	#1,INTSTAT:I2C1:0,I2C2:0,FRAM:84<CR>		
Returns the device specific internal status				
GET DIP SWITCH	ASCII READ COMMAND	#GDIP<CR> Result: #GDIP:<DIPSwitchDec>,<DIPSwitchHex><CR>	ASCII	
	TX	#1,GDIP<CR>		
	RX	#1,GDIP:65,0x41<CR>		
		Current DIP SWITCH settings:0100.0001		
Returns the current setting of the Dip switches as decimal number and as hexadecimal number. DIPSwitchDec DIPSwitchHex The current value of the DIP switches: Bit 0: DIP Switch 1 (=0:OFF, =1:ON) Bit 1: DIP Switch 2 (=0:OFF, =1:ON) Bit 2: DIP Switch 3 (=0:OFF, =1:ON) Bit 3: DIP Switch 4 (=0:OFF, =1:ON) Bit 4: DIP Switch 5, if available (=0:OFF, =1:ON) Bit 5: DIP Switch 6, if available (=0:OFF, =1:ON) Bit 6: DIP Switch 7, if available (=0:OFF, =1:ON) Bit 7: DIP Switch 8, if available (=0:OFF, =1:ON)				
ASCII COMMANDS				

SET MODBUS ADDRESS	ASCII WRITE COMMAND	#SMBADR:<UNITID> <CR> Result: #OK<CR>	ASCII	NO
	UNITID	123		
	TX	#1,SMBADR:123<CR>		
	RX	N/A		
Redefines the unit ID of the module. This change will affect the MODBUS/RTU communication immediately. As a Unit IO you can use the values 0dec to 255dec.				
HINT: The new settings are activated after a system reboot or power off on cycle!				
SET MODBUS BAUDRATE	ASCII WRITE COMMAND	#SMBBAUD:<BAUD> <CR> Result: #OK<CR>	ASCII	NO
	BAUD	128000:128000BD		
	TX	#1,SMBBAUD:128000<CR>		
	RX	N/A		
Sets a new baud rate in the FLASH For ULTRA SLIM IOs RESI-xxx-SIO: This baudrate is only used, if DIP switch mode DIP1=ON+DIP2=ON (BR) (default is 57600bd) For BIG IOs RESI-xxx-SIO: This baudrate is only used, if DIP switch mode DIP7=ON (PARAMETER) (default is 57600bd) The following baudrates are allowed: 300bd, 600bd, 900bd, 1200bd, 2400bd, 4800bd, 9600bd, 19200bd, 38400bd, 57600bd, 115200bd, 128000bd 230400bd, 250000bd, 256000bd				
HINT: The new setup parameters will be active after a restart of the module.				
SET MODBUS PARITY	ASCII WRITE COMMAND	#SMBPAR:<PARITY> <CR> Result: #OK<CR>	ASCII	NO
	PARITY	ODD:ODD PARITY		
	TX	#1,SMBPAR:ODD<CR>		
	RX	N/A		
Sets a new parity for the serial interface. MBParity: NONE: no parity EVEN: even parity ODD: odd parity				
HINT: The new setup parameters will be active after a restart of the module.				
SET MODBUS STOPS	ASCII WRITE COMMAND	#SMBSTOP:<STOPBIT> <CR> Result: #OK<CR>	ASCII	NO
	STOPBIT	TWO:TWO STOPBITS		
	TX	#1,SMBSTOP:TWO<CR>		
	RX	N/A		

Sets a new amount of stop bits for the serial interface. MBStops ONE: one stop bit TWO: two stop bits HINT: The new setup parameters will be active after a restart of the module.				
SET MODBUS PARAMS	ASCII WRITE COMMAND	#SMBPARAMS:<UNITID>,<BAUD>,<PARITY>,<STOPBIT><CR> Result: #OK<CR>	ASCII	NO
	UNITID	3		
	BAUD	115200:115200BD		
	PARITY	EVEN:EVEN PARITY		
	STOPBIT	TWO:TWO STOPBITS		
	TX	#1,SMBPARAMS:3,115200,EVEN,TWO<CR>		
	RX	N/A		
Sets all parameters for serial interface				
GET MODBUS ADDRESS	ASCII READ COMMAND	#GMBADR<CR> Result: #GMBADR:<MBUnitDec>,<MBFLASHDec>,<MBUnitHex>,<MBFLASHHex><CR>	ASCII	
	TX	#1,GMBADR<CR>		
	RX	#1,GMBADR:1,15,0x1,0xF<CR>		
		Current MODBUS unit ID:1,15,0x1,0xF		
Shows the current used MODBUS/RTU or ASCII unit address and shows also the stored unit address in the FLASH memory, which is only used if the DIP switch for the bus address is set to 0. MBUnitDec,MBUnitHex The current used MODBUS/RTU unit or ASCII address for communication MBFLASHDec,MBFLASHHex The internal stored MODBUS/RTU unit address or ASCII address from the FLASH memory, if the DIP switch DIP3 is OFF.				
GET MODBUS BAUDRATE	ASCII READ COMMAND	#GMBBAUD<CR> Result: #GMBBAUD:<BaudRate><CR>	ASCII	
	TX	#1,GMBBAUD<CR>		
	RX	#1,GMBBAUD:115200,0x1C200<CR>		
		Current baudrate:115200,0x1C200		
This is the current configured baud rate in the FLASH For ULTRA SLIM IOs RESI-xxx-SIO: This baudrate is only used, if DIP switch mode DIP1=ON+DIP2=ON (BR) (default is 57600bd) For BIG IOs RESI-xxx-SIO: This baudrate is only used, if DIP switch mode DIP7=ON (PARAMETER) (default is 57600bd) The following baudrates are allowed: 300bd, 600bd, 900bd, 1200bd, 2400bd, 4800bd, 9600bd, 19200bd, 38400bd, 57600bd, 115200bd, 128000bd 230400bd, 250000bd, 256000bd				
GET MODBUS PARITY	ASCII READ COMMAND	#GMBPAR<CR> Result: #GMBPAR:<MBParity><CR>	ASCII	
	TX	#1,GMBPAR<CR>		
	RX	#1,GMBPAR:NONE<CR>		

		Current parity:NONE		
Shows the current configured parity of the serial interface. MBParity NONE: no parity EVEN: even parity ODD: odd parity				
GET MODBUS STOP	ASCII READ COMMAND	#GMBSTOP<CR> Result: #GMBSTOP:<MBStop> <CR>	ASCII	
	TX	#1,GMBSTOP<CR>		
	RX	#1,GMBPAR:ONE<CR>		
		Current stopbit(s):ONE		
Shows the current configured parity of the serial interface. MBParity NONE: no parity EVEN: even parity ODD: odd parity				
GET MODBUS PARAMS	ASCII READ COMMAND	#GMBPARAMS<CR> Result: #GMBPARAMS:<MBUnitDec>,<MBFLASHDec>,<MBUnitHex>,<MBFLASHHex>,<MBBaudrateDec>,<MBBaudrateHex>,<MBParity>,<MBStops> <CR>	ASCII	
	TX	#1,GMBPARAMS<CR>		
	RX	#1,GMBPARAMS:1,0x1,15,0xF,115200,0x1C200,NONE,ONE <CR>		
		Current MODBUS unit ID used:1		
		Current MODBUS unit ID in FLASH:15		
		Current baudrate in FLASH:115200		
		Current parity in FLASH:NONE		
		Current stopbit(s) in FLASH:ONE		
Returns the complete settings for serial interface				
ASCII COMMANDS				
RESET	ASCII WRITE COMMAND	#RST<CR> Result: #OK<CR>	ASCII	NO
	TX	#1,RST<CR>		
	RX	N/A		
Executes a software reset (Reboot) of the module.				
FACTORY RESET	ASCII WRITE COMMAND	#FRST<CR> Result: #OK<CR>	ASCII	NO
	TX	#1,FRST<CR>		
	RX	N/A		
Performs a factory reset of all internal saved parameters				
SET MODBUS WATCHDOG TIMER	ASCII WRITE COMMAND	#SMBWATCHDOG:<WDTIME> <CR> Result: #OK<CR>	ASCII	YES

	WDTIME	100		
	TX	#1,SMBWATCHDOG:100<CR>		
	RX	#1,OK<CR>		
Enables or disables the WATCHDOG Timer for the IO module. WDTIME: 1..65535: Time for Watchdog in 1/100s =0: Watchdog is deactivated HINT: The Watchdog is internally handled every 100ms. If the IO module receives no valid frame within this time period, the outputs are set to predefined values!				
GET MODBUS WATCHDOG TIMER	ASCII READ COMMAND	#GMBWATCHDOG<CR> Result: #GMBWATCHDOG:<WDTIME> <CR>	ASCII	
	TX	#1,GMBWATCHDOG<CR>		
	RX	#1,GMBWATCHDOG:0,0x0<CR>		
		Current watchdog time:0 -> 0,0s		
Shows the actual configured time for the telegram watchdog function of the IO module. WDTIME: 1..65535: Time for Watchdog in 1/100s =0: Watchdog is deactivated HINT: The Watchdog is internally handled every 100ms. If the IO module receives no valid frame within this time period, the outputs are set to predefined values!				
CPU PARAMETERS				
GET CPU VOLTAGE	ASCII READ COMMAND	#GCPUTEMP<CR> Result: #GCPUTEMP:<CPUTemp> <CR>	ASCII	
	TX	#1,GCPUTEMP<CR>		
	RX	#1,GCPUTEMP:39.1902<CR>		
		Current internal temperature of CPU:39.1902°C		
Current internal temperature of CPU in ° Celsius.				
GET CPU VOLTAGE	ASCII READ COMMAND	#GCPUVOLT<CR> Result: #GCPUVOLT:<CPUVoltage> <CR>	ASCII	
	TX	#1,GCPUVOLT<CR>		
	RX	#1,GCPUVOLT:3.3708<CR>		
		Current supply voltage of CPU:3.3708V		
Current internal supply voltage of CPU in Volt.				
GET CPU BACKUP	ASCII READ COMMAND	#GCPUBACK<CR> Result: #GCPUBACK:<CPUBackupVoltage> <CR>	ASCII	
	TX	#1,GCPUBACK<CR>		
	RX	#1,GCPUBACK:0.0004<CR>		
		Current backup voltage of CPU:0.0004V		
Current internal backup capacitor voltage of CPU in Volt.				

Register NAME	MODBUS Register	Register VALUE	NEW REAL VALUE	NEW VALUE	DATA TYPE	DO WRITE
PRODUCT DATA						
HW_GROUP	3x65201 4x65201 I:65200	16384,0x4000 B:40 00			UINT16 R/O	
This is the group of hardware of the current product						
SW_GROUP	3x65202 4x65202 I:65201	32824,0x8038 B:80 38			UINT16 R/O	
This is the group of software of the current product						
SW_VERSION	3x65203 4x65203 I:65202	4608,0x1200 B:12 00			UINT16 R/O	
		SW VERSION:1.2.0				
This is the current software version of the firmware						
SW_AUTHOR	3x65204 4x65204 I:65203	18771,0x4953 B:49 53			UINT16 R/O	
This is the current software author of the firmware						
MODBUS SETTINGS						
UNIT_ID	3x65222 4x65222 I:65221	1,0x0001 B:00 01			UINT16 R/O	
		UNIT ID:1				
If the host reads this register, the current defined unit ID is returned.						
FLASH UNIT_ID	3x65223 4x65223 I:65222	15,0x000F B:00 0F		27	UINT16 R/W	NO
		UNIT ID:15				
If the host reads this register, the current defined unit ID from the FLASH is returned. This UnitID is used if DIP switch for UnitID is set to 15						
HINT:This settings will be active after you repower or reset your device !!						
BAUD_RATE	3x65224 4x65224 I:65223	115200,0x0001C200 B:00 01 C2 00	57600	57600	UINT32 R/W	NO
		115200Bd	ENTER BAUD RATE			
This is the current configured baud rate in the FLASH For ULTRA SLIM IOs RESI-xxx-SIO: This baudrate is only used, if DIP switch mode DIP1=ON+DIP2=ON (BR) (default is 57600bd) For BIG IOs RESI-xxx-SIO: This baudrate is only used, if DIP switch mode DIP7=ON (PARAMETER) (default is 57600bd)						

Valid baud rates are: 300bd, 600bd, 900bd, 1200bd, 2400bd, 4800bd, 9600bd, 19200bd, 38400bd, 57600bd, 115200bd, 128000bd 230400bd, 250000bd, 256000bd						
HINT:This settings will be active after you repower or reset your device !!						
PARITY	3x65226 4x65226 I:65225	0,0x0000 B:00 00		1:EVEN PARITY	UINT16 R/W	NO
		NO PARITY		SELECT PARITY		
If the register is read out, the currently set parity of the serial interface is returned. Writing a value to this register will change the new parity in FLASH. This will only take effect after a restart of the module. This can be triggered by writing to the RESET SYSTEM register. Parity values are 0: no parity 1: even parity 2: odd parity						
STOP BITS	3x65227 4x65227 I:65226	1,0x0001 B:00 01		2:TWO STOPBITS	UINT16 R/W	NO
		ONE STOPBIT		SELECT STOPBITS		
If the register is read out, the currently set number of stop bits of the serial interface is returned. Writing a value to this register will change the new number of stop bits in the FLASH. This will only take effect after a restart of the module. This can be triggered by writing to the RESET SYSTEM register. Values for stop bits are 1: one stop bit 2: two stop bits						
MODBUS TIMING	3x65228 4x65228 I:65227	0,0x0000 B:00 00		10	UINT16 R/W	NO
		Actual timing:0ms				
If the host reads this register, the current defined timing for MODBUS telegrams is returned. This timing is a time in ms which extends the standard 1.5 character timeout between two consecutive bytes on the serial line. If you write a new value to this register, the new settings are stored into the internal FLASH. Reboot the device to activate the new settings.						
MODBUS WATCHDOG TIME	3x65229 4x65229 I:65228	0,0x0000 B:00 00		50	UINT16 R/W	YES
		Actual watchdog time in 1/100s:0 -> 0,0s				
Writing a value onto this register defines a new time for the internal communication watchdog timer. The value is a timespan in 1/100s. =0: The communication watchdog is disabled =1..65535: Communication watchdog will be trigegred after x 1/100s pause on communication line In case of an communication watchdog, the module sets all outputs to the states defined in the configuration output registers Reading this registe will return the current stored time from the internal FLASH						
CPU DATA						
SERIAL1	3x65521 4x65521 I:65520	40,0x0028 B:00 28			UINT16 R/O	

Serial number of module as 96 bit unsigned integer number						
SERIAL2	3x65522 4x65522 I:65521	41,0x0029 B:00 29			UINT16 R/O	
SERIAL3	3x65523 4x65523 I:65522	22292,0x5714 B:57 14			UINT16 R/O	
SERIAL4	3x65524 4x65524 I:65523	21827,0x5543 B:55 43			UINT16 R/O	
SERIAL5	3x65525 4x65525 I:65524	13365,0x3435 B:34 35			UINT16 R/O	
SERIAL6	3x65526 4x65526 I:65525	8249,0x2039 B:20 39			UINT16 R/O	
	SERIAL:280029001457435535343920					
Serial number of module as 96 bit unsigned integer number						
CPU TEMPERATURE	3x65527 4x65527 I:65526	3903,0x0F3F B:0F 3F			UINT16 R/O	
	Current internal temperature of CPU:39,03°C					
Current internal temperature of CPU in ° Celsius multiplied by 100.						
CPU VOLTAGE	3x65528 4x65528 I:65527	337,0x0151 B:01 51			UINT16 R/O	
	Current supply voltage of CPU:3,37V					
Current internal supply voltage of CPU in Volt multiplied by 100.						
CPU BACKUP VOLTAGE	3x65529 4x65529 I:65528	0,0x0000 B:00 00			UINT16 R/O	
	Current backup voltage of CPU:0,00V					
Current internal backup capacitor voltage of CPU in Volt multiplied by 100.						
DIP SWITCH STATUS						
DIP SWITCH	3x65300 4x65300 I:65299	65,0x0041 B:00 41			UINT16 R/O	
Returns the current setting of the Dip switches. Bit 0: DIP Switch 1 (=0:OFF, =1:ON) Bit 1: DIP Switch 2 (=0:OFF, =1:ON) Bit 2: DIP Switch 3 (=0:OFF, =1:ON) Bit 3: DIP Switch 4 (=0:OFF, =1:ON) Bit 4: DIP Switch 5 (=0:OFF, =1:ON) Bit 5: DIP Switch 6 (=0:OFF, =1:ON) Bit 6: DIP Switch 7 (=0:OFF, =1:ON) Bit 7: DIP Switch 8 (=0:OFF, =1:ON)						

CONVERTER STATUS						
CONVERTER STATUS	3x65534 4x65534 I:65533	0,0x0000 B:00 00			UINT16 R/O	
Current status of the converter						
FACTORY RESET	3x65535 4x65535 I:65534	0,0x0000 B:00 00		1:PERFORM FACTORY RESET	UINT16 R/W	NO
Performs a factory reset of all internal saved parameters						
SOFTWARE RESET						
RESET	1x65536 2x65536 I:65535	0,0x00 B:00		N/A:NO CHANGE	BIT R/W	NO
Performs a software reset, whenever 1 is written to this register. If the host writes to this register 1, the module executes a soft reset (reboot).						
RESET	3x65536 4x65535 I:65535	0,0x0000 B:00 00		N/A:NO CHANGE	UINT16 R/W	NO
Performs a software reset, whenever 1 is written to this register. If the host writes to this register 1, the module executes a soft reset (reboot).						

Register NAME Command NAME	MODBUS Register ASCII Command	Register VALUE ASCII Command	NEW REAL VALUE	NEW VALUE	DATA TYPE	DO WRITE
STATUS DIGITAL INPUTS						
DI1	1x00001 2x00001 I:0	0,0x00 B:00			BIT R/O	
		Current state of DI1:0=OFF				
Current state of the digital input DIx =0:DI is OFF, =1:DI is ON						
DI2	1x00002 2x00002 I:1	0,0x00 B:00			BIT R/O	
		Current state of DI2:0=OFF				
DI3	1x00003 2x00003 I:2	0,0x00 B:00			BIT R/O	
		Current state of DI3:0=OFF				
DI4	1x00004 2x00004 I:3	0,0x00 B:00			BIT R/O	
		Current state of DI4:0=OFF				
DI5	1x00005 2x00005 I:4	0,0x00 B:00			BIT R/O	
		Current state of DI5:0=OFF				
DI6	1x00006 2x00006 I:5	0,0x00 B:00			BIT R/O	
		Current state of DI6:0=OFF				
STATUS DIGITAL OUTPUTS						
DO1	1x00007 2x00007 I:6	0,0x00 B:00		1	BIT R/W	YES
		Current state of DO1:0=OFF		ENTER NEW STATE (0 or 1)		
Current state of the digital output DOx =0:DO is OFF, =1:DO is ON						
Writing on this register changes the state of the digital output						
DO2	1x00008 2x00008 I:7	0,0x00 B:00		0	BIT R/W	NO
		Current state of DO2:0=OFF		ENTER NEW STATE (0 or 1)		

DO3	1x00009 2x00009 I:8	0,0x00 B:00		0	BIT R/W	NO
		Current state of DO3:0=OFF		ENTER NEW STATE (0 or 1)		
DO4	1x00010 2x00010 I:9	0,0x00 B:00		1	BIT R/W	YES
		Current state of DO4:0=OFF		ENTER NEW STATE (0 or 1)		
DO5	1x00011 2x00011 I:10	0,0x00 B:00		0	BIT R/W	NO
		Current state of DO5:0=OFF		ENTER NEW STATE (0 or 1)		
DO6	1x00012 2x00012 I:11	1,0x01 B:01		0	BIT R/W	NO
		Current state of DO6:1=ON		ENTER NEW STATE (0 or 1)		
DIGITAL OUTPUTS: ENABLE OPEN WIRE DETECTION ON						
ENABLE OPEN WIRE DETECTION ON DO1	1x00013 2x00013 I:12	0,0x00 B:00		1	BIT R/W	YES
		Current setup of open wire detection for state ON of DO1:0=OFF		ENTER NEW SETUP MODE (0 or 1)		
Enables/disabled detection of an open wire in DO state ON for the digital output DOx =0:Open wire detection is OFF, =1:Open wire detection is ON						
Writing on this register changes the state of the open wire detection for this output						
ENABLE OPEN WIRE DETECTION ON DO2	1x00014 2x00014 I:13	0,0x00 B:00		1	BIT R/W	YES
		Current setup of open wire detection for state ON of DO2:0=OFF		ENTER NEW SETUP MODE (0 or 1)		
ENABLE OPEN WIRE DETECTION ON DO3	1x00015 2x00015 I:14	0,0x00 B:00		1	BIT R/W	YES
		Current setup of open wire detection for state ON of DO3:0=OFF		ENTER NEW SETUP MODE (0 or 1)		
ENABLE OPEN WIRE DETECTION ON DO4	1x00016 2x00016 I:15	0,0x00 B:00		1	BIT R/W	YES
		Current setup of open wire detection for state ON of DO4:0=OFF		ENTER NEW SETUP MODE (0 or 1)		
ENABLE OPEN WIRE DETECTION ON DO5	1x00017 2x00017 I:16	0,0x00 B:00		1	BIT R/W	YES
		Current setup of open wire detection for state ON of DO5:0=OFF		ENTER NEW SETUP MODE (0 or 1)		

ENABLE OPEN WIRE DETECTION ON DO6	1x00018 2x00018 I:17	0,0x00 B:00		1		BIT R/W	YES
		Current setup of open wire detection for state ON of DO6:0=OFF		ENTER NEW SETUP MODE (0 or 1)			
DIGITAL OUTPUTS: ENABLE OPEN WIRE DETECTION OFF							
ENABLE OPEN WIRE DETECTION OFF DO1	1x00019 2x00019 I:18	0,0x00 B:00		1		BIT R/W	NO
		Current setup of open wire detection for state OFF of DO1:0=OFF		ENTER NEW SETUP MODE (0 or 1)			
Enables/disabled detection of an open wire in DO state OFF for the digital output DOx =0:Open wire detection is OFF, =1:Open wire detection is ON							
Writing on this register changes the state of the open wire detection for this output							
ENABLE OPEN WIRE DETECTION OFF DO2	1x00020 2x00020 I:19	0,0x00 B:00		1		BIT R/W	NO
		Current setup of open wire detection for state OFF of DO2:0=OFF		ENTER NEW SETUP MODE (0 or 1)			
ENABLE OPEN WIRE DETECTION OFF DO3	1x00021 2x00021 I:20	0,0x00 B:00		1		BIT R/W	NO
		Current setup of open wire detection for state OFF of DO3:0=OFF		ENTER NEW SETUP MODE (0 or 1)			
ENABLE OPEN WIRE DETECTION OFF DO4	1x00022 2x00022 I:21	0,0x00 B:00		1		BIT R/W	NO
		Current setup of open wire detection for state OFF of DO4:0=OFF		ENTER NEW SETUP MODE (0 or 1)			
ENABLE OPEN WIRE DETECTION OFF DO5	1x00023 2x00023 I:22	0,0x00 B:00		1		BIT R/W	NO
		Current setup of open wire detection for state ON of DO5:0=OFF		ENTER NEW SETUP MODE (0 or 1)			
ENABLE OPEN WIRE DETECTION OFF DO6	1x00024 2x00024 I:23	0,0x00 B:00		1		BIT R/W	NO
		Current setup of open wire detection for state OFF of DO6:0=OFF		ENTER NEW SETUP MODE (0 or 1)			
DIGITAL OUTPUTS: ENABLE SHORT TO VDD DETECTION							
ENABLE SHORT TO VDD DETECTION DO1	1x00025 2x00025 I:24	0,0x00 B:00		1		BIT R/W	YES
		Current setup of open wire detection for state OFF of DO1:0=OFF		ENTER NEW SETUP MODE (0 or 1)			

Enables/disabled detection of a shortcut to VDD in DO state OFF for the digital output DOx

=0:Shortcut to VDD detection is OFF, =1:Shortcut to VDD detection is ON

Writing on this register changes the state of the shortcut detection for this output

ENABLE SHORT TO VDD DETECTION DO2	1x00026 2x00026 l:25	0,0x00 B:00		1	BIT R/W	YES
		Current setup of open wire detection for state OFF of DO2:0=OFF		ENTER NEW SETUP MODE (0 or 1)		
ENABLE SHORT TO VDD DETECTION DO3	1x00027 2x00027 l:26	0,0x00 B:00		1	BIT R/W	YES
		Current setup of open wire detection for state OFF of DO3:0=OFF		ENTER NEW SETUP MODE (0 or 1)		
ENABLE SHORT TO VDD DETECTION DO4	1x00028 2x00028 l:27	0,0x00 B:00		1	BIT R/W	YES
		Current setup of open wire detection for state OFF of DO4:0=OFF		ENTER NEW SETUP MODE (0 or 1)		
ENABLE SHORT TO VDD DETECTION DO5	1x00029 2x00029 l:28	0,0x00 B:00		1	BIT R/W	YES
		Current setup of open wire detection for state ON of DO5:0=OFF		ENTER NEW SETUP MODE (0 or 1)		
ENABLE SHORT TO VDD DETECTION DO6	1x00030 2x00030 l:29	0,0x00 B:00		1	BIT R/W	YES
		Current setup of open wire detection for state OFF of DO6:0=OFF		ENTER NEW SETUP MODE (0 or 1)		
DIGITAL OUTPUTS: OPEN WIRE DETECTION STATUS WHILE ON						
OPEN WIRE WHILE ON DO1	1x00031 2x00031 l:30	0,0x00 B:00			BIT R/O	
		Current detection state of an open wire in state ON for DO1:0=OK				
The current detection state of an open wire in the output state ON for the digital output DOx =0:No fault, =1:Fault-open wire detected						
OPEN WIRE WHILE ON DO2	1x00032 2x00032 l:31	0,0x00 B:00			BIT R/O	
		Current detection state of an open wire in state ON for DO2:0=OK				
OPEN WIRE WHILE ON DO3	1x00033 2x00033 l:32	0,0x00 B:00			BIT R/O	
		Current detection state of an open wire in state ON for DO3:0=OK				

OPEN WIRE WHILE ON DO4	1x00034 2x00034 I:33	0,0x00 B:00			BIT R/O	
		Current detection state of an open wire in state ON for DO4:0=OK				
OPEN WIRE WHILE ON DO5	1x00035 2x00035 I:34	0,0x00 B:00			BIT R/O	
		Current detection state of an open wire in state ON for DO5:0=OK				
OPEN WIRE WHILE ON DO6	1x00036 2x00036 I:35	0,0x00 B:00			BIT R/O	
		Current detection state of an open wire in state ON for DO6:0=OK				
DIGITAL OUTPUTS: OPEN WIRE DETECTION STATUS WHILE OFF						
OPEN WIRE WHILE OFF DO1	1x00037 2x00037 I:36	0,0x00 B:00			BIT R/O	
		Current detection state of an open wire in state OFF for DO1:0=OK				
The current detection state of an open wire in the output state OFF for the digital output DOx =0:No fault, =1:Fault-open wire detected						
OPEN WIRE WHILE OFF DO2	1x00038 2x00038 I:37	0,0x00 B:00			BIT R/O	
		Current detection state of an open wire in state OFF for DO2:0=OK				
OPEN WIRE WHILE OFF DO3	1x00039 2x00039 I:38	0,0x00 B:00			BIT R/O	
		Current detection state of an open wire in state OFF for DO3:0=OK				
OPEN WIRE WHILE OFF DO4	1x00040 2x00040 I:39	0,0x00 B:00			BIT R/O	
		Current detection state of an open wire in state OFF for DO4:0=OK				
OPEN WIRE WHILE OFF DO5	1x00041 2x00041 I:40	0,0x00 B:00			BIT R/O	
		Current detection state of an open wire in state OFF for DO5:0=OK				
OPEN WIRE WHILE OFF DO6	1x00042 2x00042 I:41	0,0x00 B:00			BIT R/O	

		Current detection state of an open wire in state OFF for DO6:0=OK			
DIGITAL OUTPUTS: SHORTCUT DETECTION STATUS TO VDD WHILE OFF					
OPEN WIRE SHORTCUT TO VDD DO1	1x00043 2x00043 I:42	0,0x00 B:00			BIT R/O
		Current detection state of a shortcut to VDD in state OFF for DO1:0=OK			
The current detection state of a shortcut to VDD in the output state OFF for the digital output DOx =0:No fault, =1:Fault-shortcut to VDD detected					
OPEN WIRE SHORTCUT TO VDD DO2	1x00044 2x00044 I:43	0,0x00 B:00			BIT R/O
		Current detection state of a shortcut to VDD in state OFF for DO2:0=OK			
OPEN WIRE SHORTCUT TO VDD DO3	1x00045 2x00045 I:44	0,0x00 B:00			BIT R/O
		Current detection state of a shortcut to VDD in state OFF for DO3:0=OK			
OPEN WIRE SHORTCUT TO VDD DO4	1x00046 2x00046 I:45	0,0x00 B:00			BIT R/O
		Current detection state of a shortcut to VDD in state OFF for DO4:0=OK			
OPEN WIRE SHORTCUT TO VDD DO5	1x00047 2x00047 I:46	0,0x00 B:00			BIT R/O
		Current detection state of a shortcut to VDD in state OFF for DO5:0=OK			
OPEN WIRE SHORTCUT TO VDD DO6	1x00048 2x00048 I:47	0,0x00 B:00			BIT R/O
		Current detection state of a shortcut to VDD in state OFF for DO6:0=OK			
DIGITAL OUTPUTS: THERMAL OVERLOAD DETECTION STATUS					
THERMAL OVERLOAD DETECTION STATUS DO1	1x00049 2x00049 I:48	0,0x00 B:00			BIT R/O
		Current detection state of a thermal overload for DO1:0=OK			
The current detection state of a thermal overload for the digital output DOx =0:No fault, =1:Fault-thermal overload detected					
THERMAL OVERLOAD DETECTION STATUS DO2	1x00050 2x00050 I:49	0,0x00 B:00			BIT R/O

		Current detection state of a thermal overload for DO2:0=OK				
THERMAL OVERLOAD DETECTION STATUS DO3	1x00051 2x00051 I:50	0,0x00 B:00			BIT R/O	
		Current detection state of a thermal overload for DO3:0=OK				
THERMAL OVERLOAD DETECTION STATUS DO4	1x00052 2x00052 I:51	0,0x00 B:00			BIT R/O	
		Current detection state of a thermal overload for DO4:0=OK				
THERMAL OVERLOAD DETECTION STATUS DO5	1x00053 2x00053 I:52	0,0x00 B:00			BIT R/O	
		Current detection state of a thermal overload for DO5:0=OK				
THERMAL OVERLOAD DETECTION STATUS DO6	1x00054 2x00054 I:53	0,0x00 B:00			BIT R/O	
		Current detection state of a thermal overload for DO6:0=OK				
DIGITAL OUTPUTS: CURRENT LIMIT DETECTION STATUS WHILE ON						
CURRENT LIMIT DETECTION STATUS WHILE ON DO1	1x00055 2x00055 I:54	0,0x00 B:00			BIT R/O	
		Current detection state of a current limit while ON for DO1:0=OK				
The current detection state of a current limit while output is ON for the digital output DOx =0:No fault, =1:Fault-current limit error						
CURRENT LIMIT DETECTION STATUS WHILE ON DO2	1x00056 2x00056 I:55	0,0x00 B:00			BIT R/O	
		Current detection state of a current limit while ON for DO2:0=OK				
CURRENT LIMIT DETECTION STATUS WHILE ON DO3	1x00057 2x00057 I:56	0,0x00 B:00			BIT R/O	
		Current detection state of a current limit while ON for DO3:0=OK				
CURRENT LIMIT DETECTION STATUS WHILE ON DO4	1x00058 2x00058 I:57	0,0x00 B:00			BIT R/O	
		Current detection state of a current limit while ON for DO4:0=OK				

CURRENT LIMIT DETECTION STATUS WHILE ON DO5	1x00059 2x00059 I:58	0,0x00 B:00			BIT R/O	
		Current detection state of a current limit while ON for DO5:0=OK				
CURRENT LIMIT DETECTION STATUS WHILE ON DO6	1x00060 2x00060 I:59	0,0x00 B:00			BIT R/O	
		Current detection state of a current limit while ON for DO6:0=OK				
DIGITAL OUTPUTS: GLOBAL ERRORS DO1-DO6						
GLOBAL ERRORS FOR DO1-DO6 BIT 0	1x00061 2x00061 I:60	0,0x00 B:00			BIT R/O	
		BIT 0:Internal under voltage detected:0=OK				
GLOBAL ERRORS FOR DO1-DO6 BIT 1	1x00062 2x00062 I:61	0,0x00 B:00			BIT R/O	
		BIT 1:VA under voltage detected (<2.3V):0=OK				
GLOBAL ERRORS FOR DO1-DO6 BIT 2	1x00063 2x00063 I:62	0,0x00 B:00			BIT R/O	
		BIT 2:VDD not good detected (<17V):0=OK				
GLOBAL ERRORS FOR DO1-DO6 BIT 3	1x00064 2x00064 I:63	0,0x00 B:00			BIT R/O	
		BIT 3:VDD warning detected (<12V):0=OK				
GLOBAL ERRORS FOR DO1-DO6 BIT 4	1x00065 2x00065 I:64	0,0x00 B:00			BIT R/O	
		BIT 4:VDD under voltage detected (<8V):0=OK				
GLOBAL ERRORS FOR DO1-DO6 BIT 5	1x00066 2x00066 I:65	0,0x00 B:00			BIT R/O	
		BIT 5:Thermal shutdown:0=OK				
GLOBAL ERRORS FOR DO1-DO6 BIT 6	1x00067 2x00067 I:66	0,0x00 B:00			BIT R/O	
		BIT 6:Synchronisation error detected:0=OK				
GLOBAL ERRORS FOR DO1-DO6 BIT 7	1x00068 2x00068 I:67	0,0x00 B:00			BIT R/O	
		BIT 7:Watchdog error detected:0=OK				
The global error state for the output group. Each bit stands for a different error =0:No fault, =1:Fault						
DIGITAL OUTPUTS: INTERRUPT STATUS DO1-DO6						

INTERRUPT STATUS FOR DO1-DO6 BIT 0	1x00069 2x00069 I:68	0,0x00 B:00			BIT R/O	
		BIT 0:Overload detected:0=OK				
INTERRUPT STATUS FOR DO1-DO6 BIT 1	1x00070 2x00070 I:69	0,0x00 B:00			BIT R/O	
		BIT 1:Current limit detected:0=OK				
INTERRUPT STATUS FOR DO1-DO6 BIT 2	1x00071 2x00071 I:70	0,0x00 B:00			BIT R/O	
		BIT 2:Open wire while OFF detected:0=OK				
INTERRUPT STATUS FOR DO1-DO6 BIT 3	1x00072 2x00072 I:71	0,0x00 B:00			BIT R/O	
		BIT 3:Open wire while ON detected:0=OK				
INTERRUPT STATUS FOR DO1-DO6 BIT 4	1x00073 2x00073 I:72	0,0x00 B:00			BIT R/O	
		BIT 4:Short to VDD while ON detected:0=OK				
INTERRUPT STATUS FOR DO1-DO6 BIT 5	1x00074 2x00074 I:73	0,0x00 B:00			BIT R/O	
		BIT 5:Thermal error detected-shutdown:0=OK				
INTERRUPT STATUS FOR DO1-DO6 BIT 6	1x00075 2x00075 I:74	0,0x00 B:00			BIT R/O	
		BIT 6:Supply error detected:0=OK				
INTERRUPT STATUS FOR DO1-DO6 BIT 7	1x00076 2x00076 I:75	0,0x00 B:00			BIT R/O	
		BIT 7:Communication error detected:0=OK				
The global interrupt error state for the output group. Each bit stands for a different error =0:No fault, =1:Fault						
SPI COMMUNICATION DIGITAL OUTPUTS						
SPI COMMUNICATION DO1-DO6	1x00077 2x00077 I:76	1,0x01 B:01			BIT R/O	
		Current SPI communication for DO1-DO6:1=FAULT				
The current monitoring state of the SPI communication for the digital output group =0:No fault, =1:Fault						
SPI COMMUNICATION DO7-DO12	1x00078 2x00078 I:77	1,0x01 B:01			BIT R/O	
		Current SPI communication for DO7-DO12:1=FAULT				
DIGITAL INPUTS: RESET						

RESET COUNTERS	1x10000 2x10000 I:9999	0,0x00 B:00		1:PERFORM RESET	BIT R/W	NO
If this register is written to 1, all internal edge counters and event counters are set to 0. 0 is always returned when reading.						
STATUS DIGITAL INPUTS						
DI1	3x00001 4x00001 I:0	0,0x0000 B:00 00			UINT16 R/O	
		Current state of DI1:0=OFF				
Current state of the digital input DIx =0:DI is OFF, =1:DI is ON						
DI2	3x00002 4x00002 I:1	0,0x0000 B:00 00			UINT16 R/O	
		Current state of DI2:0=OFF				
DI3	3x00003 4x00003 I:2	0,0x0000 B:00 00			UINT16 R/O	
		Current state of DI3:0=OFF				
DI4	3x00004 4x00004 I:3	0,0x0000 B:00 00			UINT16 R/O	
		Current state of DI4:0=OFF				
DI5	3x00005 4x00005 I:4	0,0x0000 B:00 00			UINT16 R/O	
		Current state of DI5:0=OFF				
DI6	3x00006 4x00006 I:5	0,0x0000 B:00 00			UINT16 R/O	
		Current state of DI6:0=OFF				
STATUS DIGITAL OUTPUTS						
DO1	3x00007 4x00007 I:6	0,0x0000 B:00 00		1	UINT16 R/W	NO
		Current state of DO1:0=OFF		ENTER NEW STATE (0 or 1)		
Current state of the digital output DOx =0:DO is OFF, =1:DO is ON						
Writing on this register changes the state of the digital output						
DO2	3x00008 4x00008 I:7	0,0x0000 B:00 00		1	UINT16 R/W	NO
		Current state of DO2:0=OFF		ENTER NEW STATE (0 or 1)		
DO3	3x00009 4x00009 I:8	0,0x0000 B:00 00		1	UINT16 R/W	NO

		Current state of DO3:0=OFF		ENTER NEW STATE (0 or 1)		
DO4	3x00010 4x00010 I:9	0,0x0000 B:00 00		1	UINT16 R/W	NO
		Current state of DO4:0=OFF		ENTER NEW STATE (0 or 1)		
DO5	3x00011 4x00011 I:10	0,0x0000 B:00 00		1	UINT16 R/W	NO
		Current state of DO5:0=OFF		ENTER NEW STATE (0 or 1)		
DO6	3x00012 4x00012 I:11	1,0x0001 B:00 01		1	UINT16 R/W	NO
		Current state of DO6:1=ON		ENTER NEW STATE (0 or 1)		
DIGITAL OUTPUTS: ENABLE OPEN WIRE DETECTION ON						
ENABLE OPEN WIRE DETECTION ON DO1	3x00013 4x00013 I:12	0,0x0000 B:00 00		1	UINT16 R/W	NO
		Current setup of open wire detection for state ON of DO1:0=OFF		ENTER NEW SETUP MODE (0 or 1)		
Enables/disabled detection of an open wire in DO state ON for the digital output DOx =0:Open wire detection is OFF, =1:Open wire detection is ON						
Writing on this register changes the state of the open wire detection for this output						
ENABLE OPEN WIRE DETECTION ON DO2	3x00014 4x00014 I:13	0,0x0000 B:00 00		1	UINT16 R/W	NO
		Current setup of open wire detection for state ON of DO2:0=OFF		ENTER NEW SETUP MODE (0 or 1)		
ENABLE OPEN WIRE DETECTION ON DO3	3x00015 4x00015 I:14	0,0x0000 B:00 00		1	UINT16 R/W	NO
		Current setup of open wire detection for state ON of DO3:0=OFF		ENTER NEW SETUP MODE (0 or 1)		
ENABLE OPEN WIRE DETECTION ON DO4	3x00016 4x00016 I:15	0,0x0000 B:00 00		1	UINT16 R/W	NO
		Current setup of open wire detection for state ON of DO4:0=OFF		ENTER NEW SETUP MODE (0 or 1)		
ENABLE OPEN WIRE DETECTION ON DO5	3x00017 4x00017 I:16	0,0x0000 B:00 00		1	UINT16 R/W	NO
		Current setup of open wire detection for state ON of DO5:0=OFF		ENTER NEW SETUP MODE (0 or 1)		
ENABLE OPEN WIRE DETECTION ON DO6	3x00018 4x00018 I:17	0,0x0000 B:00 00		1	UINT16 R/W	NO

		Current setup of open wire detection for state ON of DO6:0=OFF	ENTER NEW SETUP MODE (0 or 1)		
DIGITAL OUTPUTS: ENABLE OPEN WIRE DETECTION OFF					
ENABLE OPEN WIRE DETECTION OFF DO1	3x00019 4x00019 I:18	0,0x0000 B:00 00	1	UINT16 R/W	NO
		Current setup of open wire detection for state OFF of DO1:0=OFF	ENTER NEW SETUP MODE (0 or 1)		
Enables/disabled detection of an open wire in DO state OFF for the digital output DOx =0:Open wire detection is OFF, =1:Open wire detection is ON					
Writing on this register changes the state of the open wire detection for this output					
ENABLE OPEN WIRE DETECTION OFF DO2	3x00020 4x00020 I:19	0,0x0000 B:00 00	1	UINT16 R/W	NO
		Current setup of open wire detection for state OFF of DO2:0=OFF	ENTER NEW SETUP MODE (0 or 1)		
ENABLE OPEN WIRE DETECTION OFF DO3	3x00021 4x00021 I:20	0,0x0000 B:00 00	1	UINT16 R/W	NO
		Current setup of open wire detection for state OFF of DO3:0=OFF	ENTER NEW SETUP MODE (0 or 1)		
ENABLE OPEN WIRE DETECTION OFF DO4	3x00022 4x00022 I:21	0,0x0000 B:00 00	1	UINT16 R/W	NO
		Current setup of open wire detection for state OFF of DO4:0=OFF	ENTER NEW SETUP MODE (0 or 1)		
ENABLE OPEN WIRE DETECTION OFF DO5	3x00023 4x00023 I:22	0,0x0000 B:00 00	1	UINT16 R/W	NO
		Current setup of open wire detection for state ON of DO5:0=OFF	ENTER NEW SETUP MODE (0 or 1)		
ENABLE OPEN WIRE DETECTION OFF DO6	3x00024 4x00024 I:23	0,0x0000 B:00 00	1	UINT16 R/W	NO
		Current setup of open wire detection for state OFF of DO6:0=OFF	ENTER NEW SETUP MODE (0 or 1)		
DIGITAL OUTPUTS: ENABLE SHORT TO VDD DETECTION					
ENABLE SHORT TO VDD DETECTION DO1	3x00025 4x00025 I:24	0,0x0000 B:00 00	1	UINT16 R/W	NO
		Current setup of open wire detection for state OFF of DO1:0=OFF	ENTER NEW SETUP MODE (0 or 1)		
Enables/disabled detection of a shortcut to VDD in DO state OFF for the digital output DOx =0:Shortcut to VDD detection is OFF, =1:Shortcut to VDD detection is ON					
Writing on this register changes the state of the shortcut detection for this output					

ENABLE SHORT TO VDD DETECTION DO2	3x00026 4x00026 I:25	0,0x0000 B:00 00		1	UINT16 R/W	NO
		Current setup of open wire detection for state OFF of DO2:0=OFF		ENTER NEW SETUP MODE (0 or 1)		
ENABLE SHORT TO VDD DETECTION DO3	3x00027 4x00027 I:26	0,0x0000 B:00 00		1	UINT16 R/W	NO
		Current setup of open wire detection for state OFF of DO3:0=OFF		ENTER NEW SETUP MODE (0 or 1)		
ENABLE SHORT TO VDD DETECTION DO4	3x00028 4x00028 I:27	0,0x0000 B:00 00		1	UINT16 R/W	NO
		Current setup of open wire detection for state OFF of DO4:0=OFF		ENTER NEW SETUP MODE (0 or 1)		
ENABLE SHORT TO VDD DETECTION DO5	3x00029 4x00029 I:28	0,0x0000 B:00 00		1	UINT16 R/W	NO
		Current setup of open wire detection for state ON of DO5:0=OFF		ENTER NEW SETUP MODE (0 or 1)		
ENABLE SHORT TO VDD DETECTION DO6	3x00030 4x00030 I:29	0,0x0000 B:00 00		1	UINT16 R/W	NO
		Current setup of open wire detection for state OFF of DO6:0=OFF		ENTER NEW SETUP MODE (0 or 1)		
DIGITAL OUTPUTS: OPEN WIRE DETECTION STATUS WHILE ON						
OPEN WIRE WHILE ON DO1	3x00031 4x00031 I:30	0,0x0000 B:00 00			UINT16 R/O	
		Current detection state of an open wire in state ON for DO1:0=OK				
The current detection state of an open wire in the output state ON for the digital output DOx =0:No fault, =1:Fault-open wire detected						
OPEN WIRE WHILE ON DO2	3x00032 4x00032 I:31	0,0x0000 B:00 00			UINT16 R/O	
		Current detection state of an open wire in state ON for DO2:0=OK				
OPEN WIRE WHILE ON DO3	3x00033 4x00033 I:32	0,0x0000 B:00 00			UINT16 R/O	
		Current detection state of an open wire in state ON for DO3:0=OK				
OPEN WIRE WHILE ON DO4	3x00034 4x00034 I:33	0,0x0000 B:00 00			UINT16 R/O	

		Current detection state of an open wire in state ON for DO4:0=OK				
OPEN WIRE WHILE ON DO5	3x00035 4x00035 I:34	0,0x0000 B:00 00			UINT16 R/O	
		Current detection state of an open wire in state ON for DO5:0=OK				
OPEN WIRE WHILE ON DO6	3x00036 4x00036 I:35	0,0x0000 B:00 00			UINT16 R/O	
		Current detection state of an open wire in state ON for DO6:0=OK				
DIGITAL OUTPUTS: OPEN WIRE DETECTION STATUS WHILE OFF						
OPEN WIRE WHILE OFF DO1	3x00037 4x00037 I:36	0,0x0000 B:00 00			UINT16 R/O	
		Current detection state of an open wire in state OFF for DO1:0=OK				
The current detection state of an open wire in the output state OFF for the digital output DOx =0:No fault, =1:Fault-open wire detected						
OPEN WIRE WHILE OFF DO2	3x00038 4x00038 I:37	0,0x0000 B:00 00			UINT16 R/O	
		Current detection state of an open wire in state OFF for DO2:0=OK				
OPEN WIRE WHILE OFF DO3	3x00039 4x00039 I:38	0,0x0000 B:00 00			UINT16 R/O	
		Current detection state of an open wire in state OFF for DO3:0=OK				
OPEN WIRE WHILE OFF DO4	3x00040 4x00040 I:39	0,0x0000 B:00 00			UINT16 R/O	
		Current detection state of an open wire in state OFF for DO4:0=OK				
OPEN WIRE WHILE OFF DO5	3x00041 4x00041 I:40	0,0x0000 B:00 00			UINT16 R/O	
		Current detection state of an open wire in state OFF for DO5:0=OK				
OPEN WIRE WHILE OFF DO6	3x00042 4x00042 I:41	0,0x0000 B:00 00			UINT16 R/O	
		Current detection state of an open wire in state OFF for DO6:0=OK				
DIGITAL OUTPUTS: SHORTCUT DETECTION STATUS TO VDD WHILE OFF						

OPEN WIRE SHORTCUT TO VDD DO1	3x00043 4x00043 I:42	0,0x0000 B:00 00			UINT16 R/O	
		Current detection state of a shortcut to VDD in state OFF for DO1:0=OK				
The current detection state of a shortcut to VDD in the output state OFF for the digital output DOx =0:No fault, =1:Fault-shortcut to VDD detected						
OPEN WIRE SHORTCUT TO VDD DO2	3x00044 4x00044 I:43	0,0x0000 B:00 00			UINT16 R/O	
		Current detection state of a shortcut to VDD in state OFF for DO2:0=OK				
OPEN WIRE SHORTCUT TO VDD DO3	3x00045 4x00045 I:44	0,0x0000 B:00 00			UINT16 R/O	
		Current detection state of a shortcut to VDD in state OFF for DO3:0=OK				
OPEN WIRE SHORTCUT TO VDD DO4	3x00046 4x00046 I:45	0,0x0000 B:00 00			UINT16 R/O	
		Current detection state of a shortcut to VDD in state OFF for DO4:0=OK				
OPEN WIRE SHORTCUT TO VDD DO5	3x00047 4x00047 I:46	0,0x0000 B:00 00			UINT16 R/O	
		Current detection state of a shortcut to VDD in state OFF for DO5:0=OK				
OPEN WIRE SHORTCUT TO VDD DO6	3x00048 4x00048 I:47	0,0x0000 B:00 00			UINT16 R/O	
		Current detection state of a shortcut to VDD in state OFF for DO6:0=OK				
DIGITAL OUTPUTS: THERMAL OVERLOAD DETECTION STATUS						
THERMAL OVERLOAD DETECTION STATUS DO1	3x00049 4x00049 I:48	0,0x0000 B:00 00			UINT16 R/O	
		Current detection state of a thermal overload for DO1:0=OK				
The current detection state of a thermal overload for the digital output DOx =0:No fault, =1:Fault-thermal overload detected						
THERMAL OVERLOAD DETECTION STATUS DO2	3x00050 4x00050 I:49	0,0x0000 B:00 00			UINT16 R/O	
		Current detection state of a thermal overload for DO2:0=OK				

THERMAL OVERLOAD DETECTION STATUS DO3	3x00051 4x00051 I:50	0,0x0000 B:00 00			UINT16 R/O	
		Current detection state of a thermal overload for DO3:0=OK				
THERMAL OVERLOAD DETECTION STATUS DO4	3x00052 4x00052 I:51	0,0x0000 B:00 00			UINT16 R/O	
		Current detection state of a thermal overload for DO4:0=OK				
THERMAL OVERLOAD DETECTION STATUS DO5	3x00053 4x00053 I:52	0,0x0000 B:00 00			UINT16 R/O	
		Current detection state of a thermal overload for DO5:0=OK				
THERMAL OVERLOAD DETECTION STATUS DO6	3x00054 4x00054 I:53	0,0x0000 B:00 00			UINT16 R/O	
		Current detection state of a thermal overload for DO6:0=OK				
DIGITAL OUTPUTS: CURRENT LIMIT DETECTION STATUS WHILE ON						
CURRENT LIMIT DETECTION STATUS WHILE ON DO1	3x00055 4x00055 I:54	0,0x0000 B:00 00			UINT16 R/O	
		Current detection state of a current limit while ON for DO1:0=OK				
The current detection state of a current limit while output is ON for the digital output DOx =0:No fault, =1:Fault-current limit error						
CURRENT LIMIT DETECTION STATUS WHILE ON DO2	3x00056 4x00056 I:55	0,0x0000 B:00 00			UINT16 R/O	
		Current detection state of a current limit while ON for DO2:0=OK				
CURRENT LIMIT DETECTION STATUS WHILE ON DO3	3x00057 4x00057 I:56	0,0x0000 B:00 00			UINT16 R/O	
		Current detection state of a current limit while ON for DO3:0=OK				
CURRENT LIMIT DETECTION STATUS WHILE ON DO4	3x00058 4x00058 I:57	0,0x0000 B:00 00			UINT16 R/O	
		Current detection state of a current limit while ON for DO4:0=OK				
CURRENT LIMIT DETECTION STATUS WHILE ON DO5	3x00059 4x00059 I:58	0,0x0000 B:00 00			UINT16 R/O	

		Current detection state of a current limit while ON for DO5:0=OK				
CURRENT LIMIT DETECTION STATUS WHILE ON DO6	3x00060 4x00060 I:59	0,0x0000 B:00 00			UINT16 R/O	
		Current detection state of a current limit while ON for DO6:0=OK				
DIGITAL OUTPUTS: GLOBAL ERRORS DO1-DO6						
GLOBAL ERRORS FOR DO1-DO6 BIT 0	3x00061 4x00061 I:60	0,0x0000 B:00 00			UINT16 R/O	
		BIT 0:Internal under voltage detected:0=OK				
GLOBAL ERRORS FOR DO1-DO6 BIT 1	3x00062 4x00062 I:61	0,0x0000 B:00 00			UINT16 R/O	
		BIT 1:VA under voltage detected (<2.3V):0=OK				
GLOBAL ERRORS FOR DO1-DO6 BIT 2	3x00063 4x00063 I:62	0,0x0000 B:00 00			UINT16 R/O	
		BIT 2:VDD not good detected (<17V):0=OK				
GLOBAL ERRORS FOR DO1-DO6 BIT 3	3x00064 4x00064 I:63	0,0x0000 B:00 00			UINT16 R/O	
		BIT 3:VDD warning detected (<12V):0=OK				
GLOBAL ERRORS FOR DO1-DO6 BIT 4	3x00065 4x00065 I:64	0,0x0000 B:00 00			UINT16 R/O	
		BIT 4:VDD under voltage detected (<8V):0=OK				
GLOBAL ERRORS FOR DO1-DO6 BIT 5	3x00066 4x00066 I:65	0,0x0000 B:00 00			UINT16 R/O	
		BIT 5:Thermal shutdown:0=OK				
GLOBAL ERRORS FOR DO1-DO6 BIT 6	3x00067 4x00067 I:66	0,0x0000 B:00 00			UINT16 R/O	
		BIT 6:Synchronisation error detected:0=OK				
GLOBAL ERRORS FOR DO1-DO6 BIT 7	3x00068 4x00068 I:67	0,0x0000 B:00 00			UINT16 R/O	
		BIT 7:Watchdog error detected:0=OK				
The global error state for the output group. Each bit stands for a different error =0:No fault, =1:Fault						
DIGITAL OUTPUTS: INTERRUPT STATUS DO1-DO6						
INTERRUPT STATUS FOR DO1-DO6 BIT 0	3x00069 4x00069 I:68	0,0x0000 B:00 00			UINT16 R/O	

		BIT 0:Overload detected:0=OK				
INTERRUPT STATUS FOR DO1-DO6 BIT 1	3x00070 4x00070 I:69	0,0x0000 B:00 00			UINT16 R/O	
		BIT 1:Current limit detected:0=OK				
INTERRUPT STATUS FOR DO1-DO6 BIT 2	3x00071 4x00071 I:70	0,0x0000 B:00 00			UINT16 R/O	
		BIT 2:Open wire while OFF detected:0=OK				
INTERRUPT STATUS FOR DO1-DO6 BIT 3	3x00072 4x00072 I:71	0,0x0000 B:00 00			UINT16 R/O	
		BIT 3:Open wire while ON detected:0=OK				
INTERRUPT STATUS FOR DO1-DO6 BIT 4	3x00073 4x00073 I:72	0,0x0000 B:00 00			UINT16 R/O	
		BIT 4:Short to VDD while ON detected:0=OK				
INTERRUPT STATUS FOR DO1-DO6 BIT 5	3x00074 4x00074 I:73	0,0x0000 B:00 00			UINT16 R/O	
		BIT 5:Thermal error detected-shutdown:0=OK				
INTERRUPT STATUS FOR DO1-DO6 BIT 6	3x00075 4x00075 I:74	0,0x0000 B:00 00			UINT16 R/O	
		BIT 6:Supply error detected:0=OK				
INTERRUPT STATUS FOR DO1-DO6 BIT 7	3x00076 4x00076 I:75	0,0x0000 B:00 00			UINT16 R/O	
		BIT 7:Communication error detected:0=OK				
The global interrupt error state for the output group. Each bit stands for a different error =0:No fault, =1:Fault						
SPI COMMUNICATION DIGITAL OUTPUTS						
SPI COMMUNICATION DO1-DO6	3x00077 4x00077 I:76	1,0x0001 B:00 01			UINT16 R/O	
		Current SPI communication for DO1-DO6:1=FAULT				
The current monitoring state of the SPI communication for the digital output group =0:No fault, =1:Fault						
DIGITAL INPUTS						
STATUS DI1 A	3x00094 4x00094 I:93	0,0x0000 B:00 00			UINT16 R/O	
		DI:0,CC:0,REC:0,FEC:0				

Status for the digital input Dlx

Bit 0-4: Lower 5 bits of CHANGE COUNTER

Bit 5-9: Lower 5 bits of RISING EDGE COUNTER

Bit 10-14: Lower 5 bits of FALLING EDGE COUNTER

Bit 15: Current Status of Dlx =0: Dlx si OFF, =1: Dlx is ON

STATUS DI1 B	3x00095 4x00095 I:94	0,0x0000 B:00 00			UINT16 R/O	
		DI:0,SKE:0,LKSE:0,LKEE:0				

Status for the digital input Dlx

Bit 0-4: Lower 5 bits of SHORT KEYPRESS EVENTS

Bit 5-9: Lower 5 bits of LONG KEYPRESS START EVENTS

Bit 10-14: Lower 5 bits of LONG KEYPRESS END EVENTS

Bit 15: Current Status of Dlx =0: Dlx si OFF, =1: Dlx is ON

STATUS DI2 A	3x00096 4x00096 I:95	0,0x0000 B:00 00			UINT16 R/O	
		DI:0,CC:0,REC:0,FEC:0				
STATUS DI2 B	3x00097 4x00097 I:96	0,0x0000 B:00 00			UINT16 R/O	
		DI:0,SKE:0,LKSE:0,LKEE:0				
STATUS DI3 A	3x00098 4x00098 I:97	0,0x0000 B:00 00			UINT16 R/O	
		DI:0,CC:0,REC:0,FEC:0				
STATUS DI3 B	3x00099 4x00099 I:98	0,0x0000 B:00 00			UINT16 R/O	
		DI:0,SKE:0,LKSE:0,LKEE:0				
STATUS DI4 A	3x00100 4x00100 I:99	0,0x0000 B:00 00			UINT16 R/O	
		DI:0,CC:0,REC:0,FEC:0				
STATUS DI4 B	3x00101 4x00101 I:100	0,0x0000 B:00 00			UINT16 R/O	
		DI:0,SKE:0,LKSE:0,LKEE:0				
STATUS DI5 A	3x00102 4x00102 I:101	0,0x0000 B:00 00			UINT16 R/O	
		DI:0,CC:0,REC:0,FEC:0				
STATUS DI5 B	3x00103 4x00103 I:102	0,0x0000 B:00 00			UINT16 R/O	
		DI:0,SKE:0,LKSE:0,LKEE:0				

STATUS DI6 A	3x00104 4x00104 I:103	0,0x0000 B:00 00			UINT16 R/O	
		DI:0,CC:0,REC:0,FEC:0				
STATUS DI6 B	3x00105 4x00105 I:104	0,0x0000 B:00 00			UINT16 R/O	
		DI:0,SKE:0,LKSE:0,LKEE:0				
STATUS						
FILTER PATTERN DI1	3x00106 4x00106 I:105	0,0x00000000 B:00 00 00 00			UINT32 R/O	
The internal pattern for corresponding digital input for AC/DC filtering. The internal used state is created out of this internal pattern via oversampling.						
FILTER PATTERN DI2	3x00108 4x00108 I:107	0,0x00000000 B:00 00 00 00			UINT32 R/O	
FILTER PATTERN DI3	3x00110 4x00110 I:109	0,0x00000000 B:00 00 00 00			UINT32 R/O	
FILTER PATTERN DI4	3x00112 4x00112 I:111	0,0x00000000 B:00 00 00 00			UINT32 R/O	
FILTER PATTERN DI5	3x00114 4x00114 I:113	0,0x00000000 B:00 00 00 00			UINT32 R/O	
FILTER PATTERN DI6	3x00116 4x00116 I:115	0,0x00000000 B:00 00 00 00			UINT32 R/O	
PULSE TIME FOR DIGITAL OUTPUTS						
PULSE TIME DO1	3x00201 4x00201 I:200	0,0x0000 B:00 00	200	20,0	UINT16 R/W	NO
Generate a pulse on digital output x in 100ms units (0,1 to 6553,5 Seconds selectable) If you write onto this register, the digital output will be switched on for the desired time in 100ms units.						
PULSE TIME DO2	3x00202 4x00202 I:201	0,0x0000 B:00 00	300	30,0	UINT16 R/W	NO
PULSE TIME DO3	3x00203 4x00203 I:202	0,0x0000 B:00 00	400	40,0	UINT16 R/W	NO
PULSE TIME DO4	3x00204 4x00204 I:203	0,0x0000 B:00 00	500	50,0	UINT16 R/W	NO

PULSE TIME DO5	3x00205 4x00205 I:204	0,0x0000 B:00 00	20	2,0	UINT16 R/W	NO
PULSE TIME DO6	3x00206 4x00206 I:205	0,0x0000 B:00 00	20	2,0	UINT16 R/W	NO
PULSE STATUS FOR DIGITAL OUTPUTS						
PULSE TIMER DO1	3x00301 4x00301 I:300	0,0x00000000 B:00 00 00 00			UINT32 R/O	
		0,0 seconds				
Remaining time of the pulse on digital output x in Milliseconds.						
PULSE TIMER DO2	3x00303 4x00303 I:302	0,0x00000000 B:00 00 00 00			UINT32 R/O	
		0,0 seconds				
PULSE TIMER DO3	3x00305 4x00305 I:304	0,0x00000000 B:00 00 00 00			UINT32 R/O	
		0,0 seconds				
PULSE TIMER DO4	3x00307 4x00307 I:306	0,0x00000000 B:00 00 00 00			UINT32 R/O	
		0,0 seconds				
PULSE TIMER DO5	3x00309 4x00309 I:308	0,0x00000000 B:00 00 00 00			UINT32 R/O	
		0,0 seconds				
PULSE TIMER DO6	3x00311 4x00311 I:310	0,0x00000000 B:00 00 00 00			UINT32 R/O	
		0,0 seconds				
PULSE STATUS FOR DIGITAL OUTPUTS						
PULSE TIMER DO1	3x00313 4x00313 I:312	0,0x00000000 B:00 00 00 00			UINT32R R/O	
		0,0 seconds				
Remaining time of the pulse on digital output x in Milliseconds.						
PULSE TIMER DO2	3x00315 4x00315 I:314	0,0x00000000 B:00 00 00 00			UINT32R R/O	
		0,0 seconds				
PULSE TIMER DO3	3x00317 4x00317 I:316	0,0x00000000 B:00 00 00 00			UINT32R R/O	
		0,0 seconds				

PULSE TIMER DO4	3x00319 4x00319 I:318	0,0x00000000 B:00 00 00 00			UINT32R R/O	
		0,0 seconds				
PULSE TIMER DO5	3x00321 4x00321 I:320	0,0x00000000 B:00 00 00 00			UINT32R R/O	
		0,0 seconds				
PULSE TIMER DO6	3x00323 4x00323 I:322	0,0x00000000 B:00 00 00 00			UINT32R R/O	
		0,0 seconds				
GENERAL STATUS OF DIS						
RESET COUNTERS	3x10000 4x10000 I:9999	0,0x0000 B:00 00		1:PERFORM RESET	UINT16 R/W	NO
If this register is written to 1, all internal edge counters and event counters are set to 0. 0 is always returned when reading.						
HAS DIS CHANGED	3x10001 4x10001 I:10000	8,0x0008 B:00 08			UINT16 R/O	
		8 event(s)				
As soon as the module registrates an event on one of the available digital inputs, this global event counter is incremented by 1. Possible events are: Detection of a short keypress Detection of the start of a long keypress Detection of the end of a long keypress						
STATUS OF ALL DIS DI1..DI6	3x10002 4x10002 I:10001	0,0x0000 B:00 00			UINT16 R/O	
		Current state of DI1:0=OFF				
		Current state of DI2:0=OFF				
		Current state of DI3:0=OFF				
		Current state of DI4:0=OFF				
		Current state of DI5:0=OFF				
		Current state of DI6:0=OFF				
Current state of all digital inputs DI1..DI6 Bit 0: =0:DI1 is OFF, =1:DI1 is ON Bit 1: =0:DI2 is OFF, =1:DI2 is ON ... Bit 4: =0:DI5 is OFF, =1:DI5 is ON Bit 5: =0:DI6 is OFF, =1:DI6 is ON						
STATUS OF DIGITAL OUTPUTS						
STATUS OF DO1-DO6	3x10003 4x10003 I:10002	32,0x0020 B:00 20		0x003F	UINT16 R/W	NO
		Current state of DO1:0=OFF	1			
		Current state of DO2:0=OFF	1			

		Current state of DO3:0=OFF	1		
		Current state of DO4:0=OFF	1		
		Current state of DO5:0=OFF	1		
		Current state of DO6:1=ON	1		

Current state of all digital outputs
 Bit 0: =0:DO1 is OFF, =1:DO1 is ON
 Bit 1: =0:DO2 is OFF, =1:DO2 is ON
 ...
 Bit 4: =0:DO5 is OFF, =1:DO5 is ON
 Bit 5: =0:DO6 is OFF, =1:DO6 is ON

Write on this register sets all digital outputs to a new state

DIGITAL OUTPUTS:ENABLE OPEN WIRE DETECTION WHILE ON

ENABLE OPEN WIRE DETECTION WHILE ON DO1-DO6	3x10004 4x10004 l:10003	0,0x0000 B:00 00		0x003F	UINT16 R/W	NO
		Current setup of open wire detection while ON for DO1:0=OFF	1			
		Current setup of open wire detection while ON for DO2:0=OFF	1			
		Current setup of open wire detection while ON for DO3:0=OFF	1			
		Current setup of open wire detection while ON for DO4:0=OFF	1			
		Current setup of open wire detection while ON for DO5:0=OFF	1			
		Current setup of open wire detection while ON for DO6:0=OFF	1			

Current setup state for open wire detection while ON for digital output DOx
 Bit 0: =0:Open wire detection for DO1 is OFF, =1:Open wire detection for DO1 is ON
 Bit 1: =0:Open wire detection for DO2 is OFF, =1:Open wire detection for DO2 is ON
 ...
 Bit 4: =0:Open wire detection for DO5 is OFF, =1:Open wire detection for DO5 is ON
 Bit 5: =0:Open wire detection for DO6 is OFF, =1:Open wire detection for DO6 is ON

Write on this register sets for all digital outputs a new setup state

DIGITAL OUTPUTS:ENABLE OPEN WIRE DETECTION WHILE OFF

ENABLE OPEN WIRE DETECTION WHILE OFF DO1-DO6	3x10005 4x10005 l:10004	0,0x0000 B:00 00		0x003F	UINT16 R/W	NO
		Current setup of open wire detection while OFF for DO1:0=OFF	1			
		Current setup of open wire detection while OFF for DO2:0=OFF	1			
		Current setup of open wire detection while OFF for DO3:0=OFF	1			
		Current setup of open wire detection while OFF for DO4:0=OFF	1			

		Current setup of open wire detection while OFF for DO5:0=OFF	1		
		Current setup of open wire detection while OFF for DO6:0=OFF	1		
Current setup state for open wire detection while OFF for digital output DOx Bit 0: =0:Open wire detection for DO1 is OFF, =1:Open wire detection for DO1 is ON Bit 1: =0:Open wire detection for DO2 is OFF, =1:Open wire detection for DO2 is ON ... Bit 4: =0:Open wire detection for DO5 is OFF, =1:Open wire detection for DO5 is ON Bit 5: =0:Open wire detection for DO6 is OFF, =1:Open wire detection for DO6 is ON Write on this register sets for all digital outputs a new setup state					
DIGITAL OUTPUTS:ENABLE SHORTCUT TO VDD DETECTION WHILE OFF					
ENABLE SHORTCUT TO VDD DETECTION WHILE OFF DO1-DO6	3x10006 4x10006 l:10005	0,0x0000 B:00 00		0x003F	UINT16 R/W
		Current setup of shortcut detection to VDD while OFF for DO1:0=OFF	1		
		Current setup of shortcut detection to VDD while OFF for DO2:0=OFF	1		
		Current setup of shortcut detection to VDD while OFF for DO3:0=OFF	1		
		Current setup of shortcut detection to VDD while OFF for DO4:0=OFF	1		
		Current setup of shortcut detection to VDD while OFF for DO5:0=OFF	1		
		Current setup of shortcut detection to VDD while OFF for DO6:0=OFF	1		
Current setup state for shortcut to VDD detection while OFF for digital output DOx Bit 0: =0:Shortcut to VDD detection for DO1 is OFF, =1:Shortcut to VDD detection for DO1 is ON Bit 1: =0:Shortcut to VDD detection for DO2 is OFF, =1:Shortcut to VDD detection for DO2 is ON ... Bit 4: =0:Shortcut to VDD detection for DO5 is OFF, =1:Shortcut to VDD detection for DO5 is ON Bit 5: =0:Shortcut to VDD detection for DO6 is OFF, =1:Shortcut to VDD detection for DO6 is ON Write on this register sets for all digital outputs a new setup state					
DIGITAL OUTPUTS:OPEN WIRE WHILE ON DETECTION STATE					
OPEN WIRE DETECTION STATE WHILE ON DO1-DO6	3x10007 4x10007 l:10006	0,0x0000 B:00 00			UINT16 R/O
		Current state of open wire detection while ON for DO1:0=OK			
		Current state of open wire detection while ON for DO2:0=OK			
		Current state of open wire detection while ON for DO3:0=OK			
		Current state of open wire detection while ON for DO4:0=OK			

		Current state of open wire detection while ON for DO5:0=OK			
		Current state of open wire detection while ON for DO6:0=OK			
Current diagnostic state for open wire detection while ON for digital output DOx Bit 0: =0:Output DO1 is OK, =1:Fault-Open wire detected on DO1 Bit 1: =0:Output DO2 is OK, =1:Fault-Open wire detected on DO2 ... Bit 4: =0:Output DO5 is OK, =1:Fault-Open wire detected on DO5 Bit 5: =0:Output DO6 is OK, =1:Fault-Open wire detected on DO6					
DIGITAL OUTPUTS:OPEN WIRE WHILE OFF DETECTION STATE					
OPEN WIRE DETECTION STATE WHILE OFF DO1-DO6	3x10008 4x10008 l:10007	0,0x0000 B:00 00		UINT16 R/O	
		Current state of open wire detection while OFF for DO1:0=OK			
		Current state of open wire detection while OFF for DO2:0=OK			
		Current state of open wire detection while OFF for DO3:0=OK			
		Current state of open wire detection while OFF for DO4:0=OK			
		Current state of open wire detection while OFF for DO5:0=OK			
		Current state of open wire detection while OFF for DO6:0=OK			
Current diagnostic state for open wire detection while OFF for digital output DOx Bit 0: =0:Output DO1 is OK, =1:Fault-Open wire detected on DO1 Bit 1: =0:Output DO2 is OK, =1:Fault-Open wire detected on DO2 ... Bit 4: =0:Output DO5 is OK, =1:Fault-Open wire detected on DO5 Bit 5: =0:Output DO6 is OK, =1:Fault-Open wire detected on DO6					
DIGITAL OUTPUTS:SHORTCUT TO VDD WHILE OFF DETECTION STATE					
SHORTCUT TO VDD WHILE OFF DETECTION STATE DO1-DO6	3x10009 4x10009 l:10008	0,0x0000 B:00 00		UINT16 R/O	
		Current state of shortcut to VDD detection while OFF for DO1:0=OK			
		Current state of shortcut to VDD detection while OFF for DO2:0=OK			
		Current state of shortcut to VDD detection while OFF for DO3:0=OK			
		Current state of shortcut to VDD detection while OFF for DO4:0=OK			
		Current state of shortcut to VDD detection while OFF for DO5:0=OK			

		Current state of shortcut to VDD detection while OFF for DO6:0=OK			
Current diagnostic state for shortcut to VDD detection while OFF for digital output DOx Bit 0: =0:Output DO1 is OK, =1:Fault-shortcut detected on DO1 Bit 1: =0:Output DO2 is OK, =1:Fault-shortcut detected on DO2 ... Bit 4: =0:Output DO5 is OK, =1:Fault-shortcut detected on DO5 Bit 5: =0:Output DO6 is OK, =1:Fault-shortcut detected on DO6					
DIGITAL OUTPUTS:THERMAL OVERLOAD DETECTION STATE					
THERMAL OVERLOAD DETECTION STATE DO1-DO6	3x10010 4x10010 I:10009	0,0x0000 B:00 00			UINT16 R/O
		Current thermal overload detection state for DO1:0=OK			
		Current thermal overload detection state for DO2:0=OK			
		Current thermal overload detection state for DO3:0=OK			
		Current thermal overload detection state for DO4:0=OK			
		Current thermal overload detection state for DO5:0=OK			
		Current thermal overload detection state for DO6:0=OK			
Current thermal overload detection state for digital output DOx Bit 0: =0:Output DO1 is OK, =1:Fault-Thermal overload on DO1 Bit 1: =0:Output DO2 is OK, =1:Fault-Thermal overload on DO2 ... Bit 4: =0:Output DO5 is OK, =1:Fault-Thermal overload on DO5 Bit 5: =0:Output DO6 is OK, =1:Fault-Thermal overload on DO6					
DIGITAL OUTPUTS:CURRENT LIMIT DETECTION STATE					
CURRENT LIMIT DETECTION STATE DO1-DO6	3x10011 4x10011 I:10010	0,0x0000 B:00 00			UINT16 R/O
		Current current limit detection state for DO1:0=OK			
		Current current limit detection state for DO2:0=OK			
		Current current limit detection state for DO3:0=OK			
		Current current limit detection state for DO4:0=OK			
		Current current limit detection state for DO5:0=OK			
		Current current limit detection state for DO6:0=OK			

Current current limit detection state for digital output DOx Bit 0: =0:Output DO1 is OK, =1:Fault-Current limit on DO1 Bit 1: =0:Output DO2 is OK, =1:Fault-Current limit on DO2 ... Bit 4: =0:Output DO5 is OK, =1:Fault-Current limit on DO5 Bit 5: =0:Output DO6 is OK, =1:Fault-Current limit on DO6					
DIGITAL OUTPUTS: GLOBAL ERRORS					
GLOBAL ERRORS FOR DO1-DO6	3x10012 4x10012 I:10011	0,0x00 B:00 00			BIT R/O
		BIT 0:Internal under voltage detected:0=FAULT			
		BIT 1:VA under voltage detected (<2.3V):0=FAULT			
		BIT 2:VDD not good detected (<17V):0=FAULT			
		BIT 3:VDD warning detected (<12V):0=FAULT			
		BIT 4:VDD under voltage detected (<8V):0=FAULT			
		BIT 5:Thermal shutdown:0=FAULT			
		BIT 6:Synchronisation error detected:0=FAULT			
		BIT 7:Watchdog error detected:0=FAULT			
The global error state for the output group. Each bit stands for a different error =0:No fault, =1:Fault					
DIGITAL OUTPUTS: INTERRUPT STATUS					
INTERRUPT STATUS FOR DO1-DO6	3x10013 4x10013 I:10012	0,0x00 B:00 00			BIT R/O
		BIT 0:Overload detected:0=FAULT			
		BIT 1:Current limit detected:0=FAULT			
		BIT 2:Open wire while OFF detected:0=FAULT			
		BIT 3:Open wire while ON detected:0=FAULT			
		BIT 4:Shortcut to VDD detected:0=FAULT			
		BIT 5:Thermal shutdown:0=FAULT			
		BIT 6:Supply error detected:0=FAULT			
		BIT 7:Communication error detected:0=FAULT			
The interrupt state for the output group. Each bit stands for a different error =0:No fault, =1:Fault					
SPI COMMUNICATION DIGITAL OUTPUTS					
SPI COMMUNICATION DIGITAL OUTPUTS	3x10014 4x10014 I:10013	1,0x0001 B:00 01			UINT16 R/O
		Current SPI communcation state of DO1-DO6:1=FAULT			
		Current SPI communcation state of DO7-DO12:0=OK			
The current monitoring state of the SPI communication for the digital output group =0:No fault, =1:Fault					
Current SPI communication state of all digital output groups Bit 0: =0:DO1-DO6 No fault, =1:DO1-DO6 Fault Bit 1: =0:DO7-DO12 No fault, =1:DO7-DO12 Fault					
DIGITAL OUTPUTS: CHIPSET TYPE					

DIGITAL OUTPUTS CHIPSET TYPE	3x10100 4x10100 I:10099	1,0x0001 B:00 01			UINT16 R/O	
		Current chipset for DOs:1=MAX14915				
The current chipset for the digital outputs: =0: NCV7608 =1: MAX14915						
DIGITAL INPUTS: STATUS FOR DIGITAL INPUT DI1						
RISE DI1	3x30001 4x30001 I:30000	0,0x0000 B:00 00			UINT16 R/O	
		0 event(s)				
Counter for rising edges on the digital input DIx. If the module detects a rising edge on the digital input, this counter is incremented by 1. After power on or a soft reset this counter is set always to 0. With the function RESET COUNTER this counter is also set to 0.						
FALL DI1	3x30002 4x30002 I:30001	0,0x0000 B:00 00			UINT16 R/O	
		0 event(s)				
Counter for falling edges on the digital input DIx. If the module detects a falling edge on the digital input, this counter is incremented by 1. After power on or a soft reset this counter is set always to 0. With the function RESET COUNTER this counter is also set to 0.						
CHANGE DI1	3x30003 4x30003 I:30002	0,0x0000 B:00 00			UINT16 R/O	
		0 event(s)				
Counter for events on the digital input DIx. If the module detects an event on the digital input, this counter is incremented by 1. After power on or a soft reset this counter is set always to 0. With the function RESET COUNTER this counter is also set to 0. The following events are available: Detecion of a short keypress Detection of the start of a long keypress Detection of the end of a long keypress						
SHORT KEYPRESS DI1	3x30004 4x30004 I:30003	0,0x0000 B:00 00			UINT16 R/O	
		0 event(s)				
Counter for short keypress events on the digital input DIx. If the module detects a short keypress on the digital input, this counter is incremented by 1. After power on or a soft reset this counter is set always to 0. With the function RESET COUNTER this counter is also set to 0.						
LONG KEYPRESS START DI1	3x30005 4x30005 I:30004	0,0x0000 B:00 00			UINT16 R/O	
		0 event(s)				
Counter for start events of long keypress actions on the digital input DIx. If the module detects the start of a long keypress action on the digital input, this counter is incremented by 1. After power on or a soft reset this counter is set always to 0. With the function RESET COUNTER this counter is also set to 0.						
LONG KEYPRESS END DI1	3x30006 4x30006 I:30005	0,0x0000 B:00 00			UINT16 R/O	

		0 event(s)			
Counter for end events of long keypress actions on the digital input DIx. If the module detects the end of a long keypress action on the digital input, this counter is incremented by 1. After power on or a soft reset this counter is set always to 0. With the function RESET COUNTER this counter is also set to 0.					
DIGITAL INPUTS: STATUS FOR DIGITAL INPUT DI2					
RISE DI2	3x30011 4x30011 I:30010	0,0x0000 B:00 00			UINT16 R/O
		0 event(s)			
FALL DI2	3x30012 4x30012 I:30011	0,0x0000 B:00 00			UINT16 R/O
		0 event(s)			
CHANGE DI2	3x30013 4x30013 I:30012	0,0x0000 B:00 00			UINT16 R/O
		0 event(s)			
SHORT KEYPRESS DI2	3x30014 4x30014 I:30013	0,0x0000 B:00 00			UINT16 R/O
		0 event(s)			
LONG KEYPRESS START DI2	3x30015 4x30015 I:30014	0,0x0000 B:00 00			UINT16 R/O
		0 event(s)			
LONG KEYPRESS END DI2	3x30016 4x30016 I:30015	0,0x0000 B:00 00			UINT16 R/O
		0 event(s)			
DIGITAL INPUTS: STATUS FOR DIGITAL INPUT DI3					
RISE DI3	3x30021 4x30021 I:30020	0,0x0000 B:00 00			UINT16 R/O
		0 event(s)			
FALL DI3	3x30022 4x30022 I:30021	0,0x0000 B:00 00			UINT16 R/O
		0 event(s)			
CHANGE DI3	3x30023 4x30023 I:30022	0,0x0000 B:00 00			UINT16 R/O
		0 event(s)			
SHORT KEYPRESS DI3	3x30024 4x30024 I:30023	0,0x0000 B:00 00			UINT16 R/O
		0 event(s)			

LONG KEYPRESS START DI3	3x30025 4x30025 I:30024	0,0x0000 B:00 00			UINT16 R/O	
		0 event(s)				
LONG KEYPRESS END DI3	3x30026 4x30026 I:30025	0,0x0000 B:00 00			UINT16 R/O	
		0 event(s)				
DIGITAL INPUTS: STATUS FOR DIGITAL INPUT DI4						
RISE DI4	3x30031 4x30031 I:30030	0,0x0000 B:00 00			UINT16 R/O	
		0 event(s)				
FALL DI4	3x30032 4x30032 I:30031	0,0x0000 B:00 00			UINT16 R/O	
		0 event(s)				
CHANGE DI4	3x30033 4x30033 I:30032	0,0x0000 B:00 00			UINT16 R/O	
		0 event(s)				
SHORT KEYPRESS DI4	3x30034 4x30034 I:30033	0,0x0000 B:00 00			UINT16 R/O	
		0 event(s)				
LONG KEYPRESS START DI4	3x30035 4x30035 I:30034	0,0x0000 B:00 00			UINT16 R/O	
		0 event(s)				
LONG KEYPRESS END DI4	3x30036 4x30036 I:30035	0,0x0000 B:00 00			UINT16 R/O	
		0 event(s)				
DIGITAL INPUTS: STATUS FOR DIGITAL INPUT DI5						
RISE DI5	3x30041 4x30041 I:30040	0,0x0000 B:00 00			UINT16 R/O	
		0 event(s)				
FALL DI5	3x30042 4x30042 I:30041	0,0x0000 B:00 00			UINT16 R/O	
		0 event(s)				
CHANGE DI5	3x30043 4x30043 I:30042	0,0x0000 B:00 00			UINT16 R/O	
		0 event(s)				

SHORT KEYPRESS DI5	3x30044 4x30044 I:30043	0,0x0000 B:00 00			UINT16 R/O	
		0 event(s)				
LONG KEYPRESS START DI5	3x30045 4x30045 I:30044	0,0x0000 B:00 00			UINT16 R/O	
		0 event(s)				
LONG KEYPRESS END DI5	3x30046 4x30046 I:30045	0,0x0000 B:00 00			UINT16 R/O	
		0 event(s)				
DIGITAL INPUTS: STATUS FOR DIGITAL INPUT DI6						
RISE DI6	3x30051 4x30051 I:30050	0,0x0000 B:00 00			UINT16 R/O	
		0 event(s)				
FALL DI6	3x30052 4x30052 I:30051	0,0x0000 B:00 00			UINT16 R/O	
		0 event(s)				
CHANGE DI6	3x30053 4x30053 I:30052	0,0x0000 B:00 00			UINT16 R/O	
		0 event(s)				
SHORT KEYPRESS DI6	3x30054 4x30054 I:30053	0,0x0000 B:00 00			UINT16 R/O	
		0 event(s)				
LONG KEYPRESS START DI6	3x30055 4x30055 I:30054	0,0x0000 B:00 00			UINT16 R/O	
		0 event(s)				
LONG KEYPRESS END DI6	3x30056 4x30056 I:30055	0,0x0000 B:00 00			UINT16 R/O	
		0 event(s)				
INITIAL & WATCHDOG STATUS FOR ALL DIGITAL OUTPUTS						
INITIAL & WATCHDOG STATUS OF DO1-DO6	3x59001 4x59001 I:59000	0,0x0000 B:00 00		0x003F	UINT16 R/W	NO
		Current init & watchdog state of DO1:0=OFF	1			
		Current init & watchdog state of DO2:0=OFF	1			
		Current init & watchdog state of DO3:0=OFF	1			
		Current init & watchdog state of DO4:0=OFF	1			
		Current init & watchdog state of DO5:0=OFF	1			

		Current init & watchdog state of DO6:0=OFF	1		
Current initial and watchdog state of all digital outputs. This state is used after power on and after a communication watchdog timeout, if a watchdog time is configured Bit 0: =0:DO1 is OFF, =1:DO1 is ON Bit 1: =0:DO2 is OFF, =1:DO2 is ON ... Bit 4: =0:DO5 is OFF, =1:DO5 is ON Bit 5: =0:DO6 is OFF, =1:DO6 is ON					
Write on this register sets all digital outputs to a new state for module restart and watchdog function. The state is saved in FLASH					
DIGITAL OUTPUTS:ENABLE OPEN WIRE DETECTION WHILE ON					
INITIAL & WATCHDOG SETUP ENABLE OPEN WIRE DETECTION WHILE ON DO1-DO6	3x59002 4x59002 1:59001	0,0x0000 B:00 00		0x003F	UINT16 R/W
		Initial setup of open wire detection while ON for DO1:0=OFF	1		
		Initial setup of open wire detection while ON for DO2:0=OFF	1		
		Initial setup of open wire detection while ON for DO3:0=OFF	1		
		Initial setup of open wire detection while ON for DO4:0=OFF	1		
		Initial setup of open wire detection while ON for DO5:0=OFF	1		
		Initial setup of open wire detection while ON for DO6:0=OFF	1		
Initial setup state for open wire detection while ON for digital output DOx. Used after power on and watchdog event Bit 0: =0:Open wire detection for DO1 is OFF, =1:Open wire detection for DO1 is ON Bit 1: =0:Open wire detection for DO2 is OFF, =1:Open wire detection for DO2 is ON ... Bit 4: =0:Open wire detection for DO5 is OFF, =1:Open wire detection for DO5 is ON Bit 5: =0:Open wire detection for DO6 is OFF, =1:Open wire detection for DO6 is ON					
Write on this register sets for all digital outputs a new setup state					
DIGITAL OUTPUTS:ENABLE OPEN WIRE DETECTION WHILE OFF					
INITIAL & WATCHDOG SETUP ENABLE OPEN WIRE DETECTION WHILE OFF DO1-DO6	3x59003 4x59003 1:59002	0,0x0000 B:00 00		0x003F	UINT16 R/W
		Initial setup of open wire detection while OFF for DO1:0=OFF	1		
		Initial setup of open wire detection while OFF for DO2:0=OFF	1		
		Initial setup of open wire detection while OFF for DO3:0=OFF	1		
		Initial setup of open wire detection while OFF for DO4:0=OFF	1		
		Initial setup of open wire detection while OFF for DO5:0=OFF	1		

		Initial setup of open wire detection while OFF for DO6:0=OFF	1		
Initial setup state for open wire detection while OFF for digital output DOx. Used after power on and watchdog event Bit 0: =0:Open wire detection for DO1 is OFF, =1:Open wire detection for DO1 is ON Bit 1: =0:Open wire detection for DO2 is OFF, =1:Open wire detection for DO2 is ON ... Bit 4: =0:Open wire detection for DO5 is OFF, =1:Open wire detection for DO5 is ON Bit 5: =0:Open wire detection for DO6 is OFF, =1:Open wire detection for DO6 is ON Write on this register sets for all digital outputs a new setup state					
DIGITAL OUTPUTS:ENABLE OPEN WIRE DETECTION WHILE OFF					
INITIAL & WATCHDOG SETUP ENABLE SHOTCUT TO VDD DETECTION WHILE OFF DO1-DO6	3x59004 4x59004 1:59003	0,0x0000 B:00 00		0x003F	UINT16 R/W NO
		Initial setup of shortcut to VDD detection while OFF for DO1:0=OFF	1		
		Initial setup of shortcut to VDD detection while OFF for DO2:0=OFF	1		
		Initial setup of shortcut to VDD detection while OFF for DO3:0=OFF	1		
		Initial setup of shortcut to VDD detection while OFF for DO4:0=OFF	1		
		Initial setup of shortcut to VDD detection while OFF for DO5:0=OFF	1		
		Initial setup of shortcut to VDD detection while OFF for DO6:0=OFF	1		
Initial setup state for shortcut to VDD detection while OFF for digital output DOx. Used after power on and watchdog event Bit 0: =0:Shortcut detection for DO1 is OFF, =1:Shortcut detection for DO1 is ON Bit 1: =0:Shortcut detection for DO2 is OFF, =1:Shortcut detection for DO2 is ON ... Bit 4: =0:Shortcut detection for DO5 is OFF, =1:Shortcut detection for DO5 is ON Bit 5: =0:Shortcut detection for DO6 is OFF, =1:Shortcut detection for DO6 is ON Write on this register sets for all digital outputs a new setup state					

Command NAME	ASCII command type	ASCII command structure	NEW REAL VALUE	NEW VALUE	DATA TYPE	DO WRITE
ASCII COMMANDS						
DIGITAL INPUTS						
GET DIGITAL INPUTS	ASCII READ COMMAND	#GDIS<CR> Result: #GDIS:<DISDec>,<DISHex><CR>			ASCII	
	TX	#1,GDIS<CR>				
	RX	#1,GDIS:0,0x0<CR>				
		Current status of digital inputs:00.0000				
Returns the current state of all 32 digital inputs as decimal number and as hexadecimal number. DISDec, DISHex The current state of all digital inputs: Bit 0: State of DI1 (=0:OFF, =1:ON) Bit 1: State of DI2 (=0:OFF, =1:ON) ... Bit 4: State of DI5 (=0:OFF, =1:ON) Bit 5: State of DI6 (=0:OFF, =1:ON)						
GET DIGITAL INPUT Dlx	ASCII READ COMMAND	#GDI<DINR><CR> Result: #GDI<DINR>:<DlxDec>,<DlxHex><CR>			ASCII	
	DINR	6				
	TX	#1,GDI6<CR>				
	RX	#1,GDI6:0,0x0<CR>				
		Current status of digital input DI6:0=OFF				
Returns the current state of the digital input Dlx as decimal number and as hexadecimal number. X stands for the desired digital input between 1 and 12. DlxDec, DlxHex: The current state of the digital input x: =0: Digital input is OFF =1: Digital input is ON						
GET ALL CHANGES	ASCII READ COMMAND	#GAC<CR> Result: #GAC:<ChangesDec>,<ChangesHex><CR>			ASCII	
	TX	#1,GAC<CR>				
	RX	#1,GAC:8,0x8<CR>				
		Current change counter:8				
Returns the counter for changes on all digital inputs. As soon as the module detects a short keypress or long key release event, this counter is incremented by 1. If this values has changed sience the last polling request, the host knows, that at least one digital input has changed its state.						
CHANGE ALL DIS	ASCII READ COMMAND	#CADISP1<CR> Result: #CADISP1:<ChangeDI1Dec>,...,<ChangeDlxDec>,<ChangeDI1Hex>,...,<ChangeDlxHex><CR>			ASCII	
	TX	#1,CADISP1<CR>				

	RX	#1,CADISP1:2,1,1,1,1,2,0x2,0x1,0x1,0x1,0x2<CR>		
		Current counter for changes on DI1:2		
		Current counter for changes on DI2:1		
		Current counter for changes on DI3:1		
		Current counter for changes on DI4:1		
		Current counter for changes on DI5:1		
		Current counter for changes on DI6:2		
Returns for each digital input the counter for changes. As soon as the module detects a signal change on a digital input, the change counter for the affected digital input is incremented by 1. A signal change can be: Detection of a short keypress Detection of the start of a long keypress Detection of a release of a long keypress				
CHANGE DIx	ASCII READ COMMAND	#CDI<DINR><CR> Result: #CDI<DINR>:<ChangesDec>,<ChangesHex><CR>	ASCII	
	DINR	6		
	TX	#1,CDI6<CR>		
	RX	#1,CDI6:2,0x2<CR>		
		Current counter for changes on digital input DI6:2		
Returns for digital input <DINR> the counter for signal changes. As soon as the module detects a signal change on a digital input, the change counter for the affected digital input is incremented by 1. A signal change can be: Detection of a short keypress Detection of the start of a long keypress Detection of a release of a long keypress				
SHORT KEY ALL DIS	ASCII READ COMMAND	#SKADISP1<CR> Result: #SKADISP1:<ShortKeyDI1Dec>,...,<ShortKeyDIxDec>, <ShortKeyDI1Hex>,...,<ShortKeyDIxHex><CR>	ASCII	
	TX	#1,SKADISP1<CR>		
	RX	#1,SKADISP1:0,1,1,1,1,0,0x0,0x1,0x1,0x1,0x0<CR>		
		Current counter for short keypress events on DI1:0		
		Current counter for short keypress events on DI2:1		
		Current counter for short keypress events on DI3:1		
		Current counter for short keypress events on DI4:1		
		Current counter for short keypress events on DI5:1		
		Current counter for short keypress events on DI6:0		
Returns for each digital input the counter for short keypress events. As soon as the module detects a short keypress on a digital input, the counter for the affected digital input is incremented by 1.				
SHORT KEY DIx	ASCII READ COMMAND	#SKDI<DINR><CR> Result: #SKDI<DINR>:<ShortKeyDec>,<ShortKeyHex><CR>	ASCII	
	DINR	6		
	TX	#1,SKDI6<CR>		
	RX	#1,SKDI6:0,0x0<CR>		
		Current counter for short keypress events on digital input DI6:0		
Returns for digital input <DINR> the counter for short keypress events. As soon as the module detects a short keypress on a digital input, the counter for the affected digital input is incremented by 1.				

LONG KEY START ALL DIS	ASCII READ COMMAND	#LKSADISP1<CR> Result: #LKSADISP1:<LongKeyStartDI1Dec>,...,<LongKeyStartDIxDec>, <LongKeyStartDI1Hex>,...,<LongKeyStartDIxHex> <CR>	ASCII	
	TX	#1,LKSADISP1<CR>		
	RX	#1,LKSADISP1:1,0,0,0,0,1,0x1,0x0,0x0,0x0,0x0,0x1<CR>		
		Current counter for long keypress start events on DI1:1		
		Current counter for long keypress start events on DI2:0		
		Current counter for long keypress start events on DI3:0		
		Current counter for long keypress start events on DI4:0		
		Current counter for long keypress start events on DI5:0		
		Current counter for long keypress start events on DI6:1		
Returns for each digital input the counter for long keypress start events. As soon as the module detects the start of a long keypress on a digital input, the counter for the affected digital input is incremented by 1.				
LONG KEY START DIx	ASCII READ COMMAND	#LKSDI<DINR> <CR> Result: #LKSDI<DINR>:<LongKeyStartDec>,<LongKeyStartHex> <CR>	ASCII	
	DINR	6		
	TX	#1,LKSDI6<CR>		
	RX	#1,LKSDI6:1,0x1<CR>		
		Current counter for long keypress start events on digital input DI6:1		
Returns for digital input <DINR> the counter for long keypress start events. As soon as the module detects the start of a long keypress on a digital input, the counter for the affected digital input is incremented by 1.				
LONG KEY END ALL DIS	ASCII READ COMMAND	#LKEADISP1<CR> Result: #LKEADISP1:<LongKeyEndDI1Dec>,...,<LongKeyEndDIxDec>, <LongKeyEndDI1Hex>,...,<LongKeyEndDIxHex> <CR>	ASCII	
	TX	#1,LKEADISP1<CR>		
	RX	#1,LKEADISP1:1,0,0,0,0,1,0x1,0x0,0x0,0x0,0x0,0x1<CR>		
		Current counter for long keypress end events on DI1:1		
		Current counter for long keypress end events on DI2:0		
		Current counter for long keypress end events on DI3:0		
		Current counter for long keypress end events on DI4:0		
		Current counter for long keypress end events on DI5:0		
		Current counter for long keypress end events on DI6:1		
Returns for each digital input the counter for long keypress end events. As soon as the module detects the end of a long keypress on a digital input, the counter for the affected digital input is incremented by 1.				
LONG KEY END DIx	ASCII READ COMMAND	#LKEDI<DINR> <CR> Result: #LKEDI<DINR>:<LongKeyEndDec>,<LongKeyEndHex> <CR>	ASCII	
	DINR	6		
	TX	#1,LKEDI6<CR>		
	RX	#1,LKEDI6:1,0x1<CR>		
		Current counter for long keypress end events on digital input DI6:1		
Returns for digital input <DINR> the counter for long keypress end events. As soon as the module detects the end of a long keypress on a digital input, the counter for the affected digital input is incremented by 1.				

RISE ALL DIS	ASCII READ COMMAND	#RADISP1<CR> Result: #RADISP1:<RiseDI1Dec>,...,<RiseDIxDec>,<RiseDI1Hex>,...,<RiseDIxHex><CR>	ASCII	
	TX	#1,RADISP1<CR>		
	RX	#1,RADISP1:1,1,1,1,1,0x1,0x1,0x1,0x1,0x1,0x1<CR>		
		Current counter for rising edges on DI1:1		
		Current counter for rising edges on DI2:1		
		Current counter for rising edges on DI3:1		
		Current counter for rising edges on DI4:1		
		Current counter for rising edges on DI5:1		
		Current counter for rising edges on DI6:1		
Returns for each digital input the counter for rising edges. As soon as the module detects a rising edge on a digital input, the rising edge counter for the affected digital input is incremented by 1.				
RISE DIx	ASCII READ COMMAND	#RDI<DINR><CR> Result: #RDI<DINR>:<RiseDec>,<RiseHex><CR>	ASCII	
	DINR	6		
	TX	#1,RDI6<CR>		
	RX	#1,RDI6:1,0x1<CR>		
		Current counter for rising edges on digital input DI6:1		
Returns for digital input <DINR> the counter for rising edges. As soon as the module detects a rising edge on a digital input, the rising edge counter for the affected digital input is incremented by 1.				
FALL ALL DIS	ASCII READ COMMAND	#FADISP1<CR> Result: #FADISP1:<FallDI1Dec>,...,<FallDIxDec>,<FallDI1Hex>,...,<FallDIxHex><CR>	ASCII	
	TX	#1,FADISP1<CR>		
	RX	#1,FADISP1:1,1,1,1,1,0x1,0x1,0x1,0x1,0x1,0x1<CR>		
		Current counter for falling edges on DI1:1		
		Current counter for falling edges on DI2:1		
		Current counter for falling edges on DI3:1		
		Current counter for falling edges on DI4:1		
		Current counter for falling edges on DI5:1		
		Current counter for falling edges on DI6:1		
Returns for each digital input the counter for falling edges. As soon as the module detects a falling edge on a digital input, the falling edge counter for the affected digital input is incremented by 1.				
FALL DIx	ASCII READ COMMAND	#FDI<DINR><CR> Result: #FDI<DINR>:<FallDec>,<FallHex><CR>	ASCII	
	DINR	6		
	TX	#1,FDI6<CR>		
	RX	#1,FDI6:1,0x1<CR>		
		Current counter for falling edges on digital input DI6:1		
Returns for digital input <DINR> the counter for falling edges. As soon as the module detects a falling edge on a digital input, the falling edge counter for the affected digital input is incremented by 1.				
RESET COUNTERS	ASCII WRITE COMMAND	#RC<CR> Result: #OK<CR>	ASCII	YES
	TX	#1,RC<CR>		

	RX	N/A		
Resets all internal counters for digital inputs and events on this digital inputs to 0.				
DIGITAL OUTPUTS				
SET DIGITAL OUTPUTS	ASCII WRITE COMMAND	#SDOS:<OutAllDOS> <CR> Result: #OK<CR>	ASCII	YES
	DO1	1:ON		
	DO2	0:OFF		
	DO3	1:ON		
	DO4	0:OFF		
	DO5	0:OFF		
	DO6	0:OFF		
	TX	#1,SDOS:5<CR>		
	RX	N/A		
Sets all digital outputs to the new state OutAllDOS The new state for all digital outputs Bit 0: State of DO1 (=0:OFF, =1:ON) Bit 1: State of DO2 (=0:OFF, =1:ON) ... Bit 4: State of DO5 (=0:OFF, =1:ON) Bit 5: State of DO6 (=0:OFF, =1:ON)				
SET DIGITAL OUTPUT DOx	ASCII WRITE COMMAND	#SDO<DONR>:<Out> <CR> Result: #OK<CR>	ASCII	YES
	DONR	1		
	DO1	1:ON		
	TX	#1,SDO1:1<CR>		
	RX	N/A		
Sets the new state for digital output DOx. The state is defined with <Out>. Out The new state of the digital output DOx: =0: digital output is OFF =1: digital output is ON				
GET DIGITAL OUTPUTS	ASCII READ COMMAND	#GDOS<CR> Result: #GDOS:<DOSDec>,<DOSHex> <CR>	ASCII	
	TX	#1,GDOS<CR>		
	RX	#1,GDOS:32,0x20<CR>		
		Current status of digital outputs:10.0000		
Returns the current state of the digital outputs as decimal number and as hexadecimal number. DOSDec, DOSHex The current state of the digital outputs: Bit 0: State of DO1 (=0:OFF, =1:ON) Bit 1: State of DO2 (=0:OFF, =1:ON) ... Bit 4: State of DO5 (=0:OFF, =1:ON) Bit 5: State of DO6 (=0:OFF, =1:ON)				

GET DIGITAL OUTPUT DOx	ASCII READ COMMAND	#GDO<DONR><CR> Result: #GDO<DONR>:<DOxDec>,<DOxHex><CR>	ASCII	
	DONR	1		
	TX	#1,GDO1<CR>		
	RX	#1,GDO1:0,0x0<CR>		
		Current status of digital output DO1:0=OFF		
Returns the current state of the digital output DOx as decimal number and as hexadecimal number. DOxDec, DOxHex The current state of the digital output DOx: =0: digital output is OFF =1: digital output is ON				
DIGITAL OUTPUTS: ENABLE OPEN WIRE DETECTION WHILE ON				
SET DIGITAL OUTPUTS ENABLE OPEN WIRE DETECTION WHILE ON	ASCII WRITE COMMAND	#SDOEOWDONS:<OpenWireDOS><CR> Result: #OK<CR>	ASCII	YES
	DO1	1:ENABLE		
	DO2	1:ENABLE		
	DO3	1:ENABLE		
	DO4	1:ENABLE		
	DO5	1:ENABLE		
	DO6	1:ENABLE		
	TX	#1,SDOEOWDONS:63<CR>		
	RX	N/A		
Sets the open wire mode for all digital outputs to the new mode OpenWireDOS. This enables the diagnostic of open wire while the digital output is ON. The new state for all digital outputs Bit 0: New mode for DO1 (=0:DISABLED, =1:ENABLED) Bit 1: New mode for DO2 (=0:DISABLED, =1:ENABLED) ... Bit 4: New mode for DO5 (=0:DISABLED, =1:ENABLED) Bit 5: New mode for DO6 (=0:DISABLED, =1:ENABLED)				
SET DIGITAL OUTPUT ENABLE OPEN WIRE DETECTION WHILE ON	ASCII WRITE COMMAND	#SDOEOWDON<DONR>:<OpenWireDOx><CR> Result: #OK<CR>	ASCII	YES
	DONR	1		
	DO1	0:DISABLE		
	TX	#1,SDOEOWDON1:0<CR>		
	RX	N/A		
Sets the open wire mode for digital output DOx to the new mode OpenWireDOx. This enables the diagnostic of open wire while the digital output is ON. The new mode of the digital output DOx: =0: diagnostic mode for digital output is DISABLED =1: diagnostic mode for digital output is ENABLED				
GET DIGITAL OUTPUTS ENABLE OPEN WIRE DETECTION WHILE ON	ASCII READ COMMAND	#GDOEOWDONS<CR> Result: #GDOEOWDONS:<OpenWireDOSDec>,<OpenWireDOSHex><CR>	ASCII	
	TX	#1,GDOEOWDONS<CR>		
	RX	#1,GDOEOWDONS:0,0x0<CR>		

		Current mode for open wire diagnostic while ON of digital outputs:00.0000		
Returns the current mode for open wire diagnostic while digital output is ON as decimal number and as hexadecimal number. OpenWireDOSDec, OpenWireDOSHex The current mode for open wire diagnostic while ON of the digital outputs: Bit 0: Open wire diagnostic mode of DO1 (=0:DISABLED, =1:ENABLED) Bit 1: Open wire diagnostic mode of DO2 (=0:DISABLED, =1:ENABLED) ... Bit 4: Open wire diagnostic mode of DO5 (=0:DISABLED, =1:ENABLED) Bit 5: Open wire diagnostic mode of DO6 (=0:DISABLED, =1:ENABLED)				
GET DIGITAL OUTPUT ENABLE OPEN WIRE DETECTION WHILE ON	ASCII READ COMMAND DONR	#GDOEOWDON<DONR> <CR> Result: #GDOEOWDON<DONR>:<OpenWireDOxDec>,<OpenWireDOxHex> <CR> 1	ASCII	
	TX	#1,GDOEOWDON1<CR>		
	RX	#1,GDOEOWDON1:0,0x0<CR>		
		Current open wire diagnostic mode while ON of digital output DO1:0=DISABLED		
Returns the current open wire diagnostic mode while ON of the digital output DOx as decimal number and as hexadecimal number. X stands for the number of the digital output. OpenWireDOxDec, OpenWireDOxHex The current diagnostic mode of the digital output DOx: =0: open wire diagnostic mode for digital output is DISABLED =1: open wire diagnostic mode for digital output is ENABLED				
DIGITAL OUTPUTS: ENABLE OPEN WIRE DETECTION WHILE OFF				
SET DIGITAL OUTPUTS ENABLE OPEN WIRE DETECTION WHILE OFF	ASCII WRITE COMMAND DO1 DO2 DO3 DO4 DO5 DO6 TX RX	#SDOEOWDOFFS:<OpenWireDOS> <CR> Result: #OK<CR> 1:ENABLE 1:ENABLE 1:ENABLE 1:ENABLE 1:ENABLE 1:ENABLE #1,SDOEOWDOFFS:63<CR> N/A	ASCII	YES
Sets the open wire mode for all digital outputs to the new mode OpenWireDOS. This enables the diagnostic of open wire while the digital output is OFF. The new state for all digital outputs Bit 0: New mode for DO1 (=0:DISABLED, =1:ENABLED) Bit 1: New mode for DO2 (=0:DISABLED, =1:ENABLED) ... Bit 4: New mode for DO5 (=0:DISABLED, =1:ENABLED) Bit 5: New mode for DO6 (=0:DISABLED, =1:ENABLED)				
SET DIGITAL OUTPUT ENABLE OPEN WIRE DETECTION WHILE OFF	ASCII WRITE COMMAND DONR DO1 TX RX	#SDOEOWDOFF<DONR>:<OpenWireDOx> <CR> Result: #OK<CR> 1 0:DISABLE #1,SDOEOWDOFF1:0<CR> N/A	ASCII	YES

Sets the open wire mode for digital output DOx to the new mode OpenWireDOx. This enables the diagnostic of open wire while the digital output is OFF. The new mode of the digital output DOx: =0: diagnostic mode for digital output is DISABLED =1: diagnostic mode for digital output is ENABLED				
GET DIGITAL OUTPUTS ENABLE OPEN WIRE DETECTION WHILE OFF	ASCII READ COMMAND	#GDOEOWDOFFS<CR> Result: #GDOEOWDOFFS:<OpenWireDOSDec>,<OpenWireDOSHex> <CR>	ASCII	
	TX	#1,GDOEOWDOFFS<CR>		
	RX	#1,GDOEOWDOFFS:0,0x0<CR>		
		Current mode for open wire diagnostic while OFF of digital outputs:00.0000		
Returns the current mode for open wire diagnostic while digital output is OFF as decimal number and as hexadecimal number. OpenWireDOSDec, OpenWireDOSHex The current mode for open wire diagnostic while OFF of the digital outputs: Bit 0: Open wire diagnostic mode of DO1 (=0:DISABLED, =1:ENABLED) Bit 1: Open wire diagnostic mode of DO2 (=0:DISABLED, =1:ENABLED) ... Bit 4: Open wire diagnostic mode of DO5 (=0:DISABLED, =1:ENABLED) Bit 5: Open wire diagnostic mode of DO6 (=0:DISABLED, =1:ENABLED)				
GET DIGITAL OUTPUT ENABLE OPEN WIRE DETECTION WHILE OFF	ASCII READ COMMAND	#GDOEOWDOFF<DONR> <CR> Result: #GDOEOWDOFF<DONR>:<OpenWireDOxDec>,<OpenWireDOxHex> <CR>	ASCII	
	DONR	1		
	TX	#1,GDOEOWDOFF1<CR>		
	RX	#1,GDOEOWDOFF1:0,0x0<CR>		
		Current open wire diagnostic mode while OFF of digital output DO1:0=DISABLED		
Returns the current open wire diagnostic mode while OFF of the digital output DOx as decimal number and as hexadecimal number. X stands for the number of the digital output. OpenWireDOxDec, OpenWireDOxHex The current diagnostic mode of the digital output DOx: =0: open wire diagnostic mode for digital output is DISABLED =1: open wire diagnostic mode for digital output is ENABLED				
DIGITAL OUTPUTS: ENABLE SHORTCUT TO VDD DETECTION WHILE OFF				
SET DIGITAL OUTPUTS ENABLE SHORTCUT TO VDD DETECTION WHILE OFF	ASCII WRITE COMMAND	#SDOESVDDS:<ShortCutDOS> <CR> Result: #OK<CR>	ASCII	YES
	DO1	1:ENABLE		
	DO2	1:ENABLE		
	DO3	1:ENABLE		
	DO4	1:ENABLE		
	DO5	1:ENABLE		
	DO6	1:ENABLE		
	TX	#1,SDOESVDDS:63<CR>		
	RX	N/A		
Sets the shortcut to VDD detection mode for all digital outputs to the new mode ShortCutDOS. This enables the diagnostic of shortcut to VDD while the digital output is OFF. The new state for all digital outputs Bit 0: New mode for DO1 (=0:DISABLED, =1:ENABLED) Bit 1: New mode for DO2 (=0:DISABLED, =1:ENABLED) ... Bit 4: New mode for DO5 (=0:DISABLED, =1:ENABLED) Bit 5: New mode for DO6 (=0:DISABLED, =1:ENABLED)				

SET DIGITAL OUTPUT ENABLE SHORTCUT TO VDD DETECTION WHILE OFF	ASCII WRITE COMMAND	#SDOESVDD<DONR>:<ShortCutDOx> <CR> Result: #OK<CR>	ASCII	YES
	DONR	1		
	DO1	0:DISABLE		
	TX	#1,SDOESVDD1:0<CR>		
	RX	N/A		
Sets the shortcut to VDD mode for digital output DOx to the new mode ShortCutDOx. This enables the diagnostic of shortcut to VDD while the digital output is OFF. The new mode of the digital output DOx: =0: diagnostic mode for digital output is DISABLED =1: diagnostic mode for digital output is ENABLED				
GET DIGITAL OUTPUTS ENABLE SHORT CUT TO VDD DETECTION WHILE OFF	ASCII READ COMMAND	#GDOESVDDS<CR> Result: #GDOESDDS:<ShortCutDOSDec>,<ShortCutDOSHex> <CR>	ASCII	
	TX	#1,GDOESVDDS<CR>		
	RX	#1,GDOESVDDS:0,0x0<CR>		
		Current mode for shortcut to VDD diagnostic while OFF of digital outputs:00.0000		
Returns the current mode for shortcut to VDD diagnostic while digital output is OFF as decimal number and as hexadecimal number. ShortCutDOSDec, ShortCutDOSHex The current mode for shortcut diagnostic while OFF of the digital outputs: Bit 0: Open wire diagnostic mode of DO1 (=0:DISABLED, =1:ENABLED) Bit 1: Open wire diagnostic mode of DO2 (=0:DISABLED, =1:ENABLED) ... Bit 4: Open wire diagnostic mode of DO5 (=0:DISABLED, =1:ENABLED) Bit 5: Open wire diagnostic mode of DO6 (=0:DISABLED, =1:ENABLED)				
GET DIGITAL OUTPUT ENABLE SHORT CUT TO VDD DETECTION WHILE OFF	ASCII READ COMMAND	#GDOESVDD<DONR> <CR> Result: #GDOESVDD<DONR>:<ShortCutDOxDec>,<ShortCutDOxHex> <CR>	ASCII	
	DONR	1		
	TX	#1,GDOESVDD1<CR>		
	RX	#1,GDOESVDD1:0,0x0<CR>		
		Current shortcut to VDD diagnostic mode while OFF of digital output DO1:0=DISABLED		
Returns the current short cut to VDD diagnostic mode while OFF of the digital output DOx as decimal number and as hexadecimal number. X stands for the number of the digital output. ShortCutDOxDec, ShortCutDOxHex The current diagnostic mode of the digital output DOx: =0: open wire diagnostic mode for digital output is DISABLED =1: open wire diagnostic mode for digital output is ENABLED				
DIGITAL OUTPUTS: SPI STATUS				
GET SPI STATUS DIGITAL OUTPUT GROUPS	ASCII READ COMMAND	#GSSDOGS<CR> Result: #GSSDOGS:<SPIDOGSDec>,<SPIDOGSHex> <CR>	ASCII	
	TX	#1,GSSDOGS<CR>		
	RX	#1,GSSDOGS:1,0x1<CR>		
		Current SPI status of digital output groups:1		
Returns the current SPI communication state of the corresponding output group as decimal number and as hexadecimal number. SPIDOGSDec,SPIDOGSHex The current SPI communication state of the digital output group: Bit 0: SPI communication state for digital output group #1 (DO1-DO6) (=0:NO FAULT, =1:FAULT)				

GET SPI STATUS DIGITAL OUTPUT GROUPx	ASCII READ COMMAND	#GSSDOG<DOGRP> <CR> Result: #GSSDOG<DOGRP>:<SPIDOGxDec>,<SPIDOGxHex> <CR>	ASCII	
	DOGRP	1		
	TX	#1,GSSDOG1<CR>		
	RX	#1,GSSDOG1:1,0x1<CR>		
		Current SPI status of digital output group DOG1:1=FAULT		
Returns the current SPI communication state of the digital output group DOGRP as decimal number and as hexadecimal number. X stands for the number of the digital output group. SPIDOGxDec, SPIDOGxHex The current SPI communication state of the digital output group DOGRP: =0: SPI communication state for output group is OK (NO FAULT) =1: SPI communication state for output group is FAULT Digital output group #1 is DO1-DO6				
DIGITAL OUTPUTS: INTERRUPT STATUS				
GET DIGITAL OUTPUTS INTERRUPT STATUS	ASCII READ COMMAND	#GDOINTS<CR> Result: #GDOINTS:<InterruptStatusDec>,<InterruptStatusHex> <CR>	ASCII	
	TX	#1,GDOINTS<CR>		
	RX	#1,GDOINTS:0,0x0<CR>		
		Current interrupt status of all digital output groups:0000.0000		
Returns the current interrupt state state of all output groups as decimal number and as hexadecimal number. InterruptStatusDec,InterruptStatusHex The current interrupt state of all digital output groups Bit 0:DO1-DO6:Overload detected (0=OK,1=FAULT) Bit 1:DO1-DO6:Current limit detected(0=OK,1=FAULT) Bit 2:DO1-DO6:Open wire while OFF detected (0=OK,1=FAULT) Bit 3:DO1-DO6:Open wire while ON detected (0=OK,1=FAULT) Bit 4:DO1-DO6:Short to VDD while ON detected (0=OK,1=FAULT) Bit 5:DO1-DO6:Thermal error detected-shutdown (0=OK,1=FAULT) Bit 6:DO1-DO6:Supply error detected (0=OK,1=FAULT) Bit 7:DO1-DO6:Communication error detected (0=OK,1=FAULT)				
GET DIGITAL OUTPUT GROUPx INTERRUPT STATUS	ASCII READ COMMAND	#GDOINT<DOGRP> <CR> Result: #GDOINT<DOGRP>:<InterruptStatusDec>,<InterruptStatusHex> <CR>	ASCII	
	DOGRP	1		
	TX	#1,GDOINT1<CR>		
	RX	#1,GDOINT1:0,0x0<CR>		
		Current interrupt status of digital output group 1:0000.0000		

Returns the current interrupt state of the digital output group DOGRP as decimal number and as hexadecimal number. X stands for the number of the digital output group. InterruptStatusDec, InterruptStatusHex Group 1: DO1-DO6 Group 2: DO7-DO12 Bit 0:Overload detected (0=OK,1=FAULT) Bit 1:Current limit detected(0=OK,1=FAULT) Bit 2:Open wire while OFF detected (0=OK,1=FAULT) Bit 3:Open wire while ON detected (0=OK,1=FAULT) Bit 4:Short to VDD while ON detected (0=OK,1=FAULT) Bit 5:Thermal error detected-shutdown (0=OK,1=FAULT) Bit 6:Supply error detected (0=OK,1=FAULT) Bit 7:Communication error detected (0=OK,1=FAULT)				
DIGITAL OUTPUTS: GLOBAL ERRORS				
GET DIGITAL OUTPUTS GLOBAL ERRORS	ASCII READ COMMAND	#GDOERRS<CR> Result: #GDOERRS:<GlobalErrorsDec>,<GlobalErrorsHex> <CR>	ASCII	
	TX	#1,GDOERRS<CR>		
	RX	#1,GDOERRS:0,0x0<CR>		
		Current global errors of all digital output groups:0000.0000		
Returns the current interrupt state state of all output groups as decimal number and as hexadecimal number. InterruptStatusDec,InterruptStatusHex The current interrupt state of all digital output groups Bit 0:DO1-DO6:Internal under voltage detected (0=OK,1=FAULT) Bit 1:DO1-DO6:VA under voltage detected (<2.3V) (0=OK,1=FAULT) Bit 2:DO1-DO6:VDD not good detected (<17V) (0=OK,1=FAULT) Bit 3:DO1-DO6:VDD warning detected (<12V) (0=OK,1=FAULT) Bit 4:DO1-DO6:VDD under voltage detected (<8V) (0=OK,1=FAULT) Bit 5:DO1-DO6:Thermal shutdown (0=OK,1=FAULT) Bit 6:DO1-DO6:Synchronisation error detected (0=OK,1=FAULT) Bit 7:DO1-DO6:Watchdog error detected (0=OK,1=FAULT)				
GET DIGITAL OUTPUT GROUPx GLOBAL ERRORS	ASCII READ COMMAND	#GDOERR<DOGRP> <CR> Result: #GDOERR<DOGRP>:<GlobalErrorsDec>,<GlobalErrorsHex> <CR>	ASCII	
	DOGRP	1		
	TX	#1,GDOERR1<CR>		
	RX	#1,GDOERR1:0,0x0<CR>		
		Current global errors of digital output group 1:0000.0000		
Returns the current interrupt state of the digital output group DOGRP as decimal number and as hexadecimal number. X stands for the number of the digital output group. InterruptStatusDec, InterruptStatusHex Group 1: DO1-DO6 Group 2: DO7-DO12 Bit 0:Internal under voltage detected (0=OK,1=FAULT) Bit 1:VA under voltage detected (<2.3V) (0=OK,1=FAULT) Bit 2:VDD not good detected (<17V) (0=OK,1=FAULT) Bit 3:VDD warning detected (<12V) (0=OK,1=FAULT) Bit 4:VDD under voltage detected (<8V) (0=OK,1=FAULT) Bit 5:Thermal shutdown (0=OK,1=FAULT) Bit 6:Synchronisation error detected (0=OK,1=FAULT) Bit 7:Watchdog error detected (0=OK,1=FAULT)				
DIGITAL OUTPUTS: THERMAL OVERLOAD DETECTION				

GET DIGITAL OUTPUTS THERMAL OVERLOAD DETECTION	ASCII READ COMMAND	#GDOTOS<CR> Result: #GDOTOS:<StatusDOSDec>,<StatusDOSHex><CR>	ASCII	
	TX	#1,GDOTOS<CR>		
	RX	#1,GDOTOS:0,0x0<CR>		
		Current thermal overload detection status of digital outputs:00.0000		
Returns the current state of the thermal overload detection for all digital outputs as decimal number and as hexadecimal number. StatusDOSDec, StatusDOSHex The current detection state of the digital outputs: Bit 0: State of DO1 (=0:OFF, =1:ON) Bit 1: State of DO2 (=0:OFF, =1:ON) ... Bit 4: State of DO5 (=0:OFF, =1:ON) Bit 5: State of DO6 (=0:OFF, =1:ON)				
GET DIGITAL OUTPUT DOx THERMAL OVERLOAD DETECTION	ASCII READ COMMAND	#GDOTO<DONR><CR> Result: #GDOTO<DONR>:<StatusDOxDec>,<StatusDOxHex><CR>	ASCII	
	DONR	1		
	TX	#1,GDOTO1<CR>		
	RX	#1,GDOTO1:0,0x0<CR>		
		Current thermal overload detection status of DO1:0=OFF		
Returns the current state of the thermal overload detection for digital output DOx as decimal number and as hexadecimal number. StatusDOxDec, StatusDOxHex The current detection state for digital output DOx: =0: digital output is OK =1: FAULT detected on digital output				
DIGITAL OUTPUTS: CURRENT LIMIT DETECTION				
GET DIGITAL OUTPUTS CURRENT LIMIT DETECTION	ASCII READ COMMAND	#GDOCLS<CR> Result: #GDOCLS:<StatusDOSDec>,<StatusDOSHex><CR>	ASCII	
	TX	#1,GDOCLS<CR>		
	RX	#1,GDOCLS:0,0x0<CR>		
		Current current limit detection status of digital outputs:00.0000		
Returns the current state of the current limit detection for all digital outputs as decimal number and as hexadecimal number. StatusDOSDec, StatusDOSHex The current detection state of the digital outputs: Bit 0: State of DO1 (=0:OFF, =1:ON) Bit 1: State of DO2 (=0:OFF, =1:ON) ... Bit 4: State of DO5 (=0:OFF, =1:ON) Bit 5: State of DO6 (=0:OFF, =1:ON)				
GET DIGITAL OUTPUT DOx CURRENT LIMIT DETECTION	ASCII READ COMMAND	#GDOCL<DONR><CR> Result: #GDOCL<DONR>:<StatusDOxDec>,<StatusDOxHex><CR>	ASCII	
	DONR	1		
	TX	#1,GDOCL1<CR>		
	RX	#1,GDOCL1:0,0x0<CR>		
		Current current limit detection status of DO1:0=OFF		

Returns the current state of the current limit detection for digital output DOx as decimal number and as hexadecimal number. StatusDOxDec, StatusDOxHex The current detection state for digital output DOx: =0: digital output is OK =1: FAULT detected on digital output				
DIGITAL OUTPUTS: OPEN WIRE DETECTION WHILE ON				
GET DIGITAL OUTPUTS OPEN WIRE FAULT DETECTION WHILE ON	ASCII READ COMMAND	#GDOOWFONS<CR> Result: #GDOOWFONS:<StatusDOSDec>,<StatusDOSHex><CR>	ASCII	
	TX	#1,GDOOWFONS<CR>		
	RX	#1,GDOOWFONS:0,0x0<CR>		
		Current open wire fault detection status while ON of digital outputs:00.0000		
Returns the current state of the open wire fault detection while ON for all digital outputs as decimal number and as hexadecimal number. StatusDOSDec, StatusDOSHex The current detection state of the digital outputs: Bit 0: State of DO1 (=0:OFF, =1:ON) Bit 1: State of DO2 (=0:OFF, =1:ON) ... Bit 4: State of DO5 (=0:OFF, =1:ON) Bit 5: State of DO6 (=0:OFF, =1:ON)				
GET DIGITAL OUTPUT DOx OPEN WIRE FAULT DETECTION WHILE ON	ASCII READ COMMAND	#GDOOWFON<DONR><CR> Result: #GDOOWFON<DONR>:<StatusDOxDec>,<StatusDOxHex><CR>	ASCII	
	DONR	1		
	TX	#1,GDOOWFON1<CR>		
	RX	#1,GDOOWFON1:0,0x0<CR>		
		Current open wire fault detection status while ON of DO1:0=OFF		
Returns the current state of the open wire fault detection while ON for digital output DOx as decimal number and as hexadecimal number. StatusDOxDec, StatusDOxHex The current detection state for digital output DOx: =0: digital output is OK =1: FAULT detected on digital output				
DIGITAL OUTPUTS: OPEN WIRE DETECTION WHILE OFF				
GET DIGITAL OUTPUTS OPEN WIRE FAULT DETECTION WHILE OFF	ASCII READ COMMAND	#GDOOWFOFFS<CR> Result: #GDOOWFOFFS:<StatusDOSDec>,<StatusDOSHex><CR>	ASCII	
	TX	#1,GDOOWFOFFS<CR>		
	RX	#1,GDOOWFOFFS:0,0x0<CR>		
		Current open wire fault detection status while OFF of digital outputs:00.0000		
Returns the current state of the open wire fault detection while OFF for all digital outputs as decimal number and as hexadecimal number. StatusDOSDec, StatusDOSHex The current detection state of the digital outputs: Bit 0: State of DO1 (=0:OFF, =1:ON) Bit 1: State of DO2 (=0:OFF, =1:ON) ... Bit 4: State of DO5 (=0:OFF, =1:ON) Bit 5: State of DO6 (=0:OFF, =1:ON)				

GET DIGITAL OUTPUT DOx OPEN WIRE FAULT DETECTION WHILE OFF	ASCII READ COMMAND	#GDOOWFOFF<DONR> <CR> Result: #GDOOWFOFF<DONR>:<StatusDOxDec>,<StatusDOxHex> <CR>	ASCII	
	DONR	1		
	TX	#1,GDOOWFOFF1<CR>		
	RX	#1,GDOOWFOFF1:0,0x0<CR>		
		Current open wire fault detection status while OFF of DO1:0=OFF		
Returns the current state of the open wire fault detection while OFF for digital output DOx as decimal number and as hexadecimal number. StatusDOxDec, StatusDOxHex The current detection state for digital output DOx: =0: digital output is OK =1: FAULT detected on digital output				
DIGITAL OUTPUTS: SHORTCUT TO VDD DETECTION WHILE OFF				
GET DIGITAL OUTPUTS SHORTCUT TO VDD FAULT DETECTION WHILE OFF	ASCII READ COMMAND	#GDOSVDDS<CR> Result: #GDOSVDDS:<StatusDOSDec>,<StatusDOSHex> <CR>	ASCII	
	TX	#1,GDOSVDDS<CR>		
	RX	#1,GDOSVDDS:0,0x0<CR>		
		Current shortcut to VDD fault detection status while OFF of digital outputs:00.0000		
Returns the current state of the shortcut to VDD fault detection while OFF for all digital outputs as decimal number and as hexadecimal number. StatusDOSDec, StatusDOSHex The current detection state of the digital outputs: Bit 0: State of DO1 (=0:OFF, =1:ON) Bit 1: State of DO2 (=0:OFF, =1:ON) ... Bit 4: State of DO5 (=0:OFF, =1:ON) Bit 5: State of DO6 (=0:OFF, =1:ON)				
GET DIGITAL OUTPUT DOx SHORTCUT TO VDD FAULT DETECTION WHILE OFF	ASCII READ COMMAND	#GDOSVDD<DONR> <CR> Result: #GDOSVDD<DONR>:<StatusDOxDec>,<StatusDOxHex> <CR>	ASCII	
	DONR	1		
	TX	#1,GDOSVDD1<CR>		
	RX	#1,GDOSVDD1:0,0x0<CR>		
		Current shortcut to VDD fault detection status while OFF of DO1:0=OFF		
Returns the current state of the shortcut to VDD fault detection while OFF for digital output DOx as decimal number and as hexadecimal number. StatusDOxDec, StatusDOxHex The current detection state for digital output DOx: =0: digital output is OK =1: FAULT detected on digital output				
DIGITAL OUTPUTS: PULSE OUTPUT				
PULSE DOx	ASCII WRITE COMMAND	#PDO<DONR>:<Time> <CR> Result: #OK<CR>	ASCII	YES
	DONR	1		
	TIME	200		
	TX	#1,PDO1:200<CR>		
	RX	N/A		

This command switches the digital output DOx on for the pulse duration <PulseTimeIn100ms>*100ms. PulseTimeIn100ms: A duration in 100ms units. The corresponding digital output is switched on for this time period.				
GET PULSE TIMER DOx	ASCII READ COMMAND	#GPT<DONR> <CR> Result: #GPT:<TimeDec>,<TimeHex> <CR>	ASCII	
	DONR	1		
	TX	#1,GPT1<CR>		
	RX	#1,GPT1:0,0x0<CR>		
		Current pulse time for DO1:0,0s		
Returns the remaining timer value of the pulse for digital output DOx in ms. PulseTimeInMSDec, PulseTimeInMSHex The remaining time of the pulse in Milliseconds				
INITIAL & WATCHDOG STATE FOR DIGITAL OUTPUTS				
SET INITIAL & WATCHDOG STATE FOR DIGITAL OUTPUTS	ASCII WRITE COMMAND	#SCDOS:<OutAllDOS> <CR> Result: #OK<CR>	ASCII	YES
	DO1	0:OFF		
	DO2	0:OFF		
	DO3	0:OFF		
	DO4	0:OFF		
	DO5	0:OFF		
	DO6	0:OFF		
	TX	#1,SCDOS:0<CR>		
	RX	N/A		
Write on this register sets all digital outputs to a new state for module restart and watchdog function. The state is saved in FLASH. This state is used after power on and after a communcation watchdog timeout, if a watchdog time is cfgured. OutAllDOS The new state for the digital outputs: Bit 0: New state of DO1 (=0:OFF, =1:ON) Bit 1: New state of DO2 (=0:OFF, =1:ON) ... Bit 4: New state of DO5 (=0:OFF, =1:ON) Bit 5: New state of DO6 (=0:OFF, =1:ON)				
GET INITIAL & WATCHDOG STATE FOR DIGITAL OUTPUTS	ASCII READ COMMAND	#GDOS<CR> Result: #GDOS:<DOSDec>,<DOSHex> <CR>	ASCII	
	TX	#1,GDOS<CR>		
	RX	#1,GDOS:32,0x20<CR>		
		Current status of digital outputs:10.0000		

Returns the current initial and watchdog state of the digital outputs as decimal number and as hexadecimal number. This state is used after power on and after a communication watchdog timeout, if a watchdog time is configured

DOSDec, DOSHex

The current state of the digital outputs:

Bit 0: State of DO1 (=0:OFF, =1:ON)

Bit 1: State of DO2 (=0:OFF, =1:ON)

...

Bit 4: State of DO5 (=0:OFF, =1:ON)

Bit 5: State of DO6 (=0:OFF, =1:ON)

DIGITAL OUTPUTS: INIT & WATCHDOG ENABLE OPEN WIRE DETECTION WHILE ON

SET CONFIG DIGITAL OUTPUTS ENABLE OPEN WIRE DETECTION WHILE ON	ASCII WRITE COMMAND	#SCDOEOWDONS:<OpenWireDOS> <CR> Result: #OK<CR>	ASCII	YES
	DO1	1:ENABLE		
	DO2	1:ENABLE		
	DO3	1:ENABLE		
	DO4	1:ENABLE		
	DO5	1:ENABLE		
	DO6	1:ENABLE		
	TX	#1,SCDOEOWDONS:63<CR>		
	RX	N/A		

Sets the open wire mode for all digital outputs to the new mode OpenWireDOS for init & watchdog. This enables the diagnostic of open wire while the digital output is ON.

This state is used after power on and after a communication watchdog timeout, if a watchdog time is configured

The new state for all digital outputs

Bit 0: New mode for DO1 (=0:DISABLED, =1:ENABLED)

Bit 1: New mode for DO2 (=0:DISABLED, =1:ENABLED)

...

Bit 4: New mode for DO5 (=0:DISABLED, =1:ENABLED)

Bit 5: New mode for DO6 (=0:DISABLED, =1:ENABLED)

GET CONFIG DIGITAL OUTPUTS ENABLE OPEN WIRE DETECTION WHILE ON	ASCII READ COMMAND	#GCDOEOWDONS<CR> Result: #GCDOEOWDONS:<OpenWireDOSDec>,<OpenWireDOSHex> <CR>	ASCII	
	TX	#1,GCDOEOWDONS<CR>		
	RX	#1,GCDOEOWDONS:0,0x0<CR>		
		Init & watchdog mode for open wire diagnostic while ON of digital outputs:00.0000		

Returns the current mode for open wire diagnostic while digital output is ON as decimal number and as hexadecimal number.

This values are used after power on of the module an after a watchdog event.

OpenWireDOSDec, OpenWireDOSHex

The current mode for open wire diagnostic while ON of the digital outputs:

Bit 0: Open wire diagnostic mode of DO1 (=0:DISABLED, =1:ENABLED)

Bit 1: Open wire diagnostic mode of DO2 (=0:DISABLED, =1:ENABLED)

...

Bit 4: Open wire diagnostic mode of DO5 (=0:DISABLED, =1:ENABLED)

Bit 5: Open wire diagnostic mode of DO6 (=0:DISABLED, =1:ENABLED)

DIGITAL OUTPUTS: INIT & WATCHDOG ENABLE OPEN WIRE DETECTION WHILE OFF

SET CONFIG DIGITAL OUTPUTS ENABLE OPEN WIRE DETECTION WHILE OFF	ASCII WRITE COMMAND	#SCDOEOWDOFFS:<OpenWireDOS> <CR> Result: #OK<CR>	ASCII	YES
---	---------------------------	--	-------	-----

	DO1	1:ENABLE		
	DO2	1:ENABLE		
	DO3	1:ENABLE		
	DO4	1:ENABLE		
	DO5	1:ENABLE		
	DO6	1:ENABLE		
	TX	#1,SCDOEOWDOFFS:63<CR>		
	RX	N/A		
Sets the open wire mode for all digital outputs to the new mode OpenWireDOS for init & watchdog. This enables the diagnostic of open wire while the digital output is OFF. This state is used after power on and after a communication watchdog timeout, if a watchdog time is configured The new state for all digital outputs Bit 0: New mode for DO1 (=0:DISABLED, =1:ENABLED) Bit 1: New mode for DO2 (=0:DISABLED, =1:ENABLED) ... Bit 4: New mode for DO5 (=0:DISABLED, =1:ENABLED) Bit 5: New mode for DO6 (=0:DISABLED, =1:ENABLED)				
GET CONFIG DIGITAL OUTPUTS	ASCII	#GCDOEOWDOFFS<CR>	ASCII	
ENABLE OPEN WIRE	READ	Result:		
DETECTION WHILE OFF	COMMAND	#GCDOEOWDOFFS:<OpenWireDOSDec>,<OpenWireDOSHex><CR>		
	TX	#1,GCDOEOWDOFFS<CR>		
	RX	#1,GCDOEOWDOFFS:0,0x0<CR>		
		Current mode for open wire diagnostic while OFF of digital outputs:00.0000		
Returns the current mode for open wire diagnostic while digital output is OFF as decimal number and as hexadecimal number. This values are used after power on of the module an after a watchdog event. OpenWireDOSDec, OpenWireDOSHex The current mode for open wire diagnostic while OFF of the digital outputs: Bit 0: Open wire diagnostic mode of DO1 (=0:DISABLED, =1:ENABLED) Bit 1: Open wire diagnostic mode of DO2 (=0:DISABLED, =1:ENABLED) ... Bit 4: Open wire diagnostic mode of DO5 (=0:DISABLED, =1:ENABLED) Bit 5: Open wire diagnostic mode of DO6 (=0:DISABLED, =1:ENABLED)				
DIGITAL OUTPUTS: INIT & WATCHDOG ENABLE SHORTCUT TO VDD DETECTION WHILE OFF				
SET CONFIG DIGITAL OUTPUTS	ASCII	#SCDOESVDDS:<ShortCutDOS><CR>	ASCII	YES
ENABLE SHORTCUT TO VDD	WRITE	Result:		
DETECTION WHILE OFF	COMMAND	#OK<CR>		
	DO1	1:ENABLE		
	DO2	1:ENABLE		
	DO3	1:ENABLE		
	DO4	1:ENABLE		
	DO5	1:ENABLE		
	DO6	1:ENABLE		
	TX	#1,SCDOESVDDS:63<CR>		
	RX	N/A		

Sets the shortcut to VDD detection mode for all digital outputs to the new mode ShortCutDOS for init & watchdog. This enables the diagnostic of shortcut to VDD while the digital output is OFF. This state is used after power on and after a communication watchdog timeout, if a watchdog time is configured The new state for all digital outputs Bit 0: New mode for DO1 (=0:DISABLED, =1:ENABLED) Bit 1: New mode for DO2 (=0:DISABLED, =1:ENABLED) ... Bit 4: New mode for DO5 (=0:DISABLED, =1:ENABLED) Bit 5: New mode for DO6 (=0:DISABLED, =1:ENABLED)				
GET CONFIG DIGITAL OUTPUTS	ASCII	#GCDOESVDDS<CR>	ASCII	
ENABLE SHORT CUT TO VDD	READ	Result:		
DETECTION WHILE OFF	COMMAND	#GCDOESDDS:<ShortCutDOSDec>,<ShortCutDOSHex> <CR>		
	TX	#1,GCDOESVDDS<CR>		
	RX	#1,GCDOESVDDS:0,0x0<CR>		
		Current mode for shortcut to VDD diagnostic while OFF of digital outputs:00.0000		
Returns the current mode for shortcut to VDD diagnostic while digital output is OFF as decimal number and as hexadecimal number. This values are used after power on of the module an after a watchdog event. ShortCutDOSDec, ShortCutDOSHex The current mode for shortcut diagnostic while OFF of the digital outputs: Bit 0: Open wire diagnostic mode of DO1 (=0:DISABLED, =1:ENABLED) Bit 1: Open wire diagnostic mode of DO2 (=0:DISABLED, =1:ENABLED) ... Bit 4: Open wire diagnostic mode of DO51 (=0:DISABLED, =1:ENABLED) Bit 5: Open wire diagnostic mode of DO6 (=0:DISABLED, =1:ENABLED)				
GET DIGITAL OUTPUTS	ASCII	#GDOCHIPSET<CR>	ASCII	
CHIPSET NAME	READ	Result:		
	COMMAND	#GDOCHIPSET:<ChipSetName>		
	TX	#1,GDOCHIPSET<CR>		
	RX	#1,GDOCHIPSET:MAX14915<CR>		
		Current name of chipset for digital outputs:MAX14915		
Returns the current name of the chipset of the digital outputs				

Register NAME Command NAME	MODBUS Register ASCII Command	Register VALUE ASCII Command	NEW REAL VALUE	NEW VALUE	DATA TYPE	DO WRITE
ASCII COMMANDS						
AIOX CONFIGURATION						
SET IO TYPES	ASCII WRITE COMMAND	#SIOTYPS:<IOTyp1>,<IOTyp2>,<IOTyp3>,<IOTyp4> <CR> Result: #OK<CR>			ASCII	YES
	IOTyp1	VO[0-10V]				
	IOTyp2	VO[0-10V]				
	IOTyp3	VO[0-10V]				
	IOTyp4	VO[0-10V]				
	TX	#1,SIOTYPS:VO[0-10V],VO[0-10V],VO[0-10V],VO[0-10V] <CR>				
	RX	#1,OK<CR>				
This command defines for all 4 universal IOs a new type of IO: IOTypx stands for the new type: UU: Unused – high impedance VI[0-10V]: VOLTAGE INPUT for 0 to 10V Signals VI[2-10V]: VOLTAGE INPUT for 2 to 10V Signals VO[0-10V]: VOLTAGE OUTPUT for 0 to 10V Signals VO[2-10V]: VOLTAGE OUTPUT for 2 to 10V Signals CI[0-20mA;LP]: CURRENT INPUT for 0 to 20mA Signals – loop powered CI[4-20mA;LP]: CURRENT INPUT for 4 to 20mA Signals – loop powered CI[0-20mA;EP]: CURRENT INPUT for 0 to 20mA Signals – external powered CI[4-20mA;EP]: CURRENT INPUT for 4 to 20mA Signals – external powered CO[0-20mA]: CURRENT OUTPUT for 0 to 20mA Signals CO[4-20mA]: CURRENT OUTPUT for 4 to 20mA Signals RTDI[OHM]: RTD SENSOR INPUT for Ohm measurement between 0 and 1MOhm DI[24V;L]: DIGITAL INPUT for 24Vdc – logic, threshold 12V DI[24V;LP]: DIGITAL INPUT for 24Vdc – loop powered HINT: The last IO type is automatically stored in FRAM and will be used after a system restart.						
SET IO TYPx	ASCII WRITE COMMAND	#SIOTYP<IONR>:<IOTypx> <CR> Result: #OK<CR>			ASCII	YES
	IONR	1				
	IOTypx	VO[0-10V]				
	TX	#1,SIOTYP1:VO[0-10V] <CR>				
	RX	#1,OK<CR>				

This command defines for the universal IO IONR a new type of IO:
IOTypx stands for the new type:
UU: Unused – high impedance
VI[0-10V]: VOLTAGE INPUT for 0 to 10V Signals
VI[2-10V]: VOLTAGE INPUT for 2 to 10V Signals
VO[0-10V]: VOLTAGE OUTPUT for 0 to 10V Signals
VO[2-10V]: VOLTAGE OUTPUT for 2 to 10V Signals
CI[0-20mA;LP]: CURRENT INPUT for 0 to 20mA Signals – loop powered
CI[4-20mA;LP]: CURRENT INPUT for 4 to 20mA Signals – loop powered
CI[0-20mA;EP]: CURRENT INPUT for 0 to 20mA Signals – external powered
CI[4-20mA;EP]: CURRENT INPUT for 4 to 20mA Signals – external powered
CO[0-20mA]: CURRENT OUTPUT for 0 to 20mA Signals
CO[4-20mA]: CURRENT OUTPUT for 4 to 20mA Signals
RTDI[OHM]: RTD SENSOR INPUT for Ohm measurement between 0 and 1MOhm
DI[24V;L]: DIGITAL INPUT for 24Vdc – logic, threshold 12V
DI[24V;LP]: DIGITAL INPUT for 24Vdc – loop powered

HINT: The last IO type is automatically stored in FRAM and will be used after a system restart.

GET IO TYPES	ASCII READ COMMAND	#GIOTYPS<CR> Result: #GIOTYPS:<IOTyp1Txt>,<IOTyp2Txt>,...,<IOTyp4Txt> <CR>	ASCII	
	TX	#1,GIOTYPS<CR>		
	RX	#1,GIOTYPS:VO[0-10V],VO[0-10V],VO[0-10V],VO[0-10V] <CR>		
		Actual type of IO1:VO[0-10V]		
		Actual type of IO2:VO[0-10V]		
		Actual type of IO3:VO[0-10V]		
		Actual type of IO4:VO[0-10V]		

This command shows for all 4 universal IOs the current selected type of IO:
IOTypx stands for the types:
UU: Unused – high impedance
VI[0-10V]: VOLTAGE INPUT for 0 to 10V Signals
VI[2-10V]: VOLTAGE INPUT for 2 to 10V Signals
VO[0-10V]: VOLTAGE OUTPUT for 0 to 10V Signals
VO[2-10V]: VOLTAGE OUTPUT for 2 to 10V Signals
CI[0-20mA;LP]: CURRENT INPUT for 0 to 20mA Signals – loop powered
CI[4-20mA;LP]: CURRENT INPUT for 4 to 20mA Signals – loop powered
CI[0-20mA;EP]: CURRENT INPUT for 0 to 20mA Signals – external powered
CI[4-20mA;EP]: CURRENT INPUT for 4 to 20mA Signals – external powered
CO[0-20mA]: CURRENT OUTPUT for 0 to 20mA Signals
CO[4-20mA]: CURRENT OUTPUT for 4 to 20mA Signals
RTDI[OHM]: RTD SENSOR INPUT for Ohm measurement between 0 and 1MOhm
DI[24V;L]: DIGITAL INPUT for 24Vdc – logic, threshold 12V
DI[24V;LP]: DIGITAL INPUT for 24Vdc – loop powered

GET IO TYPx	ASCII READ COMMAND	#GIOTYP<IONR> <CR> Result: #GIOTYP<IONR>:<IOTypxTxt> <CR>	ASCII	
	IONR	1		
	TX	#1,GIOTYP1<CR>		
	RX	#1,GIOTYP1:VO[0-10V] <CR>		
		Actual type of IO1:VO[0-10V]		

This command shows for the universal IO IONR the current selected type:
IOType stands for the types:
UU: Unused – high impedance
VI[0-10V]: VOLTAGE INPUT for 0 to 10V Signals
VI[2-10V]: VOLTAGE INPUT for 2 to 10V Signals
VO[0-10V]: VOLTAGE OUTPUT for 0 to 10V Signals
VO[2-10V]: VOLTAGE OUTPUT for 2 to 10V Signals
CI[0-20mA;LP]: CURRENT INPUT for 0 to 20mA Signals – loop powered
CI[4-20mA;LP]: CURRENT INPUT for 4 to 20mA Signals – loop powered
CI[0-20mA;EP]: CURRENT INPUT for 0 to 20mA Signals – external powered
CI[4-20mA;EP]: CURRENT INPUT for 4 to 20mA Signals – external powered
CO[0-20mA]: CURRENT OUTPUT for 0 to 20mA Signals
CO[4-20mA]: CURRENT OUTPUT for 4 to 20mA Signals
RTDI[OHM]: RTD SENSOR INPUT for Ohm measurement between 0 and 1MOhm
DI[24V;L]: DIGITAL INPUT for 24Vdc – logic, threshold 12V
DI[24V;LP]: DIGITAL INPUT for 24Vdc – loop powered

VOLTAGE INPUTS

GET VOLTAGE INPUTS IN VOLT	ASCII READ COMMAND	#GVISV<CR> Result: #GVISV:<IOVolt1DbI>,<IOVolt2DbI>,...,<IOVolt4DbI><CR>	ASCII	
	TX	#1,GVISV<CR>		
	RX	#1,GVISV:999.99,999.99,999.99,999.99<CR>		
		Actual voltage on IO1:999.99V		
		Actual voltage on IO2:999.99V		
		Actual voltage on IO3:999.99V		
		Actual voltage on IO4:999.99V		

This command shows for all VOLTAGE INPUT IOs the current measurement in Volt.
The measurement range is 0.0 to 10.00V.
All IOs with a different usage type will return 999.99 to indicate, that no measurement is done.

GET VOLTAGE INPUT IN VOLT	ASCII READ COMMAND	#GVIV<IONR><CR> Result: #GVIV<IONR>:<IOxVoltDbI><CR>	ASCII	
	IONR	1		
	TX	#1,GVIV1<CR>		
	RX	#1,GVIV1:999.99<CR>		
		Actual voltage on IO1:999.99V		

This command shows for the VOLTAGE INPUT IO <IONR> the current measurement in Volt.
The measurement range is 0.0 to 10.00V.
All IOs with a different usage type will return 999.99 to indicate, that no measurement is done.

GET VOLTAGE INPUTS IN PERCENT	ASCII READ COMMAND	#GVISP<CR> Result: #GVISP:<IOPercent1DbI>,<IOPercent2DbI>,...,<IOPercent4DbI><CR>	ASCII	
	TX	#1,GVISP<CR>		
	RX	#1,GVISP:999.99,999.99,999.99,999.99<CR>		
		Actual percentage on IO1:999.99%		
		Actual percentage on IO2:999.99%		
		Actual percentage on IO3:999.99%		

		Actual percentage on IO4:999.99%		
This command shows for all VOLTAGE INPUT IOs the current measurement in Percent. The measurement range is 0.0V -> 0.0% to 10.00V -> 100.0%. All IOs with a different usage type will return 999.99 to indicate, that no measurement is done.				
GET VOLTAGE INPUT IN PERCENT	ASCII READ COMMAND	#GVIP<IONR> <CR> Result: #GVIP<IONR>:<IOxPercentDbI> <CR>	ASCII	
	IONR	1		
	TX	#1,GVIP1<CR>		
	RX	#1,GVIP1:999.99<CR>		
		Actual percentage on IO1:999.99%		
This command shows for VOLTAGE INPUT IO <IONR> the current measurement in Percent. The measurement range is 0.0V -> 0.0% to 10.00V -> 100.0%. All IOs with a different usage type will return 999.99 to indicate, that no measurement is done.				
VOLTAGE DIGITAL INPUTS				
GET VOLTAGE DIGITAL INPUTS	ASCII READ COMMAND	#GVDIS<CR> Result: #GVDIS:<IODI1Dec>,<IODI2Dec>,...,<IODI4Dec> <CR>	ASCII	
	TX	#1,GVDIS<CR>		
	RX	#1,GVDIS:X,X,X,X<CR>		
		Actual voltage digital input state on IO1:X		
		Actual voltage digital input state on IO2:X		
		Actual voltage digital input state on IO3:X		
		Actual voltage digital input state on IO4:X		
This command shows for all VOLTAGE DIGITAL INPUT IOs the current state. The digital input can have the values 0 and 1. All IOs with a different usage type will return X to indicate, that no measurement is done.				
GET VOLTAGE DIGITAL INPUT	ASCII READ COMMAND	#GVDI<IONR> <CR> Result: #GVDI<IONR>:<IOxDIDec> <CR>	ASCII	
	IONR	1		
	TX	#1,GVDI1<CR>		
	RX	#1,GVDI3:X<CR>		
		Actual voltage digital input state on IO1:X		
This command shows for VOLTAGE DIGITAL INPUT IO <IONR> the current state. The digital input can have the values 0 and 1. All IOs with a different usage type will return X to indicate, that no measurement is done.				
GET VOLTAGE DIGITAL INPUTS CURRENT	ASCII READ COMMAND	#GVDISC<CR> Result: #GVDISC:<IOmA1DbI>,<IOmA2DbI>,...,<IOmA4DbI> <CR>	ASCII	
	TX	#1,GVDISC<CR>		
	RX	#1,GVDISC:999.99,999.99,999.99,999.99<CR>		
		Actual input current on IO1:999.99mA		
		Actual input current on IO2:999.99mA		
		Actual input current on IO3:999.99mA		
		Actual input current on IO4:999.99mA		

This command shows for all VOLTAGE DIGITAL INPUT IOs the actual current in mA.

The measurement range is 0.0mA to 35mA.

All IOs with a different usage type will return 999.99 to indicate, that no measurement is done.

GET VOLTAGE DIGITAL INPUT CURRENT	ASCII READ COMMAND	#GVDIC <IONR> <CR> Result: #GVDIC <IONR>:<IOxmADbl> <CR>	ASCII	
	IONR	1		
	TX	#1,GVDIC1<CR>		
	RX	#1,GVDIC1:999.99<CR>		
		Actual input current on IO1:999.99mA		

This command shows for VOLTAGE DIGITAL INPUT IO <IONR> the actual current in mA.

The measurement range is 0.0mA to 35mA.

All IOs with a different usage type will return 999.99 to indicate, that no measurement is done.

VOLTAGE OUTPUTS

SET VOLTAGE OUTPUTS IN VOLT	ASCII WRITE COMMAND	#SVOSV:<IO1VoltDbl>,<IO2VoltDbl>,<IO3VoltDbl>,<IO4VoltDbl> <CR> Result: #OK<CR>	ASCII	YES
	IO1Volt	10,000		
	IO2Volt	7,500		
	IO3Volt	5,500		
	IO4Volt	2,500		
	TX	#1,SVOSV:10,7.5,5.5,2.5<CR>		
	RX	#1,OK<CR>		

This command sets for all VOLTAGE OUTPUT IOs the current output voltage in Volt.

The range is 0.0 to 11.00V.

SET VOLTAGE OUTPUTx IN VOLT	ASCII WRITE COMMAND	#SVOV<IONR>:<IOxVoltDbl> <CR> Result: #OK<CR>	ASCII	NO
	IONR	1		
	IOxVolt	2,000		
	TX	#1,SVOV1:2<CR>		
	RX	N/A		

This command sets for VOLTAGE OUTPUT IO <IONR> the current output voltage in Volt.

The range is 0.0 to 11.00V.

SET VOLTAGE OUTPUTS IN PERCENT	ASCII WRITE COMMAND	#SVOSP:<IO1PercentDbl>,<IO2PercentDbl>,<IO3PercentDbl>,<IO4PercentDbl> <CR> Result: #OK<CR>	ASCII	NO
	IO1Percent	110,000		
	IO2Percent	100,000		
	IO3Percent	75,000		
	IO4Percent	50,000		
	TX	#1,SVOSP:110,100,75,50<CR>		
	RX	N/A		

This command sets for all VOLTAGE OUTPUT IOs the current output voltage in Percent.

The range is 0.0V -> 0.00% to 11.00V -> 110.00%.

SET VOLTAGE OUTPUTx IN PERCENT	ASCII WRITE COMMAND	#SVOP<IONR>:<IOxPercentDbl> <CR> Result: #OK<CR>	ASCII	NO
	IONR	1		
	IOxPercent	2,000		
	TX	#1,SVOP1:2<CR>		
	RX	N/A		
This command sets for VOLTAGE OUTPUT IO <IONR> the current output voltage in Percent. The range is 0.0V -> 0.00% to 11.00V -> 110.00%.				
GET VOLTAGE OUTPUTS IN VOLT	ASCII READ COMMAND	#GVOSV<CR> Result: #GVOSV:<IO1VoltDbl>,<IO2VoltDbl>,...,<IO4VoltDbl> <CR>	ASCII	
	TX	#1,GVOSV<CR>		
	RX	#1,GVOSV:0.00,0.00,0.00,0.00<CR>		
		Actual voltage output on IO1:0.00V		
		Actual voltage output on IO2:0.00V		
		Actual voltage output on IO3:0.00V		
		Actual voltage output on IO4:0.00V		
This command shows for all VOLTAGE OUTPUT IOs the current output voltage in Volt. The range is 0.0V to 11.00V. All IOs with a different usage type will return 999.99 to indicate, that no measurement is done.				
GET VOLTAGE OUTPUT IN VOLT	ASCII READ COMMAND	#GVOV<IONR> <CR> Result: #GVOV<IONR>:<IOxVoltDbl> <CR>	ASCII	
	IONR	1		
	TX	#1,GVOV1<CR>		
	RX	#1,GVOV3:5.50<CR>		
		Actual voltage output on IO1:5.50V		
This command shows for VOLTAGE OUTPUT IO <IONR> the current output voltage in Volt. The range is 0.0V to 11.00V. All IOs with a different usage type will return 999.99 to indicate, that no measurement is done.				
GET VOLTAGE OUTPUTS IN PERCENT	ASCII READ COMMAND	#GVOSP<CR> Result: #GVOSP:<IO1PercentDbl>,<IO2PercentDbl>,...,<IO4PercentDbl> <CR>	ASCII	
	TX	#1,GVOSP<CR>		
	RX	#1,GVOSP:100.00,75.00,55.00,25.00<CR>		
		Actual percentage voltage output on IO1:100.00%		
		Actual percentage voltage output on IO2:75.00%		
		Actual percentage voltage output on IO3:55.00%		
		Actual percentage voltage output on IO4:25.00%		
This command shows for all VOLTAGE OUTPUT IOs the current output voltage in Percent. The range is 0.0V -> 0.00% to 11.00V -> 110.00% (10.00V -> 100.00%). All IOs with a different usage type will return 999.99 to indicate, that no measurement is done.				
GET VOLTAGE OUTPUT IN PERCENT	ASCII READ COMMAND	#GVOP<IONR> <CR> Result: #GVOP<IONR>:<IOxPercentDbl> <CR>	ASCII	

	IONR	1		
	TX	#1,GVOP1<CR>		
	RX	#1,GVOP3:55.00<CR>		
		Actual percentage voltage output on IO1:55.00%		
This command shows for VOLTAGE OUTPUT IO <IONR> the current output voltage in Percent. The range is 0.0V -> 0.00% to 11.00V -> 110.00% (10.00V -> 100.00%). All IOs with a different usage type will return 999.99 to indicate, that no measurement is done.				
GET VOLTAGE OUTPUTS CURRENT	ASCII READ COMMAND	#GVOSC<CR> Result: #GVOSC:<IOmA1Dbl>,<IOmA2Dbl>,...,<IOmA4Dbl><CR>	ASCII	
	TX	#1,GVOSC<CR>		
	RX	#1,GVOSC:0.00,0.00,0.00,-0.00<CR>		
		Actual output current on IO1:0.00mA		
		Actual output current on IO2:0.00mA		
		Actual output current on IO3:0.00mA		
		Actual output current on IO4:-0.00mA		
This command shows for all VOLTAGE OUTPUT IOs the actual current in mA. The measurement range is 0.0mA to 35mA. All IOs with a different usage type will return 999.99 to indicate, that no measurement is done.				
GET VOLTAGE OUTPUT CURRENT	ASCII READ COMMAND	#GVOC<IONR><CR> Result: #GVOC<IONR>:<IOxmADbl><CR>	ASCII	
	IONR	1		
	TX	#1,GVOC1<CR>		
	RX	#1,GVOC1:0.00<CR>		
		Actual output current on IO1:0.00mA		
This command shows for VOLTAGE OUTPUT IO <IONR> the actual current in mA. The measurement range is 0.0mA to 35mA. All IOs with a different usage type will return 999.99 to indicate, that no measurement is done.				
CURRENT INPUTS				
GET CURRENT INPUTS IN mA	ASCII READ COMMAND	#GCISMA<CR> Result: #GCISMA:<IO1mAADbl>,<IO2mAADbl>,...,<IO4mAADbl><CR>	ASCII	
	TX	#1,GCISMA<CR>		
	RX	#1,GCISMA:999.99,999.99,999.99,999.99<CR>		
		Actual current input on IO1:999.99mA		
		Actual current input on IO2:999.99mA		
		Actual current input on IO3:999.99mA		
		Actual current input on IO4:999.99mA		
This command shows for all CURRENT INPUT IOs the current measured input current in mA. The range is 0.00 to 25.00mA All IOs with a different usage type will return 999.99 to indicate, that no measurement is done.				
GET CURRENT INPUT IN mA	ASCII READ COMMAND	#GCIMA<IONR><CR> Result: #GCIMA<IONR>:<IOxmADbl><CR>	ASCII	
	IONR	1		

	TX	#1,GCIMA1<CR>		
	RX	#1,GCIMA3:999.99<CR>		
		Actual current input on IO1:999.99mA		
This command shows for CURRENT INPUT IO <IONR> the current measured input current in mA. The range is 0.00 to 25.00mA All IOs with a different usage type will return 999.99 to indicate, that no measurement is done.				
GET CURRENT INPUTS IN PERCENT	ASCII READ COMMAND	#GCISP<CR> Result: #GCISP:<IO1PercentDbl>,<IO2PercentDbl>,...,<IO4PercentDbl><CR>	ASCII	
	TX	#1,GCISP<CR>		
	RX	#1,GCISP:999.99,999.99,999.99,999.99<CR>		
		Actual percentage for current input on IO1:999.99%		
		Actual percentage for current input on IO2:999.99%		
		Actual percentage for current input on IO3:999.99%		
		Actual percentage for current input on IO4:999.99%		
This command shows for all CURRENT INPUT IOs the current measured input current in Percent. The range is 0.00mA -> 0.00% to 25.00mA -> 125.00% (20mA=100%) All IOs with a different usage type will return 999.99 to indicate, that no measurement is done.				
GET CURRENT INPUT IN PERCENT	ASCII READ COMMAND	#GCIP<IONR><CR> Result: #GCIP<IONR>:<IOxPercentDbl><CR>	ASCII	
	IONR	1		
	TX	#1,GCIP1<CR>		
	RX	#1,GCIP3:999.99<CR>		
		Actual percentage for current input on IO1:999.99%		
This command shows for CURRENT INPUT IO <IONR> the current measured input current in Percent. The range is 0.00mA -> 0.00% to 25.00mA -> 125.00% (20mA=100%) All IOs with a different usage type will return 999.99 to indicate, that no measurement is done.				
CURRENT OUTPUTS				
SET CURRENT OUTPUTS IN mA	ASCII WRITE COMMAND	#SCOSMA:<IO1mADbl>,<IO2mADbl>,<IO3mADbl>,<IO4mADbl><CR> Result: #OK<CR>	ASCII	NO
	IO1mA	2,000		
	IO2mA	4,000		
	IO3mA	6,000		
	IO4mA	25,000		
	TX	#1,SCOSMA:2,4,6,25<CR>		
	RX	N/A		
This command sets for all CURRENT OUTPUT IOs the actual output current in mA. The range is 0.00mA to 25.00mA				
SET CURRENT OUTPUTx IN mA	ASCII WRITE COMMAND	#SCOMA<IONR>:<IOxmADbl><CR> Result: #OK<CR>	ASCII	NO
	IONR	1		
	IOxVlt	2,000		
	TX	#1,SCOMA1:<IOxmADbl><CR>		

	RX	N/A		
This command sets for CURRENT OUTPUT <IONR> IOs the actual output current in mA. The range is 0.00mA to 25.00mA				
SET CURRENT OUTPUTS IN PERCENT	ASCII WRITE COMMAND	#SCOSP:<IO1PercentDbl>,<IO2PercentDbl>,<IO3PercentDbl>,<IO4PercentDbl> <CR> Result: #OK<CR>	ASCII	NO
	IO1Percent	125,000		
	IO2Percent	100,000		
	IO3Percent	75,000		
	IO4Percent	50,000		
	TX	#1,SCOSP:125,100,75,50<CR>		
	RX	N/A		
This command sets for all CURRENT OUTPUT IOs the new output current in Percent. The range is 0.00mA -> 0.00% to 25.00mA -> 125.00% (20mA -> 100.00%)				
SET CURRENT OUTPUTx IN PERCENT	ASCII WRITE COMMAND	#SCOP<IONR>:<IOxPercentDbl> <CR> Result: #OK<CR>	ASCII	NO
	IONR	1		
	IOxPercent	,000		
	TX	#1,SCOP1:0<CR>		
	RX	N/A		
This command sets for CURRENT OUTPUT IO <IONR> the new output current in Percent. The range is 0.00mA -> 0.00% to 25.00mA -> 125.00% (20mA -> 100.00%)				
GET CURRENT OUTPUTS IN mA	ASCII READ COMMAND	#GCOSMA<CR> Result: #GCOSMA:<IO1mADbl>,<IO2mADbl>,...,<IO4mADbl> <CR>	ASCII	
	TX	#1,GCOSMA<CR>		
	RX	#1,GCOSMA:999.99,999.99,999.99,999.99<CR>		
		Actual value of current output on IO1:999.99mA		
		Actual value of current output on IO2:999.99mA		
		Actual value of current output on IO3:999.99mA		
		Actual value of current output on IO4:999.99mA		
This command shows for all CURRENT OUTPUT IOs the actual output current in mA. The range is 0.00mA to 25.00mA All IOs with a different usage type will return 999.99 to indicate, that no measurement is done.				
GET CURRENT OUTPUT IN mA	ASCII READ COMMAND	#GCOMA<IONR> <CR> Result: #GCOMA<IONR>:<IOxmADbl> <CR>	ASCII	
	IONR	1		
	TX	#1,GCOMA1<CR>		
	RX	#1,GCOMA3:999.99<CR>		
		Actual value of current output on IO1:999.99mA		
This command shows for CURRENT OUTPUT IO <IONR> the actual output current in mA. The range is 0.00mA to 25.00mA All IOs with a different usage type will return 999.99 to indicate, that no measurement is done.				

GET CURRENT OUTPUTS IN PERCENT	ASCII READ COMMAND	#GCOSP<CR> Result: #GCOSP:<IO1PercentDbl>,<IO2PercentDbl>,...,<IO4PercentDbl><CR>	ASCII	
	TX	#1,GCOSP<CR>		
	RX	#1,GCOSP:999.99,999.99,999.99,999.99<CR>		
		Actual percentage of current output on IO1:999.99%		
		Actual percentage of current output on IO2:999.99%		
		Actual percentage of current output on IO3:999.99%		
		Actual percentage of current output on IO4:999.99%		
This command shows for all CURRENT OUTPUT IOs the actual output current in Percent. The range is 0.00mA -> 0.00% to 25.00mA -> 125.00% (20mA -> 100.00%) All IOs with a different usage type will return 999.99 to indicate, that no measurement is done.				
GET CURRENT OUTPUT IN PERCENT	ASCII READ COMMAND	#GCOP<IONR><CR> Result: #GCOP<IONR>:<IOxPercentDbl><CR>	ASCII	
	IONR	1		
	TX	#1,GCOP1<CR>		
	RX	#1,GCOP3:999.99<CR>		
		Actual percentage of current output on IO1:999.99%		
This command shows for CURRENT OUTPUT IO <IONR> the actual output current in Percent. The range is 0.00mA -> 0.00% to 25.00mA -> 125.00% (20mA -> 100.00%) All IOs with a different usage type will return 999.99 to indicate, that no measurement is done.				
GET CURRENT OUTPUTS VOLTAGE	ASCII READ COMMAND	#GCOSV<CR> Result: #GCOSV:<IO1VoltsDbl>,<IO2VoltsDbl>,...,<IO4VoltsDbl><CR>	ASCII	
	TX	#1,GCOSV<CR>		
	RX	#1,GCOSV:999.99,999.99,999.99,999.99<CR>		
		Measured voltage of current output on IO1:999.99V		
		Measured voltage of current output on IO2:999.99V		
		Measured voltage of current output on IO3:999.99V		
		Measured voltage of current output on IO4:999.99V		
This command shows for all CURRENT OUTPUT IOs the actual output voltage in Volt. The range is 0-10V All IOs with a different usage type will return 999.99 to indicate, that no measurement is done.				
GET CURRENT OUTPUT VOLTAGE	ASCII READ COMMAND	#GCOV<IONR><CR> Result: #GCOV<IONR>:<IOxVoltDbl><CR>	ASCII	
	IONR	1		
	TX	#1,GCOV1<CR>		
	RX	#1,GCOV3:999.99<CR>		
		Measured voltage of current output on IO1:999.99V		
This command shows for CURRENT OUTPUT IO <IONR> the actual output voltage in Volt. The range is 0-10V All IOs with a different usage type will return 999.99 to indicate, that no measurement is done.				

RTD INPUTS OHM				
GET RTD INPUTS IN OHM	ASCII READ COMMAND	#GRTDISOHM<CR> Result: #GRTDISOHM:<IO1OhmDbl>,<IO2OhmDbl>,...,<IO4OhmDbl><CR>	ASCII	
	TX	#1,GRTDISOHM<CR>		
	RX	#1,GRTDISOHM:99999999.999,99999999.999,99999999.999,99999999.999<CR>		
		Actual measured RTD input on IO1:99999999.999Ohm		
		Actual measured RTD input on IO2:99999999.999Ohm		
		Actual measured RTD input on IO3:99999999.999Ohm		
		Actual measured RTD input on IO4:99999999.999Ohm		
This command shows for RTD INPUT IOs the actual measured RTD value in Ohm. The range is 0.000Ohm to 1000000.00Ohm All IOs with a different usage type will return 99999999.999 to indicate, that no measurement is done.				
GET RTD INPUT IN OHM	ASCII READ COMMAND	#GRTDIOHM<IONR><CR> Result: #GRTDIOHM<IONR>:<IOxOhmDbl><CR>	ASCII	
	IONR	1		
	TX	#1,GRTDIOHM1<CR>		
	RX	#1,GRTDIOHM3:99999999.999<CR>		
		Actual measured RTD input on IO1:99999999.999Ohm		
This command shows for RTD INPUT IO <IONR> the actual measured RTD value in Ohm. The range is 0.000Ohm to 1000000.00Ohm All IOs with a different usage type will return 99999999.999 to indicate, that no measurement is done.				
GET AVERAGE RTD INPUTS IN OHM	ASCII READ COMMAND	#GAVGRTDISOHM<CR> Result: #GAVGRTDISOHM:<IO1OhmDbl>,<IO2OhmDbl>,...,<IO4OhmDbl><CR>	ASCII	
	TX	#1,GAVGRTDISOHM<CR>		
	RX	#1,GAVGRTDISOHM:99999999.999,99999999.999,99999999.999,99999999.999<CR>		
		Average measured RTD input on IO1:99999999.999Ohm		
		Average measured RTD input on IO2:99999999.999Ohm		
		Average measured RTD input on IO3:99999999.999Ohm		
		Average measured RTD input on IO4:99999999.999Ohm		
This command shows for RTD INPUT IOs the average measured RTD value in Ohm. The range is 0.000Ohm to 1000000.00Ohm All IOs with a different usage type will return 99999999.999 to indicate, that no measurement is done.				
GET AVG RTD INPUT IN OHM	ASCII READ COMMAND	#GAVGRTDIOHM<IONR><CR> Result: #GAVGRTDIOHM<IONR>:<IOxOhmDbl><CR>	ASCII	
	IONR	1		
	TX	#1,GAVGRTDIOHM1<CR>		
	RX	#1,GAVGRTDIOHM3:99999999.999<CR>		
		Average measured RTD input on IO1:99999999.999Ohm		

This command shows for RTD INPUT IO <IONR> the average measured RTD value in Ohm. The range is 0.000Ohm to 1000000.00Ohm All IOs with a different usage type will return 99999999.999 to indicate, that no measurement is done.				
RTD INPUTS PT100 CELSIUS				
GET RTD INPUTS AS PT100 CELSIUS	ASCII READ COMMAND	#GRTDISPT100C <CR> Result: #GRTDISPT100C:<RTD1Dbl>,<RTD2Dbl>,...,<RTD4Dbl> <CR>	ASCII	
	TX	#1,GRTDISPT100C <CR>		
	RX	#1,GRTDISPT100C:9999.990,9999.990,9999.990,9999.990 <CR>		
		Actual measured RTD input as PT100 on IO1:9999.990°C		
		Actual measured RTD input as PT100 on IO2:9999.990°C		
		Actual measured RTD input as PT100 on IO3:9999.990°C		
		Actual measured RTD input as PT100 on IO4:9999.990°C		
This command shows for RTD INPUT IOs the actual measured RTD value linearized as PT100 sensor in °Celsius. -999.990: Temperature is lower than 50°C +999.990: Temperature is higher than 130°C All IOs with a different usage type will return 9999.990 to indicate, that no measurement is done.				
GET RTD INPUT AS PT100 CELSIUS	ASCII READ COMMAND	#GRTDIPT100C <IONR> <CR> Result: #GRTDIPT100C <IONR>:<IOxDbl> <CR>	ASCII	
	IONR	1		
	TX	#1,GRTDIPT100C1 <CR>		
	RX	#1,GRTDIPT100C3:9999.990 <CR>		
		Actual measured RTD input as PT100 on IO1:9999.990°C		
This command shows for RTD INPUT IO <IONR> the actual measured RTD value linearized as PT100 sensor in °Celsius -999.990: Temperature is lower than 50°C +999.990: Temperature is higher than 130°C All IOs with a different usage type will return 9999.990 to indicate, that no measurement is done.				
GET AVERAGE RTD INPUTS AS PT100 CELSIUS	ASCII READ COMMAND	#GAVGRTDISPT100C <CR> Result: #GAVGRTDISPT100C:<RTD1Dbl>,<RTD2Dbl>,...,<RTD4Dbl> <CR>	ASCII	
	TX	#1,GAVGRTDISPT100C <CR>		
	RX	#1,GAVGRTDISPT100C:9999.990,9999.990,9999.990,9999.990 <CR>		
		Average measured RTD input as PT100 on IO1:9999.990°C		
		Average measured RTD input as PT100 on IO2:9999.990°C		
		Average measured RTD input as PT100 on IO3:9999.990°C		
		Average measured RTD input as PT100 on IO4:9999.990°C		
This command shows for RTD INPUT IOs the average measured RTD value linearized as PT100 sensor in °Celsius. -999.990: Temperature is lower than 50°C +999.990: Temperature is higher than 130°C All IOs with a different usage type will return 9999.990 to indicate, that no measurement is done.				
GET AVG RTD INPUT AS PT100 CELSIUS	ASCII READ COMMAND	#GAVGRTDIPT100C <IONR> <CR> Result: #GAVGRTDIPT100C <IONR>:<IOxDbl> <CR>	ASCII	
	IONR	1		

	TX	#1,GAVGRDTIPT100C1<CR>		
	RX	#1,GAVGRDTIPT100C1:9999.990<CR>		
		Average measured RTD input as PT100 on IO1:9999.990°C		
This command shows for RTD INPUT IO <IONR> the average measured RTD value linearized as PT100 sensor in °Celsius -999.990: Temperature is lower than 50°C +999.990: Temperature is higher than 130°C All IOs with a different usage type will return 9999.990 to indicate, that no measurement is done.				
RTD INPUTS PT1000 CELSIUS				
GET RTD INPUTS AS PT1000 CELSIUS	ASCII READ COMMAND	#GRTDISPT1000C<CR> Result: #GRTDISPT1000C:<RTD1Dbl>,<RTD2Dbl>,...,<RTD4Dbl><CR>	ASCII	
	TX	#1,GRTDISPT1000C<CR>		
	RX	#1,GRTDISPT1000C:9999.990,9999.990,9999.990,9999.990<CR>		
		Actual measured RTD input as PT1000 on IO1:9999.990°C		
		Actual measured RTD input as PT1000 on IO2:9999.990°C		
		Actual measured RTD input as PT1000 on IO3:9999.990°C		
		Actual measured RTD input as PT1000 on IO4:9999.990°C		
This command shows for RTD INPUT IOs the actual measured RTD value linearized as PT1000 sensor in °Celsius. -999.990: Temperature is lower than 50°C +999.990: Temperature is higher than 130°C All IOs with a different usage type will return 9999.990 to indicate, that no measurement is done.				
GET RTD INPUT AS PT1000 CELSIUS	ASCII READ COMMAND	#GRTDIPT1000C<IONR><CR> Result: #GRTDIPT1000C<IONR>:<IOxDbl><CR>	ASCII	
	IONR	1		
	TX	#1,GRTDIPT1000C1<CR>		
	RX	#1,GRTDIPT1000C3:9999.990<CR>		
		Actual measured RTD input as PT1000 on IO1:9999.990°C		
This command shows for RTD INPUT IO <IONR> the actual measured RTD value linearized as PT1000 sensor in °Celsius -999.990: Temperature is lower than 50°C +999.990: Temperature is higher than 130°C All IOs with a different usage type will return 9999.990 to indicate, that no measurement is done.				
GET AVERAGE RTD INPUTS AS PT1000 CELSIUS	ASCII READ COMMAND	#GAVGRTDISPT1000C<CR> Result: #GAVGRTDISPT1000C:<RTD1Dbl>,<RTD2Dbl>,...,<RTD4Dbl><CR>	ASCII	
	TX	#1,GAVGRTDISPT1000C<CR>		
	RX	#1,GAVGRTDISPT1000C:9999.990,9999.990,9999.990,9999.990<CR>		
		Average measured RTD input as PT1000 on IO1:9999.990°C		
		Average measured RTD input as PT1000 on IO2:9999.990°C		
		Average measured RTD input as PT1000 on IO3:9999.990°C		
		Average measured RTD input as PT1000 on IO4:9999.990°C		
This command shows for RTD INPUT IOs the average measured RTD value linearized as PT1000 sensor in °Celsius. -999.990: Temperature is lower than 50°C +999.990: Temperature is higher than 130°C All IOs with a different usage type will return 9999.990 to indicate, that no measurement is done.				

GET AVG RTD INPUT AS PT1000 CELSIUS	ASCII READ COMMAND	#GAVGRTDIPT1000C<IONR><CR> Result: #GAVGRTDIPT1000C<IONR>:<IOxDbl><CR>	ASCII	
	IONR	1		
	TX	#1,GAVGRTDIPT1000C1<CR>		
	RX	#1,GAVGRTDIPT1000C1:9999.990<CR>		
		Average measured RTD input as PT1000 on IO1:9999.990°C		
This command shows for RTD INPUT IO <IONR> the average measured RTD value linearized as PT1000 sensor in °Celsius -999.990: Temperature is lower than 50°C +999.990: Temperature is higher than 130°C All IOs with a different usage type will return 9999.990 to indicate, that no measurement is done.				
RTD INPUTS NI1000-DIN43760 CELSIUS				
GET RTD INPUTS AS NI1000 DIN43760 CELSIUS	ASCII READ COMMAND	#GRTDISNI1000DIN43760C<CR> Result: #GRTDISNI1000DIN43760C:<RTD1Dbl>,<RTD2Dbl>,...,<RTD4Dbl><CR>	ASCII	
	TX	#1,GRTDISNI1000DIN43760C<CR>		
	RX	#1,GRTDISNI1000DIN43760C:9999.990,9999.990,9999.990,9999.990<CR>		
		Actual measured RTD input as NI1000-DIN43760 on IO1:9999.990°C		
		Actual measured RTD input as NI1000-DIN43760 on IO2:9999.990°C		
		Actual measured RTD input as NI1000-DIN43760 on IO3:9999.990°C		
		Actual measured RTD input as NI1000-DIN43760 on IO4:9999.990°C		
This command shows for RTD INPUT IOs the actual measured RTD value linearized as NI1000 DIN43760 sensor in °Celsius. -999.990: Temperature is lower than 50°C +999.990: Temperature is higher than 130°C All IOs with a different usage type will return 9999.990 to indicate, that no measurement is done.				
GET RTD INPUT AS NI1000 DIN43760 CELSIUS	ASCII READ COMMAND	#GRTDINI1000DIN43760C<IONR><CR> Result: #GRTDINI1000DIN43760C<IONR>:<IOxDbl><CR>	ASCII	
	IONR	1		
	TX	#1,GRTDINI1000DIN43760C1<CR>		
	RX	#1,GRTDINI1000DIN43760C3:9999.990<CR>		
		Actual measured RTD input as NI1000-DIN43760 on IO1:9999.990°C		
This command shows for RTD INPUT IO <IONR> the actual measured RTD value linearized as NI1000 DIN43760 sensor in °Celsius -999.990: Temperature is lower than 50°C +999.990: Temperature is higher than 130°C All IOs with a different usage type will return 9999.990 to indicate, that no measurement is done.				
GET AVERAGE RTD INPUTS AS NI1000 DIN43760 CELSIUS	ASCII READ COMMAND	#GAVGRTDISNI1000DIN43760C<CR> Result: #GAVGRTDISNI1000DIN43760C:<RTD1Dbl>,<RTD2Dbl>,...,<RTD4Dbl><CR>	ASCII	
	TX	#1,GAVGRTDISNI1000DIN43760C<CR>		
	RX	#1,GAVGRTDISNI1000DIN43760C:9999.990,9999.990,9999.990,9999.990<CR>		
		Average measured RTD input as NI1000-DIN43760 on IO1:9999.990°C		
		Average measured RTD input as NI1000-DIN43760 on IO2:9999.990°C		
		Average measured RTD input as NI1000-DIN43760 on IO3:9999.990°C		

		Average measured RTD input as NI1000-DIN43760 on IO4:9999.990°C		
This command shows for RTD INPUT IOs the average measured RTD value linearized as NI1000 DIN43760 sensor in °Celsius. -999.990: Temperature is lower than 50°C +999.990: Temperature is higher than 130°C All IOs with a different usage type will return 9999.990 to indicate, that no measurement is done.				
GET AVG RTD INPUT AS NI1000 DIN43760 CELSIUS	ASCII READ COMMAND	#GAVGRTDINI1000DIN43760C<IONR><CR> Result: #GAVGRTDINI1000DIN43760C<IONR>:<IOxDbl><CR>	ASCII	
	IONR	1		
	TX	#1,GAVGRTDINI1000DIN43760C1<CR>		
	RX	#1,GAVGRTDINI1000DIN43760C1:9999.990<CR>		
		Average measured RTD input as NI1000-DIN43760 on IO1:9999.990°C		
This command shows for RTD INPUT IO <IONR> the average measured RTD value linearized as NI1000 DIN43760 sensor in °Celsius -999.990: Temperature is lower than 50°C +999.990: Temperature is higher than 130°C All IOs with a different usage type will return 9999.990 to indicate, that no measurement is done.				
RTD INPUTS PT100 KELVIN				
GET RTD INPUTS AS PT100 KELVIN	ASCII READ COMMAND	#GRTDISPT100K<CR> Result: #GRTDISPT100K:<RTD1Dbl>,<RTD2Dbl>,...,<RTD4Dbl><CR>	ASCII	
	TX	#1,GRTDISPT100K<CR>		
	RX	#1,GRTDISPT100K:9999.990,9999.990,9999.990,9999.990<CR>		
		Actual measured RTD input as PT100 on IO1:9999.990°K		
		Actual measured RTD input as PT100 on IO2:9999.990°K		
		Actual measured RTD input as PT100 on IO3:9999.990°K		
		Actual measured RTD input as PT100 on IO4:9999.990°K		
This command shows for RTD INPUT IOs the actual measured RTD value linearized as PT100 sensor in °Kelvin -999.990: Temperature is lower than 223.15°K +999.990: Temperature is higher than 403.15°K All IOs with a different usage type will return 9999.990 to indicate, that no measurement is done.				
GET RTD INPUT AS PT100 KELVIN	ASCII READ COMMAND	#GRTDIPT100K<IONR><CR> Result: #GRTDIPT100K<IONR>:<IOxDbl><CR>	ASCII	
	IONR	1		
	TX	#1,GRTDIPT100K1<CR>		
	RX	#1,GRTDIPT100K3:9999.990<CR>		
		Actual measured RTD input as PT100 on IO1:9999.990°K		
This command shows for RTD INPUT IO <IONR> the actual measured RTD value linearized as PT100 sensor in °Kelvin -999.990: Temperature is lower than 223.15°K +999.990: Temperature is higher than 403.15°K All IOs with a different usage type will return 9999.990 to indicate, that no measurement is done.				
GET AVERAGE RTD INPUTS AS PT100 KELVIN	ASCII READ COMMAND	#GAVGRTDISPT100K<CR> Result: #GAVGRTDISPT100K:<RTD1Dbl>,<RTD2Dbl>,...,<RTD4Dbl><CR>	ASCII	
	TX	#1,GAVGRTDISPT100K<CR>		

	RX	#1,GAVGRDISPT100K:9999.990,9999.990,9999.990,9999.990<CR>		
		Average measured RTD input as PT100 on IO1:9999.990°K		
		Average measured RTD input as PT100 on IO2:9999.990°K		
		Average measured RTD input as PT100 on IO3:9999.990°K		
		Average measured RTD input as PT100 on IO4:9999.990°K		
This command shows for RTD INPUT IOs the average measured RTD value linearized as PT100 sensor in °Kelvin -999.990: Temperature is lower than 223.15°K +999.990: Temperature is higher than 403.15°K All IOs with a different usage type will return 9999.990 to indicate, that no measurement is done.				
GET AVG RTD INPUT AS PT100 KELVIN	ASCII READ COMMAND	#GAVGRTDIPT100K<IONR> <CR> Result: #GAVGRTDIPT100K<IONR>:<IOxDbl> <CR>	ASCII	
	IONR	1		
	TX	#1,GAVGRTDIPT100K1<CR>		
	RX	#1,GAVGRTDIPT100K1:9999.990<CR>		
		Average measured RTD input as PT100 on IO1:9999.990°K		
This command shows for RTD INPUT IO <IONR> the average measured RTD value linearized as PT100 sensor in °Kelvin -999.990: Temperature is lower than 223.15°K +999.990: Temperature is higher than 403.15°K All IOs with a different usage type will return 9999.990 to indicate, that no measurement is done.				
RTD INPUTS PT1000 KELVIN				
GET RTD INPUTS AS PT1000 KELVIN	ASCII READ COMMAND	#GRTDISPT1000K<CR> Result: #GRTDISPT1000K:<RTD1Dbl>,<RTD2Dbl>,...,<RTD4Dbl> <CR>	ASCII	
	TX	#1,GRTDISPT1000K<CR>		
	RX	#1,GRTDISPT1000K:9999.990,9999.990,9999.990,9999.990<CR>		
		Actual measured RTD input as PT1000 on IO1:9999.990°K		
		Actual measured RTD input as PT1000 on IO2:9999.990°K		
		Actual measured RTD input as PT1000 on IO3:9999.990°K		
		Actual measured RTD input as PT1000 on IO4:9999.990°K		
This command shows for RTD INPUT IOs the actual measured RTD value linearized as PT1000 sensor in °Kelvin -999.990: Temperature is lower than 223.15°K +999.990: Temperature is higher than 403.15°K All IOs with a different usage type will return 9999.990 to indicate, that no measurement is done.				
GET RTD INPUT AS PT1000 KELVIN	ASCII READ COMMAND	#GRTDIPT1000K<IONR> <CR> Result: #GRTDIPT1000K<IONR>:<IOxDbl> <CR>	ASCII	
	IONR	1		
	TX	#1,GRTDIPT1000K1<CR>		
	RX	#1,GRTDIPT1000K3:9999.990<CR>		
		Actual measured RTD input as PT1000 on IO1:9999.990°K		
This command shows for RTD INPUT IO <IONR> the actual measured RTD value linearized as PT1000 sensor in °Kelvin -999.990: Temperature is lower than 223.15°K +999.990: Temperature is higher than 403.15°K All IOs with a different usage type will return 9999.990 to indicate, that no measurement is done.				

GET AVERAGE RTD INPUTS AS PT1000 KELVIN	ASCII READ COMMAND	#GAVGRTDISPT1000K<CR> Result: #GAVGRTDISPT1000K:<RTD1Dbl>,<RTD2Dbl>,...,<RTD4Dbl><CR>	ASCII	
	TX	#1,GAVGRTDISPT1000K<CR>		
	RX	#1,GAVGRTDISPT1000K:9999.990,9999.990,9999.990,9999.990<CR>		
		Average measured RTD input as PT1000 on IO1:9999.990°K		
		Average measured RTD input as PT1000 on IO2:9999.990°K		
		Average measured RTD input as PT1000 on IO3:9999.990°K		
		Average measured RTD input as PT1000 on IO4:9999.990°K		

This command shows for RTD INPUT IOs the average measured RTD value linearized as PT1000 sensor in °Kelvin

-999.990: Temperature is lower than 223.15°K

+999.990: Temperature is higher than 403.15°K

All IOs with a different usage type will return 9999.990 to indicate, that no measurement is done.

GET AVG RTD INPUT AS PT1000 KELVIN	ASCII READ COMMAND	#GAVGRTDIPT1000K<IONR><CR> Result: #GAVGRTDIPT1000K<IONR>:<IOxDbl><CR>	ASCII	
	IONR	1		
	TX	#1,GAVGRTDIPT1000K1<CR>		
	RX	#1,GAVGRTDIPT1000K1:9999.990<CR>		
		Average measured RTD input as PT1000 on IO1:9999.990°K		

This command shows for RTD INPUT IO <IONR> the average measured RTD value linearized as PT1000 sensor in °Kelvin

-999.990: Temperature is lower than 223.15°K

+999.990: Temperature is higher than 403.15°K

All IOs with a different usage type will return 9999.990 to indicate, that no measurement is done.

RTD INPUTS NI1000-DIN43760 KELVIN

GET RTD INPUTS AS NI1000 DIN43760 KELVIN	ASCII READ COMMAND	#GRTDISNI1000DIN43760K<CR> Result: #GRTDISNI1000DIN43760K:<RTD1Dbl>,<RTD2Dbl>,...,<RTD4Dbl><CR>	ASCII	
	TX	#1,GRTDISNI1000DIN43760K<CR>		
	RX	#1,GRTDISNI1000DIN43760K:9999.990,9999.990,9999.990,9999.990<CR>		
		Actual measured RTD input as NI1000-DIN43760 on IO1:9999.990°K		
		Actual measured RTD input as NI1000-DIN43760 on IO2:9999.990°K		
		Actual measured RTD input as NI1000-DIN43760 on IO3:9999.990°K		
		Actual measured RTD input as NI1000-DIN43760 on IO4:9999.990°K		

This command shows for RTD INPUT IOs the actual measured RTD value linearized as NI1000 DIN43760 sensor in °Kelvin

-999.990: Temperature is lower than 223.15°K

+999.990: Temperature is higher than 403.15°K

All IOs with a different usage type will return 9999.990 to indicate, that no measurement is done.

GET RTD INPUT AS NI1000 DIN43760 KELVIN	ASCII READ COMMAND	#GRTDINI1000DIN43760K<IONR><CR> Result: #GRTDINI1000DIN43760K<IONR>:<IOxDbl><CR>	ASCII	
	IONR	1		
	TX	#1,GRTDINI1000DIN43760K1<CR>		
	RX	#1,GRTDINI1000DIN43760K3:9999.990<CR>		

		Actual measured RTD input as NI1000-DIN43760 on IO1:9999.990°K		
This command shows for RTD INPUT IO <IONR> the actual measured RTD value linearized as NI1000 DIN43760 sensor in °Kelvin -999.990: Temperature is lower than 223.15°K +999.990: Temperature is higher than 403.15°K All IOs with a different usage type will return 9999.990 to indicate, that no measurement is done.				
GET AVERAGE RTD INPUTS AS NI1000 DIN43760 KELVIN	ASCII READ COMMAND	#GAVGRTDISNI1000DIN43760K<CR> Result: #GAVGRTDISNI1000DIN43760K:<RTD1DbI>,<RTD2DbI>,...,<RTD4DbI> <CR>	ASCII	
	TX	#1,GAVGRTDISNI1000DIN43760K<CR>		
	RX	#1,GAVGRTDISNI1000DIN43760K:9999.990,9999.990,9999.990,9999.990<CR>		
		Average measured RTD input as NI1000-DIN43760 on IO1:9999.990°K		
		Average measured RTD input as NI1000-DIN43760 on IO2:9999.990°K		
		Average measured RTD input as NI1000-DIN43760 on IO3:9999.990°K		
		Average measured RTD input as NI1000-DIN43760 on IO4:9999.990°K		
This command shows for RTD INPUT IOs the average measured RTD value linearized as NI1000 DIN43760 sensor in °Kelvin -999.990: Temperature is lower than 223.15°K +999.990: Temperature is higher than 403.15°K All IOs with a different usage type will return 9999.990 to indicate, that no measurement is done.				
GET AVG RTD INPUT AS NI1000 DIN43760 KELVIN	ASCII READ COMMAND	#GAVGRTDINI1000DIN43760K<IONR> <CR> Result: #GAVGRTDINI1000DIN43760K<IONR>:<IOxDbI> <CR>	ASCII	
	IONR	1		
	TX	#1,GAVGRTDINI1000DIN43760K1<CR>		
	RX	#1,GAVGRTDINI1000DIN43760K1:9999.990<CR>		
		Average measured RTD input as NI1000-DIN43760 on IO1:9999.990°K		
This command shows for RTD INPUT IO <IONR> the average measured RTD value linearized as NI1000 DIN43760 sensor in °Kelvin -999.990: Temperature is lower than 223.15°K +999.990: Temperature is higher than 403.15°K All IOs with a different usage type will return 9999.990 to indicate, that no measurement is done.				
RTD INPUTS PT100 FAHRENHEIT				
GET RTD INPUTS AS PT100 FAHRENHEIT	ASCII READ COMMAND	#GRTDISPT100F<CR> Result: #GRTDISPT100F:<RTD1DbI>,<RTD2DbI>,...,<RTD4DbI> <CR>	ASCII	
	TX	#1,GRTDISPT100F<CR>		
	RX	#1,GRTDISPT100F:9999.990,9999.990,9999.990,9999.990<CR>		
		Actual measured RTD input as PT100 on IO1:9999.990°F		
		Actual measured RTD input as PT100 on IO2:9999.990°F		
		Actual measured RTD input as PT100 on IO3:9999.990°F		
		Actual measured RTD input as PT100 on IO4:9999.990°F		
This command shows for RTD INPUT IOs the actual measured RTD value linearized as PT100 sensor in °Fahrenheit -999.990: Temperature is lower than -58°F +999.990: Temperature is higher than 266°F All IOs with a different usage type will return 9999.990 to indicate, that no measurement is done.				

GET RTD INPUT AS PT100 FAHRENHEIT	ASCII READ COMMAND	#GRTDIPT100F<IONR> <CR> Result: #GRTDIPT100F<IONR>:<IOxDbl> <CR>	ASCII	
	IONR	1		
	TX	#1,GRTDIPT100F1<CR>		
	RX	#1,GRTDIPT100F3:9999.990<CR>		
		Actual measured RTD input as PT100 on IO1:9999.990°F		
This command shows for RTD INPUT IO <IONR> the actual measured RTD value linearized as PT100 sensor in °Fahrenheit -999.990: Temperature is lower than -58°F +999.990: Temperature is higher than 266°F All IOs with a different usage type will return 9999.990 to indicate, that no measurement is done.				
GET AVERAGE RTD INPUTS AS PT100 FAHRENHEIT	ASCII READ COMMAND	#GAVGRTDISPT100F<CR> Result: #GAVGRTDISPT100F:<RTD1Dbl>,<RTD2Dbl>,...,<RTD4Dbl> <CR>	ASCII	
	TX	#1,GAVGRTDISPT100F<CR>		
	RX	#1,GAVGRTDISPT100F:9999.990,9999.990,9999.990,9999.990<CR>		
		Average measured RTD input as PT100 on IO1:9999.990°F		
		Average measured RTD input as PT100 on IO2:9999.990°F		
		Average measured RTD input as PT100 on IO3:9999.990°F		
		Average measured RTD input as PT100 on IO4:9999.990°F		
This command shows for RTD INPUT IOs the average measured RTD value linearized as PT100 sensor in °Fahrenheit -999.990: Temperature is lower than -58°F +999.990: Temperature is higher than 266°F All IOs with a different usage type will return 9999.990 to indicate, that no measurement is done.				
GET AVG RTD INPUT AS PT100 FAHRENHEIT	ASCII READ COMMAND	#GAVGRTDIPT100F<IONR> <CR> Result: #GAVGRTDIPT100F<IONR>:<IOxDbl> <CR>	ASCII	
	IONR	1		
	TX	#1,GAVGRTDIPT100F1<CR>		
	RX	#1,GAVGRTDIPT100F1:9999.990<CR>		
		Average measured RTD input as PT100 on IO1:9999.990°F		
This command shows for RTD INPUT IO <IONR> the average measured RTD value linearized as PT100 sensor in °Fahrenheit -999.990: Temperature is lower than -58°F +999.990: Temperature is higher than 266°F All IOs with a different usage type will return 9999.990 to indicate, that no measurement is done.				
RTD INPUTS PT1000 FAHRENHEIT				
GET RTD INPUTS AS PT1000 FAHRENHEIT	ASCII READ COMMAND	#GRTDISPT1000F<CR> Result: #GRTDISPT1000F:<RTD1Dbl>,<RTD2Dbl>,...,<RTD4Dbl> <CR>	ASCII	
	TX	#1,GRTDISPT1000F<CR>		
	RX	#1,GRTDISPT1000F:9999.990,9999.990,9999.990,9999.990<CR>		
		Actual measured RTD input as PT1000 on IO1:9999.990°F		
		Actual measured RTD input as PT1000 on IO2:9999.990°F		
		Actual measured RTD input as PT1000 on IO3:9999.990°F		

		Actual measured RTD input as PT1000 on IO4:9999.990°F		
This command shows for RTD INPUT IOs the actual measured RTD value linearized as PT1000 sensor in °Fahrenheit -999.990: Temperature is lower than -58°F +999.990: Temperature is higher than 266°F All IOs with a different usage type will return 9999.990 to indicate, that no measurement is done.				
GET RTD INPUT AS PT1000 FAHRENHEIT	ASCII READ COMMAND	#GRTDIPT1000F<IONR> <CR> Result: #GRTDIPT1000F<IONR>:<IOxDbl> <CR>	ASCII	
	IONR	1		
	TX	#1,GRTDIPT1000F1<CR>		
	RX	#1,GRTDIPT1000F3:9999.990<CR>		
		Actual measured RTD input as PT1000 on IO1:9999.990°F		
This command shows for RTD INPUT IO <IONR> the actual measured RTD value linearized as PT1000 sensor in °Fahrenheit -999.990: Temperature is lower than -58°F +999.990: Temperature is higher than 266°F All IOs with a different usage type will return 9999.990 to indicate, that no measurement is done.				
GET AVERAGE RTD INPUTS AS PT1000 FAHRENHEIT	ASCII READ COMMAND	#GAVGRTDISPT1000F<CR> Result: #GAVGRTDISPT1000F:<RTD1Dbl>,<RTD2Dbl>,...,<RTD4Dbl> <CR>	ASCII	
	TX	#1,GAVGRTDISPT1000F<CR>		
	RX	#1,GAVGRTDISPT1000F:9999.990,9999.990,9999.990,9999.990<CR>		
		Average measured RTD input as PT1000 on IO1:9999.990°F		
		Average measured RTD input as PT1000 on IO2:9999.990°F		
		Average measured RTD input as PT1000 on IO3:9999.990°F		
		Average measured RTD input as PT1000 on IO4:9999.990°F		
This command shows for RTD INPUT IOs the average measured RTD value linearized as PT1000 sensor in °Fahrenheit -999.990: Temperature is lower than -58°F +999.990: Temperature is higher than 266°F All IOs with a different usage type will return 9999.990 to indicate, that no measurement is done.				
GET AVG RTD INPUT AS PT1000 FAHRENHEIT	ASCII READ COMMAND	#GAVGRTDIPT1000F<IONR> <CR> Result: #GAVGRTDIPT1000F<IONR>:<IOxDbl> <CR>	ASCII	
	IONR	1		
	TX	#1,GAVGRTDIPT1000F1<CR>		
	RX	#1,GAVGRTDIPT1000F1:9999.990<CR>		
		Average measured RTD input as PT1000 on IO1:9999.990°F		
This command shows for RTD INPUT IO <IONR> the average measured RTD value linearized as PT1000 sensor in °Fahrenheit -999.990: Temperature is lower than -58°F +999.990: Temperature is higher than 266°F All IOs with a different usage type will return 9999.990 to indicate, that no measurement is done.				
RTD INPUTS NI1000-DIN43760 FAHRENHEIT				
GET RTD INPUTS AS NI1000 DIN43760 FAHRENHEIT	ASCII READ COMMAND	#GRTDISNI1000DIN43760F<CR> Result: #GRTDISNI1000DIN43760F:<RTD1Dbl>,<RTD2Dbl>,...,<RTD4Dbl> <CR>	ASCII	
	TX	#1,GRTDISNI1000DIN43760F<CR>		

	RX	#1,GRTDISNI1000DIN43760F:9999.990,9999.990,9999.990,9999.990<CR>		
		Actual measured RTD input as NI1000-DIN43760 on IO1:9999.990°F		
		Actual measured RTD input as NI1000-DIN43760 on IO2:9999.990°F		
		Actual measured RTD input as NI1000-DIN43760 on IO3:9999.990°F		
		Actual measured RTD input as NI1000-DIN43760 on IO4:9999.990°F		
This command shows for RTD INPUT IOs the actual measured RTD value linearized as NI1000 DIN43760 sensor in °Fahrenheit -999.990: Temperature is lower than -58°F +999.990: Temperature is higher than 266°F All IOs with a different usage type will return 9999.990 to indicate, that no measurement is done.				
GET RTD INPUT AS NI1000 DIN43760 FARENEHEIT	ASCII READ COMMAND	#GRTDINI1000DIN43760F<IONR><CR> Result: #GRTDINI1000DIN43760F<IONR>:<IOxDbl><CR>	ASCII	
	IONR	1		
	TX	#1,GRTDINI1000DIN43760F1<CR>		
	RX	#1,GRTDINI1000DIN43760F3:9999.990<CR>		
		Actual measured RTD input as NI1000-DIN43760 on IO1:9999.990°F		
This command shows for RTD INPUT IO <IONR> the actual measured RTD value linearized as NI1000 DIN43760 sensor in °Fahrenheit -999.990: Temperature is lower than -58°F +999.990: Temperature is higher than 266°F All IOs with a different usage type will return 9999.990 to indicate, that no measurement is done.				
GET AVERAGE RTD INPUTS AS NI1000 DIN43760 FARENEHEIT	ASCII READ COMMAND	#GAVGRTDISNI1000DIN43760F<CR> Result: #GAVGRTDISNI1000DIN43760F:<RTD1Dbl>,<RTD2Dbl>,...,<RTD4Dbl><CR>	ASCII	
	TX	#1,GAVGRTDISNI1000DIN43760F<CR>		
	RX	#1,GAVGRTDISNI1000DIN43760F:9999.990,9999.990,9999.990,9999.990<CR>		
		Average measured RTD input as NI1000-DIN43760 on IO1:9999.990°F		
		Average measured RTD input as NI1000-DIN43760 on IO2:9999.990°F		
		Average measured RTD input as NI1000-DIN43760 on IO3:9999.990°F		
		Average measured RTD input as NI1000-DIN43760 on IO4:9999.990°F		
This command shows for RTD INPUT IOs the average measured RTD value linearized as NI1000 DIN43760 sensor in °Fahrenheit -999.990: Temperature is lower than -58°F +999.990: Temperature is higher than 266°F All IOs with a different usage type will return 9999.990 to indicate, that no measurement is done.				
GET AVG RTD INPUT AS NI1000 DIN43760 FARENEHEIT	ASCII READ COMMAND	#GAVGRTDINI1000DIN43760F<IONR><CR> Result: #GAVGRTDINI1000DIN43760F<IONR>:<IOxDbl><CR>	ASCII	
	IONR	1		
	TX	#1,GAVGRTDINI1000DIN43760F1<CR>		
	RX	#1,GAVGRTDINI1000DIN43760F1:9999.990<CR>		
		Average measured RTD input as NI1000-DIN43760 on IO1:9999.990°F		
This command shows for RTD INPUT IO <IONR> the average measured RTD value linearized as NI1000 DIN43760 sensor in °Fahrenheit -999.990: Temperature is lower than -58°F +999.990: Temperature is higher than 266°F All IOs with a different usage type will return 9999.990 to indicate, that no measurement is done.				

Register NAME Command NAME	MODBUS Register ASCII Command	Register VALUE ASCII Command	NEW REAL VALUE	NEW VALUE	DATA TYPE	DO WRITE
ASCII COMMANDS						
INTER PROCESSOR COMMUNICATION						
AIOX IS ONLINE	ASCII READ COMMAND	#G16AIOXISONLINE<CR> Result: #G16AIOXISONLINE:<YesNo> <CR>			ASCII	
	TX	#1,G16AIOXISONLINE<CR>				
	RX	#1,G16AIOXISONLINE:YES<CR>				
		Actual communication state co-processor to AIOX processor:YES				
This command returns the actual state of the serial communication between the ARM co-processor and the additional processor for the AIOX. YES: Currently the communication is fine NO: There is a mayor problem/hardware fault between the two processors						
CHIP COMMUNICATION						
ARE CHIPS ONLINE	ASCII READ COMMAND	#ARECHIPSONLINE<CR> Result: #ARECHIPSONLINE:<Chip1IsOnline> <CR>			ASCII	
	TX	#1,ARECHIPSONLINE<CR>				
	RX	#1,ARECHIPSONLINE:1<CR>				
		Actual state of CHIP1:1				
This command shows the current SPI communication status with each chip. ChipxIsOnline: =0: Currently there is a SPI error in the communication and the chip is offline =1: The SPI communication with the chip is ok						
IS CHIPx ONLINE	ASCII READ COMMAND	#ISCHIPONLINE<CHIPNR> <CR> Result: #ISCHIPONLINE<CHIPNR>:<ChipxIsOnline> <CR>			ASCII	
	CHIPNR	1				
	TX	#1,ISCHIPONLINE1<CR>				
	RX	#1,ISCHIPONLINE1:1<CR>				
		Actual state of CHIP1:1				
This command shows the current SPI communication status with chip <CHIPNR>. =0: Currently there is a SPI error in the communication and the chip is offline =1: The SPI communication with the chip is ok						
GET ALL SPI ERRORS	ASCII READ COMMAND	#GASPIERRS<CR> Result: #GASPIERRS:<SPI1ErrDec>,<SPI1ErrHex> <CR>			ASCII	
	TX	#1,GASPIERRS<CR>				
	RX	#1,GASPIERRS:0,0x0<CR>				
		Actual SPI errors of CHIP1:0				
This command shows the acutal SPI errors since power up for every chip						

GET SPI ERROR	ASCII READ COMMAND	#GSPERR<CHIPNR> <CR> Result: #GSPERR<CHIPNR>:<SPlexErrDec>,<SPlexErrHex> <CR>	ASCII	
	CHIPNR	1		
	TX	#1,GSPERR1<CR>		
	RX	#1,GSPERR1:0,0x0<CR>		
		Actual SPI errors of CHIP1:0		
This command shows the acutal SPI errors since power up for chip <CHIPNR>				
GET CHIP STATEMACHINES	ASCII READ COMMAND	#GCHIPSMS<CR> Result: #GCHIPSMS:<Chip1StateMachine> <CR>	ASCII	
	TX	#1,GCHIPSMS<CR>		
	RX	#1,GCHIPSMS:12090<CR>		
		Actual state of CHIP1:12090		
This command shows the acutal state of the internal communication state machine for all chips				
GET CHIP STATEMACHINE	ASCII READ COMMAND	#GCHIPSM<CHIPNR> <CR> Result: #GCHIPSM<CHIPNR>:<ChipxStateMachine> <CR>	ASCII	
	CHIPNR	1		
	TX	#1,GCHIPSM1<CR>		
	RX	#1,GCHIPSM1:12010<CR>		
		Actual state of CHIP1:12010		
This command shows the acutal state of the internal communication state machine for chip <CHIPNR>				
RESET CHIP STATEMACHINE	ASCII WRITE COMMAND	#RCHIPSM<CHIPNR> <CR> Result: #OK<CR>	ASCII	YES
	CHIPNR	1		
	TX	#1,RCHIPSM1<CR>		
	RX	N/A		
This command restarts the state machine for chip <CHIPNR>. The affected chip will be resetted & initialized completely				
CHIP STATUS				
GET ALL LIVE STATES	ASCII READ COMMAND	#GALSTATES<CR> Result: #GALSTATE:<Chip1LiveStateDec>,<Chip1LiveStateHex> <CR>	ASCII	
	TX	#1,GALSTATES<CR>		
	RX	#1,GALSTATES:27648,0x6C00<CR>		
		Actual live state of CHIP1:27648,0x6C00		

Returns the actual chip status of all chips.
Each result bit stands for a different state:
Bit 0: VI_ERR_CURR_A: Status of channel A:Voltage or current error detected on Channel A. This bit is interpreted differently depending on which of the following IO function selected:
Voltage output: short-circuit error. The error condition is debounced for 2 ms before the status bit is set.
Current output: open circuit error. The error condition is debounced for 2 ms before the status bit is set.
Current input, loop powered: short-circuit error. A short to ground is detected
Current input, externally powered: short-circuit error. A current source >25 mA is detected
Bit 1: VI_ERR_CURR_B: Status of voltage input B. Same like VI_ERR_CURR_A
Bit 2: VI_ERR_CURR_C: Status of voltage input C. Same like VI_ERR_CURR_A
Bit 3: VI_ERR_CURR_D: Status of voltage input D. Same like VI_ERR_CURR_A
Bit 4: HI_TEMP_STATUS: If the die temperature is typically at or above 115°C, the HI_TEMP_STATUS bit is asserted
Bit 5: CHARGE_PUMP_STATUS: Charge pump error detected.
Bit 6: ALDO5V_STATUS: ALDO5V Power Supply Monitor Error. This bit is asserted when the ALDO5V pin falls below 4.05 V. Usually ~5V.
Bit 7: AVDD_STATUS: AVDD Power Supply Monitor Error. This bit is asserted when the AVDD pin falls below 9.26 V. Usually ~17V.
Bit 8: DVCC_STATUS: DVCC Power Supply Monitor Error. This bit is asserted when the DVCC pin falls below 1.93 V. Usually ~3.3V.
Bit 9: ALDO1V8_STATUS: ALDO1V8 Power Supply Monitor Error. This bit is asserted when the ALDO1V8 pin falls below 1.35 V. Usually ~1.8V.
Bit 10-12: ADC_CH_CURR: Current converted channel of the ADC (0:A, 1:B, 2:C, 3:D, 4:Diagnostic 0, 5:Diagnostic 1, 6:Diagnostic 2, 7:Diagnostic 3)
Bit 13: ADC_BUSY: ADC busy status bit.
Bit 14: ADC_DATA_RDY:ADC data ready. The ADC_DATA_RDY bit asserts when a conversion cycle has completed. The bit stays asserted until a user writes 1 to clear the bit. In single conversion mode, the ADC_RDY pin follows the ADC_DATA_RDY bit and only deasserts when the ADC_DATA_RDY bit is cleared. In continuous conversion mode, the ADC_RDY pin returns high after 24 µs.
Bit 15: RESERVED: Reserved

GET LIVE STATE	ASCII	#GLSTATE<CHIPNR> <CR>	ASCII	
	READ	Result:		
	COMMAND	#GLSTATE<CHIPNR>:<ChipxLiveStateDec>,<ChipxLiveStateHex> <CR>		
	CHIPNR	1		
	TX	#1,GLSTATE1<CR>		
	RX	#1,GLSTATE4:29696,0x7400<CR>		
		Actual live state of CHIP1:29696,0x7400		
		Live state bit 0: VI_ERR_CURR_A:0		
		Live state bit 1: VI_ERR_CURR_B:0		
		Live state bit 2: VI_ERR_CURR_C:0		
		Live state bit 3: VI_ERR_CURR_D:0		
		Live state bit 4: HI_TEMP_STATUS:0		
		Live state bit 5: CHARGE_PUMP_STATUS:0		
		Live state bit 6: ALDO5V_STATUS:0		
		Live state bit 7: AVDD_STATUS:0		
		Live state bit 8: DVCC_STATUS:0		
		Live state bit 9: ALDO1V8_STATUS:0		
		Live state bit 10-12: ADC_CH_CURR:5		
		Live state bit 13: ADC_BUSY:1		
		Live state bit 14: ADC_DATA_RDY:0		
		Live state bit 15: RESERVED:0		

Returns the actual chip status of chip <CHIPNR> Each result bit stands for a different state: Bit 0: VI_ERR_CURR_A: Status of channel A:Voltage or current error detected on Channel A. This bit is interpreted differently depending on which of the following IO function selected: Voltage output: short-circuit error. The error condition is debounced for 2 ms before the status bit is set. Current output: open circuit error. The error condition is debounced for 2 ms before the status bit is set. Current input, loop powered: short-circuit error. A short to ground is detected Current input, externally powered: short-circuit error. A current source >25 mA is detected Bit 1: VI_ERR_CURR_B: Status of voltage input B. Same like VI_ERR_CURR_A Bit 2: VI_ERR_CURR_C: Status of voltage input C. Same like VI_ERR_CURR_A Bit 3: VI_ERR_CURR_D: Status of voltage input D. Same like VI_ERR_CURR_A Bit 4: HI_TEMP_STATUS: If the die temperature is typically at or above 115°C, the HI_TEMP_STATUS bit is asserted Bit 5: CHARGE_PUMP_STATUS: Charge pump error detected. Bit 6: ALDO5V_STATUS: ALDO5V Power Supply Monitor Error. This bit is asserted when the ALDO5V pin falls below 4.05 V. Usually ~5V. Bit 7: AVDD_STATUS: AVDD Power Supply Monitor Error. This bit is asserted when the AVDD pin falls below 9.26 V. Usually ~17V. Bit 8: DVCC_STATUS: DVCC Power Supply Monitor Error. This bit is asserted when the DVCC pin falls below 1.93 V. Usually ~3.3V. Bit 9: ALDO1V8_STATUS: ALDO1V8 Power Supply Monitor Error. This bit is asserted when the ALDO1V8 pin falls below 1.35 V. Usually ~1.8V. Bit 10-12: ADC_CH_CURR: Current converted channel of the ADC (0:A, 1:B, 2:C, 3:D, 4:Diagnostic 0, 5:Diagnostic 1, 6:Diagnostic 2, 7:Diagnostic 3) Bit 13: ADC_BUSY: ADC busy status bit. Bit 14: ADC_DATA_RDY:ADC data ready. The ADC_DATA_RDY bit asserts when a conversion cycle has completed. The bit stays asserted until a user writes 1 to clear the bit. In single conversion mode, the ADC_RDY pin follows the ADC_DATA_RDY bit and only deasserts when the ADC_DATA_RDY bit is cleared. In continuous conversion mode, the ADC_RDY pin returns high after 24 µs. Bit 15: RESERVED: Reserved				
GET ALL ALERT STATES	ASCII READ COMMAND	#GAASTATES<CR> Result: #GAASTATES:<Chip1AlertStateDec>,<Chip1AlertStateHex><CR>	ASCII	
	TX	#1,GAASTATES<CR>		
	RX	#1,GAASTATES:33792,0x8400<CR>		
		Actual alert state of CHIP1:33792,0x8400		
Returns the actual alert states for all chips. Each result bit stands for a different state: Bit 0: VI_ERR_CURR_A: Status of channel A:Voltage or current error detected on Channel A. This bit is interpreted differently depending on which of the following IO function selected: Voltage output: short-circuit error. The error condition is debounced for 2 ms before the status bit is set. Current output: open circuit error. The error condition is debounced for 2 ms before the status bit is set. Current input, loop powered: short-circuit error. A short to ground is detected Current input, externally powered: short-circuit error. A current source >25 mA is detected Bit 1: VI_ERR_CURR_B: Status of voltage input B. Same like VI_ERR_CURR_A Bit 2: VI_ERR_CURR_C: Status of voltage input C. Same like VI_ERR_CURR_A Bit 3: VI_ERR_CURR_D: Status of voltage input D. Same like VI_ERR_CURR_A Bit 4: HI_TEMP_STATUS: If the die temperature is typically at or above 115°C, the HI_TEMP_STATUS bit is asserted Bit 5: CHARGE_PUMP_STATUS: Charge pump error detected. Bit 6: ALDO5V_STATUS: ALDO5V Power Supply Monitor Error. This bit is asserted when the ALDO5V pin falls below 4.05 V. Usually ~5V. Bit 7: AVDD_STATUS: AVDD Power Supply Monitor Error. This bit is asserted when the AVDD pin falls below 9.26 V. Usually ~17V. Bit 8: DVCC_STATUS: DVCC Power Supply Monitor Error. This bit is asserted when the DVCC pin falls below 1.93 V. Usually ~3.3V. Bit 9: ALDO1V8_STATUS: ALDO1V8 Power Supply Monitor Error. This bit is asserted when the ALDO1V8 pin falls below 1.35 V. Usually ~1.8V. Bit 10: ADC_CONV_ERR: ADC Conversion Error. ADC results may be outside the selected measurement range. Bit 11: ADC_SAT_ERR: ADC Saturation Error. ADC may be outside the user selected measurement range. Bit 12: SPI_SCLK_CNT_ERR: SPI SCLK count error detected. This bit is asserted if an SPI command is applied but 32 SCLKs are not provided. Bit 13: SPI_CRC_ERR: SPI CRC error detected. This bit is asserted if an invalid CRC is received. Bit 14: CAL_MEM_ERR: Calibration Memory Error. This flag asserts under the following two conditions: When a calibration memory CRC error or an uncorrectable error correcting code (ECC) error is detected on the calibration memory upload. It is not possible to clear this bit if there is a CRC error or uncorrectable ECC error. It is recommended to reset the device and check the supplies in this situation. When there is an attempted SPI access to a register before the calibration memory refresh is complete. Do not address the device until the calibration memory is refreshed. Writing 1 to this bit clears the flag, if the flag is asserted due to this condition. Bit 15: RESET_OCCURRED: Reset occurred. This bit is asserted after a reset event, which asserts the ALERT pin after the reset. Write a 1 to this bit to clear the flag. Note that a mask bit is not provided for this bit.				

GET ALERT STATE	ASCII	#GASTATE<CHIPNR><CR>	ASCII	
	READ	Result:		
	COMMAND	#GASTATE<CHIPNR>:<ChipxAlertState><CR>		
	CHIPNR	1		
	TX	#1,GASTATE1<CR>		
	RX	#1,GASTATE4:33792,0x8400<CR>		
		Actual alert state of CHIP1:33792,0x8400		
		Alert state bit 0: VI_ERR_A:0		
		Alert state bit 1: VI_ERR_B:0		
		Alert state bit 2: VI_ERR_C:0		
		Alert state bit 3: VI_ERR_D:0		
		Alert state bit 4: HI_TEMP_ERR:0		
		Alert state bit 5: CHARGE_PUMP_ERR:0		
		Alert state bit 6: ALDO5V_ERR:0		
		Alert state bit 7: AVDD_ERR:0		
		Alert state bit 8: DVCC_ERR:0		
		Alert state bit 9: ALDO1V8_ERR:0		
		Alert state bit 10: ADC_CONV_ERR:1		
		Alert state bit 11: ADC_SAT_ERR:0		
		Alert state bit 12: SPI_SCLK_CNT_ERR:0		
		Alert state bit 13: SPI_CRC_ERR:0		
		Alert state bit 14: CAL_MEM_ERR:0		
		Alert state bit 15: RESET OCCURED:0		
Returns the actual alert states for chip <CHIPNR>. Each result bit stands for a different state: Bit 0: VI_ERR_CURR_A: Status of channel A:Voltage or current error detected on Channel A. This bit is interpreted differently depending on which of the following IO function selected: Voltage output: short-circuit error. The error condition is debounced for 2 ms before the status bit is set. Current output: open circuit error. The error condition is debounced for 2 ms before the status bit is set. Current input, loop powered: short-circuit error. A short to ground is detected Current input, externally powered: short-circuit error. A current source >25 mA is detected Bit 1: VI_ERR_CURR_B: Status of voltage input B. Same like VI_ERR_CURR_A Bit 2: VI_ERR_CURR_C: Status of voltage input C. Same like VI_ERR_CURR_A Bit 3: VI_ERR_CURR_D: Status of voltage input D. Same like VI_ERR_CURR_A Bit 4: HI_TEMP_STATUS: If the die temperature is typically at or above 115°C, the HI_TEMP_STATUS bit is asserted Bit 5: CHARGE_PUMP_STATUS: Charge pump error detected. Bit 6: ALDO5V_STATUS: ALDO5V Power Supply Monitor Error. This bit is asserted when the ALDO5V pin falls below 4.05 V. Usually ~5V. Bit 7: AVDD_STATUS: AVDD Power Supply Monitor Error. This bit is asserted when the AVDD pin falls below 9.26 V. Usually ~17V. Bit 8: DVCC_STATUS: DVCC Power Supply Monitor Error. This bit is asserted when the DVCC pin falls below 1.93 V. Usually ~3.3V. Bit 9: ALDO1V8_STATUS: ALDO1V8 Power Supply Monitor Error. This bit is asserted when the ALDO1V8 pin falls below 1.35 V. Usually ~1.8V. Bit 10: ADC_CONV_ERR: ADC Conversion Error. ADC results may be outside the selected measurement range. Bit 11: ADC_SAT_ERR: ADC Saturation Error. ADC may be outside the user selected measurement range. Bit 12: SPI_SCLK_CNT_ERR: SPI SCLK count error detected. This bit is asserted if an SPI command is applied but 32 SCLKs are not provided. Bit 13: SPI_CRC_ERR: SPI CRC error detected. This bit is asserted if an invalid CRC is received. Bit 14: CAL_MEM_ERR: Calibration Memory Error. This flag asserts under the following two conditions: When a calibration memory CRC error or an uncorrectable error correcting code (ECC) error is detected on the calibration memory upload. It is not possible to clear this bit if there is a CRC error or uncorrectable ECC error. It is recommended to reset the device and check the supplies in this situation. When there is an attempted SPI access to a register before the calibration memory refresh is complete. Do not address the device until the calibration memory is refreshed. Writing 1 to this bit clears the flag, if the flag is asserted due to this condition. Bit 15: RESET_OCCURRED: Reset occurred. This bit is asserted after a reset event, which asserts the ALERT pin after the reset. Write a 1 to this bit to clear the flag. Note that a mask bit is not provided for this bit.				

CLEAR ALERT STATE	ASCII WRITE COMMAND	#CALERTS<CHIPNR>:<AlertState> <CR> Result: #OK<CR>	ASCII	YES
	CHIPNR	1		
	Bit 0	1:RESET FLAG 0:VI_ERR_A		
	Bit 1	1:RESET FLAG 1:VI_ERR_B		
	Bit 2	1:RESET FLAG 2:VI_ERR_C		
	Bit 3	1:RESET FLAG 3:VI_ERR_D		
	Bit 4	1:RESET FLAG 4:HI_TEMP_ERR		
	Bit 5	1:RESET FLAG 5:CHARGE_PUMP_ERR		
	Bit 6	1:RESET FLAG 6:ALDO5V_ERR		
	Bit 7	1:RESET FLAG 7:AVDD_ERR		
	Bit 8	1:RESET FLAG 8:DVCC_ERR		
	Bit 9	1:RESET FLAG 9:ALDO1V8_ERR		
	Bit 10	1:RESET FLAG 10:ADC_CONV_ERR		
	Bit 11	1:RESET FLAG 11:ADC_SAT_ERR		
	Bit 12	1:RESET FLAG 12:SPI_SCLK_ERR		
	Bit 13	1:RESET FLAG 13:SPI_CRC_ERR		
	Bit 14	1:RESET FLAG 14:CAL_MEM_ERR		
	Bit 15	1:RESET FLAG 15:RESET_OCCURED		
	TX	#1,CALERTS1:65535<CR>		
	RX	N/A		

With this command you can reset individual alert bits in the alert status register

CHIP TEMPERATURES

GET CHIP TEMPERATURES	ASCII READ COMMAND	#GCHIPTemps<CR> Result: #GCHIPTemps:<Chip1TempDbl> <CR>	ASCII	
	TX	#1,GCHIPTemps<CR>		
	RX	#1,GCHIPTemps:46.37<CR>		
		Actual temperature of CHIP1:46.37°C		

This command returns for every AIOX chip the actual chip temperature in °C

GET CHIP TEMPERATURE	ASCII READ COMMAND	#GCHIPTemp<CHIPNR> <CR> Result: #GCHIPTemp<CHIPNR>:<ChipxTempDbl> <CR>	ASCII	
	CHIPNR	1		
	TX	#1,GCHIPTemp1<CR>		
	RX	#1,GCHIPTemp1:46.37<CR>		
		Actual temperature of CHIP1:46.37°C		

This command returns for AIOX chip <CHIPNR> the actual chip temperature in °C

AVERAGE CHIP TEMPERATURES

GET AVERAGE CHIP TEMPERATURES	ASCII READ COMMAND	#GAVGCHIPTemps<CR> Result: #GAVGCHIPTemps:<Chip1AvgTempDbl> <CR>	ASCII	
-------------------------------	--------------------------	--	-------	--

	TX	#1,GAVGCHIPTemps<CR>		
	RX	#1,GAVGCHIPTemps:46.36<CR>		
		Average temperature of CHIP1:46.36°C		
This command returns for every AIOX chip the average chip temperature in °C				
GET AVERAGE CHIP TEMPERATURE	ASCII READ COMMAND	#GAVGCHIPTemp<CHIPNR> <CR> Result: #GAVGCHIPTemp<CHIPNR>:<ChipxAvgTempDbl> <CR>	ASCII	
	CHIPNR	1		
	TX	#1,GAVGCHIPTemp1<CR>		
	RX	#1,GAVGCHIPTemp1:46.36<CR>		
		Average temperature of CHIP1:46.36°C		
This command returns for AIOX chip <CHIPNR> the average chip temperature in °C				
CHIP SUPPLY VOLTAGES				
GET SUPPLY VOLTAGES	ASCII READ COMMAND	#GVAVDDS<CR> Result: #GVAVDDS:<Chip1VAVDDDBl> <CR>	ASCII	
	TX	#1,GVAVDDS<CR>		
	RX	#1,GVAVDDS:14.61<CR>		
		Actual supply voltage of CHIP1:14.61V		
This command returns for every AIOX chip the actual supply voltage in Volts. This must be >14.5V, if not, there is a severe wiring or other hardware issue!				
GET SUPPLY VOLTAGE	ASCII READ COMMAND	#GVAVDD<CHIPNR> <CR> Result: #GVAVDD<CHIPNR>:<ChipxVAVDD> <CR>	ASCII	
	CHIPNR	1		
	TX	#1,GVAVDD1<CR>		
	RX	#1,GVAVDD1:14.61<CR>		
		Actual supply voltage of CHIP1:14.61V		
This command returns for AIOX chip <CHIPNR> the actual supply voltage in Volts. This must be >14.5V, if not, there is a severe wiring or other hardware issue!				
AVERAGE CHIP SUPPLY VOLTAGES				
GET AVERAGE SUPPLY VOLTAGES	ASCII READ COMMAND	#GAVGVAVDDS<CR> Result: #GAVGVAVDDS:<Chip1AvgVAVDDDBl> <CR>	ASCII	
	TX	#1,GAVGVAVDDS<CR>		
	RX	#1,GAVGVAVDDS:14.61<CR>		
		Average supply voltage of CHIP1:14.61V		
This command returns for every AIOX chip the average supply voltage in Volts. This must be >14.5V, if not, there is a severe wiring or other hardware issue!				
GET AVERAGE SUPPLY VOLTAGE	ASCII READ COMMAND	#GAVGVAVDD<CHIPNR> <CR> Result: #GAVGVAVDD<CHIPNR>:<ChipxAvgVAVDD> <CR>	ASCII	
	CHIPNR	1		
	TX	#1,GAVGVAVDD1<CR>		

	RX	#1,GAVGVAVDD1:14.61<CR>		
		Average supply voltage of CHIP1:14.61V		
This command returns for AIOX chip <CHIPNR> the average supply voltage in Volts. This must be >14.5V, if not, there is a severe wiring or other hardware issue!				
CHIP GROUND VOLTAGES				
GET GROUND VOLTAGES	ASCII READ COMMAND	#GVAGNDS<CR> Result: #GVAGNDS:<Chip1VAGNDDbl><CR>	ASCII	
	TX	#1,GVAGNDS<CR>		
	RX	#1,GVAGNDS:0.00<CR>		
		Actual ground voltage of CHIP1:0.00V		
This command returns for every AIOX chip the actual ground voltage in Volts. This must be 0, if not, there is a severe wiring or other hardware issue!				
GET GROUND VOLTAGE	ASCII READ COMMAND	#GVAGND<CHIPNR><CR> Result: #GVAGND<CHIPNR>:<ChipxVAGNDDbl><CR>	ASCII	
	CHIPNR	1		
	TX	#1,GVAGND1<CR>		
	RX	#1,GVAGND1:0.00<CR>		
		Actual ground voltage of CHIP1:0.00V		
This command returns for AIOX chip <CHIPNR> the actual ground voltage in Volts. This must be 0, if not, there is a severe wiring or other hardware issue!				
AVERAGE CHIP GROUND VOLTAGES				
GET AVERAGE GROUND VOLTAGES	ASCII READ COMMAND	#GAVGVAGNDS<CR> Result: #GAVGVAGNDS:<Chip1AvgVAGNDDbl><CR>	ASCII	
	TX	#1,GAVGVAGNDS<CR>		
	RX	#1,GAVGVAGNDS:0.00<CR>		
		Average ground voltage of CHIP1:0.00V		
This command returns for every AIOX chip the average ground voltage in Volts. This must be 0, if not, there is a severe wiring or other hardware issue!				
GET AVERAGE GROUND VOLTAGE	ASCII READ COMMAND	#GAVGVAGND<CHIPNR><CR> Result: #GAVGVAGND<CHIPNR>:<ChipxAvgVAVGNDDbl><CR>	ASCII	
	CHIPNR	1		
	TX	#1,GAVGVAGND1<CR>		
	RX	#1,GAVGVAGND1:0.00<CR>		
		Average ground voltage of CHIP1:0.00V		
This command returns for AIOX chip <CHIPNR> the average ground voltage in Volts. This must be 0, if not, there is a severe wiring or other hardware issue!				

Register NAME Command NAME	MODBUS Register ASCII Command	Register VALUE ASCII Command	NEW REAL VALUE	NEW VALUE	DATA TYPE	DO WRITE
ASCII COMMANDS						
SET CONFIG OUTPUT VALUES	ASCII WRITE COMMAND	#SCFGOVs:<IO1CfgValDbl>,<IO2CfgValDbl>,<IO3CfgValDbl>,<IO4CfgValDbl><CR> Result: #OK<CR>			ASCII	YES
	IO1Value	,000				
	IO2Value	,000				
	IO3Value	,000				
	IO4Value	,000				
	TX	#1,SCFGOVs:0,0,0,0<CR>				
	RX	N/A				
This command sets for all outputs the standard value in Volt or in mA, which are used when the controller is restartet or performing a watchdog reset and the channel is used as voltage output or current output. For voltage outputs the range is 0 to 11,0V. For current outputs the range is 0 to 25mA.						
SET CONFIG OUTPUT VALUEx	ASCII WRITE COMMAND	#SCFGOV<IONR>:<IOxCfgValueDbl><CR> Result: #OK<CR>			ASCII	YES
	IONR	1				
	IOxCfgValue	,000				
	TX	#1,SCFGOV1:0<CR>				
	RX	N/A				
This command sets for one outputs the standard value in Volt or in mA, which is used when the controller is restartet and the channel is used as voltage output or current output. For voltage outputs the range is 0 to 11,0V. For current outputs the range is 0 to 25mA.						
GET CONFIG OUTPUT VALUES	ASCII READ COMMAND	#GCFGOVs<CR> Result: #GCFGOVs:<IOVolt1Dbl>,<IOVolt2Dbl>,...,<IOVolt4Dbl><CR>			ASCII	
	TX	#1,GCFGOVs<CR>				
	RX	#1,GCFGOVs:999.99,999.99,999.99,999.99<CR>				
		Actual config value on IO1:999.99V or mA				
		Actual config value on IO2:999.99V or mA				
		Actual config value on IO3:999.99V or mA				
		Actual config value on IO4:999.99V or mA				
This command shows for all channels the current saved startup values for use as voltage or current outputs For voltage outputs the range is 0 to 11,0V. For current outputs the range is 0 to 25mA. All IOs with a different usage type will return 999.99.						
GET CONFIG OUTPUT VALUE	ASCII READ COMMAND	#GCFGOV<IONR><CR> Result: #GCFGOV<IONR>:<IOxValueDbl><CR>			ASCII	

	IONR	1		
	TX	#1,GCFGOV1<CR>		
	RX	#1,GCFGOV1:999.99<CR>		
		Actual config value on IO1:999.99V or mA		
This command shows for one channel the current saved startup value for use as voltage or current output. For voltage outputs the range is 0 to 11,0V. For current outputs the range is 0 to 25mA. All IOs with a different usage type will return 999.99.				
RESET 16AIOXCPU	ASCII WRITE COMMAND	#R16AIOXCPU<CR> Result: #OK<CR>	ASCII	NO
	TX	#1,R16AIOXCPU<CR>		
	RX	N/A		
This command restarts the internal CPU of the 16AIOX addon print. All channels will be resetted & initialized completely				

Register NAME Command NAME	MODBUS Register ASCII Command	Register VALUE ASCII Command	NEW REAL VALUE	NEW VALUE	DATA TYPE	DO WRITE
AIOX IO TYPES						
IO TYPE1	3x40001 4x40001 I:40000	0,0x0000 B:00 00		13:RTDI[OHM]	UINT16 R/W	YES
		Actual IO type of AIOx:0:UU		CHOOSE NEW IO TYPE FROM LIST		
Current configured IO type for AIOXx =0: UNUSED =1: VOLTAGE INPUT[0-10V] =2: VOLTAGE INPUT[2-10V] =3: VOLTAGE OUTPUT[0-10V] =4: VOLTAGE OUTPUT[2-10V] =5: CURRENT INPUT LOOP POWERED[0-20mA] =6: CURRENT INPUT LOOP POWERED[4-20mA] =7: CURRENT INPUT EXTERNAL POWERED[0-20mA] =8: CURRENT INPUT EXTERNAL POWERED[4-20mA] =9: CURRENT OUTPUT[0-20mA] =10: CURRENT OUTPUT[4-20mA] =11: DIGITAL INPUT LOGIC 24V= =12: DIGITAL INPUT LOOP POWERED =13: RESISTANCE MEASUREMENT						
HINT: The last IO type is automatically stored in FRAM and will be used after a system restart.						
IO TYPE2	3x40002 4x40002 I:40001	0,0x0000 B:00 00		12:DI[24V;LP]	UINT16 R/W	YES
		Actual IO type of AIOx:0:UU		CHOOSE NEW IO TYPE FROM LIST		
IO TYPE3	3x40003 4x40003 I:40002	0,0x0000 B:00 00		1:VI[0-10V]	UINT16 R/W	NO
		Actual IO type of AIOx:0:UU		CHOOSE NEW IO TYPE FROM LIST		
IO TYPE4	3x40004 4x40004 I:40003	0,0x0000 B:00 00		1:VI[0-10V]	UINT16 R/W	NO
		Actual IO type of AIOx:0:UU		CHOOSE NEW IO TYPE FROM LIST		
AIOX:VOLTAGE INPUTS						
VOLTAGE INPUT1 IN VOLTS	3x40005 4x40005 I:40004	65535,0xFFFF B:FF FF			UINT16 R/O	
		Actual value of VIx:65535=N/V				
Current value of voltage input in x*100V, range 0-10V =65535,0xFFFF: The channel is not configured as voltage input						

VOLTAGE INPUT2 IN VOLTS	3x40006 4x40006 I:40005	65535,0xFFFF B:FF FF			UINT16 R/O	
		Actual value of VIx:65535=N/V				
VOLTAGE INPUT3 IN VOLTS	3x40007 4x40007 I:40006	65535,0xFFFF B:FF FF			UINT16 R/O	
		Actual value of VIx:65535=N/V				
VOLTAGE INPUT4 IN VOLTS	3x40008 4x40008 I:40007	65535,0xFFFF B:FF FF			UINT16 R/O	
		Actual value of VIx:65535=N/V				
AIOX:VOLTAGE INPUTS						
VOLTAGE INPUT1 IN PERCENT	3x40009 4x40009 I:40008	65535,0xFFFF B:FF FF			UINT16 R/O	
		Actual value of VIx:65535=N/V				
Current value of voltage input in x*100%, range 0-100% =65535,0xFFFF: The channel is not configured as voltage input						
VOLTAGE INPUT3 IN PERCENT	3x40010 4x40010 I:40009	65535,0xFFFF B:FF FF			UINT16 R/O	
		Actual value of VIx:65535=N/V				
VOLTAGE INPUT3 IN PERCENT	3x40011 4x40011 I:40010	65535,0xFFFF B:FF FF			UINT16 R/O	
		Actual value of VIx:65535=N/V				
VOLTAGE INPUT4 IN PERCENT	3x40012 4x40012 I:40011	65535,0xFFFF B:FF FF			UINT16 R/O	
		Actual value of VIx:65535=N/V				
AIOX:VOLTAGE OUTPUTS						
VOLTAGE OUTPUT1 IN VOLTS	3x40013 4x40013 I:40012	65535,0xFFFF B:FF FF	1100	11	UINT16 R/W	NO
		Actual value of VOx:65535=N/V			ENTER NEW VALUE FOR VOx	
Current value of voltage output in x*100V, range 0-11V =65535,0xFFFF: The channel is not configured as voltage output						
Writing a new value onto this register sets voltage output x to a new output value in Volt						
VOLTAGE OUTPUT2 IN VOLTS	3x40014 4x40014 I:40013	65535,0xFFFF B:FF FF	1100	11	UINT16 R/W	NO
		Actual value of VOx:65535=N/V			ENTER NEW VALUE FOR VOx	

VOLTAGE OUTPUT3 IN VOLTS	3x40015 4x40015 I:40014	65535,0xFFFF B:FF FF	1100	11	UINT16 R/W	NO
		Actual value of VOx:65535=N/V		ENTER NEW VALUE FOR VOx		
VOLTAGE OUTPUT4 IN VOLTS	3x40016 4x40016 I:40015	65535,0xFFFF B:FF FF	1100	11	UINT16 R/W	NO
		Actual value of VOx:65535=N/V		ENTER NEW VALUE FOR VOx		
AIOX:VOLTAGE OUTPUTS						
VOLTAGE OUTPUT1 IN PERCENT	3x40017 4x40017 I:40016	65535,0xFFFF B:FF FF	11000	110	UINT16 R/W	NO
		Actual value of VOx:65535=N/V		ENTER NEW VALUE FOR VOx		
Current value of voltage output in x*100%, range 0-110% (100%=10V) =65535,0xFFFF: The channel is not configured as voltage output						
Writing a new value onto this register sets voltage output x to a new output value in percent						
VOLTAGE OUTPUT2 IN PERCENT	3x40018 4x40018 I:40017	65535,0xFFFF B:FF FF	5000	50	UINT16 R/W	NO
		Actual value of VOx:65535=N/V		ENTER NEW VALUE FOR VOx		
VOLTAGE OUTPUT3 IN PERCENT	3x40019 4x40019 I:40018	65535,0xFFFF B:FF FF	3000	30	UINT16 R/W	NO
		Actual value of VOx:65535=N/V		ENTER NEW VALUE FOR VOx		
VOLTAGE OUTPUT4 IN PERCENT	3x40020 4x40020 I:40019	65535,0xFFFF B:FF FF	7500	75	UINT16 R/W	NO
		Actual value of VOx:65535=N/V		ENTER NEW VALUE FOR VOx		
AIOX:VOLTAGE OUTPUTS						
VOLTAGE OUTPUT1 MEASURED CURRENT	3x40021 4x40021 I:40020	-32768,0x8000 B:80 00			SINT16 R/O	
		Actual measured output current of VOx:-32768=N/V				
Returns the measured output current in x*100mA on voltage output VOx, Range -25mA..+25mA =-32768,0x8000: The channel is not configured as voltage output						
VOLTAGE OUTPUT2 MEASURED CURRENT	3x40022 4x40022 I:40021	-32768,0x8000 B:80 00			SINT16 R/O	
		Actual measured output current of VOx:-32768=N/V				
VOLTAGE OUTPUT3 MEASURED CURRENT	3x40023 4x40023 I:40022	-32768,0x8000 B:80 00			SINT16 R/O	
		Actual measured output current of VOx:-32768=N/V				

VOLTAGE OUTPUT4 MEASURED CURRENT	3x40024 4x40024 I:40023	-32768,0x8000 B:80 00			SINT16 R/O	
		Actual measured output current of VOx:-32768=N/V				
AIOX:CURRENT INPUTS						
CURRENT INPUT1 IN MILLIAMPERE	3x40025 4x40025 I:40024	65535,0xFFFF B:FF FF			UINT16 R/O	
		Actual value of Clx:65535=N/V				
Current value of current input in x*100mA, range 0-25mA =65535,0xFFFF: The channel is not configured as current input						
CURRENT INPUT2 IN MILLIAMPERE	3x40026 4x40026 I:40025	65535,0xFFFF B:FF FF			UINT16 R/O	
		Actual value of Vlx:65535=N/V				
CURRENT INPUT3 IN MILLIAMPERE	3x40027 4x40027 I:40026	65535,0xFFFF B:FF FF			UINT16 R/O	
		Actual value of Vlx:65535=N/V				
CURRENT INPUT4 IN MILLIAMPERE	3x40028 4x40028 I:40027	65535,0xFFFF B:FF FF			UINT16 R/O	
		Actual value of Vlx:65535=N/V				
AIOX:CURRENT INPUTS						
CURRENT INPUT1 IN PERCENT	3x40029 4x40029 I:40028	65535,0xFFFF B:FF FF			UINT16 R/O	
		Actual value of Clx:65535=N/V				
Current value of current input in x*100%, range 0-125% (100%=20mA) =65535,0xFFFF: The channel is not configured as current input						
CURRENT INPUT2 IN PERCENT	3x40030 4x40030 I:40029	65535,0xFFFF B:FF FF			UINT16 R/O	
		Actual value of Clx:65535=N/V				
CURRENT INPUT3 IN PERCENT	3x40031 4x40031 I:40030	65535,0xFFFF B:FF FF			UINT16 R/O	
		Actual value of Clx:65535=N/V				
CURRENT INPUT4 IN PERCENT	3x40032 4x40032 I:40031	65535,0xFFFF B:FF FF			UINT16 R/O	
		Actual value of Clx:65535=N/V				
AIOX:CURRENT OUTPUTS						

CURRENT OUTPUT1 IN MILIAMPERE	3x40033 4x40033 I:40032	65535,0xFFFF B:FF FF	500	5	UINT16 R/W	NO
		Actual value of COx:65535=N/V		ENTER NEW VALUE FOR COx		
Current value of current output in x*100mA, range 0-25mA =65535,0xFFFF: The channel is not configured as current output						
Writing a new value onto this register sets current output x to a new output value in Milliampere						
CURRENT OUTPUT2 IN MILIAMPERE	3x40034 4x40034 I:40033	65535,0xFFFF B:FF FF	500	5	UINT16 R/W	NO
		Actual value of COx:65535=N/V		ENTER NEW VALUE FOR COx		
CURRENT OUTPUT3 IN MILIAMPERE	3x40035 4x40035 I:40034	65535,0xFFFF B:FF FF	500	5	UINT16 R/W	NO
		Actual value of COx:65535=N/V		ENTER NEW VALUE FOR COx		
CURRENT OUTPUT4 IN MILIAMPERE	3x40036 4x40036 I:40035	65535,0xFFFF B:FF FF	500	5	UINT16 R/W	NO
		Actual value of COx:65535=N/V		ENTER NEW VALUE FOR COx		
AIOX:CURRENT OUTPUTS						
CURRENT OUTPUT1 IN PERCENT	3x40037 4x40037 I:40036	65535,0xFFFF B:FF FF	5000	50	UINT16 R/W	NO
		Actual value of COx:65535=N/V		ENTER NEW VALUE FOR COx		
Current value of current output in x*100%, range 0-125% (100%=20mA) =65535,0xFFFF: The channel is not configured as current output						
Writing a new value onto this register sets current output x to a new output value in percent						
CURRENT OUTPUT2 IN PERCENT	3x40038 4x40038 I:40037	65535,0xFFFF B:FF FF	5000	50	UINT16 R/W	NO
		Actual value of COx:65535=N/V		ENTER NEW VALUE FOR COx		
CURRENT OUTPUT3 IN PERCENT	3x40039 4x40039 I:40038	65535,0xFFFF B:FF FF	5000	50	UINT16 R/W	NO
		Actual value of COx:65535=N/V		ENTER NEW VALUE FOR COx		
CURRENT OUTPUT4 IN PERCENT	3x40040 4x40040 I:40039	65535,0xFFFF B:FF FF	5000	50	UINT16 R/W	NO
		Actual value of COx:65535=N/V		ENTER NEW VALUE FOR COx		
AIOX:CURRENT OUTPUTS						
CURRENT OUTPUT1 MEASURED VOLTS	3x40041 4x40041 I:40040	65535,0xFFFF B:FF FF			UINT16 R/O	

		Actual measured output voltage COx:65535=N/V				
Current measured output voltage for current output x*100V, range 0-10V =65535,0xFFFF: The channel is not configured as current output						
CURRENT OUTPUT2 MEASURED VOLTS	3x40042 4x40042 I:40041	65535,0xFFFF B:FF FF			UINT16 R/O	
		Actual measured output voltage COx:65535=N/V				
CURRENT OUTPUT3 MEASURED VOLTS	3x40043 4x40043 I:40042	65535,0xFFFF B:FF FF			UINT16 R/O	
		Actual measured output voltage COx:65535=N/V				
CURRENT OUTPUT4 MEASURED VOLTS	3x40044 4x40044 I:40043	65535,0xFFFF B:FF FF			UINT16 R/O	
		Actual measured output voltage COx:65535=N/V				
AIOX:DIGITAL INPUTS						
DIGITAL INPUT1	3x40045 4x40045 I:40044	65535,0xFFFF B:FF FF			UINT16 R/O	
		Actual state of digital input DIx:65535=N/V				
Current measured state of digital input DIx =0: Digital input is OFF or loop is closed =1: Digital input is ON (+24V attached) or loop is open =65535,0xFFFF: The channel is not configured as digital input						
DIGITAL INPUT2	3x40046 4x40046 I:40045	65535,0xFFFF B:FF FF			UINT16 R/O	
		Actual state of digital input DIx:65535=N/V				
DIGITAL INPUT3	3x40047 4x40047 I:40046	65535,0xFFFF B:FF FF			UINT16 R/O	
		Actual measured output voltage COx:65535=N/V				
DIGITAL INPUT4	3x40048 4x40048 I:40047	65535,0xFFFF B:FF FF			UINT16 R/O	
		Actual measured output voltage COx:65535=N/V				
AIOX:DIGITAL INPUTS						
DIGITAL INPUT1 MEASURED CURRENT	3x40049 4x40049 I:40048	-32768,0x8000 B:80 00			SINT16 R/O	
		Actual measured output current of DIx:-32768=N/V				
Returns the measured output current in x*100mA on DIGITAL INPUT VOx, Range -25mA..+25mA =-32768,0x8000: The channel is not configured as DIGITAL INPUT						

DIGITAL INPUT2 MEASURED CURRENT	3x40050 4x40050 I:40049	-32768,0x8000 B:80 00			SINT16 R/O	
		Actual measured output current of DIx:-32768=N/V				
DIGITAL INPUT3 MEASURED CURRENT	3x40051 4x40051 I:40050	-32768,0x8000 B:80 00			SINT16 R/O	
		Actual measured output current of DIx:-32768=N/V				
DIGITAL INPUT4 MEASURED CURRENT	3x40052 4x40052 I:40051	-32768,0x8000 B:80 00			SINT16 R/O	
		Actual measured output current of DIx:-32768=N/V				

Register NAME Command NAME	MODBUS Register ASCII Command	Register VALUE ASCII Command	NEW REAL VALUE	NEW VALUE	DATA TYPE	DO WRITE
AIOX:RTD INPUTS OHM*10						
RTD INPUT1 IN OHM*10	3x41001 4x41001 I:41000	65534,0xFFFE B:FF FE			UINT16 R/O	
		Actual measured ohm value of RTDIx:65534=OPEN				
Current measured RTD in Ohm*10 between 0 and 600000 =0..60000: Current measured resistance in Ohm*10 =65534,0xFFFE: The sensor or cabling is open (broken, not connected, or out of range) =65535,0xFFFF: The channel is not configured as RTD input						
RTD INPUT2 IN OHM*10	3x41002 4x41002 I:41001	65534,0xFFFE B:FF FE			UINT16 R/O	
		Actual measured ohm value of RTDIx:65534=OPEN				
RTD INPUT3 IN OHM*10	3x41003 4x41003 I:41002	65534,0xFFFE B:FF FE			UINT16 R/O	
		Actual measured ohm value of RTDIx:65534=OPEN				
RTD INPUT4 IN OHM*10	3x41004 4x41004 I:41003	65534,0xFFFE B:FF FE			UINT16 R/O	
		Actual measured ohm value of RTDIx:65534=OPEN				
AIOX:RTD INPUTS OHM*1						
RTD INPUT1 IN OHM	3x41005 4x41005 I:41004	65535,0xFFFF B:FF FF			UINT16 R/O	
		Actual measured ohm value of RTDIx:65535=N/V				
Current measured RTD in Ohm*1 between 0 and 60000 =0..60000: Current measured resistance in Ohm*1 =65534,0xFFFE: The sensor or cabling is open (broken, not connected, or out of range) =65535,0xFFFF: The channel is not configured as RTD input						
RTD INPUT2 IN OHM	3x41006 4x41006 I:41005	65535,0xFFFF B:FF FF			UINT16 R/O	
		Actual measured ohm value of RTDIx:65535=N/V				
RTD INPUT3 IN OHM	3x41007 4x41007 I:41006	65535,0xFFFF B:FF FF			UINT16 R/O	
		Actual measured ohm value of RTDIx:65535=N/V				

RTD INPUT4 IN OHM	3x41008 4x41008 I:41007	65535,0xFFFF B:FF FF			UINT16 R/O		
		Actual measured ohm value of RTDlx:65535=N/V					
AIOX:RTD INPUTS OHM/10							
RTD INPUT1 IN OHM/10	3x41009 4x41009 I:41008	65535,0xFFFF B:FF FF			UINT16 R/O		
		Actual measured ohm value of RTDlx:65535=N/V					
Current measured RTD in Ohm/10 between 0 and 60000 =0..60000: Current measured resistance in Ohm/10 =65534,0xFFFE: The sensor or cabling is open (broken, not connected, or out of range) =65535,0xFFFF: The channel is not configured as RTD input							
RTD INPUT2 IN OHM/10	3x41010 4x41010 I:41009	65535,0xFFFF B:FF FF			UINT16 R/O		
		Actual measured ohm value of RTDlx:65535=N/V					
RTD INPUT3 IN OHM/10	3x41011 4x41011 I:41010	65535,0xFFFF B:FF FF			UINT16 R/O		
		Actual measured ohm value of RTDlx:65535=N/V					
RTD INPUT4 IN OHM/10	3x41012 4x41012 I:41011	65535,0xFFFF B:FF FF			UINT16 R/O		
		Actual measured ohm value of RTDlx:65535=N/V					
AIOX:RTD INPUTS PT100 CELSIUS							
RTD INPUT1 AS PT100 IN CELSIUS	3x41013 4x41013 I:41012	-32768,0x8000 B:80 00			SINT16 R/O		
		Actual measured PT100 temperature RTDlx:-32768=N/V					
Current measured RTD sensor value linearized as PT100 sensor in Celsius*100 in the range of -5000 to +13000 for -50.0 to +130.0 °C -32766,0x8002: Measured value is below -50°C -32767,0x8001: Measured value is above +130°C -32768,0x8000: The channel is not configured as RTD input							
RTD INPUT2 AS PT100 IN CELSIUS	3x41014 4x41014 I:41013	-32768,0x8000 B:80 00			SINT16 R/O		
		Actual measured PT100 temperature RTDlx:-32768=N/V					
RTD INPUT3 AS PT100 IN CELSIUS	3x41015 4x41015 I:41014	-32768,0x8000 B:80 00			SINT16 R/O		
		Actual measured PT100 temperature RTDlx:-32768=N/V					
RTD INPUT4 AS PT100 IN CELSIUS	3x41016 4x41016 I:41015	-32768,0x8000 B:80 00			SINT16 R/O		

		Actual measured PT100 temperature RTDlx:-32768=N/V				
AIOX:RTD INPUTS PT1000 CELSIUS						
RTD INPUT1 AS PT1000 IN CELSIUS	3x41017 4x41017 I:41016	-32768,0x8000 B:80 00			SINT16 R/O	
		Actual measured PT1000 temperature RTDlx:-32768=N/V				
Current measured RTD sensor value linearized as PT1000 sensor in Celsius*100 in the range of -5000 to +13000 for -50.0 to +130.0 °C -32766,0x8002: Measured value is below -50°C -32767,0x8001: Measured value is above +130°C -32768,0x8000: The channel is not configured as RTD input						
RTD INPUT2 AS PT1000 IN CELSIUS	3x41018 4x41018 I:41017	-32768,0x8000 B:80 00			SINT16 R/O	
		Actual measured PT1000 temperature RTDlx:-32768=N/V				
RTD INPUT3 AS PT1000 IN CELSIUS	3x41019 4x41019 I:41018	-32768,0x8000 B:80 00			SINT16 R/O	
		Actual measured PT1000 temperature RTDlx:-32768=N/V				
RTD INPUT4 AS PT1000 IN CELSIUS	3x41020 4x41020 I:41019	-32768,0x8000 B:80 00			SINT16 R/O	
		Actual measured PT1000 temperature RTDlx:-32768=N/V				
AIOX:RTD INPUTS NI1000-DIN43760 CELSIUS						
RTD INPUT1 AS NI1000-DIN43760 IN CELSIUS	3x41021 4x41021 I:41020	-32768,0x8000 B:80 00			SINT16 R/O	
		Actual measured NI1000-DIN43760 temperature RTDlx:-32768=N/V				
Current measured RTD sensor value linearized as NI1000-DIN43760 sensor in Celsius*100 in the range of -5000 to +13000 for -50.0 to +130.0 °C -32766,0x8002: Measured value is below -50°C -32767,0x8001: Measured value is above +130°C -32768,0x8000: The channel is not configured as RTD input						
RTD INPUT2 AS NI1000-DIN43760 IN CELSIUS	3x41022 4x41022 I:41021	-32768,0x8000 B:80 00			SINT16 R/O	
		Actual measured NI1000-DIN43760 temperature RTDlx:-32768=N/V				
RTD INPUT3 AS NI1000-DIN43760 IN CELSIUS	3x41023 4x41023 I:41022	-32768,0x8000 B:80 00			SINT16 R/O	
		Actual measured NI1000-DIN43760 temperature RTDlx:-32768=N/V				
RTD INPUT4 AS NI1000-DIN43760 IN CELSIUS	3x41024 4x41024 I:41023	-32768,0x8000 B:80 00			SINT16 R/O	
		Actual measured NI1000-DIN43760 temperature RTDlx:-32768=N/V				
AIOX:RTD INPUTS PT100 KELVIN						

RTD INPUT1 AS PT100 IN KELVIN	3x41025 4x41025 I:41024	65535,0xFFFF B:FF FF			UINT16 R/O	
		Actual measured PT100 temperature RTDIx:65535=655,35°K				
Current measured RTD sensor value linearized as PT100 sensor in Kelvin*100 in the range of 22315 to 40315 for 223.15 to 403.15 °K 65533,0xFFFFD: Measured value is below 223,15°K 65534,0xFFFFE: Measured value is above 403,15°K 65535,0xFFFFF: The channel is not configured as RTD input						
RTD INPUT2 AS PT100 IN KELVIN	3x41026 4x41026 I:41025	65535,0xFFFF B:FF FF			UINT16 R/O	
		Actual measured PT100 temperature RTDIx:65535=655,35°K				
RTD INPUT3 AS PT100 IN KELVIN	3x41027 4x41027 I:41026	65535,0xFFFF B:FF FF			UINT16 R/O	
		Actual measured PT100 temperature RTDIx:65535=655,35°K				
RTD INPUT4 AS PT100 IN KELVIN	3x41028 4x41028 I:41027	65535,0xFFFF B:FF FF			UINT16 R/O	
		Actual measured PT100 temperature RTDIx:65535=655,35°K				
AIOX:RTD INPUTS PT1000 KELVIN						
RTD INPUT1 AS PT1000 IN KELVIN	3x41029 4x41029 I:41028	65535,0xFFFF B:FF FF			UINT16 R/O	
		Actual measured PT1000 temperature RTDIx:65535=655,35°K				
Current measured RTD sensor value linearized as PT1000 sensor in Kelvin*100 in the range of 22315 to 40315 for 223.15 to 403.15 °K 65533,0xFFFFD: Measured value is below 223,15°K 65534,0xFFFFE: Measured value is above 403,15°K 65535,0xFFFFF: The channel is not configured as RTD input						
RTD INPUT2 AS PT1000 IN KELVIN	3x41030 4x41030 I:41029	65535,0xFFFF B:FF FF			UINT16 R/O	
		Actual measured PT1000 temperature RTDIx:65535=655,35°K				
RTD INPUT3 AS PT1000 IN KELVIN	3x41031 4x41031 I:41030	65535,0xFFFF B:FF FF			UINT16 R/O	
		Actual measured PT1000 temperature RTDIx:65535=655,35°K				
RTD INPUT4 AS PT1000 IN KELVIN	3x41032 4x41032 I:41031	65535,0xFFFF B:FF FF			UINT16 R/O	
		Actual measured PT1000 temperature RTDIx:65535=655,35°K				
AIOX:RTD INPUTS NI1000-DIN43760 KELVIN						
RTD INPUT1 AS NI1000-DIN43760 IN KELVIN	3x41033 4x41033 I:41032	65535,0xFFFF B:FF FF			UINT16 R/O	

		Actual measured NI1000-DIN43760 temperature RTDIx:65535=655,35°K				
Current measured RTD sensor value linearized as NI1000-DIN43760 sensor in Kelvin*100 in the range of 22315 to 40315 for 223.15 to 403.15 °K 65533,0xFFFFD: Measured value is below 223,15°K 65534,0xFFFFE: Measured value is above 403,15°K 65535,0xFFFF: The channel is not configured as RTD input						
RTD INPUT2 AS NI1000-DIN43760 IN KELVIN	3x41034 4x41034 I:41033	65535,0xFFFF B:FF FF			UINT16 R/O	
		Actual measured NI1000-DIN43760 temperature RTDIx:65535=655,35°K				
RTD INPUT3 AS NI1000-DIN43760 IN KELVIN	3x41035 4x41035 I:41034	65535,0xFFFF B:FF FF			UINT16 R/O	
		Actual measured NI1000-DIN43760 temperature RTDIx:65535=655,35°K				
RTD INPUT4 AS NI1000-DIN43760 IN KELVIN	3x41036 4x41036 I:41035	65535,0xFFFF B:FF FF			UINT16 R/O	
		Actual measured NI1000-DIN43760 temperature RTDIx:65535=655,35°K				
AIOX:RTD INPUTS PT100 FAHRENHEIT						
RTD INPUT1 AS PT100 IN FAHRENHEIT	3x41037 4x41037 I:41036	-32768,0x8000 B:80 00			SINT16 R/O	
		Actual measured PT100 temperature RTDIx:-32768=N/V				
Current measured RTD sensor value linearized as PT100 sensor in Fahrenheit*100 in the range of -5800 to +26600 for -58.0 to +266.0 °F -32766,0x8002: Measured value is below -58°C -32767,0x8001: Measured value is above +266°C -32768,0x8000: The channel is not configured as RTD input						
RTD INPUT2 AS PT100 IN FAHRENHEIT	3x41038 4x41038 I:41037	-32768,0x8000 B:80 00			SINT16 R/O	
		Actual measured PT100 temperature RTDIx:-32768=N/V				
RTD INPUT3 AS PT100 IN FAHRENHEIT	3x41039 4x41039 I:41038	-32768,0x8000 B:80 00			SINT16 R/O	
		Actual measured PT100 temperature RTDIx:-32768=N/V				
RTD INPUT4 AS PT100 IN FAHRENHEIT	3x41040 4x41040 I:41039	-32768,0x8000 B:80 00			SINT16 R/O	
		Actual measured PT100 temperature RTDIx:-32768=N/V				
AIOX:RTD INPUTS PT1000 FAHRENHEIT						
RTD INPUT1 AS PT1000 IN FAHRENHEIT	3x41041 4x41041 I:41040	-32768,0x8000 B:80 00			SINT16 R/O	
		Actual measured PT1000 temperature RTDIx:-32768=N/V				

Current measured RTD sensor value linearized as PT1000 sensor in Fahrenheit*100 in the range of -5800 to +26600 for -58.0 to +266.0 °F

-32766,0x8002: Measured value is below -58°C

-32767,0x8001: Measured value is above +266°C

-32768,0x8000: The channel is not configured as RTD input

RTD INPUT2 AS PT1000 IN FAHRENHEIT	3x41042 4x41042 I:41041	-32768,0x8000 B:80 00			SINT16 R/O	
		Actual measured PT1000 temperature RTDlx:-32768=N/V				
RTD INPUT3 AS PT1000 IN FAHRENHEIT	3x41043 4x41043 I:41042	-32768,0x8000 B:80 00			SINT16 R/O	
		Actual measured PT1000 temperature RTDlx:-32768=N/V				
RTD INPUT4 AS PT1000 IN FAHRENHEIT	3x41044 4x41044 I:41043	-32768,0x8000 B:80 00			SINT16 R/O	
		Actual measured PT1000 temperature RTDlx:-32768=N/V				

AIOX:RTD INPUTS NI1000-DIN43760 FAHRENHEIT

RTD INPUT1 AS NI1000-DIN43760 IN FAHRENHEIT	3x41045 4x41045 I:41044	-32768,0x8000 B:80 00			SINT16 R/O	
		Actual measured NI1000-DIN43760 temperature RTDlx:-32768=N/V				

Current measured RTD sensor value linearized as NI1000-DIN43760 sensor in Fahrenheit*100 in the range of -5800 to +26600 for -58.0 to +266.0 °F

-32766,0x8002: Measured value is below -58°C

-32767,0x8001: Measured value is above +266°C

-32768,0x8000: The channel is not configured as RTD input

RTD INPUT2 AS NI1000-DIN43760 IN FAHRENHEIT	3x41046 4x41046 I:41045	-32768,0x8000 B:80 00			SINT16 R/O	
		Actual measured NI1000-DIN43760 temperature RTDlx:-32768=N/V				
RTD INPUT3 AS NI1000-DIN43760 IN FAHRENHEIT	3x41047 4x41047 I:41046	-32768,0x8000 B:80 00			SINT16 R/O	
		Actual measured NI1000-DIN43760 temperature RTDlx:-32768=N/V				
RTD INPUT4 AS NI1000-DIN43760 IN FAHRENHEIT	3x41048 4x41048 I:41047	-32768,0x8000 B:80 00			SINT16 R/O	
		Actual measured NI1000-DIN43760 temperature RTDlx:-32768=N/V				

AIOX:RTD INPUTS OHM*100

RTD INPUT1 IN OHM*100	3x41501 4x41501 I:41500	4294967295,0xFFFFFFFF B:FF FF FF FF			UINT32 R/O	
		Actual measured ohm value of RTDlx:-1=N/V				

Current measured RTD in Ohm*100

=0xFFFFFFFF: The channel is not configured as RTD input

RTD INPUT2 IN OHM*100	3x41503 4x41503 I:41502	4294967295,0xFFFFFFFF B:FF FF FF FF			UINT32 R/O	
		Actual measured ohm value of RTDlx:-1=N/V				
RTD INPUT3 IN OHM*100	3x41505 4x41505 I:41504	4294967295,0xFFFFFFFF B:FF FF FF FF			UINT32 R/O	
		Actual measured ohm value of RTDlx:-1=N/V				
RTD INPUT4 IN OHM*100	3x41507 4x41507 I:41506	4294967295,0xFFFFFFFF B:FF FF FF FF			UINT32 R/O	
		Actual measured ohm value of RTDlx:-1=N/V				
AIOX:RTD INPUTS OHM*100						
RTD INPUT1 IN OHM*100	3x41509 4x41509 I:41508	4294967295,0xFFFFFFFF B:FF FF FF FF			UINT32R R/O	
		Actual measured ohm value of RTDlx:-1=N/V				
Current measured RTD in Ohm*100 =0xFFFFFFFF: The channel is not configured as RTD input						
RTD INPUT2 IN OHM*100	3x41511 4x41511 I:41510	4294967295,0xFFFFFFFF B:FF FF FF FF			UINT32R R/O	
		Actual measured ohm value of RTDlx:-1=N/V				
RTD INPUT3 IN OHM*100	3x41513 4x41513 I:41512	4294967295,0xFFFFFFFF B:FF FF FF FF			UINT32R R/O	
		Actual measured ohm value of RTDlx:-1=N/V				
RTD INPUT4 IN OHM*100	3x41515 4x41515 I:41514	4294967295,0xFFFFFFFF B:FF FF FF FF			UINT32R R/O	
		Actual measured ohm value of RTDlx:-1=N/V				

Register NAME Command NAME	MODBUS Register ASCII Command	Register VALUE ASCII Command	NEW REAL VALUE	NEW VALUE	DATA TYPE	DO WRITE
AIOX:AVERAGE RTD INPUTS OHM*10						
AVERAGE RTD INPUT1 IN OHM*10	3x42001 4x42001 I:42000	65535,0xFFFF B:FF FF			UINT16 R/O	
		Measured average ohm value of RTDIx:65535=N/V				
Measured average RTD in Ohm*10 between 0 and 600000 =0..60000: Measured average resistance in Ohm*10 =65534,0xFFFF: The sensor or cabling is open (broken, not connected, or out of range) =65535,0xFFFF: The channel is not configured as RTD input						
AVERAGE RTD INPUT2 IN OHM*10	3x42002 4x42002 I:42001	65535,0xFFFF B:FF FF			UINT16 R/O	
		Measured average ohm value of RTDIx:65535=N/V				
AVERAGE RTD INPUT3 IN OHM*10	3x42003 4x42003 I:42002	65535,0xFFFF B:FF FF			UINT16 R/O	
		Measured average ohm value of RTDIx:65535=N/V				
AVERAGE RTD INPUT4 IN OHM*10	3x42004 4x42004 I:42003	65535,0xFFFF B:FF FF			UINT16 R/O	
		Measured average ohm value of RTDIx:65535=N/V				
AIOX:AVERAGE RTD INPUTS OHM*1						
AVERAGE RTD INPUT1 IN OHM	3x42005 4x42005 I:42004	65535,0xFFFF B:FF FF			UINT16 R/O	
		Measured average ohm value of RTDIx:65535=N/V				
Measured average RTD in Ohm*1 between 0 and 60000 =0..60000: Measured average resistance in Ohm*1 =65534,0xFFFF: The sensor or cabling is open (broken, not connected, or out of range) =65535,0xFFFF: The channel is not configured as RTD input						
AVERAGE RTD INPUT2 IN OHM	3x42006 4x42006 I:42005	65535,0xFFFF B:FF FF			UINT16 R/O	
		Measured average ohm value of RTDIx:65535=N/V				
AVERAGE RTD INPUT3 IN OHM	3x42007 4x42007 I:42006	65535,0xFFFF B:FF FF			UINT16 R/O	
		Measured average ohm value of RTDIx:65535=N/V				

AVERAGE RTD INPUT4 IN OHM	3x42008 4x42008 I:42007	65535,0xFFFF B:FF FF			UINT16 R/O	
		Measured average ohm value of RTDlx:65535=N/V				
AIOX:AVERAGE RTD INPUTS OHM/10						
AVERAGE RTD INPUT1 IN OHM/10	3x42009 4x42009 I:42008	65535,0xFFFF B:FF FF			UINT16 R/O	
		Measured average ohm value of RTDlx:65535=N/V				
Measured average RTD in Ohm/10 between 0 and 60000 =0..60000: Measured average resistance in Ohm/10 =65534,0xFFFE: The sensor or cabling is open (broken, not connected, or out of range) =65535,0xFFFF: The channel is not configured as RTD input						
AVERAGE RTD INPUT2 IN OHM/10	3x42010 4x42010 I:42009	65535,0xFFFF B:FF FF			UINT16 R/O	
		Measured average ohm value of RTDlx:65535=N/V				
AVERAGE RTD INPUT3 IN OHM/10	3x42011 4x42011 I:42010	65535,0xFFFF B:FF FF			UINT16 R/O	
		Measured average ohm value of RTDlx:65535=N/V				
AVERAGE RTD INPUT4 IN OHM/10	3x42012 4x42012 I:42011	65535,0xFFFF B:FF FF			UINT16 R/O	
		Measured average ohm value of RTDlx:65535=N/V				
AIOX:AVERAGE RTD INPUTS PT100 CELSIUS						
AVERAGE RTD INPUT1 AS PT100 IN CELSIUS	3x42013 4x42013 I:42012	-32768,0x8000 B:80 00			SINT16 R/O	
		Measured average PT100 temperature RTDlx:-32768=N/V				
Calculated average value of RTD sensor value linearized as PT100 sensor in Celsius*100 in the range of -5000 to +13000 for -50.0 to +130.0 °C -32766,0x8002: Measured value is below -50°C -32767,0x8001: Measured value is above +130°C -32768,0x8000: The channel is not configured as RTD input						
AVERAGE RTD INPUT2 AS PT100 IN CELSIUS	3x42014 4x42014 I:42013	-32768,0x8000 B:80 00			SINT16 R/O	
		Measured average PT100 temperature RTDlx:-32768=N/V				
AVERAGE RTD INPUT3 AS PT100 IN CELSIUS	3x42015 4x42015 I:42014	-32768,0x8000 B:80 00			SINT16 R/O	
		Measured average PT100 temperature RTDlx:-32768=N/V				
AVERAGE RTD INPUT4 AS PT100 IN CELSIUS	3x42016 4x42016 I:42015	-32768,0x8000 B:80 00			SINT16 R/O	

		Measured average PT100 temperature RTDlx:-32768=N/V		
AIOX:AVERAGE RTD INPUTS PT1000 CELSIUS				
AVERAGE RTD INPUT1 AS PT1000 IN CELSIUS	3x42017 4x42017 I:42016	-32768,0x8000 B:80 00		SINT16 R/O
		Measured average PT1000 temperature RTDlx:-32768=N/V		
Calculated average value of RTD sensor value linearized as PT1000 sensor in Celsius*100 in the range of -5000 to +13000 for -50.0 to +130.0 °C -32766,0x8002: Measured value is below -50°C -32767,0x8001: Measured value is above +130°C -32768,0x8000: The channel is not configured as RTD input				
AVERAGE RTD INPUT2 AS PT1000 IN CELSIUS	3x42018 4x42018 I:42017	-32768,0x8000 B:80 00		SINT16 R/O
		Measured average PT1000 temperature RTDlx:-32768=N/V		
AVERAGE RTD INPUT3 AS PT1000 IN CELSIUS	3x42019 4x42019 I:42018	-32768,0x8000 B:80 00		SINT16 R/O
		Measured average PT1000 temperature RTDlx:-32768=N/V		
AVERAGE RTD INPUT4 AS PT1000 IN CELSIUS	3x42020 4x42020 I:42019	-32768,0x8000 B:80 00		SINT16 R/O
		Measured average PT1000 temperature RTDlx:-32768=N/V		
AIOX:AVERAGE RTD INPUTS NI1000-DIN43760 CELSIUS				
AVERAGE RTD INPUT1 AS NI1000-DIN43760 IN CELSIUS	3x42021 4x42021 I:42020	-32768,0x8000 B:80 00		SINT16 R/O
		Measured average NI1000-DIN43760 temperature RTDlx:-32768=N/V		
Calculated average value of RTD sensor value linearized as NI1000-DIN43760 sensor in Celsius*100 in the range of -5000 to +13000 for -50.0 to +130.0 °C -32766,0x8002: Measured value is below -50°C -32767,0x8001: Measured value is above +130°C -32768,0x8000: The channel is not configured as RTD input				
AVERAGE RTD INPUT2 AS NI1000-DIN43760 IN CELSIUS	3x42022 4x42022 I:42021	-32768,0x8000 B:80 00		SINT16 R/O
		Measured average NI1000-DIN43760 temperature RTDlx:-32768=N/V		
AVERAGE RTD INPUT3 AS NI1000-DIN43760 IN CELSIUS	3x42023 4x42023 I:42022	-32768,0x8000 B:80 00		SINT16 R/O
		Measured average NI1000-DIN43760 temperature RTDlx:-32768=N/V		
AVERAGE RTD INPUT4 AS NI1000-DIN43760 IN CELSIUS	3x42024 4x42024 I:42023	-32768,0x8000 B:80 00		SINT16 R/O
		Measured average NI1000-DIN43760 temperature RTDlx:-32768=N/V		
AIOX:AVERAGE RTD INPUTS PT100 KELVIN				

AVERAGE RTD INPUT1 AS PT100 IN KELVIN	3x42025 4x42025 I:42024	65535,0xFFFF B:FF FF			UINT16 R/O	
		Measured average PT100 temperature RTDlx:65535=655,35°K				
Average value of measured RTD sensor linearized as PT100 sensor in Kelvin*100 in the range of 22315 to 40315 for 223.15 to 403.15 °K 65533,0xFFFFD: Measured value is below 223,15°K 65534,0xFFFFE: Measured value is above 403,15°K 65535,0xFFFFF: The channel is not configured as RTD input						
AVERAGE RTD INPUT2 AS PT100 IN KELVIN	3x42026 4x42026 I:42025	65535,0xFFFF B:FF FF			UINT16 R/O	
		Measured average PT100 temperature RTDlx:65535=655,35°K				
AVERAGE RTD INPUT3 AS PT100 IN KELVIN	3x42027 4x42027 I:42026	65535,0xFFFF B:FF FF			UINT16 R/O	
		Measured average PT100 temperature RTDlx:65535=655,35°K				
AVERAGE RTD INPUT4 AS PT100 IN KELVIN	3x42028 4x42028 I:42027	65535,0xFFFF B:FF FF			UINT16 R/O	
		Measured average PT100 temperature RTDlx:65535=655,35°K				
AIOX:AVERAGE RTD INPUTS PT1000 KELVIN						
AVERAGE RTD INPUT1 AS PT1000 IN KELVIN	3x42029 4x42029 I:42028	65535,0xFFFF B:FF FF			UINT16 R/O	
		Measured average PT1000 temperature RTDlx:65535=655,35°K				
Average value of measured RTD sensor linearized as PT1000 sensor in Kelvin*100 in the range of 22315 to 40315 for 223.15 to 403.15 °K 65533,0xFFFFD: Measured value is below 223,15°K 65534,0xFFFFE: Measured value is above 403,15°K 65535,0xFFFFF: The channel is not configured as RTD input						
AVERAGE RTD INPUT2 AS PT1000 IN KELVIN	3x42030 4x42030 I:42029	65535,0xFFFF B:FF FF			UINT16 R/O	
		Measured average PT1000 temperature RTDlx:65535=655,35°K				
AVERAGE RTD INPUT3 AS PT1000 IN KELVIN	3x42031 4x42031 I:42030	65535,0xFFFF B:FF FF			UINT16 R/O	
		Measured average PT1000 temperature RTDlx:65535=655,35°K				
AVERAGE RTD INPUT4 AS PT1000 IN KELVIN	3x42032 4x42032 I:42031	65535,0xFFFF B:FF FF			UINT16 R/O	
		Measured average PT1000 temperature RTDlx:65535=655,35°K				
AIOX:AVERAGE RTD INPUTS NI1000-DIN43760 KELVIN						
AVERAGE RTD INPUT1 AS NI1000-DIN43760 IN KELVIN	3x42033 4x42033 I:42032	65535,0xFFFF B:FF FF			UINT16 R/O	

		Measured average NI1000-DIN43760 temperature RTDlx:65535=655,35°K		
Average value of measured RTD sensor linearized as NI1000-DIN43760 sensor in Kelvin*100 in the range of 22315 to 40315 for 223.15 to 403.15 °K 65533,0xFFFF: Measured value is below 223,15°K 65534,0xFFFF: Measured value is above 403,15°K 65535,0xFFFF: The channel is not configured as RTD input				
AVERAGE RTD INPUT2 AS NI1000-DIN43760 IN KELVIN	3x42034 4x42034 I:42033	65535,0xFFFF B:FF FF		UINT16 R/O
		Measured average NI1000-DIN43760 temperature RTDlx:65535=655,35°K		
AVERAGE RTD INPUT3 AS NI1000-DIN43760 IN KELVIN	3x42035 4x42035 I:42034	65535,0xFFFF B:FF FF		UINT16 R/O
		Measured average NI1000-DIN43760 temperature RTDlx:65535=655,35°K		
AVERAGE RTD INPUT4 AS NI1000-DIN43760 IN KELVIN	3x42036 4x42036 I:42035	65535,0xFFFF B:FF FF		UINT16 R/O
		Measured average NI1000-DIN43760 temperature RTDlx:65535=655,35°K		
AIOX:AVERAGE RTD INPUTS PT100 FAHRENHEIT				
AVERAGE RTD INPUT1 AS PT100 IN FAHRENHEIT	3x42037 4x42037 I:42036	-32768,0x8000 B:80 00		SINT16 R/O
		Measured average PT100 temperature RTDlx:-32768=N/V		
Average value of measured RTD sensor value linearized as PT100 sensor in Fahrenheit*100 in the range of -5800 to +26600 for -58.0 to +266.0 °F -32766,0x8002: Measured value is below -58°C -32767,0x8001: Measured value is above +266°C -32768,0x8000: The channel is not configured as RTD input				
AVERAGE RTD INPUT2 AS PT100 IN FAHRENHEIT	3x42038 4x42038 I:42037	-32768,0x8000 B:80 00		SINT16 R/O
		Measured average PT100 temperature RTDlx:-32768=N/V		
AVERAGE RTD INPUT3 AS PT100 IN FAHRENHEIT	3x42039 4x42039 I:42038	-32768,0x8000 B:80 00		SINT16 R/O
		Measured average PT100 temperature RTDlx:-32768=N/V		
AVERAGE RTD INPUT4 AS PT100 IN FAHRENHEIT	3x42040 4x42040 I:42039	-32768,0x8000 B:80 00		SINT16 R/O
		Measured average PT100 temperature RTDlx:-32768=N/V		
AIOX:AVERAGE RTD INPUTS PT1000 FAHRENHEIT				
AVERAGE RTD INPUT1 AS PT1000 IN FAHRENHEIT	3x42041 4x42041 I:42040	-32768,0x8000 B:80 00		SINT16 R/O
		Measured average PT1000 temperature RTDlx:-32768=N/V		

Average value of measured RTD sensor value linearized as PT1000 sensor in Fahrenheit*100 in the range of -5800 to +26600 for -58.0 to +266.0 °F
 -32766,0x8002: Measured value is below -58°C
 -32767,0x8001: Measured value is above +266°C
 -32768,0x8000: The channel is not configured as RTD input

AVERAGE RTD INPUT2 AS PT1000 IN FAHRENHEIT	3x42042 4x42042 I:42041	-32768,0x8000 B:80 00			SINT16 R/O	
		Measured average PT1000 temperature RTDlx:-32768=N/V				
AVERAGE RTD INPUT3 AS PT1000 IN FAHRENHEIT	3x42043 4x42043 I:42042	-32768,0x8000 B:80 00			SINT16 R/O	
		Measured average PT1000 temperature RTDlx:-32768=N/V				
AVERAGE RTD INPUT4 AS PT1000 IN FAHRENHEIT	3x42044 4x42044 I:42043	-32768,0x8000 B:80 00			SINT16 R/O	
		Measured average PT1000 temperature RTDlx:-32768=N/V				

AIOX:AVERAGE RTD INPUTS NI1000-DIN43760 FAHRENHEIT

AVERAGE RTD INPUT1 AS NI1000-DIN43760 IN FAHRENHEIT	3x42045 4x42045 I:42044	-32768,0x8000 B:80 00			SINT16 R/O	
		Measured average NI1000-DIN43760 temperature RTDlx:-32768=N/V				

Average value of measured RTD sensor value linearized as NI1000-DIN43760 sensor in Fahrenheit*100 in the range of -5800 to +26600 for -58.0 to +266.0 °F
 -32766,0x8002: Measured value is below -58°C
 -32767,0x8001: Measured value is above +266°C
 -32768,0x8000: The channel is not configured as RTD input

AVERAGE RTD INPUT2 AS NI1000-DIN43760 IN FAHRENHEIT	3x42046 4x42046 I:42045	-32768,0x8000 B:80 00			SINT16 R/O	
		Measured average NI1000-DIN43760 temperature RTDlx:-32768=N/V				
AVERAGE RTD INPUT3 AS NI1000-DIN43760 IN FAHRENHEIT	3x42047 4x42047 I:42046	-32768,0x8000 B:80 00			SINT16 R/O	
		Measured average NI1000-DIN43760 temperature RTDlx:-32768=N/V				
AVERAGE RTD INPUT4 AS NI1000-DIN43760 IN FAHRENHEIT	3x42048 4x42048 I:42047	-32768,0x8000 B:80 00			SINT16 R/O	
		Measured average NI1000-DIN43760 temperature RTDlx:-32768=N/V				

AIOX:RTD INPUTS OHM*100

AVERAGE RTD INPUT1 IN OHM*100	3x42501 4x42501 I:42500	4294967295,0xFFFFFFFF B:FF FF FF FF			UINT32 R/O	
		Measured average ohm value of RTDlx:-1=N/V				

Measured average RTD in Ohm*100
 =0xFFFFFFFF: The channel is not configured as RTD input

AVERAGE RTD INPUT2 IN OHM*100	3x42503 4x42503 I:42502	4294967295,0xFFFFFFFF B:FF FF FF FF			UINT32 R/O	
		Measured average ohm value of RTDlx:-1=N/V				
AVERAGE RTD INPUT3 IN OHM*100	3x42505 4x42505 I:42504	4294967295,0xFFFFFFFF B:FF FF FF FF			UINT32 R/O	
		Measured average ohm value of RTDlx:-1=N/V				
AVERAGE RTD INPUT4 IN OHM*100	3x42507 4x42507 I:42506	4294967295,0xFFFFFFFF B:FF FF FF FF			UINT32 R/O	
		Measured average ohm value of RTDlx:-1=N/V				
AIOX:AVERAGE RTD INPUTS OHM*100						
AVERAGE RTD INPUT1 IN OHM*100	3x42509 4x42509 I:42508	4294967295,0xFFFFFFFF B:FF FF FF FF			UINT32R R/O	
		Measured average ohm value of RTDlx:-1=N/V				
Measured average RTD in Ohm*100 =0xFFFFFFFF: The channel is not configured as RTD input						
AVERAGE RTD INPUT2 IN OHM*100	3x42511 4x42511 I:42510	4294967295,0xFFFFFFFF B:FF FF FF FF			UINT32R R/O	
		Measured average ohm value of RTDlx:-1=N/V				
AVERAGE RTD INPUT3 IN OHM*100	3x42513 4x42513 I:42512	4294967295,0xFFFFFFFF B:FF FF FF FF			UINT32R R/O	
		Measured average ohm value of RTDlx:-1=N/V				
AVERAGE RTD INPUT4 IN OHM*100	3x42515 4x42515 I:42514	4294967295,0xFFFFFFFF B:FF FF FF FF			UINT32R R/O	
		Measured average ohm value of RTDlx:-1=N/V				

Register NAME Command NAME	MODBUS Register ASCII Command	Register VALUE ASCII Command	NEW REAL VALUE	NEW VALUE	DATA TYPE	DO WRITE
AIOX CHIP TEMPERATURE						
TEMPERATURE CHIP 1 IN CELSIUS	3x43001 4x43001 !43000	464,0x01D0 B:01 D0			UINT16 R/O	
Actual measured temperature of CHIPx:46,4°C						
Current measured chip temperature for CHIPx in x*10 °C. Each CHIP supports 4 AIOX channels.						
AIOX CHIP TEMPERATURE						
AVERAGE TEMPERATURE CHIP 1 IN CELSIUS	3x43002 4x43002 !43001	464,0x01D0 B:01 D0			UINT16 R/O	
Measured average temperature of CHIPx:46,4°C						
Measured average chip temperature for CHIPx in x*10 °C. Each CHIP supports 4 AIOX channels.						
AIOX CHIP VOLTAGES						
Vavdd CHIP 1 IN VOLT	3x43003 4x43003 !43002	146,0x0092 B:00 92			UINT16 R/O	
Actual measured voltage Vavdd of CHIPx:14,6V						
Current measured voltage Vavdd for CHIPx in x*10 Volts. Each CHIP supports 4 AIOX channels. This must be >14.5V, if not, there is a severe wiring or other hardware issue!						
AIOX CHIP VOLTAGES						
AVERAGE Vavdd CHIP 1 IN VOLT	3x43004 4x43004 !43003	146,0x0092 B:00 92			UINT16 R/O	
Measured average voltage Vavdd of CHIPx:14,6V						
Current measured voltage Vavdd for CHIPx in x*10 Volts. Each CHIP supports 4 AIOX channels. This must be >14.5V, if not, there is a severe wiring or other hardware issue!						
AIOX CHIP VOLTAGES						
Vagnd CHIP 1 IN VOLT	3x43005 4x43005 !43004	0,0x0000 B:00 00			UINT16 R/O	
Actual measured voltage Vagnd of CHIPx:0,0V						
Current measured voltage Vagnd for CHIPx in x*10 Volts. Each CHIP supports 4 AIOX channels. This must be 0V, if not, there is a severe wiring or other hardware issue!						
AIOX CHIP VOLTAGES						
AVERAGE Vagnd CHIP 1 IN VOLT	3x43006 4x43006 !43005	0,0x0000 B:00 00			UINT16 R/O	
Measured average voltage Vagnd of CHIPx:0,0V						
Current measured voltage Vagnd for CHIPx in x*10 Volts. Each CHIP supports 4 AIOX channels. This must be 0V, if not, there is a severe wiring or other hardware issue!						

AIOX CHIP STATUS						
LIVE STATUS CHIP 1	3x43007 4x43007 I:43006	30720,0x7800 B:78 00			UINT16 R/O	
		Actual live status of CHIPx:7800				

Current live status for CHIPx. Each CHIP supports 4 AIOX channels.
Each result bit stands for a different state:
Bit 0: VI_ERR_CURR_A: Status of channel A:Voltage or current error detected on Channel A. This bit is interpreted differently depending on which of the following IO function selected:
Voltage output: short-circuit error. The error condition is debounced for 2 ms before the status bit is set.
Current output: open circuit error. The error condition is debounced for 2 ms before the status bit is set.
Current input, loop powered: short-circuit error. A short to ground is detected
Current input, externally powered: short-circuit error. A current source >25 mA is detected
Bit 1: VI_ERR_CURR_B: Status of voltage input B. Same like VI_ERR_CURR_A
Bit 2: VI_ERR_CURR_C: Status of voltage input C. Same like VI_ERR_CURR_A
Bit 3: VI_ERR_CURR_D: Status of voltage input D. Same like VI_ERR_CURR_A
Bit 4: HI_TEMP_STATUS: If the die temperature is typically at or above 115°C, the HI_TEMP_STATUS bit is asserted
Bit 5: CHARGE_PUMP_STATUS: Charge pump error detected.
Bit 6: ALDO5V_STATUS: ALDO5V Power Supply Monitor Error. This bit is asserted when the ALDO5V pin falls below 4.05 V. Usually ~5V.
Bit 7: AVDD_STATUS: AVDD Power Supply Monitor Error. This bit is asserted when the AVDD pin falls below 9.26 V. Usually ~17V.
Bit 8: DVCC_STATUS: DVCC Power Supply Monitor Error. This bit is asserted when the DVCC pin falls below 1.93 V. Usually ~3.3V.
Bit 9: ALDO1V8_STATUS: ALDO1V8 Power Supply Monitor Error. This bit is asserted when the ALDO1V8 pin falls below 1.35 V. Usually ~1.8V.
Bit 10-12: ADC_CH_CURR: Current converted channel of the ADC (0:A, 1:B, 2:C, 3:D, 4:Diagnostic 0, 5:Diagnostic 1, 6:Diagnostic 2, 7:Diagnostic 3)
Bit 13: ADC_BUSY: ADC busy status bit.
Bit 14: ADC_DATA_RDY:ADC data ready. The ADC_DATA_RDY bit asserts when a conversion cycle has completed. The bit stays asserted until a user writes 1 to clear the bit. In single conversion mode, the ADC_RDY pin follows the ADC_DATA_RDY bit and only deasserts when the ADC_DATA_RDY bit is cleared. In continuous conversion mode, the ADC_RDY pin returns high after 24 µs.
Bit 15: RESERVED: Reserved

AIOX CHIP STATUS						
ALERT STATUS CHIP 1	3x43008 4x43008 I:43007	33792,0x8400 B:84 00			UINT16 R/O	
		Actual alert status of CHIPx:8400				

Current alert status for CHIPx. Each CHIP supports 4 AIOX channels.
Each result bit stands for a different state:
Bit 0: VI_ERR_CURR_A: Status of channel A:Voltage or current error detected on Channel A. This bit is interpreted differently depending on which of the following IO function selected:
Voltage output: short-circuit error. The error condition is debounced for 2 ms before the status bit is set.
Current output: open circuit error. The error condition is debounced for 2 ms before the status bit is set.
Current input, loop powered: short-circuit error. A short to ground is detected
Current input, externally powered: short-circuit error. A current source >25 mA is detected
Bit 1: VI_ERR_CURR_B: Status of voltage input B. Same like VI_ERR_CURR_A
Bit 2: VI_ERR_CURR_C: Status of voltage input C. Same like VI_ERR_CURR_A
Bit 3: VI_ERR_CURR_D: Status of voltage input D. Same like VI_ERR_CURR_A
Bit 4: HI_TEMP_STATUS: If the die temperature is typically at or above 115°C, the HI_TEMP_STATUS bit is asserted
Bit 5: CHARGE_PUMP_STATUS: Charge pump error detected.
Bit 6: ALDO5V_STATUS: ALDO5V Power Supply Monitor Error. This bit is asserted when the ALDO5V pin falls below 4.05 V. Usually ~5V.
Bit 7: AVDD_STATUS: AVDD Power Supply Monitor Error. This bit is asserted when the AVDD pin falls below 9.26 V. Usually ~17V.
Bit 8: DVCC_STATUS: DVCC Power Supply Monitor Error. This bit is asserted when the DVCC pin falls below 1.93 V. Usually ~3.3V.
Bit 9: ALDO1V8_STATUS: ALDO1V8 Power Supply Monitor Error. This bit is asserted when the ALDO1V8 pin falls below 1.35 V. Usually ~1.8V.
Bit 10: ADC_CONV_ERR: ADC Conversion Error. ADC results may be outside the selected measurement range.
Bit 11: ADC_SAT_ERR: ADC Saturation Error. ADC may be outside the user selected measurement range.
Bit 12: SPI_SCLK_CNT_ERR: SPI SCLK count error detected. This bit is asserted if an SPI command is applied but 32 SCLKs are not provided.
Bit 13: SPI_CRC_ERR: SPI CRC error detected. This bit is asserted if an invalid CRC is received.
Bit 14: CAL_MEM_ERR: Calibration Memory Error. This flag asserts under the following two conditions: When a calibration memory CRC error or an uncorrectable error correcting code (ECC) error is detected on the calibration memory upload. It is not possible to clear this bit if there is a CRC error or uncorrectable ECC error. It is recommended to reset the device and check the supplies in this situation. When there is an attempted SPI access to a register before the calibration memory refresh is complete. Do not address the device until the calibration memory is refreshed. Writing 1 to this bit clears the flag, if the flag is asserted due to this condition.
Bit 15: RESET_OCCURRED: Reset occurred. This bit is asserted after a reset event, which asserts the ALERT pin after the reset. Write a 1 to this bit to clear the flag. Note that a mask bit is not provided for this bit.

AIOX SPI STATUS

SPI ERRORS CHIP 1	3x43009 4x43009 l:43008	0,0x0000 B:00 00			UINT16 R/O	
		Actual SPI error counter of CHIPx:0 error(s)				

Current SPI error counter for CHIPx. Each CHIP supports 4 AIOX channels.
This command shows the acutal SPI errors since power up for every chip

AIOX STATE MACHINES

STATE MACHINE CHIP 1	3x43010 4x43010 l:43009	12070,0x2F26 B:2F 26			UINT16 R/O	
		Actual state of CHIPx:12070				

This command shows the acutal state of the internal communication state machine for CHIPx

AIOX ONLINE

IS ONLINE CHIP 1	3x43011 4x43011 l:43010	1,0x0001 B:00 01			UINT16 R/O	
		Is CHIPx online:1=YES				

This command shows the acutal state of the internal communication state machine for CHIPx

AIOX CLEAR ALARM STATE

CLEAR ALERT STATES CHIP 1	3x43012 4x43012 l:43011	0,0x0000 B:00 00	65535		UINT16 R/W	YES
		0:VI_ERR_A		1:RESET FLAG		
		1:VI_ERR_B		1:RESET FLAG		

		2:VI_ERR_C		1:RESET FLAG		
		3:VI_ERR_D		1:RESET FLAG		
		4:HI_TEMP_ERR		1:RESET FLAG		
		5:CHARGE_PUMP_ERR		1:RESET FLAG		
		6:ALDO5V_ERR		1:RESET FLAG		
		7:AVDD_ERR		1:RESET FLAG		
		8:DVCC_ERR		1:RESET FLAG		
		9:ALDO1V8_ERR		1:RESET FLAG		
		10:ADC_CONV_ERR		1:RESET FLAG		
		11:ADC_SAT_ERR		1:RESET FLAG		
		12:SPI_SCLK_ERR		1:RESET FLAG		
		13:SPI_CRC_ERR		1:RESET FLAG		
		14:CAL_MEM_ERR		1:RESET FLAG		
		15:RESET_OCCURED		1:RESET FLAG		
With this command you can reset individual alert bits in the alert status register of CHIPx						
AIOX RESET STATE MACHINE						
RESET CHIP 1 STATE MACHINE	3x43013 4x43013 1:43012	0,0x0000 B:00 00	1	1:RESET STATE MACHINE	UINT16 R/W	YES
This command restarts the state machine for chip CHIPx . The affected chip will be resetted & initialized completely						

Register NAME Command NAME	MODBUS Register ASCII Command	Register VALUE ASCII Command	NEW REAL VALUE	NEW VALUE	DATA TYPE	DO WRITE
AIOX CONFIG OUTPUT VALUES						
CONFIG OUTPUT VALUE AIOX1	3x44001 4x44001 I:44000	65535,0xFFFF B:FF FF	100	1	UINT16 R/W	YES
		Actual config value for AIOx:N/A		ENTER NEW CONFIG VALUE FOR AIOx		
This command sets for all outputs the standard value in Volt*100 or in mA*100, which are used when the controller is restartet or a watchdog condition has ocured and the channel is used as voltage output or current output. For voltage outputs the range is 0 to 1100 (0 to 11,0V). For current outputs the range is 0 to 2500 (0 to 25mA). All IOs with a different usage type will return 65535,0xFFFF.						
CONFIG OUTPUT VALUE AIOX2	3x44002 4x44002 I:44001	65535,0xFFFF B:FF FF	200	2	UINT16 R/W	YES
		Actual config value for AIOx:N/A		ENTER NEW CONFIG VALUE FOR AIOx		
CONFIG OUTPUT VALUE AIOX3	3x44003 4x44003 I:44002	65535,0xFFFF B:FF FF	300	3	UINT16 R/W	YES
		Actual config value for AIOx:N/A		ENTER NEW CONFIG VALUE FOR AIOx		
CONFIG OUTPUT VALUE AIOX4	3x44004 4x44004 I:44003	65535,0xFFFF B:FF FF	400	4	UINT16 R/W	YES
		Actual config value for AIOx:N/A		ENTER NEW CONFIG VALUE FOR AIOx		
INTER PROCESSOR COMMUNICATION						
AIOX IS ONLINE	3x50000 4x50000 I:49999	1,0x0001 B:00 01			UINT16 R/O	
		Actual communication status co-processor to AIOX processor:OK				
This command returns the actual state of the serial communication between the ARM co-processor and the additional processor for the AIOX. =1: Currently the communication is fine =0: There is a mayor problem/hardware fault between the two processors						