

Register NAME	MODBUS Register	Register VALUE	DATA TYPE	DO WRITE
<b>ASCII COMMANDS</b>				
HEART BEAT	ASCII READ COMMAND	#HB<CR> Result: #HB<CR>	ASCII	
	TX	#255,HB<CR>		
	RX	#255,HB<CR>		
Sends an Heartbeat to test the communication				
GET VERSION	ASCII READ COMMAND	#VERSION<CR> Result: #VERSION:<VersionHi>,<VersionMed>,<VersionLo><CR>	ASCII	
	TX	#255,VERSION<CR>		
	RX	#255,VERSION:1.1.0<CR>		
		Actual SW version:1.1.0		
Returns the version number of the module VersionHi: Version number high (1..255) VersionMed: Version number medium (1..255) VersionLo: Version number low (1..255)				
GET TYPE	ASCII READ COMMAND	#TYPE<CR> Result: #TYPE:<Type><CR>	ASCII	
	TX	#255,TYPE<CR>		
	RX	#255,TYPE:RESI-C4-A-16DI15DO16AIOX<CR>		
		Actual module type:RESI-C4-A-16DI15DO16AIOX		
Returns the actual module type				
GET FEATURES	ASCII READ COMMAND	#FTRS<CR> Result: #FTRS:<Type><CR>	ASCII	
	TX	#255,FTRS<CR>		
	RX	#255,FTRS:RESI-C4-A-16DI15DO16AIOX,RS485,DI:16,DO:15,AIOX:16,DOIC:MAX14915<CR>		
		Actual module type:N/A		
		Number of digital inputs:N/A		
		Type of digital inputs:N/A		
Returns the actual module features				
GET OWNER	ASCII READ COMMAND	#OWNER<CR> Result: #OWNER:<Owner><CR>	ASCII	
	TX	#255,OWNER<CR>		
	RX	#255,OWNER:RESI<CR>		
		Actual owner:RESI		
Returns the actual owner of the module				

GET CREATOR	ASCII READ COMMAND	#CREATOR<CR> Result: #CREATOR:<Creator><CR>	ASCII	
	TX	#255,CREATOR<CR>		
	RX	#255,CREATOR:DI HC SIGL,MSC<CR>		
		Actual creator:DI HC SIGL,MSC		
Returns the actual creator of the module				
GET COPYRIGHT	ASCII READ COMMAND	#COPYRIGHT<CR> Result: #COPYRIGHT:<Copyright><CR>	ASCII	
	TX	#255,COPYRIGHT<CR>		
	RX	#255,COPYRIGHT:2015-24 BY RESI AND DI HC SIGL,MSC WWW.RESI.CC<CR>		
		Actual copyright:2015-24 BY RESI AND DI HC SIGL,MSC WWW.RESI.CC		
Returns the actual copyright of the module				
GET SERIAL NUMBER	ASCII READ COMMAND	#SN<CR> Result: #SN:<Serial><CR>	ASCII	
	TX	#255,SN<CR>		
	RX	#255,SN:36002B000F53554637303820<CR>		
		Actual serial number:36002B000F53554637303820		
Returns the actual serial number of the module				
SET BOX NAME	ASCII WRITE COMMAND BOXNAME	#SETBOXNAME:<BOXNAME><CR> Result: #OK<CR> MYBOX	ASCII	YES
	TX	#255,SETBOXNAME:MYBOX<CR>		
	RX	N/A		
Sets a new box name for the controller				
GET BOX NAME	ASCII READ COMMAND	#BOXNAME<CR> Result: #BOXNAME:<BoxName><CR>	ASCII	
	TX	#255,BOXNAME<CR>		
	RX	#255,BOXNAME:NONAME<CR>		
		Actual box name:NONAME		
Returns the actual box name of the module. If no box name is defined, the value NONAME is returned				
GET INTERNAL STATUS	ASCII READ COMMAND	#INTSTAT<CR> Result: #INTSTAT:<Status><CR>	ASCII	
	TX	#255,INTSTAT<CR>		
	RX	#255,INTSTAT:I2C1:0,I2C2:0<CR>		
		Actual internal status:I2C1		
Returns the device specific internal status				

GET DIP SWITCH	ASCII READ COMMAND	#GDIP<CR> Result: #GDIP:<DIPSwitchDec>,<DIPSwitchHex><CR>	ASCII	
	TX	#255,GDIP<CR>		
	RX	#255,GDIP:0,0x0<CR>		
		Actual DIP SWITCH settings:00000000		
Returns the actual setting of the Dip switches as decimal number and as hexadecimal number. DIPSwitchDec DIPSwitchHex The current value of the DIP switches: Bit 0: DIP Switch 1 (=0:OFF, =1:ON) Bit 1: DIP Switch 2 (=0:OFF, =1:ON) Bit 2: DIP Switch 3 (=0:OFF, =1:ON) Bit 3: DIP Switch 4 (=0:OFF, =1:ON) Bit 4: DIP Switch 5 (=0:OFF, =1:ON) Bit 5: DIP Switch 6 (=0:OFF, =1:ON) Bit 6: DIP Switch 7(=0:OFF, =1:ON) Bit 7: DIP Switch 8 (=0:OFF, =1:ON)				
<b>SYSTEM COMMANDS</b>				
RESET	ASCII WRITE COMMAND	#RST<CR> Result: #OK<CR>	ASCII	NO
	TX	#255,RST<CR>		
	RX	N/A		
Executes a software reset (Reboot) of the module. Be aware that you will lose all serial interfaces in USB!!!				
FACTORY RESET	ASCII WRITE COMMAND	#FRST<CR> Result: #OK<CR>	ASCII	NO
	TX	#255,FRST<CR>		
	RX	N/A		
Executes a factory reset of the module				
WATCHDOG TIMER	ASCII WRITE COMMAND	#WD:<WDTIME><CR> Result: #OK<CR>	ASCII	NO
	WDTIME	10		
	TX	#255,WD:10<CR>		
	RX	N/A		
Enables or disables the WATCHDOG Timer for the Raspberry Pi module. WDTIME: 1..3600000: Time for Watchdog in Milliseconds (Maximum 60 Minutes) =0: No Watchdog is generated HINT: The Watchdog is internally handled every 10ms, so every value below 10 will reset immediately the Raspberry Pi computer.				
SET IO WATCHDOG TIMER	ASCII WRITE COMMAND	#SIOWATCHDOG:<IOWDTIME><CR> Result: #OK<CR>	ASCII	NO
	IOWDTIME	10		
	TX	#255,SIOWATCHDOG:10<CR>		

	RX	N/A		
Sets a new time for the internal IO WATCHDOG Timer. <IOWDTIME> is a time in 100ms. =0: No IO Watchdog is used HINT: The Watchdog is internally handled every 100ms, if the Timer reaches 0, all internal IOS will be set to a preconfigured state. Every ASCII command or MODBUS request will reset this timer.				
GET IO WATCHDOG TIMER	ASCII READ COMMAND	#GIOWATCHDOG<CR> Result: #GIOWATCHDOG::<IOWDTIME><CR>	ASCII	
	TX	#255,GIOWATCHDOG<CR>		
	RX	#255,GIOWATCHDOG:0,0x0<CR>		
Returns the actual time for the internal IO WATCHDOG Timer. <IOWDTIME> is a time in 100ms. =0: No IO Watchdog is used HINT: The Watchdog is internally handled every 100ms, if the Timer reaches 0, all internal IOS will be set to a preconfigured state. Every ASCII command or MODBUS request will reset this timer.				
<b>CPU PARAMETERS</b>				
GET CPU VOLTAGE	ASCII READ COMMAND	#GCPUTEMP<CR> Result: #GCPUTEMP:<CPUTemp><CR>	ASCII	
	TX	#255,GCPUTEMP<CR>		
	RX	#255,GCPUTEMP:38.8966<CR>		
		Actual internal temperature of CPU:38.8966°C		
Current internal temperature of CPU in ° Celsius.				
GET CPU VOLTAGE	ASCII READ COMMAND	#GCPUVOLT<CR> Result: #GCPUVOLT:<CPUVoltage><CR>	ASCII	
	TX	#255,GCPUVOLT<CR>		
	RX	#255,GCPUVOLT:3.3254<CR>		
		Actual supply voltage of CPU:3.3254V		
Current internal supply voltage of CPU in Volt.				
GET CPU BACKUP	ASCII READ COMMAND	#GCPUBACK<CR> Result: #GCPUBACK:<CPUBackupVoltage><CR>	ASCII	
	TX	#255,GCPUBACK<CR>		
	RX	#255,GCPUBACK:3.1871<CR>		
		Actual backup voltage of CPU for RTC:3.1871V		
Current internal backup voltage of CPU for the RTC in Volt.				

Register NAME	MODBUS Register	Register VALUE	DATA TYPE	DO WRITE
<b>ASCII COMMANDS:REAL TIME CLOCK</b>				
GET REAL TIME CLOCK	ASCII READ COMMAND	#GRTC<CR> Result: #GRTC:YMD,<YEAR>,<MONTH>,<DAY>,HMS,<HOUR>,<MINUTE>,<SECOND>,<WEEKDAY> ,DOK,<DATEOK>,TOK,<TIMEOK><CR>	ASCII	
	TX	#255,GRTC<CR>		
	RX	#255,GRTC:YMD,24,3,6,HMS,14,19,9,WED,DOK,1,TOK,1<CR>		
		Actual date DD.MM.YYYY:6.3.2024		
		Actual time HH.MM.SS (24h):14:19:09		
		Actual Weekday:WED		
		Battery buffered date is ok:YES		
		Battery buffered time is ok:YES		
Shows current RTC time of battery backup RTC on module				
<b>ASCII COMMANDS:REAL TIME CLOCK</b>				
SET REAL TIME CLOCK	ASCII WRITE COMMAND	#SRTC:YMD,<YEAR>,<MONTH>,<DAY>,HMS,<HOUR>,<MINUTE>,<SECOND>,<WEEKDAY><CR> Result: #OK<CR>	ASCII	YES
	YEAR	2024		
	MONTH	04		
	DAY	13		
	HOUR	18		
	MINUTE	30		
	SECOND	41		
	WEEKDAY	SAT		
	TX	#255,SRTC:YMD,24,04,13,HMS,18,30,41,SAT<CR>		
	RX	#255,OK<CR>		
Executes a software reset (Reboot) of the module.				

Register NAME	MODBUS Register	Register VALUE	DATA TYPE	DO WRITE
<b>ASCII COMMANDS:FRAM</b>				
GET FRAMSIZE	ASCII READ COMMAND	#GFRAMSIZE <CR> Result: #GFRAMSIZE:<FRAMType>,<FRAMSize>,<UsedSizeDEC>,<UsedSizeHEX> <CR>	ASCII	
	TX	#255,GFRAMSIZE <CR>		
	RX	#255,GFRAMSIZE:FM25L16B_G,2kB,186,0xBA <CR>		
Reads the actual type and size of the used FRAM. The <UsedSize> describes the internal used space in bytes of the FRAM				
<b>ASCII COMMANDS:FRAM</b>				
GET FRAM16	ASCII READ COMMAND	#GFRAM16:<INDEX> <CR> Result: #GFRAM16:<INDEXDEC>,<VALUEDEC>,<INDEXHEX>,<VALUEHEX> <CR> or #GFRAM16:<INDEXDEC>,<ERR>,<INDEXHEX>,<ERR><CR>	ASCII	
	INDEX	350		
	TX	#255,GFRAM16:350 <CR>		
	RX	#255,GFRAM16:350,1234,0x15E,0x4D2 <CR>		
		FRAM Index in bytes:350		
		FRAM Value in decimal:1234		
Reads the actual UINT16 value (2 bytes) of FRAM memory <INDEX>. <INDEX> is a BYTE index in the FRAM strogae starting with 0.				
GET FRAM32	ASCII READ COMMAND	#GFRAM32:<INDEX> <CR> Result: #GFRAM32:<INDEXDEC>,<VALUEDEC>,<INDEXHEX>,<VALUEHEX> <CR> or #GFRAM32:<INDEXDEC>,<ERR>,<INDEXHEX>,<ERR><CR>	ASCII	
	INDEX	360		
	TX	#255,GFRAM32:360 <CR>		
	RX	#255,GFRAM32:360,123456,0x168,0x1E240 <CR>		
		FRAM Index in bytes:360		
		FRAM Value in decimal:123456		
Reads the actual UINT32 value 4 bytes) of FRAM memory <INDEX>. <INDEX> is a BYTE index in the FRAM strogae starting with 0.				
GET FRAMDBL	ASCII READ COMMAND	#GFRAMDBL:<INDEX> <CR> Result: #GFRAMDBL:<INDEXDEC>,<VALUEDBL>,<INDEXHEX>,<VALUEDBL> <CR> or #GFRAMDBL:<INDEXDEC>,<ERR>,<INDEXHEX>,<ERR><CR>	ASCII	
	INDEX	400		
	TX	#255,GFRAMDBL:400 <CR>		
	RX	#255,GFRAMDBL:400,3.1415926,0x190,3.1415926 <CR>		
		FRAM Index in bytes:400		
		FRAM Value in decimal:3.1415926		
Reads the actual DOUBLE value 8 bytes) of FRAM memory <INDEX>. <INDEX> is a BYTE index in the FRAM strogae starting with 0.				
<b>ASCII COMMANDS:FRAM</b>				

SET FRAM16	ASCII WRITE COMMAND	#SFRAM16:<INDEX>,<VALUE><CR> Result: #SFRAM16:OK<CR> or #SFRAM16:ERR<CR>	ASCII	YES
	INDEX	350		
	VALUE	1234		
	TX	#255,SFRAM16:350,1234<CR>		
	RX	#255,SFRAM16:OK<CR>		
Writes a new UINT16 value (2 byte) into FRAM memory <INDEX>. <INDEX> is a BYTE index in the FRAM strogae starting with 0.				
SET FRAM32	ASCII WRITE COMMAND	#SFRAM32:<INDEX>,<VALUE><CR> Result: #SFRAM32:OK<CR> or #SFRAM32:ERR<CR>	ASCII	YES
	INDEX	360		
	VALUE	123456		
	TX	#255,SFRAM32:360,123456<CR>		
	RX	#255,SFRAM32:OK<CR>		
Writes a new UINT32 value (4 byte) into FRAM memory <INDEX>. <INDEX> is a BYTE index in the FRAM strogae starting with 0.				
SET FRAMDBL	ASCII WRITE COMMAND	#SFRAMDBL:<INDEX>,<DOUBLEVALUE><CR> Result: #SFRAMDBL:OK<CR> or #SERAMDBL:ERR<CR>	ASCII	YES
	INDEX	400		
	DOUBLEVALUE	3,1415926		
	TX	#255,SFRAMDBL:400,3.1415926<CR>		
	RX	#255,SFRAMDBL:OK<CR>		
Writes a new DOUBLE value (8 byte) into FRAM memory <INDEX>. <INDEX> is a BYTE index in the FRAM strogae starting with 0.				

Register NAME	MODBUS Register	Register VALUE	DATA TYPE	DO WRITE
<b>LED STATUS:LED1:GREEN</b>				
GET LED1	ASCII READ COMMAND	#GLED1<CR> Result: #GLED1:<LEDMode>,<LEDStateDec>,<LEDStateHex><CR>	ASCII	
	TX	#255,GLED1<CR>		
	RX	#255,GLED1:BLINK,0,0x0<CR>		
		Actual LED state:BLINK LED ist currently 0		
Returns the actual state of the LED1:GREEN on the cover of module				
<b>LED COMMANDS:LED1:GREEN</b>				
SET LED1 OFF	ASCII WRITE COMMAND	#SL1OFF<CR> Result: #OK<CR>	ASCII	YES
	TX	#255,SL1OFF<CR>		
	RX	#255,OK<CR>		
Sets the current state of the LED1:GREEN on the cover of module to OFF				
SET LED1 ON	ASCII WRITE COMMAND	#SL1ON<CR> Result: #OK<CR>	ASCII	YES
	TX	#255,SL1ON<CR>		
	RX	#255,OK<CR>		
Sets the current state of the LED1:GREEN on the cover of module to ON				
SET LED1 INVERT	ASCII WRITE COMMAND	#SL1INV<CR> Result: #OK<CR>	ASCII	YES
	TX	#255,SL1INV<CR>		
	RX	#255,OK<CR>		
Inverts the current state of the LED1:GREEN on the cover of module from ON to OFF or from OFF to ON				
SET LED1 PULSE	ASCII WRITE COMMAND	#SL1PULSE:<PULSETIME><CR> Result: #OK<CR>	ASCII	YES
	PULSETIME	1000		
	TX	#255,SL1PULSE:1000<CR>		
	RX	#255,OK<CR>		
Sets the current state of the LED1:GREEN on the cover of module to PULSE and defines the one time pulse duration in Milliseconds between 1 and 60000				
SET LED1 BLINK	ASCII WRITE COMMAND	#SL1BLINK:<BLINKTIME><CR> Result: #OK<CR>	ASCII	YES
	BLINKTIME	1000		
	TX	#255,SL1BLINK:1000<CR>		
	RX	#255,OK<CR>		



Sets the current state of the LED1:GREEN on the cover of module to PULSE and defines the one time pulse duration in Milliseconds between 1 and 60000

SET LED1 FLASH	ASCII WRITE COMMAND	#SL1FLASH:<ONTIME>,<OFFTIME><CR> Result: #OK<CR>	ASCII	YES
	ONTIME	200		
	OFFTIME	3000		
	TX	#255,SL1FLASH:200,3000<CR>		
	RX	#255,OK<CR>		

Sets the current state of the LED1:GREEN on the cover of module to FLASH and defines the on and off intervals in Milliseconds between 20 and 600000

Register NAME	MODBUS Register	Register VALUE	DATA TYPE	DO WRITE
<b>LED STATUS:LED2:WHITE</b>				
GET LED2	ASCII READ COMMAND	#GLED2<CR> Result: #GLED2:<LEDMode>,<LEDStateDec>,<LEDStateHex><CR>	ASCII	
	TX	#255,GLED2<CR>		
	RX	#255,GLED2:ON,1,0x1<CR>		
		Actual LED state:ON LED ist currently 1		
Returns the actual state of the LED2:WHITE on the cover of module				
<b>LED COMMANDS:LED2:WHITE</b>				
SET LED2 OFF	ASCII WRITE COMMAND	#SL2OFF<CR> Result: #OK<CR>	ASCII	YES
	TX	#255,SL2OFF<CR>		
	RX	#255,OK<CR>		
Sets the current state of the LED2:WHITE on the cover of module to OFF				
SET LED2 ON	ASCII WRITE COMMAND	#SL2ON<CR> Result: #OK<CR>	ASCII	YES
	TX	#255,SL2ON<CR>		
	RX	#255,OK<CR>		
Sets the current state of the LED2:WHITE on the cover of module to ON				
SET LED2 INVERT	ASCII WRITE COMMAND	#SL2INV<CR> Result: #OK<CR>	ASCII	YES
	TX	#255,SL2INV<CR>		
	RX	#255,OK<CR>		
Inverts the current state of the LED2:WHITE on the cover of module from ON to OFF or from OFF to ON				
SET LED2 PULSE	ASCII WRITE COMMAND	#SL2PULSE:<PULSETIME><CR> Result: #OK<CR>	ASCII	YES
	PULSETIME	1000		
	TX	#255,SL2PULSE:1000<CR>		
	RX	#255,OK<CR>		
Sets the current state of the LED2:WHITE on the cover of module to PULSE and defines the one time pulse duration in Milliseconds between 1 and 60000				
SET LED2 BLINK	ASCII WRITE COMMAND	#SL2BLINK:<BLINKTIME><CR> Result: #OK<CR>	ASCII	YES
	BLINKTIME	1000		
	TX	#255,SL2BLINK:1000<CR>		
	RX	#255,OK<CR>		

Sets the current state of the LED2:WHITE on the cover of module to PULSE and defines the one time pulse duration in Milliseconds between 1 and 60000

SET LED2 FLASH	ASCII WRITE COMMAND	#SL2FLASH:<ONTIME>,<OFFTIME><CR> Result: #OK<CR>	ASCII	YES
	ONTIME	200		
	OFFTIME	3000		
	TX	#255,SL2FLASH:200,3000<CR>		
	RX	#255,OK<CR>		

Sets the current state of the LED2:WHITE on the cover of module to FLASH and defines the on and off intervals in Milliseconds between 20 and 600000

Register NAME	MODBUS Register	Register VALUE	DATA TYPE	DO WRITE
<b>LED STATUS:LED3:RED</b>				
GET LED3	ASCII READ COMMAND	#GLED3<CR> Result: #GLED3:<LEDMode>,<LEDStateDec>,<LEDStateHex><CR>	ASCII	
	TX	#255,GLED3<CR>		
	RX	#255,GLED3:OFF,0,0x0<CR>		
		Actual LED state:OFF LED ist currently 0		
Returns the actual state of the LED3:RED on the cover of module				
<b>LED COMMANDS:LED3:RED</b>				
SET LED3 OFF	ASCII WRITE COMMAND	#SL3OFF<CR> Result: #OK<CR>	ASCII	YES
	TX	#255,SL3OFF<CR>		
	RX	#255,OK<CR>		
Sets the current state of the LED3:RED on the cover of module to OFF				
SET LED3 ON	ASCII WRITE COMMAND	#SL3ON<CR> Result: #OK<CR>	ASCII	YES
	TX	#255,SL3ON<CR>		
	RX	#255,OK<CR>		
Sets the current state of the LED3:RED on the cover of module to ON				
SET LED3 INVERT	ASCII WRITE COMMAND	#SL3INV<CR> Result: #OK<CR>	ASCII	YES
	TX	#255,SL3INV<CR>		
	RX	#255,OK<CR>		
Inverts the current state of the LED3:RED on the cover of module from ON to OFF or from OFF to ON				
SET LED3 PULSE	ASCII WRITE COMMAND	#SL3PULSE:<PULSETIME><CR> Result: #OK<CR>	ASCII	YES
	PULSETIME	1000		
	TX	#255,SL3PULSE:1000<CR>		
	RX	#255,OK<CR>		
Sets the current state of the LED3:RED on the cover of module to PULSE and defines the one time pulse duration in Milliseconds between 1 and 60000				
SET LED3 BLINK	ASCII WRITE COMMAND	#SL3BLINK:<BLINKTIME><CR> Result: #OK<CR>	ASCII	YES
	BLINKTIME	1000		
	TX	#255,SL3BLINK:1000<CR>		
	RX	#255,OK<CR>		

Sets the current state of the LED3:RED on the cover of module to PULSE and defines the one time pulse duration in Milliseconds between 1 and 60000

SET LED3 FLASH	ASCII WRITE COMMAND	#SL3FLASH:<ONTIME>,<OFFTIME><CR> Result: #OK<CR>	ASCII	YES
	ONTIME	200		
	OFFTIME	3000		
	TX	#255,SL3FLASH:200,3000<CR>		
	RX	#255,OK<CR>		

Sets the current state of the LED3:RED on the cover of module to FLASH and defines the on and off intervals in Milliseconds between 20 and 600000

Register NAME	MODBUS Register	Register VALUE	DATA TYPE	DO WRITE
<b>LED STATUS:LED4:YELLOW</b>				
GET LED4	ASCII READ COMMAND	#GLED4<CR> Result: #GLED4:<LEDMode>,<LEDStateDec>,<LEDStateHex><CR>	ASCII	
	TX	#255,GLED4<CR>		
	RX	#255,GLED4:OFF,0,0x0<CR>		
		Actual LED state:OFF LED ist currently 0		
Returns the actual state of the LED4:YELLOW on the cover of module				
<b>LED COMMANDS:LED4:YELLOW</b>				
SET LED4 OFF	ASCII WRITE COMMAND	#SL4OFF<CR> Result: #OK<CR>	ASCII	YES
	TX	#255,SL4OFF<CR>		
	RX	#255,OK<CR>		
Sets the current state of the LED4:YELLOW on the cover of module to OFF				
SET LED4 ON	ASCII WRITE COMMAND	#SL4ON<CR> Result: #OK<CR>	ASCII	YES
	TX	#255,SL4ON<CR>		
	RX	#255,OK<CR>		
Sets the current state of the LED4:YELLOW on the cover of module to ON				
SET LED4 INVERT	ASCII WRITE COMMAND	#SL4INV<CR> Result: #OK<CR>	ASCII	YES
	TX	#255,SL4INV<CR>		
	RX	#255,OK<CR>		
Inverts the current state of the LED4:YELLOW on the cover of module from ON to OFF or from OFF to ON				
SET LED4 PULSE	ASCII WRITE COMMAND	#SL4PULSE:<PULSETIME><CR> Result: #OK<CR>	ASCII	YES
	PULSETIME	1000		
	TX	#255,SL4PULSE:1000<CR>		
	RX	#255,OK<CR>		
Sets the current state of the LED4:YELLOW on the cover of module to PULSE and defines the one time pulse duration in Milliseconds between 1 and 60000				
SET LED4 BLINK	ASCII WRITE COMMAND	#SL4BLINK:<BLINKTIME><CR> Result: #OK<CR>	ASCII	YES
	BLINKTIME	1000		
	TX	#255,SL4BLINK:1000<CR>		
	RX	#255,OK<CR>		

Sets the current state of the LED4:YELLOW on the cover of module to PULSE and defines the one time pulse duration in Milliseconds between 1 and 60000

SET LED4 FLASH	ASCII WRITE COMMAND	#SL4FLASH:<ONTIME>,<OFFTIME><CR> Result: #OK<CR>	ASCII	YES
	ONTIME	200		
	OFFTIME	3000		
	TX	#255,SL4FLASH:200,3000<CR>		
	RX	#255,OK<CR>		

Sets the current state of the LED4:YELLOW on the cover of module to FLASH and defines the on and off intervals in Milliseconds between 20 and 600000

Register NAME	MODBUS Register	Register VALUE	NEW REAL VALUE	NEW VALUE	DATA TYPE	DO WRITE
<b>PRODUCT INFO</b>						
HW_GROUP	3x65201 4x65201 I:65200	50176,0xC400 B:C4 00			UINT16 R/O	
This is the group of hardware of the current product						
HW_TYPE	3x65202 4x65202 I:65201	69,0x0045 B:00 45			UINT16 R/O	
This is the type of hardware of the current product						
SW_VERSION	3x65203 4x65203 I:65202	272,0x0110 B:01 10			UINT16 R/O	
SW VERSION:0.1.0						
This is the current software version of the firmware						
SW_AUTHOR	3x65204 4x65204 I:65203	21321,0x5349 B:53 49			UINT16 R/O	
This is the current software author of the firmware						
MANUFACTURER	3x65205 4x65205 I:65204	1380275017,0x52455349 B:52 45 53 49			UINT32 R/O	
This is the current software author of the firmware						
NUMBER OF DIGITAL INPUTS	3x65207 4x65207 I:65206	32,0x0020 B:00 20			UINT16 R/O	
Number of DIS:32						
This is the current software version of the firmware						
NUMBER OF DIGITAL OUTPUTS	3x65208 4x65208 I:65207	12,0x000C B:00 0C			UINT16 R/O	
Number of DOS:12						
This is the current software version of the firmware						
NUMBER OF ANALOG INPUTS	3x65209 4x65209 I:65208	0,0x0000 B:00 00			UINT16 R/O	
Number of AIS:0						
This is the current software version of the firmware						
NUMBER OF ANALOG OUTPUTS	3x65210 4x65210 I:65209	0,0x0000 B:00 00			UINT16 R/O	
Number of AOS:0						



This is the current software version of the firmware						
NUMBER OF UNIVERSAL IN/OUTPUTS	3x65211 4x65211 I:65210	16,0x0010 B:00 10			UINT16 R/O	
		Number of AIOX:16				
This is the current software version of the firmware						
NUMBER OF SPECIAL INPUTS	3x65212 4x65212 I:65211	0,0x0000 B:00 00			UINT16 R/O	
		Number of special inputs:0				
This is the current software version of the firmware						
NUMBER OF SPECIAL OUTPUTS	3x65213 4x65213 I:65212	0,0x0000 B:00 00			UINT16 R/O	
		Number of special outputs:0				
This is the current software version of the firmware						
FEATURE1	3x65214 4x65214 I:65213	2,0x0002 B:00 02			UINT16 R/O	
		Feature:RS485				
This is the feature list of the controller: 0:NONE, 1:RS232, 2:RS485, 3:KNX, 4:DALI, 5:MBUS, 6:LORA, 7:LTE, 8:2xETHERNET						
FEATURE2	3x65215 4x65215 I:65214	0,0x0000 B:00 00			UINT16 R/O	
		Feature:NONE				
FEATURE3	3x65216 4x65216 I:65215	0,0x0000 B:00 00			UINT16 R/O	
		Feature:NONE				
FEATURE4	3x65217 4x65217 I:65216	0,0x0000 B:00 00			UINT16 R/O	
		Feature:NONE				
FEATURE5	3x65218 4x65218 I:65217	0,0x0000 B:00 00			UINT16 R/O	
		Feature:NONE				
FEATURE6	3x65219 4x65219 I:65218	0,0x0000 B:00 00			UINT16 R/O	
		Feature:NONE				
FEATURE7	3x65220 4x65220 I:65219	0,0x0000 B:00 00			UINT16 R/O	

		Feature:NONE				
FEATURE8	3x65221 4x65221 I:65220	0,0x0000 B:00 00			UINT16 R/O	
		Feature:NONE				
<b>MODBUS WATCHDOG</b>						
MODBUS WATCHDOG TIME	3x65222 4x65222 I:65221	0,0x0000 B:00 00		50	UINT16 R/W	NO
		Actual watchdog time in 1/100s:0 -> 0,0s				
<p>Writing a value onto this register defines a new time for the internal communication watchdog timer. The value is a timespan in 1/100s.          =0: The communication watchdog is disabled          =1..65535: Communication watchdog will be triggered after x 1/100s pause on communication line</p> <p>In case of an communication watchdog, the module sets all outputs to the states defined in the configuration output registers</p> <p>Reading this register will return the current stored time from the internal FRAM</p>						
RASPBERRY PI WATCHDOG TIMER	3x65223 4x65223 I:65222	0,0x0000 B:00 00		50	UINT16 R/W	NO
		remaining watchdog time in 10ms:0 -> 0,000s				
<p>Enables or disables the WATCHDOG Timer for the Raspberry Pi module.          1..65535: Time for Watchdog in x10 Milliseconds (Maximum 655,35 seconds)          =0: No Watchdog is generated</p>						
<b>FRAM</b>						
GET FRAM TYPE	3x65224 4x65224 I:65223	2,0x0002 B:00 02			UINT16 R/O	
		FRAM size & type:FM25L16 2kB				
<p>Returns the current type of the FRAM and its total size          =2:FM25L16B_G, 2kB          =64:FM25V05, 64kB          =128:FM25V10, 128kB</p>						
GET FRAM USED BYTES	3x65225 4x65225 I:65224	166,0x00A6 B:00 A6			UINT16 R/O	
		FRAM used bytes:166				
Returns the amount of used bytes from system in FRAM						
<b>RTC REAL TIME CLOCK</b>						
RTC YEAR	3x65231 4x65231 I:65230	24,0x0018 B:00 18		24	UINT16 R/W	NO
		Actual RTC year:24				
<p>Returns the actual year of the internal real time clock in the range of 24 to 99.          Writing to this register prepares the setting of a new time.</p>						

RTC MONTH	3x65232 4x65232 l:65231	3,0x0003 B:00 03		1		UINT16 R/W	NO
		Actual RTC month:3					
Returns the actual month of the internal real time clock in the range of 1 to 12 Writing to this register prepares the setting of a new time.							
RTC DAY	3x65233 4x65233 l:65232	9,0x0009 B:00 09		1		UINT16 R/W	NO
		Actual RTC day:9					
Returns the actual day of the internal real time clock in the range of 1 to 31 Writing to this register prepares the setting of a new time.							
RTC HOUR	3x65234 4x65234 l:65233	11,0x000B B:00 0B		12		UINT16 R/W	NO
		Actual RTC month:11					
Returns the actual hour of the internal real time clock in the range of 0 to 23 Writing to this register prepares the setting of a new time.							
RTC MINUTE	3x65235 4x65235 l:65234	52,0x0034 B:00 34		45		UINT16 R/W	NO
		Actual RTC hour:52					
Returns the actual minute of the internal real time clock in the range of 0 to 59 Writing to this register prepares the setting of a new time.							
RTC SECOND	3x65236 4x65236 l:65235	17,0x0011 B:00 11		30		UINT16 R/W	NO
		Actual RTC second:17					
Returns the actual second of the internal real time clock in the range of 0 to 59 Writing to this register prepares the setting of a new time.							
RTC DAY OF WEEK	3x65237 4x65237 l:65236	6,0x0006 B:00 06		5:FRIDAY		UINT16 R/W	NO
		Actual RTC week day:SAT		SELECT DAY OF WEEK			
Returns the actual day of week in the range 1 to 7 1:MON, 2:TUE, 3:WED, 4:THU, 5:FRI, 6:SAT, 7:SUN Writing to this register writes a new date and time and weekday to the RTC							
<b>DIP SWITCH STATUS</b>							
DIP SWITCH	3x65501 4x65501 l:65500	255,0x00FF B:00 FF				UINT16 R/O	

Returns the actual setting of the Dip switches.

Bit 0: DIP Switch 1 (=0:OFF, =1:ON)  
 Bit 1: DIP Switch 2 (=0:OFF, =1:ON)  
 Bit 2: DIP Switch 3 (=0:OFF, =1:ON)  
 Bit 3: DIP Switch 4 (=0:OFF, =1:ON)  
 Bit 4: DIP Switch 5 (=0:OFF, =1:ON)  
 Bit 5: DIP Switch 6 (=0:OFF, =1:ON)  
 Bit 6: DIP Switch 7 (=0:OFF, =1:ON)  
 Bit 7: DIP Switch 8 (=0:OFF, =1:ON)

**CPU DATA**

SERIAL1	3x65521 4x65521 I:65520	14592,0x3900 B:39 00			UINT16 R/O	
Serial number of module as 96 bit unsigned integer number						
SERIAL2	3x65522 4x65522 I:65521	11264,0x2C00 B:2C 00			UINT16 R/O	
SERIAL3	3x65523 4x65523 I:65522	595,0x0253 B:02 53			UINT16 R/O	
SERIAL4	3x65524 4x65524 I:65523	21830,0x5546 B:55 46			UINT16 R/O	
SERIAL5	3x65525 4x65525 I:65524	14128,0x3730 B:37 30			UINT16 R/O	
SERIAL6	3x65526 4x65526 I:65525	14368,0x3820 B:38 20			UINT16 R/O	
		SERIAL:0039002C5302465530372038				
Serial number of module as 96 bit unsigned integer number						
CPU TEMPERATURE	3x65527 4x65527 I:65526	5096,0x13E8 B:13 E8			UINT16 R/O	
		Actual internal temperature of CPU:50,96°C				
Current internal temperature of CPU in ° Celsius multiplied by 100.						
CPU VOLTAGE	3x65528 4x65528 I:65527	334,0x014E B:01 4E			UINT16 R/O	
		Actual supply voltage of CPU:3,34V				
Current internal supply voltage of CPU in Volt multiplied by 1000.						
CPU BACKUP	3x65529 4x65529 I:65528	318,0x013E B:01 3E			UINT16 R/O	
		Actual backup voltage of CPU for RTC:3,18V				
Current internal backup voltage of CPU for RTC in Volt multiplied by 1000.						

**RESETs**

RASPBERRY PI RESET	3x65534 4x65534 I:65533	0,0x00 B:00 00		1:PERFORM RASPBERRY PI RESET	BIT R/W	NO
Resets the Raspberry Pi						
RASPBERRY PI RESET	3x65534 4x65534 I:65533	0,0x0000 B:00 00		1:PERFORM RASPBERRY PI RESET	UINT16 R/W	NO
Resets the Raspberry Pi						
FACTORY RESET	1x65535 2x65535 I:65534	0,0x00 B:00		1:PERFORM FACTORY RESET	BIT R/W	NO
Performs a factory reset of all internal saved parameters						
FACTORY RESET	3x65535 4x65535 I:65534	0,0x0000 B:00 00		1:PERFORM FACTORY RESET	UINT16 R/W	NO
Performs a factory reset of all internal saved parameters						
RESET	1x65536 2x65536 I:65535	0,0x00 B:00		1:PERFORM ARM RESET	BIT R/W	NO
Performs a software reset, whenever 1 is written to this register. If the host writes to this register 1, the module executes a soft reset (reboot). Be aware that you will lose all serial interfaces in USB!!!						
RESET	3x65536 4x65535 I:65535	0,0x0000 B:00 00		1:PERFORM ARM RESET	UINT16 R/W	NO
Performs a software reset, whenever 1 is written to this register. If the host writes to this register 1, the module executes a soft reset (reboot). Be aware that you will lose all serial interfaces in USB!!!						

Register NAME	MODBUS Register	Register VALUE	NEW REAL VALUE	NEW VALUE	DATA TYPE	DO WRITE
<b>DIP SWITCH STATUS</b>						
DIP SWITCH DIP1	1x65001 2x65001 I:65000	0,0x00 B:00			BIT R/O	
Returns the actual setting of the Dip switches. =0: DIP is OFF =1: DIP is ON						
DIP SWITCH DIP2	1x65002 2x65002 I:65001	0,0x00 B:00			BIT R/O	
DIP SWITCH DIP3	1x65003 2x65003 I:65002	0,0x00 B:00			BIT R/O	
DIP SWITCH DIP4	1x65004 2x65004 I:65003	0,0x00 B:00			BIT R/O	
DIP SWITCH DIP5	1x65005 2x65005 I:65004	0,0x00 B:00			BIT R/O	
DIP SWITCH DIP6	1x65006 2x65006 I:65005	0,0x00 B:00			BIT R/O	
DIP SWITCH DIP7	1x65007 2x65007 I:65006	0,0x00 B:00			BIT R/O	
DIP SWITCH DIP8	1x65008 2x65008 I:65007	0,0x00 B:00			BIT R/O	
<b>LED1:GREEN</b>						
LED1:GREEN SET TO OFF	1x65009 2x65009 I:65008	????		N/A:DO NOTHING	BIT W/O	NO
Writing 1 to this coil sets the LED to OFF						
LED1:GREEN SET TO ON	1x65010 2x65010 I:65009	????		N/A:DO NOTHING	BIT W/O	NO
Writing 1 to this coil sets the LED to ON						
LED1:GREEN INVERT LED STATE	1x65011 2x65011 I:65010	????		N/A:DO NOTHING	BIT W/O	NO
Writing 1 to this coil inverts the actual LED state						
LED1:GREEN BLINK	1x65012 2x65012 I:65011	????		N/A:DO NOTHING	BIT W/O	NO

Writing 1 to this coil start symmetrical blinking of LED with last defined time						
LED1:GREEN FLASH	1x65013 2x65013 I:65012	????		N/A:DO NOTHING	BIT W/O	NO
Writing 1 to this coil start asymmetrical flashing of LED with last defined times						
LED1:GREEN PULSE	1x65014 2x65014 I:65013	????		N/A:DO NOTHING	BIT W/O	NO
Writing 1 to this coil start one time pulse of LED with last defined time						
LED1:GREEN BLINK 5s	1x65015 2x65015 I:65014	????		N/A:DO NOTHING	BIT W/O	NO
Writing 1 to this coil start symmetrical blinking of LED with 5s ON-5s OFF cycle						
LED1:GREEN BLINK 1s	1x65016 2x65016 I:65015	????		N/A:DO NOTHING	BIT W/O	NO
Writing 1 to this coil start symmetrical blinking of LED with 1s ON-1s OFF cycle						
LED1:GREEN BLINK 250ms	1x65017 2x65017 I:65016	????		N/A:DO NOTHING	BIT W/O	NO
Writing 1 to this coil start symmetrical blinking of LED with 250ms ON-250ms OFF cycle						
LED1:GREEN BLINK 50ms	1x65018 2x65018 I:65017	????		N/A:DO NOTHING	BIT W/O	NO
Writing 1 to this coil start symmetrical blinking of LED with 50ms ON-50ms OFF cycle						
LED1:GREEN FLASH 5s-1s	1x65019 2x65019 I:65018	????		N/A:DO NOTHING	BIT W/O	NO
Writing 1 to this coil start asymmetrical flashing of LED with 5s ON-1s OFF cycle						
LED1:GREEN FLASH 1s-250ms	1x65020 2x65020 I:65019	????		N/A:DO NOTHING	BIT W/O	NO
Writing 1 to this coil start asymmetrical flashing of LED with 1s ON-250ms OFF cycle						
LED1:GREEN FLASH 500ms-100ms	1x65021 2x65021 I:65020	????		N/A:DO NOTHING	BIT W/O	NO
Writing 1 to this coil start asymmetrical flashing of LED with 500ms ON-100ms OFF cycle						
LED1:GREEN FLASH 300ms-50ms	1x65022 2x65022 I:65021	????		N/A:DO NOTHING	BIT W/O	NO
Writing 1 to this coil start asymmetrical flashing of LED with 300ms ON-50ms OFF cycle						
LED1:GREEN PULSE 1s	1x65023 2x65023 I:65022	????		N/A:DO NOTHING	BIT W/O	NO
Writing 1 to this coil start one time pulse of LED with 1s ON						

LED1:GREEN PULSE 500ms	1x65024 2x65024 I:65023	????		N/A:DO NOTHING	BIT W/O	NO
Writing 1 to this coil start one time pulse of LED with 500ms ON						
LED1:GREEN PULSE 250ms	1x65025 2x65025 I:65024	????		N/A:DO NOTHING	BIT W/O	NO
Writing 1 to this coil start one time pulse of LED with 250ms ON						
LED1:GREEN PULSE 100ms	1x65026 2x65026 I:65025	????		N/A:DO NOTHING	BIT W/O	NO
Writing 1 to this coil start one time pulse of LED with 100ms ON						
LED1:GREEN PULSE 20ms	1x65027 2x65027 I:65026	????		N/A:DO NOTHING	BIT W/O	NO
Writing 1 to this coil start one time pulse of LED with 20ms ON						
<b>LED2:WHITE</b>						
LED2:WHITE SET TO OFF	1x65029 2x65029 I:65028	????		N/A:DO NOTHING	BIT W/O	NO
Writing 1 to this coil sets the LED to OFF						
LED2:WHITE SET TO ON	1x65030 2x65030 I:65029	????		N/A:DO NOTHING	BIT W/O	NO
Writing 1 to this coil sets the LED to ON						
LED2:WHITE INVERT LED STATE	1x65031 2x65031 I:65030	????		N/A:DO NOTHING	BIT W/O	NO
Writing 1 to this coil inverts the actual LED state						
LED2:WHITE BLINK	1x65032 2x65032 I:65031	????		N/A:DO NOTHING	BIT W/O	NO
Writing 1 to this coil start symmetrical blinking of LED with last defined time						
LED2:WHITE FLASH	1x65033 2x65033 I:65032	????		N/A:DO NOTHING	BIT W/O	NO
Writing 1 to this coil start asymmetrical flashing of LED with last defined times						
LED2:WHITE PULSE	1x65034 2x65034 I:65033	????		N/A:DO NOTHING	BIT W/O	NO
Writing 1 to this coil start one time pulse of LED with last defined time						
LED2:WHITE BLINK 5s	1x65035 2x65035 I:65034	????		N/A:DO NOTHING	BIT W/O	NO
Writing 1 to this coil start symmetrical blinking of LED with 5s ON-5s OFF cycle						



LED2:WHITE BLINK 1s	1x65036 2x65036 I:65035	????		N/A:DO NOTHING	BIT W/O	NO
Writing 1 to this coil start symmetrical blinking of LED with 1s ON-1s OFF cycle						
LED2:WHITE BLINK 250ms	1x65037 2x65037 I:65036	????		N/A:DO NOTHING	BIT W/O	NO
Writing 1 to this coil start symmetrical blinking of LED with 250ms ON-250ms OFF cycle						
LED2:WHITE BLINK 50ms	1x65038 2x65038 I:65037	????		N/A:DO NOTHING	BIT W/O	NO
Writing 1 to this coil start symmetrical blinking of LED with 50ms ON-50ms OFF cycle						
LED2:WHITE FLASH 5s-1s	1x65039 2x65039 I:65038	????		N/A:DO NOTHING	BIT W/O	NO
Writing 1 to this coil start asymmetrical flashing of LED with 5s ON-1s OFF cycle						
LED2:WHITE FLASH 1s-250ms	1x65040 2x65040 I:65039	????		N/A:DO NOTHING	BIT W/O	NO
Writing 1 to this coil start asymmetrical flashing of LED with 1s ON-250ms OFF cycle						
LED2:WHITE FLASH 500ms-100ms	1x65041 2x65041 I:65040	????		N/A:DO NOTHING	BIT W/O	NO
Writing 1 to this coil start asymmetrical flashing of LED with 500ms ON-100ms OFF cycle						
LED2:WHITE FLASH 300ms-50ms	1x65042 2x65042 I:65041	????		N/A:DO NOTHING	BIT W/O	NO
Writing 1 to this coil start asymmetrical flashing of LED with 300ms ON-50ms OFF cycle						
LED2:WHITE PULSE 1s	1x65043 2x65043 I:65042	????		N/A:DO NOTHING	BIT W/O	NO
Writing 1 to this coil start one time pulse of LED with 1s ON						
LED2:WHITE PULSE 500ms	1x65044 2x65044 I:65043	????		N/A:DO NOTHING	BIT W/O	NO
Writing 1 to this coil start one time pulse of LED with 500ms ON						
LED2:WHITE PULSE 250ms	1x65045 2x65045 I:65044	????		N/A:DO NOTHING	BIT W/O	NO
Writing 1 to this coil start one time pulse of LED with 250ms ON						
LED2:WHITE PULSE 100ms	1x65046 2x65046 I:65045	????		N/A:DO NOTHING	BIT W/O	NO
Writing 1 to this coil start one time pulse of LED with 100ms ON						

LED2:WHITE PULSE 20ms	1x65047 2x65047 I:65046	????		N/A:DO NOTHING	BIT W/O	NO
Writing 1 to this coil start one time pulse of LED with 20ms ON						
<b>LED3:RED</b>						
LED3:RED SET TO OFF	1x65049 2x65049 I:65048	????		N/A:DO NOTHING	BIT W/O	NO
Writing 1 to this coil sets the LED to OFF						
LED3:RED SET TO ON	1x65050 2x65050 I:65049	????		N/A:DO NOTHING	BIT W/O	NO
Writing 1 to this coil sets the LED to ON						
LED3:RED INVERT LED STATE	1x65051 2x65051 I:65050	????		N/A:DO NOTHING	BIT W/O	NO
Writing 1 to this coil inverts the actual LED state						
LED3:RED BLINK	1x65052 2x65052 I:65051	????		N/A:DO NOTHING	BIT W/O	NO
Writing 1 to this coil start symmetrical blinking of LED with last defined time						
LED3:RED FLASH	1x65053 2x65053 I:65052	????		N/A:DO NOTHING	BIT W/O	NO
Writing 1 to this coil start asymmetrical flashing of LED with last defined times						
LED3:RED PULSE	1x65054 2x65054 I:65053	????		N/A:DO NOTHING	BIT W/O	NO
Writing 1 to this coil start one time pulse of LED with last defined time						
LED3:RED BLINK 5s	1x65055 2x65055 I:65054	????		N/A:DO NOTHING	BIT W/O	NO
Writing 1 to this coil start symmetrical blinking of LED with 5s ON-5s OFF cycle						
LED3:RED BLINK 1s	1x65056 2x65056 I:65055	????		N/A:DO NOTHING	BIT W/O	NO
Writing 1 to this coil start symmetrical blinking of LED with 1s ON-1s OFF cycle						
LED3:RED BLINK 250ms	1x65057 2x65057 I:65056	????		N/A:DO NOTHING	BIT W/O	NO
Writing 1 to this coil start symmetrical blinking of LED with 250ms ON-250ms OFF cycle						
LED3:RED BLINK 50ms	1x65058 2x65058 I:65057	????		N/A:DO NOTHING	BIT W/O	NO
Writing 1 to this coil start symmetrical blinking of LED with 50ms ON-50ms OFF cycle						

LED3:RED FLASH 5s-1s	1x65059 2x65059 I:65058	????		N/A:DO NOTHING	BIT W/O	NO
Writing 1 to this coil start asymmetrical flashing of LED with 5s ON-1s OFF cycle						
LED3:RED FLASH 1s-250ms	1x65060 2x65060 I:65059	????		N/A:DO NOTHING	BIT W/O	NO
Writing 1 to this coil start asymmetrical flashing of LED with 1s ON-250ms OFF cycle						
LED3:RED FLASH 500ms-100ms	1x65061 2x65061 I:65060	????		N/A:DO NOTHING	BIT W/O	NO
Writing 1 to this coil start asymmetrical flashing of LED with 500ms ON-100ms OFF cycle						
LED3:RED FLASH 300ms-50ms	1x65062 2x65062 I:65061	????		N/A:DO NOTHING	BIT W/O	NO
Writing 1 to this coil start asymmetrical flashing of LED with 300ms ON-50ms OFF cycle						
LED3:RED PULSE 1s	1x65063 2x65063 I:65062	????		N/A:DO NOTHING	BIT W/O	NO
Writing 1 to this coil start one time pulse of LED with 1s ON						
LED3:RED PULSE 500ms	1x65064 2x65064 I:65063	????		N/A:DO NOTHING	BIT W/O	NO
Writing 1 to this coil start one time pulse of LED with 500ms ON						
LED3:RED PULSE 250ms	1x65065 2x65065 I:65064	????		N/A:DO NOTHING	BIT W/O	NO
Writing 1 to this coil start one time pulse of LED with 250ms ON						
LED3:RED PULSE 100ms	1x65066 2x65066 I:65065	????		N/A:DO NOTHING	BIT W/O	NO
Writing 1 to this coil start one time pulse of LED with 100ms ON						
LED3:RED PULSE 20ms	1x65067 2x65067 I:65066	????		N/A:DO NOTHING	BIT W/O	NO
Writing 1 to this coil start one time pulse of LED with 20ms ON						
<b>LED4:YELLOW</b>						
LED4:YELLOW SET TO OFF	1x65069 2x65069 I:65068	????		N/A:DO NOTHING	BIT W/O	NO
Writing 1 to this coil sets the LED to OFF						
LED4:YELLOW SET TO ON	1x65070 2x65070 I:65069	????		N/A:DO NOTHING	BIT W/O	NO
Writing 1 to this coil sets the LED to ON						

LED4:YELLOW INVERT LED STATE	1x65071 2x65071 I:65070	????		N/A:DO NOTHING	BIT W/O	NO
Writing 1 to this coil inverts the actual LED state						
LED4:YELLOW BLINK	1x65072 2x65072 I:65071	????		N/A:DO NOTHING	BIT W/O	NO
Writing 1 to this coil start symmetrical blinking of LED with last defined time						
LED4:YELLOW FLASH	1x65073 2x65073 I:65072	????		N/A:DO NOTHING	BIT W/O	NO
Writing 1 to this coil start asymmetrical flashing of LED with last defined times						
LED4:YELLOW PULSE	1x65074 2x65074 I:65073	????		N/A:DO NOTHING	BIT W/O	NO
Writing 1 to this coil start one time pulse of LED with last defined time						
LED4:YELLOW BLINK 5s	1x65075 2x65075 I:65074	????		N/A:DO NOTHING	BIT W/O	NO
Writing 1 to this coil start symmetrical blinking of LED with 5s ON-5s OFF cycle						
LED4:YELLOW BLINK 1s	1x65076 2x65076 I:65075	????		N/A:DO NOTHING	BIT W/O	NO
Writing 1 to this coil start symmetrical blinking of LED with 1s ON-1s OFF cycle						
LED4:YELLOW BLINK 250ms	1x65077 2x65077 I:65076	????		N/A:DO NOTHING	BIT W/O	NO
Writing 1 to this coil start symmetrical blinking of LED with 250ms ON-250ms OFF cycle						
LED4:YELLOW BLINK 50ms	1x65078 2x65078 I:65077	????		N/A:DO NOTHING	BIT W/O	NO
Writing 1 to this coil start symmetrical blinking of LED with 50ms ON-50ms OFF cycle						
LED4:YELLOW FLASH 5s-1s	1x65079 2x65079 I:65078	????		N/A:DO NOTHING	BIT W/O	NO
Writing 1 to this coil start asymmetrical flashing of LED with 5s ON-1s OFF cycle						
LED4:YELLOW FLASH 1s-250ms	1x65080 2x65080 I:65079	????		N/A:DO NOTHING	BIT W/O	NO
Writing 1 to this coil start asymmetrical flashing of LED with 1s ON-250ms OFF cycle						
LED4:YELLOW FLASH 500ms-100ms	1x65081 2x65081 I:65080	????		N/A:DO NOTHING	BIT W/O	NO
Writing 1 to this coil start asymmetrical flashing of LED with 500ms ON-100ms OFF cycle						

LED4:YELLOW FLASH 300ms-50ms	1x65082 2x65082 I:65081	????		N/A:DO NOTHING	BIT W/O	NO
Writing 1 to this coil start asymmetrical flashing of LED with 300ms ON-50ms OFF cycle						
LED4:YELLOW PULSE 1s	1x65083 2x65083 I:65082	????		N/A:DO NOTHING	BIT W/O	NO
Writing 1 to this coil start one time pulse of LED with 1s ON						
LED4:YELLOW PULSE 500ms	1x65084 2x65084 I:65083	????		N/A:DO NOTHING	BIT W/O	NO
Writing 1 to this coil start one time pulse of LED with 500ms ON						
LED4:YELLOW PULSE 250ms	1x65085 2x65085 I:65084	????		N/A:DO NOTHING	BIT W/O	NO
Writing 1 to this coil start one time pulse of LED with 250ms ON						
LED4:YELLOW PULSE 100ms	1x65086 2x65086 I:65085	????		N/A:DO NOTHING	BIT W/O	NO
Writing 1 to this coil start one time pulse of LED with 100ms ON						
LED4:YELLOW PULSE 20ms	1x65087 2x65087 I:65086	????		N/A:DO NOTHING	BIT W/O	NO
Writing 1 to this coil start one time pulse of LED with 20ms ON						
<b>DIP SWITCH STATUS</b>						
DIP SWITCH	3x65501 4x65501 I:65500	0,0x0000 B:00 00			UINT16 R/O	
Returns the actual setting of the Dip switches. Bit 0: DIP Switch 1 (=0:OFF, =1:ON) Bit 1: DIP Switch 2 (=0:OFF, =1:ON) Bit 2: DIP Switch 3 (=0:OFF, =1:ON) Bit 3: DIP Switch 4 (=0:OFF, =1:ON) Bit 4: DIP Switch 5 (=0:OFF, =1:ON) Bit 5: DIP Switch 6 (=0:OFF, =1:ON) Bit 6: DIP Switch 7 (=0:OFF, =1:ON) Bit 7: DIP Switch 8 (=0:OFF, =1:ON)						
<b>LED1:GREEN</b>						
LED1:GREEN STATE	3x65502 4x65502 I:65501	4,0x0004 B:00 04		1:SET TO ON	UINT16 R/W	NO
		State of LED:FLASH				

Returns the actual state of the LED

Writing to this register will set a new state for the LED

0: Switch LED permanent OFF

1: Switch LED permanent ON

2: Invert last state of LED

3: Start symmetrical blinking of LED with TIME1 ON and TIME1 OFF

4: Start asymmetrical flashing of LED with TIME1 ON and TIME2 OFF

5: Start one time pulse of LED with TIME1 ON and infinite OFF

LED1:GREEN TIME1	3x65503 4x65503 I:65502	200,0x00C8 B:00 C8		1000	UINT16 R/W	YES
		Actual time 1 in ms:200				

Returns the actual time1 for blink,flash and pulse ON time in Milliseconds

Writing to this register sets a new time in the range 20-65534ms

LED1:GREEN TIME2	3x65504 4x65504 I:65503	3000,0x0BB8 B:0B B8		2000	UINT16 R/W	YES
		Actual time 2 in ms:3000				

Returns the actual time2 for blink and flash OFF time in Milliseconds

Writing to this register sets a new time in the range 20-65534ms

**LED2:WHITE**

LED2:WHITE STATE	3x65505 4x65505 I:65504	4,0x0004 B:00 04		1:SET TO ON	UINT16 R/W	NO
		State of LED:FLASH				

Returns the actual state of the LED

Writing to this register will set a new state for the LED

0: Switch LED permanent OFF

1: Switch LED permanent ON

2: Invert last state of LED

3: Start symmetrical blinking of LED with TIME1 ON and TIME1 OFF

4: Start asymmetrical flashing of LED with TIME1 ON and TIME2 OFF

5: Start one time pulse of LED with TIME1 ON and infinite OFF

LED2:WHITE TIME1	3x65506 4x65506 I:65505	200,0x00C8 B:00 C8		1000	UINT16 R/W	YES
		Actual time 1 in ms:200				

Returns the actual time1 for blink,flash and pulse ON time in Milliseconds

Writing to this register sets a new time in the range 20-65534ms

LED2:WHITE TIME2	3x65507 4x65507 I:65506	3000,0x0BB8 B:0B B8		2000	UINT16 R/W	YES
		Actual time 2 in ms:3000				

Returns the actual time2 for blink and flash OFF time in Milliseconds

Writing to this register sets a new time in the range 20-65534ms

**LED3:RED**

LED3:RED STATE	3x65508 4x65508 I:65507	4,0x0004 B:00 04		1:SET TO ON	UINT16 R/W	NO
-------------------	-------------------------------	---------------------	--	-------------	---------------	----

		State of LED:FLASH				
Returns the actual state of the LED Writing to this register will set a new state for the LED 0: Switch LED permanent OFF 1: Switch LED permanent ON 2: Invert last state of LED 3: Start symmetrical blinking of LED with TIME1 ON and TIME1 OFF 4: Start asymmetrical flashing of LED with TIME1 ON and TIME2 OFF 5: Start one time pulse of LED with TIME1 ON and infinite OFF						
LED3:RED TIME1	3x65509 4x65509 I:65508	200,0x00C8 B:00 C8		1000	UINT16 R/W	YES
		Actual time 1 in ms:200				
Returns the actual time1 for blink,flash and pulse ON time in Milliseconds Writing to this register sets a new time in the range 20-65534ms						
LED3:RED TIME2	3x65510 4x65510 I:65509	3000,0x0BB8 B:0B B8		2000	UINT16 R/W	YES
		Actual time 2 in ms:3000				
Returns the actual time2 for blink and flash OFF time in Milliseconds Writing to this register sets a new time in the range 20-65534ms						
<b>LED4:YELLOW</b>						
LED4:YELLOW STATE	3x65511 4x65511 I:65510	0,0x0000 B:00 00		1:SET TO ON	UINT16 R/W	NO
		State of LED:OFF				
Returns the actual state of the LED Writing to this register will set a new state for the LED 0: Switch LED permanent OFF 1: Switch LED permanent ON 2: Invert last state of LED 3: Start symmetrical blinking of LED with TIME1 ON and TIME1 OFF 4: Start asymmetrical flashing of LED with TIME1 ON and TIME2 OFF 5: Start one time pulse of LED with TIME1 ON and infinite OFF						
LED4:YELLOW TIME1	3x65512 4x65512 I:65511	200,0x00C8 B:00 C8		1000	UINT16 R/W	YES
		Actual time 1 in ms:200				
Returns the actual time1 for blink,flash and pulse ON time in Milliseconds Writing to this register sets a new time in the range 20-65534ms						
LED4:YELLOW TIME2	3x65513 4x65513 I:65512	3000,0x0BB8 B:0B B8		2000	UINT16 R/W	YES
		Actual time 2 in ms:3000				
Returns the actual time2 for blink and flash OFF time in Milliseconds Writing to this register sets a new time in the range 20-65534ms						

Command NAME	ASCII command type	ASCII command structure	NEW REAL VALUE	NEW VALUE	DATA TYPE	DO WRITE
<b>ASCII COMMANDS</b>						
<b>DIGITAL INPUTS</b>						
GET DIGITAL INPUTS	ASCII READ COMMAND	#GDIS<CR> Result: #GDIS:<DISDec>,<DISHex><CR>			ASCII	
	TX	#255,GDIS<CR>				
	RX	#255,GDIS:0,0x0<CR>				
		Actual status of digital inputs:0000.0000.0000.0000				
Returns the actual state of all digital inputs as decimal number and as hexadecimal number. DISDec, DISHex The current state of all digital inputs: Bit 0: State of DI1 (=0:OFF, =1:ON) Bit 1: State of DI2 (=0:OFF, =1:ON) Bit 2: State of DI3 (=0:OFF, =1:ON) ... Bit 13: State of DI14 (=0:OFF, =1:ON) Bit 14: State of DI15 (=0:OFF, =1:ON) Bit 15: State of DI16 (=0:OFF, =1:ON)						
GET DIGITAL INPUT DIx	ASCII READ COMMAND	#GDI<DINR><CR> Result: #GDI<DINR>:<DlxDec>,<DlxHex><CR>			ASCII	
	DINR	1				
	TX	#255,GDI1<CR>				
	RX	#255,GDI1:0,0x0<CR>				
		Actual status of digital input DI1:0=OFF				
<DINR>: 1=DI1..16=DI16						
Returns the actual state of the digital input Dix as decimal number and as hexadecimal number. DlxDec, DlxHex: The current state of the digital input x: =0: Digital input is OFF =1: Digital input is ON						
GET ALL CHANGES	ASCII READ COMMAND	#GAC<CR> Result: #GAC:<ChangesDec>,<ChangesHex><CR>			ASCII	
	TX	#255,GAC<CR>				
	RX	#255,GAC:0,0x0<CR>				
		Actual change counter:0				
Returns the counter for changes on all digital inputs. As soon as the module detects a short keypress or long key press or long key release event, this counter is incremented by 1. If this values has changed since the last polling request, the host knows, that at least one digital input has changed its state.						





SHORT KEY ALL DIS PART x	ASCII READ COMMAND	#SKADISP<PART><CR> Result: #SKADISP<PART>:<ShortKeyDInDec>, ..., <ShortKeyDIn+15Dec>, <ShortKeyDInHex>, ..., <ShortKeyDIn+15Hex><CR>	ASCII	
	PART	1		
	TX	#255,SKADISP1<CR>		
	RX	#255,SKADISP1:0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0x0,0x0,0x0,0x0,0x0,0x0,0x0,0x0,0x0,0x0,0x0,0x0,0x0,0x0,0x0,0x0,0x0<CR>		
		Actual counter for short keypress events on DI1:0		
		Actual counter for short keypress events on DI2:0		
		Actual counter for short keypress events on DI3:0		
		Actual counter for short keypress events on DI4:0		
		Actual counter for short keypress events on DI5:0		
		Actual counter for short keypress events on DI6:0		
		Actual counter for short keypress events on DI7:0		
		Actual counter for short keypress events on DI8:0		
		Actual counter for short keypress events on DI9:0		
		Actual counter for short keypress events on DI10:0		
		Actual counter for short keypress events on DI11:0		
		Actual counter for short keypress events on DI12:0		
		Actual counter for short keypress events on DI13:0		
		Actual counter for short keypress events on DI14:0		
		Actual counter for short keypress events on DI15:0		
		Actual counter for short keypress events on DI16:0		
<PART>: 1, 1=DI1-DI16				
Returns for each digital input the counter for short keypress events. As soon as the module detects a short keypress on a digital input, the counter for the affected digital input is incremented by 1.				
The parameter <PART> defines the part of the digital inputs. The command returns maximal 16 digital inputs.				
SHORT KEY DIx	ASCII READ COMMAND	#SKDI<DINR><CR> Result: #SKDI<DINR>:<ShortKeyDec>,<ShortKeyHex><CR>	ASCII	
	DINR	1		
	TX	#255,SKDI1<CR>		
	RX	#255,SKDI1:0,0x0<CR>		
		Actual counter for short keypress events on digital input DI1:0		
<DINR>: 1=DI1..16=DI16				
Returns for digital input <DINR> the counter for short keypress events.				
As soon as the module detects a short keypress on a digital input, the counter for the affected digital input is incremented by 1.				
LONG KEY START ALL DIS PART x	ASCII READ COMMAND	#LKSADISP<PART><CR> Result: #LKSADISP<PART>:<LongKeyStartDInDec>, ..., <LongKeyStartDIn+15Dec>, <LongKeyStartDInHex>, ..., <LongKeyStartDIn+15Hex><CR>	ASCII	
	PART	1		
	TX	#255,LKSADISP1<CR>		

	RX	#255,LKSADISP1:0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0x0,0x0,0x0,0x0,0x0,0x0,0x0,0x0,0x0,0x0,0x0,0x0,0x0,0x0,0x0,0x0,0x0,0x0<CR>		
		Actual counter for long keypress start events on DI1:0		
		Actual counter for long keypress start events on DI2:0		
		Actual counter for long keypress start events on DI3:0		
		Actual counter for long keypress start events on DI4:0		
		Actual counter for long keypress start events on DI5:0		
		Actual counter for long keypress start events on DI6:0		
		Actual counter for long keypress start events on DI7:0		
		Actual counter for long keypress start events on DI8:0		
		Actual counter for long keypress start events on DI9:0		
		Actual counter for long keypress start events on DI10:0		
		Actual counter for long keypress start events on DI11:0		
		Actual counter for long keypress start events on DI12:0		
		Actual counter for long keypress start events on DI13:0		
		Actual counter for long keypress start events on DI14:0		
		Actual counter for long keypress start events on DI15:0		
		Actual counter for long keypress start events on DI16:0		
<b>&lt;PART&gt;: 1, 1=DI1-DI16</b>				
Returns for each digital input the counter for long keypress start events. As soon as the module detects the start of a long keypress on a digital input, the counter for the affected digital input is incremented by 1.				
The parameter <PART> defines the part of the digital inputs. The command returns maximal 16 digital inputs.				
LONG KEY START DIx	ASCII READ COMMAND	#LKSDI<DINR> <CR> Result: #LKSDI<DINR>:<LongKeyStartDec>,<LongKeyStartHex> <CR>	ASCII	
	DINR	1		
	TX	#255,LKSDI1<CR>		
	RX	#255,LKSDI1:0,0x0<CR>		
		Actual counter for long keypress start events on digital input DI1:0		
<b>&lt;DINR&gt;: 1=DI1..16=DI16</b>				
Returns for digital input <DINR> the counter for long keypress start events.				
As soon as the module detects the start of a long keypress on a digital input, the counter for the affected digital input is incremented by 1.				
LONG KEY END ALL DIS PART x	ASCII READ COMMAND	#LKEADISP<PART> <CR> Result: #LKEADISP<PART>:<LongKeyEndDInDec>,...,<LongKeyEndDIn+15Dec>,<LongKeyEndDInHex>,...,<LongKeyEndDIn+15Hex> <CR>	ASCII	
	PART	1		
	TX	#255,LKEADISP1<CR>		
	RX	#255,LKEADISP1:0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0x0,0x0,0x0,0x0,0x0,0x0,0x0,0x0,0x0,0x0,0x0,0x0,0x0,0x0,0x0,0x0,0x0,0x0<CR>		
		Actual counter for long keypress end events on DI1:0		
		Actual counter for long keypress end events on DI2:0		
		Actual counter for long keypress end events on DI3:0		
		Actual counter for long keypress end events on DI4:0		

		Actual counter for long keypress end events on DI5:0			
		Actual counter for long keypress end events on DI6:0			
		Actual counter for long keypress end events on DI7:0			
		Actual counter for long keypress end events on DI8:0			
		Actual counter for long keypress end events on DI9:0			
		Actual counter for long keypress end events on DI10:0			
		Actual counter for long keypress end events on DI11:0			
		Actual counter for long keypress end events on DI12:0			
		Actual counter for long keypress end events on DI13:0			
		Actual counter for long keypress end events on DI14:0			
		Actual counter for long keypress end events on DI15:0			
		Actual counter for long keypress end events on DI16:0			
<b>&lt;PART&gt;</b> : 1, 1=DI1-DI16					
Returns for each digital input the counter for long keypress end events. As soon as the module detects the end of a long keypress on a digital input, the counter for the affected digital input is incremented by 1.					
The parameter <PART> defines the part of the digital inputs. The command returns maximal 16 digital inputs.					
LONG KEY END DIx	ASCII READ COMMAND	#LKEDI<DINR> <CR> Result: #LKEDI<DINR>:<LongKeyEndDec>,<LongKeyEndHex> <CR>	ASCII		
	DINR	1			
	TX	#255,LKEDI1<CR>			
	RX	#255,LKEDI1:0,0x0<CR>			
		Actual counter for long keypress end events on digital input DI1:0			
<b>&lt;DINR&gt;</b> : 1=DI1..16=DI16					
Returns for digital input <DINR> the counter for long keypress end events. As soon as the module detects the end of a long keypress on a digital input, the counter for the affected digital input is incremented by 1.					
RISE ALL DIS PART x	ASCII READ COMMAND	#RADISP<PART> <CR> Result: #RADISP<PART>:<RiseDIInDec>,...,<RiseDIIn+15Dec>, <RiseDIInHex>,...,<RiseDIIn+15Hex> <CR>	ASCII		
	PART	1			
	TX	#255,RADISP1<CR>			
	RX	#255,RADISP1:0,0,0,0,0,0,0,0,0,0,0,0,0,0,0x0,0x0,0x0,0x0,0x0,0x0,0x0,0x0,0x0,0x0,0x0,0x0,0x0,0x0,0x0,0x0,0x0,0x0<CR>			
		Actual counter for rising edges on DI1:0			
		Actual counter for rising edges on DI2:0			
		Actual counter for rising edges on DI3:0			
		Actual counter for rising edges on DI4:0			
		Actual counter for rising edges on DI5:0			
		Actual counter for rising edges on DI6:0			
		Actual counter for rising edges on DI7:0			
		Actual counter for rising edges on DI8:0			
		Actual counter for rising edges on DI9:0			
		Actual counter for rising edges on DI10:0			



&lt;PART&gt;: 1, 1=DI1-DI16

Returns for each digital input the counter for falling edges. As soon as the module detects a falling edge on a digital input, the falling edge counter for the affected digital input is incremented by 1.

The parameter &lt;PART&gt; defines the part of the digital inputs. The command returns maximal 16 digital inputs.

FALL Dix	ASCII READ COMMAND	#FDI<DINR> <CR> Result: #FDI<DINR>:<FallDec>,<FallHex> <CR>	ASCII	
	DINR	1		
	TX	#255,FDI1<CR>		
	RX	#255,FDI1:0,0x0<CR>		
		Actual counter for falling edges on digital input DI1:0		

&lt;DINR&gt;: 1=DI1..16=DI16

Returns for digital input &lt;DINR&gt; the counter for falling edges.

As soon as the module detects a falling edge on a digital input, the falling edge counter for the affected digital input is incremented by 1.

RESET COUNTERS	ASCII WRITE COMMAND	#RC<CR> Result: #OK<CR>	ASCII	NO
	TX	#255,RC<CR>		
	RX	N/A		

Resets all internal counters for digital inputs and events on this digital inputs to 0.

**DIGITAL INPUTS EVENTS**

EVENTS ON	ASCII WRITE COMMAND	#EVTON<CR> Result: #OK<CR>	ASCII	NO
	TX	#255,EVTON<CR>		
	RX	#1,OK<CR>		

Activates event sending of changes on digital inputs

Whenever a change is detected on the digital inputs, the IO module sends immediately

#&lt;BusAdr&gt;,EVT:DIS:&lt;AllDISasDec&gt;,&lt;AllDISasHex&gt; &lt;CR&gt;

EVENTS OFF	ASCII WRITE COMMAND	#EVTOFF<CR> Result: #OK<CR>	ASCII	NO
	TX	#255,EVTOFF<CR>		
	RX	#1,OK<CR>		

Deactivates event sending of changes on digital inputs

Whenever a change is detected on the digital inputs, the IO module sends immediately

#&lt;BusAdr&gt;,EVT:DIS:&lt;AllDISasDec&gt;,&lt;AllDISasHex&gt; &lt;CR&gt;

Command NAME	ASCII command type	ASCII command structure	NEW REAL VALUE	NEW VALUE	DATA TYPE	DO WRITE
<b>ASCII COMMANDS</b>						
<b>DIGITAL OUTPUTS</b>						
UPDATE DIGITAL INPUTS AND OUTPUTS	ASCII WRITE COMMAND	#UDIOS:<OutAllDOS><CR> Result: #UDIOS:<InAllDISDec>,<InAllDISHex><CR>			ASCII	YES
	DO1	0:OFF				
	DO2	0:OFF				
	DO3	0:OFF				
	DO4	0:OFF				
	DO5	0:OFF				
	DO6	0:OFF				
	DO7	0:OFF				
	DO8	0:OFF				
	DO9	0:OFF				
	DO10	0:OFF				
	DO11	0:OFF				
	DO12	0:OFF				
	DO13	0:OFF				
	DO14	0:OFF				
	DO15	0:OFF				
	TX	#255,UDIOS:0<CR>				
	RX	#255,UDIOS:0,0x0<CR>				
		Actual status of digital inputs:0000.0000.0000.0000				

Sets all digital outputs to the new state OutAllDOS and gives back the current status of all digital inputs InAllDIS as decimal and hexadecimal value

OutAllDOS: The new state for all digital outputs

Bit 0: State of DO1 (=0:OFF, =1:ON)

Bit 1: State of DO2 (=0:OFF, =1:ON)

Bit 2: State of DO3 (=0:OFF, =1:ON)

...

Bit 12: State of DO13 (=0:OFF, =1:ON)

Bit 13: State of DO14 (=0:OFF, =1:ON)

Bit 14: State of DO15 (=0:OFF, =1:ON)

InAllDIS: The current state for all digital inputs

Bit 0: State of DI1 (=0:OFF, =1:ON)

Bit 1: State of DI2 (=0:OFF, =1:ON)

Bit 2: State of DI3 (=0:OFF, =1:ON)

...

Bit 13: State of DI14 (=0:OFF, =1:ON)

Bit 14: State of DI15 (=0:OFF, =1:ON)

Bit 15: State of DI16 (=0:OFF, =1:ON)

SET DIGITAL OUTPUTS	ASCII WRITE COMMAND	#SDOS:<OutAllDOS> <CR> Result: #OK<CR>	ASCII	YES
	DO1	0:OFF		
	DO2	0:OFF		
	DO3	0:OFF		
	DO4	0:OFF		
	DO5	0:OFF		
	DO6	0:OFF		
	DO7	0:OFF		
	DO8	0:OFF		
	DO9	0:OFF		
	DO10	0:OFF		
	DO11	0:OFF		
	DO12	0:OFF		
	DO13	0:OFF		
	DO14	0:OFF		
	DO15	0:OFF		
	TX	#255,SDOS:0<CR>		
	RX	#255,OK<CR>		
<p>Sets all digital outputs to the new state OutAllDOS  The new state for all digital outputs  Bit 0: State of DO1 (=0:OFF, =1:ON)  Bit 1: State of DO2 (=0:OFF, =1:ON)  Bit 2: State of DO3 (=0:OFF, =1:ON)  ...  Bit 12: State of DO13 (=0:OFF, =1:ON)  Bit 13: State of DO14 (=0:OFF, =1:ON)  Bit 14: State of DO15 (=0:OFF, =1:ON)</p>				
SET DIGITAL OUTPUT DOx	ASCII WRITE COMMAND	#SDO<DONR>:<Out> <CR> Result: #OK<CR>	ASCII	NO
	DONR	2		
	DOx	0:OFF		
	TX	#255,SDO2:0<CR>		
	RX	N/A		
<DONR>: 1=DO1..15=DO15				
<p>Sets the new state for digital output DOx. The state is defined with &lt;Out&gt;.  Out  The new state of the digital output DOx:  =0: digital output is OFF  =1: digital output is ON</p>				
GET DIGITAL OUTPUTS	ASCII READ COMMAND	#GDOS<CR> Result: #GDOS:<DOSDec>,<DOSHex> <CR>	ASCII	
	TX	#255,GDOS<CR>		



	RX	#255,GDOS:0,0x0<CR>		
		Actual status of digital outputs:000.0000.0000.0000		
Returns the actual state of the digital outputs as decimal number and as hexadecimal number. DOSDec, DOSHex The current state of the digital outputs: Bit 0: State of DO1 (=0:OFF, =1:ON) Bit 1: State of DO2 (=0:OFF, =1:ON) Bit 2: State of DO3 (=0:OFF, =1:ON) ... Bit 12: State of DO13 (=0:OFF, =1:ON) Bit 13: State of DO14 (=0:OFF, =1:ON) Bit 14: State of DO15 (=0:OFF, =1:ON)				
GET DIGITAL OUTPUT DOx	ASCII READ COMMAND	#GDO<DONR> <CR> Result: #GDO<DONR>:<DOxDec>,<DOxHex> <CR>	ASCII	
	DONR	2		
	TX	#255,GDO2<CR>		
	RX	#255,GDO2:0,0x0<CR>		
		Actual status of digital output DO2:0=OFF		
Returns the actual state of the digital output DOx as decimal number and as hexadecimal number. DOxDec, DOxHex The current state of the digital output DOx: =0: relay output is OFF =1: relay output is ON				
<b>DIGITAL OUTPUTS: PULSE OUTPUT</b>				
PULSE DOx	ASCII WRITE COMMAND	#PDO<DONR>:<Time> <CR> Result: #OK<CR>	ASCII	YES
	DONR	2		
	TIME	200		
	TX	#255,PDO2:200<CR>		
	RX	#255,OK<CR>		
<DONR>: 1=DO1..15=DO15				
<Time>: 0..65535*100ms				
This command switches the digital output DOx on for the pulse duration <PulseTimeIn100ms>*100ms. PulseTimeIn100ms: A duration in 100ms units. The corresponding digital output is switched on for this time period.				
GET PULSE TIMER DOx	ASCII READ COMMAND	#GPT<DONR> <CR> Result: #GPT:<TimeDec>,<TimeHex> <CR>	ASCII	
	DONR	2		
	TX	#255,GPT2<CR>		
	RX	#255,GPT2:19810,0x4D62<CR>		
		Actual pulse time for DO2:19,8s		
<DONR>: 1=DO1..15=DO15				
Returns the remaining timer value of the pulse for digital output DOx in ms. PulseTimeInMSDec, PulseTimeInMSHex The remaining time of the pulse in Milliseconds				

Command NAME	ASCII command type	ASCII command structure	NEW REAL VALUE	NEW VALUE	DATA TYPE	DO WRITE
<b>ASCII COMMANDS</b>						
<b>DIGITAL OUTPUTS</b>						
<b>DIGITAL OUTPUTS: ENABLE OPEN WIRE DETECTION WHILE ON</b>						
SET DIGITAL OUTPUTS ENABLE OPEN WIRE DETECTION WHILE ON	ASCII WRITE COMMAND	#SDOEOWDONS:<OpenWireDOS> <CR> Result: #OK<CR>			ASCII	YES
	DO1	0:OFF				
	DO2	0:OFF				
	DO3	0:OFF				
	DO4	0:OFF				
	DO5	0:OFF				
	DO6	0:OFF				
	DO7	0:OFF				
	DO8	0:OFF				
	DO9	0:OFF				
	DO10	0:OFF				
	DO11	0:OFF				
	DO12	0:OFF				
	DO13	0:OFF				
	DO14	0:OFF				
	DO15	0:OFF				
	TX	#255,SDOEOWDONS:0<CR>				
	RX	#255,OK<CR>				
Sets the open wire mode for all digital outputs to the new mode OpenWireDOS. This enables the diagnostic of open wire while the digital output is ON. The new state for all digital outputs Bit 0: New mode for DO1 (=0:DISABLED, =1:ENABLED) Bit 1: New mode for DO2 (=0:DISABLED, =1:ENABLED) ... Bit 13: New mode for DO14 (=0:DISABLED, =1:ENABLED) Bit 14: New mode for DO15 (=0:DISABLED, =1:ENABLED)						
SET DIGITAL OUTPUT ENABLE OPEN WIRE DETECTION WHILE ON	ASCII WRITE COMMAND	#SDOEOWDON<DONR>:<OpenWireDOx> <CR> Result: #OK<CR>			ASCII	YES
	DONR	2				
	DOx	0:DISABLE				
	TX	#255,SDOEOWDON2:0<CR>				
	RX	#255,OK<CR>				
<DONR>: 1=DO1..15=DO15						
<OpenWireDOx>: 0=DISABLE..1=ENABLE						

Sets the open wire mode for digital output DOx to the new mode OpenWireDOx. This enables the diagnostic of open wire while the digital output is ON.

The new mode of the digital output DOx:

=0: diagnostic mode for digital output is DISABLED

=1: diagnostic mode for digital output is ENABLED

GET DIGITAL OUTPUTS ENABLE OPEN WIRE DETECTION WHILE ON	ASCII READ COMMAND	#GDOEOWDONS<CR> Result: #GDOEOWDONS:<OpenWireDOSDec>,<OpenWireDOSHex> <CR>	ASCII	
	TX	#255,GDOEOWDONS<CR>		
	RX	#255,GDOEOWDONS:0,0x0<CR>		
		Actual mode for open wire diagnostic while ON of digital outputs: DO1-DO15:000.0000.0000.0000		

Returns the actual mode for open wire diagnostic while digital output is ON as decimal number and as hexadecimal number.

OpenWireDOSDec, OpenWireDOSHex

The current mode for open wire diagnostic while ON of the digital outputs:

Bit 0: Open wire diagnostic mode of DO1 (=0:DISABLED, =1:ENABLED)

Bit 1: Open wire diagnostic mode of DO2 (=0:DISABLED, =1:ENABLED)

...

Bit 13: Open wire diagnostic mode of DO14 (=0:DISABLED, =1:ENABLED)

Bit 14: Open wire diagnostic mode of DO15 (=0:DISABLED, =1:ENABLED)

GET DIGITAL OUTPUT ENABLE OPEN WIRE DETECTION WHILE ON	ASCII READ COMMAND	#GDOEOWDON<DONR> <CR> Result: #GDOEOWDON<DONR>:<OpenWireDOxDec>,<OpenWireDOxHex> <CR>	ASCII	
	DONR	2		
	TX	#255,GDOEOWDON2<CR>		
	RX	#255,GDOEOWDON2:0,0x0<CR>		
		Actual open wire diagnostic mode while ON of digital output DO2:0=DISABLED		

<DONR>: 1=DO1..15=DO15

Returns the actual open wire diagnostic mode while ON of the digital output DOx as decimal number and as hexadecimal number.

OpenWireDOxDec, OpenWireDOxHex

The current diagnostic mode of the digital output DOx:

=0: open wire diagnostic mode for digital output is DISABLED

=1: open wire diagnostic mode for digital output is ENABLED

#### DIGITAL OUTPUTS: ENABLE OPEN WIRE DETECTION WHILE OFF

SET DIGITAL OUTPUTS ENABLE OPEN WIRE DETECTION WHILE OFF	ASCII WRITE COMMAND	#SDOEOWDOFFS:<OpenWireDOS> <CR> Result: #OK<CR>	ASCII	YES
	DO1	0:OFF		
	DO2	0:OFF		
	DO3	0:OFF		
	DO4	0:OFF		
	DO5	0:OFF		
	DO6	0:OFF		
	DO7	0:OFF		
	DO8	0:OFF		
	DO9	0:OFF		
	DO10	0:OFF		
	DO11	0:OFF		

	DO12	0:OFF		
	DO13	0:OFF		
	DO14	0:OFF		
	DO15	0:OFF		
	TX	#255,SDOEOWDOFFS:0<CR>		
	RX	#255,OK<CR>		

Sets the open wire mode for all digital outputs to the new mode OpenWireDOS. This enables the diagnostic of open wire while the digital output is OFF.

The new state for all digital outputs

Bit 0: New mode for DO1 (=0:DISABLED, =1:ENABLED)

Bit 1: New mode for DO2 (=0:DISABLED, =1:ENABLED)

...

Bit 13: New mode for DO14 (=0:DISABLED, =1:ENABLED)

Bit 14: New mode for DO15 (=0:DISABLED, =1:ENABLED)

SET DIGITAL OUTPUT ENABLE OPEN WIRE DETECTION WHILE OFF	ASCII WRITE COMMAND	#SDOEOWDOFF<DONR>:<OpenWireDOx> <CR> Result: #OK<CR>	ASCII	YES
	DONR	2		
	DOx	0:DISABLE		
	TX	#255,SDOEOWDOFF2:0<CR>		
	RX	#255,OK<CR>		

<DONR>: 1=DO1..15=DO15

<OpenWireDOx>: 0=DISABLE..1=ENABLE

Sets the open wire mode for digital output DOx to the new mode OpenWireDOx. This enables the diagnostic of open wire while the digital output is OFF.

The new mode of the digital output DOx:

=0: diagnostic mode for digital output is DISABLED

=1: diagnostic mode for digital output is ENABLED

GET DIGITAL OUTPUTS ENABLE OPEN WIRE DETECTION WHILE OFF	ASCII READ COMMAND	#GDOEOWDOFFS<CR> Result: #GDOEOWDOFFS:<OpenWireDOSDec>,<OpenWireDOSHex> <CR>	ASCII	
	TX	#255,GDOEOWDOFFS<CR>		
	RX	#255,GDOEOWDOFFS:0,0x0<CR>		
		Actual mode for open wire diagnostic while OFF of digital outputs:		
		DO1-DO15:000.0000.0000.0000		

Returns the actual mode for open wire diagnostic while digital output is OFF as decimal number and as hexadecimal number.

OpenWireDOSDec, OpenWireDOSHex

The current mode for open wire diagnostic while OFF of the digital outputs:

Bit 0: Open wire diagnostic mode of DO1 (=0:DISABLED, =1:ENABLED)

Bit 1: Open wire diagnostic mode of DO2 (=0:DISABLED, =1:ENABLED)

...

Bit 13: Open wire diagnostic mode of DO14 (=0:DISABLED, =1:ENABLED)

Bit 14: Open wire diagnostic mode of DO15 (=0:DISABLED, =1:ENABLED)

GET DIGITAL OUTPUT ENABLE OPEN WIRE DETECTION WHILE OFF	ASCII READ COMMAND	#GDOEOWDOFF<DONR> <CR> Result: #GDOEOWDOFF<DONR>:<OpenWireDOxDec>,<OpenWireDOxHex> <CR>	ASCII	
	DONR	2		
	TX	#255,GDOEOWDOFF2<CR>		
	RX	#255,GDOEOWDOFF2:0,0x0<CR>		

		Actual open wire diagnostic mode while OFF of digital output DO2:0=DISABLED		
<DONR>: 1=DO1..15=DO15				
Returns the actual open wire diagnostic mode while OFF of the digital output DOx as decimal number and as hexadecimal number. OpenWireDOxDec, OpenWireDOxHex The current diagnostic mode of the digital output DOx: =0: open wire diagnostic mode for digital output is DISABLED =1: open wire diagnostic mode for digital output is ENABLED				
<b>DIGITAL OUTPUTS: ENABLE SHORTCUT TO VDD DETECTION WHILE OFF</b>				
SET DIGITAL OUTPUTS ENABLE SHORTCUT TO VDD DETECTION WHILE OFF	ASCII WRITE COMMAND	#SDOESVDDS:<ShortCutDOS><CR> Result: #OK<CR>	ASCII	YES
	DO1	0:OFF		
	DO2	0:OFF		
	DO3	0:OFF		
	DO4	0:OFF		
	DO5	0:OFF		
	DO6	0:OFF		
	DO7	0:OFF		
	DO8	0:OFF		
	DO9	0:OFF		
	DO10	0:OFF		
	DO11	0:OFF		
	DO12	0:OFF		
	DO13	0:OFF		
	DO14	0:OFF		
	DO15	0:OFF		
	TX	#255,SDOESVDDS:0<CR>		
	RX	#255,OK<CR>		
Sets the shortcut to VDD detection mode for all digital outputs to the new mode ShortCutDOS. This enables the diagnostic of shortcut to VDD while the digital output is OFF. The new state for all digital outputs Bit 0: New mode for DO1 (=0:DISABLED, =1:ENABLED) Bit 1: New mode for DO2 (=0:DISABLED, =1:ENABLED) ... Bit 13: New mode for DO14 (=0:DISABLED, =1:ENABLED) Bit 14: New mode for DO15 (=0:DISABLED, =1:ENABLED)				
SET DIGITAL OUTPUT ENABLE SHORTCUT TO VDD DETECTION WHILE OFF	ASCII WRITE COMMAND	#SDOESVDD<DONR>:<ShortCutDOx><CR> Result: #OK<CR>	ASCII	YES
	DONR	2		
	DOx	0:DISABLE		
	TX	#255,SDOESVDD2:0<CR>		
	RX	#255,OK<CR>		
<DONR>: 1=DO1..15=DO15				
<ShortCutDOx>: 0=DISABLE..1=ENABLE				

Sets the shortcut to VDD mode for digital output DOx to the new mode ShortCutDOx. This enables the diagnostic of shortcut to VDD while the digital output is OFF.

The new mode of the digital output DOx:

=0: diagnostic mode for digital output is DISABLED

=1: diagnostic mode for digital output is ENABLED

GET DIGITAL OUTPUTS ENABLE SHORT CUT TO VDD DETECTION WHILE OFF	ASCII READ COMMAND	#GDOESVDDS<CR> Result: #GDOESDDS:<ShortCutDOSDec>,<ShortCutDOSHex><CR>	ASCII	
	TX	#255,GDOESVDDS<CR>		
	RX	#255,GDOESVDDS:0,0x0<CR>		
		Actual mode for shortcut to VDD diagnostic while OFF of digital outputs: DO1-DO15:000.0000.0000.0000		

Returns the actual mode for shortcut to VDD diagnostic while digital output is OFF as decimal number and as hexadecimal number.

ShortCutDOSDec, ShortCutDOSHex

The current mode for shortcut diagnostic while OFF of the digital outputs:

Bit 0: Open wire diagnostic mode of DO1 (=0:DISABLED, =1:ENABLED)

Bit 1: Open wire diagnostic mode of DO2 (=0:DISABLED, =1:ENABLED)

...

Bit 13: Open wire diagnostic mode of DO14 (=0:DISABLED, =1:ENABLED)

Bit 14: Open wire diagnostic mode of DO15 (=0:DISABLED, =1:ENABLED)

GET DIGITAL OUTPUT ENABLE SHORT CUT TO VDD DETECTION WHILE OFF	ASCII READ COMMAND	#GDOESVDD<DONR><CR> Result: #GDOESVDD<DONR>:<ShortCutDOxDec>,<ShortCutDOxHex><CR>	ASCII	
	DONR	2		
	TX	#255,GDOESVDD2<CR>		
	RX	#255,GDOESVDD2:0,0x0<CR>		
		Actual shortcut to VDD diagnostic mode while OFF of digital output DO2:0=DISABLED		

<DONR>: 1=DO1..15=DO15

Returns the actual short cut to VDD diagnostic mode while OFF of the digital output DOx as decimal number and as hexadecimal number.

ShortCutDOxDec, ShortCutDOxHex

The current diagnostic mode of the digital output DOx:

=0: open wire diagnostic mode for digital output is DISABLED

=1: open wire diagnostic mode for digital output is ENABLED

#### DIGITAL OUTPUTS: SPI STATUS

GET SPI STATUS DIGITAL OUTPUT GROUPS	ASCII READ COMMAND	#GSSDOGS<CR> Result: #GSSDOGS:<SPIDOGSDec>,<SPIDOGSHex><CR>	ASCII	
	TX	#255,GSSDOGS<CR>		
	RX	#255,GSSDOGS:0,0x0<CR>		
		Actual SPI status of digital output groups:00		

digital output group #1, chip #1:DO1-DO8

digital output group #2, chip #2:DO9-DO15

Returns the actual SPI communication state of the corresponding output group as decimal number and as hexadecimal number.

SPIDOGSDec,SPIDOGSHex

The current SPI communication state of the digital output group:

Bit 0: SPI communication state for digital output group #1 (=0:NO FAULT, =1:FAULT)

Bit 1: SPI communication state for digital output group #2 (=0:NO FAULT, =1:FAULT)

GET SPI STATUS DIGITAL OUTPUT GROUPx	ASCII READ COMMAND DOGRP	#GSSDOG<DOGRP><CR> Result: #GSSDOG<DOGRP>:<SPIDOGxDec>,<SPIDOGxHex><CR> 2	ASCII	
	TX	#255,GSSDOG2<CR>		
	RX	#255,GSSDOG2:0,0x0<CR>		
		Actual SPI status of digital output group DOG2:0=NO FAULT		
<DOGRP>: 1=CHIP1..2=CHIP2				
digital output group #1, chip #1:DO1-DO8 digital output group #2, chip #2:DO9-DO15				
Returns the actual SPI communication state of the digital output group DOGRP as decimal number and as hexadecimal number. SPIDOGxDec, SPIDOGxHex The current SPI communication state of the digital output group DOGRP: =0: SPI communication state for output group is OK (NO FAULT) =1: SPI communication state for output group is FAULT				
<b>DIGITAL OUTPUTS: INTERRUPT STATUS</b>				
GET DIGITAL OUTPUTS INTERRUPT STATUS	ASCII READ COMMAND DOGRP	#GDOINTS<CR> Result: #GDOINTS:<InterruptStatusDec>,<InterruptStatusHex><CR> 2	ASCII	
	TX	#255,GDOINTS<CR>		
	RX	#255,GDOINTS:16448,0x4040<CR>		
		Actual interrupt status of all digital output groups:		
		CHIP #1:0100.0000		
		CHIP #2:0100.0000		
digital output group #1, chip #1:DO1-DO8 digital output group #2, chip #2:DO9-DO15				
Returns the actual interrupt state of all output groups as decimal number and as hexadecimal number. InterruptStatusDec,InterruptStatusHex: The current interrupt state of digital output group 1-4 (CHIP1-4): For each chip 8 bits are used: CHIP#1:Bits 0-7, CHIP#2:Bits 8-15				
Bit 0: Overload detected (0=OK,1=FAULT) Bit 1: Current limit detected(0=OK,1=FAULT) Bit 2: Open wire while OFF detected (0=OK,1=FAULT) Bit 3: Open wire while ON detected (0=OK,1=FAULT) Bit 4: Short to VDD while ON detected (0=OK,1=FAULT) Bit 5: Thermal error detected-shutdown (0=OK,1=FAULT) Bit 6: Supply error detected (0=OK,1=FAULT) Bit 7: Communication error detected (0=OK,1=FAULT)				
GET DIGITAL OUTPUT GROUPx INTERRUPT STATUS	ASCII READ COMMAND DOGRP	#GDOINT<DOGRP><CR> Result: #GDOINT<DOGRP>:<InterruptStatusDec>,<InterruptStatusHex><CR> 2	ASCII	
	TX	#255,GDOINT2<CR>		
	RX	#255,GDOINT2:64,0x40<CR>		
		Actual interrupt status of digital output group 2:0100.0000		
<DOGRP>: 1=CHIP1..2=CHIP2				

digital output group #1, chip #1:DO1-DO8  
digital output group #2, chip #2:DO9-DO15

Returns the actual interrupt state of the digital output group DOGRP as decimal number and as hexadecimal number.

InterruptStatusDec, InterruptStatusHex

Bit 0:Overload detected (0=OK,1=FAULT)

Bit 1:Current limit detected(0=OK,1=FAULT)

Bit 2:Open wire while OFF detected (0=OK,1=FAULT)

Bit 3:Open wire while ON detected (0=OK,1=FAULT)

Bit 4:Short to VDD while ON detected (0=OK,1=FAULT)

Bit 5:Thermal error detected-shutdown (0=OK,1=FAULT)

Bit 6:Supply error detected (0=OK,1=FAULT)

Bit 7:Communication error detected (0=OK,1=FAULT)

#### DIGITAL OUTPUTS: GLOBAL ERRORS

GET DIGITAL OUTPUTS GLOBAL ERRORS	ASCII READ COMMAND	#GDOERRS<CR> Result: #GDOERRS:<GlobalErrorsDec>, <GlobalErrorsHex> <CR>	ASCII	
	TX	#255,GDOERRS<CR>		
	RX	#255,GDOERRS:7196,0x1C1C<CR>		
		Actual global errors of all digital output groups:		
		CHIP #1:0001.1100		
		CHIP #2:0001.1100		

digital output group #1, chip #1:DO1-DO8  
digital output group #2, chip #2:DO9-DO15

Returns the actual global error state of all output groups as decimal number and as hexadecimal number.

GlobalErrorsDec,GlobalErrorsHex: The current global error of all digital output groups 1-4 (CHIP1-4)

For each chip 8 bits are used: CHIP#1:Bits 0-7, CHIP#2:Bits 8-15

Bit 0: Internal under voltage detected (0=OK,1=FAULT)

Bit 1: VA under voltage detected (<2.3V) (0=OK,1=FAULT)

Bit 2: VDD not good detected (<17V) (0=OK,1=FAULT)

Bit 3: VDD warning detected (<12V) (0=OK,1=FAULT)

Bit 4: VDD under voltage detected (<8V) (0=OK,1=FAULT)

Bit 5: Thermal shutdown (0=OK,1=FAULT)

Bit 6: Synchronisation error detected (0=OK,1=FAULT)

Bit 7: Watchdog error detected (0=OK,1=FAULT)

GET DIGITAL OUTPUT GROUPx GLOBAL ERRORS	ASCII READ COMMAND	#GDOERR<DOGRP> <CR> Result: #GDOERR<DOGRP>:<GlobalErrorsDec>, <GlobalErrorsHex> <CR>	ASCII	
	DOGRP	2		
	TX	#255,GDOERR2<CR>		
	RX	#255,GDOERR2:28,0x1C<CR>		
		Actual global errors of digital output group 2:0001.1100		

<DOGRP>: 1=CHIP1..2=CHIP2

digital output group #1, chip #1:DO1-DO8  
digital output group #2, chip #2:DO9-DO15



Returns the actual interrupt state of the digital output group DOGRP as decimal number and as hexadecimal number.

InterruptStatusDec, InterruptStatusHex

Bit 0: Internal under voltage detected (0=OK,1=FAULT)

Bit 1: VA under voltage detected (<2.3V) (0=OK,1=FAULT)

Bit 2: VDD not good detected (<17V) (0=OK,1=FAULT)

Bit 3: VDD warning detected (<12V) (0=OK,1=FAULT)

Bit 4: VDD under voltage detected (<8V) (0=OK,1=FAULT)

Bit 5: Thermal shutdown (0=OK,1=FAULT)

Bit 6: Synchronisation error detected (0=OK,1=FAULT)

Bit 7: Watchdog error detected (0=OK,1=FAULT)

#### DIGITAL OUTPUTS: THERMAL OVERLOAD DETECTION

GET DIGITAL OUTPUTS THERMAL OVERLOAD DETECTION	ASCII READ COMMAND	#GDOTOS<CR> Result: #GDOTOS:<StatusDOSDec>,<StatusDOSHex> <CR>	ASCII	
	TX	#255,GDOTOS<CR>		
	RX	#255,GDOTOS:0,0x0<CR>		
		Actual thermal overload detection status of digital outputs:		
		DO1-DO15:000.0000.0000.0000		

Returns the actual state of the thermal overload detection for all digital outputs as decimal number and as hexadecimal number.

StatusDOSDec, StatusDOSHex

The current detection state of the digital outputs:

Bit 0: Thermal overload detected on DO1 (=0:NO, =1:YES)

Bit 1: Thermal overload detected on DO2 (=0:NO, =1:YES)

...

Bit 13: Thermal overload detected on DO14 (=0:NO, =1:YES)

Bit 14: Thermal overload detected on DO15 (=0:NO, =1:YES)

GET DIGITAL OUTPUT DOx THERMAL OVERLOAD DETECTION	ASCII READ COMMAND DONR	#GDOTO<DONR> <CR> Result: #GDOTO<DONR>:<StatusDOxDec>,<StatusDOxHex> <CR> 2	ASCII	
	TX	#255,GDOTO2<CR>		
	RX	#255,GDOTO2:0,0x0<CR>		
		Thermal overload detected on DO2:0=NO		

<DONR>: 1=DO1..15=DO15

Returns the actual state of the thermal overload detection for digital output DOx as decimal number and as hexadecimal number.

StatusDOxDec, StatusDOxHex

The current detection state for digital output DOx:

=0: digital output is OK

=1: FAULT detected on digital output

#### DIGITAL OUTPUTS: CURRENT LIMIT DETECTION

GET DIGITAL OUTPUTS CURRENT LIMIT DETECTION	ASCII READ COMMAND	#GDOCLS<CR> Result: #GDOCLS:<StatusDOSDec>,<StatusDOSHex> <CR>	ASCII	
	TX	#255,GDOCLS<CR>		
	RX	#255,GDOCLS:0,0x0<CR>		
		Actual current limit detection status of digital outputs:		
		DO1-DO15:000.0000.0000.0000		

Returns the actual state of the current limit detection for all digital outputs as decimal number and as hexadecimal number.

StatusDOSDec, StatusDOSHex

The current detection state of the digital outputs:

Bit 0: Current limit reached for DO1 (=0:NO, =1:YES)

Bit 1: Current limit reached for DO2 (=0:NO, =1:YES)

...

Bit 13: Current limit reached for DO14 (=0:NO, =1:YES)

Bit 14: Current limit reached for DO15 (=0:NO, =1:YES)

GET DIGITAL OUTPUT DOx CURRENT LIMIT DETECTION	ASCII READ COMMAND	#GDOCL<DONR> <CR> Result: #GDOCL<DONR>:<StatusDOxDec>,<StatusDOxHex> <CR>	ASCII	
	DONR	2		
	TX	#255,GDOCL2 <CR>		
	RX	#255,GDOCL2:0,0x0 <CR>		
		Actual current limit detection status of DO2:0=OK		

<DONR>: 1=DO1..15=DO15

Returns the actual state of the current limit detection for digital output DOx as decimal number and as hexadecimal number.

StatusDOxDec, StatusDOxHex

The current detection state for digital output DOx:

=0: digital output is OK

=1: FAULT detected on digital output

#### DIGITAL OUTPUTS: OPEN WIRE DETECTION WHILE ON

GET DIGITAL OUTPUTS OPEN WIRE FAULT DETECTION WHILE ON	ASCII READ COMMAND	#GDOOWFONS<CR> Result: #GDOOWFONS:<StatusDOSDec>,<StatusDOSHex> <CR>	ASCII	
	TX	#255,GDOOWFONS<CR>		
	RX	#255,GDOOWFONS:0,0x0<CR>		
		Actual open wire fault detection status while ON of digital outputs:		
		DO1-DO15:000.0000.0000.0000		

Returns the actual state of the open wire fault detection while ON for all digital outputs as decimal number and as hexadecimal number.

StatusDOSDec, StatusDOSHex

The current detection state of the digital outputs:

Bit 0: State of DO1 (=0:OK, =1:FAULT)

Bit 1: State of DO2 (=0:OK, =1:FAULT)

...

Bit 13: State of DO14 (=0:OK, =1:FAULT)

Bit 14: State of DO15 (=0:OK, =1:FAULT)

GET DIGITAL OUTPUT DOx OPEN WIRE FAULT DETECTION WHILE ON	ASCII READ COMMAND	#GDOOWFON<DONR> <CR> Result: #GDOOWFON<DONR>:<StatusDOxDec>,<StatusDOxHex> <CR>	ASCII	
	DONR	2		
	TX	#255,GDOOWFON2 <CR>		
	RX	#255,GDOOWFON2:0,0x0 <CR>		
		Actual open wire fault detection status while ON of DO2:0=OK		

<DONR>: 1=DO1..15=DO15

Returns the actual state of the open wire fault detection while ON for digital output DOx as decimal number and as hexadecimal number.

StatusDOxDec, StatusDOxHex

The current detection state for digital output DOx:

=0: digital output is OK

=1: FAULT detected on digital output

#### DIGITAL OUTPUTS: OPEN WIRE DETECTION WHILE OFF

GET DIGITAL OUTPUTS OPEN WIRE FAULT DETECTION WHILE OFF	ASCII READ COMMAND	#GDOOWFOFFS<CR> Result: #GDOOWFOFFS:<StatusDOSDec>,<StatusDOSHex><CR>	ASCII	
	TX	#255,GDOOWFOFFS<CR>		
	RX	#255,GDOOWFOFFS:0,0x0<CR>		
		Actual open wire fault detection status while OFF of digital outputs: DO1-DO15:000.0000.0000.0000		

Returns the actual state of the open wire fault detection while OFF for all digital outputs as decimal number and as hexadecimal number.

StatusDOSDec, StatusDOSHex

The current detection state of the digital outputs:

Bit 0: State of DO1 (=0:OK, =1:FAULT)

Bit 1: State of DO2 (=0:OK, =1:FAULT)

...

Bit 13: State of DO14 (=0:OK, =1:FAULT)

Bit 14: State of DO15 (=0:OK, =1:FAULT)

GET DIGITAL OUTPUT DOx OPEN WIRE FAULT DETECTION WHILE OFF	ASCII READ COMMAND	#GDOOWFOFF<DONR><CR> Result: #GDOOWFOFF<DONR>:<StatusDOxDec>,<StatusDOxHex><CR>	ASCII	
	DONR	2		
	TX	#255,GDOOWFOFF2<CR>		
	RX	#255,GDOOWFOFF2:0,0x0<CR>		
		Actual open wire fault detection status while OFF of DO2:0=OK		

<DONR>: 1=DO1..15=DO15

Returns the actual state of the open wire fault detection while OFF for digital output DOx as decimal number and as hexadecimal number.

StatusDOxDec, StatusDOxHex

The current detection state for digital output DOx:

=0: digital output is OK

=1: FAULT detected on digital output

#### DIGITAL OUTPUTS: SHORTCUT TO VDD DETECTION WHILE OFF

GET DIGITAL OUTPUTS SHORTCUT TO VDD FAULT DETECTION WHILE OFF	ASCII READ COMMAND	#GDOSVDDS<CR> Result: #GDOSVDDS:<StatusDOSDec>,<StatusDOSHex><CR>	ASCII	
	TX	#255,GDOSVDDS<CR>		
	RX	#255,GDOSVDDS:0,0x0<CR>		
		Actual shortcut to VDD fault detection status while OFF of digital outputs: DO1-DO15:000.0000.0000.0000		

Returns the actual state of the shortcut to VDD fault detection while OFF for all digital outputs as decimal number and as hexadecimal number.

StatusDOSDec, StatusDOSHex

The current detection state of the digital outputs:

Bit 0: State of DO1 (=0:OK, =1:FAULT)

Bit 1: State of DO2 (=0:OK, =1:FAULT)

...

Bit 13: State of DO14 (=0:OK, =1:FAULT)

Bit 14: State of DO15 (=0:OK, =1:FAULT)

GET DIGITAL OUTPUT DOx SHORTCUT TO VDD FAULT DETECTION WHILE OFF	ASCII READ COMMAND	#GDOSVDD<DONR><CR> Result: #GDOSVDD<DONR>:<StatusDOxDec>,<StatusDOxHex><CR>	ASCII	
	DONR	2		
	TX	#255,GDOSVDD2<CR>		
	RX	#255,GDOSVDD2:0,0x0<CR>		
		Actual shortcut to VDD fault detection status while OFF of DO2:0=OK		

<DONR>: 1=DO1..15=DO15

Returns the actual state of the shortcut to VDD fault detection while OFF for digital output DOx as decimal number and as hexadecimal number.

StatusDOxDec, StatusDOxHex

The current detection state for digital output DOx:

=0: digital output is OK

=1: FAULT detected on digital output

GET DIGITAL OUTPUTS CHIPSET NAME	ASCII READ COMMAND	#GDOCHIPSET<CR> Result: #GDOCHIPSET:<ChipSetName>	ASCII	
	TX	#255,GDOCHIPSET<CR>		
	RX	#255,GDOCHIPSET:MAX14915<CR>		
		Actual name of chipset for digital outputs:MAX14915		

Returns the actual name of the chipset of the digital outputs

Command NAME	ASCII command type	ASCII command structure	NEW REAL VALUE	NEW VALUE	DATA TYPE	DO WRITE
<b>ASCII COMMANDS</b>						
<b>DIGITAL OUTPUTS</b>						
<b>INITIAL &amp; WATCHDOG STATE FOR DIGITAL OUTPUTS</b>						
SET INITIAL & WATCHDOG STATE FOR DIGITAL OUTPUTS	ASCII WRITE COMMAND	#SCDOS:<OutAllDOS> <CR> Result: #OK<CR>			ASCII	YES
	DO1	0:OFF				
	DO2	0:OFF				
	DO3	0:OFF				
	DO4	0:OFF				
	DO5	0:OFF				
	DO6	0:OFF				
	DO7	0:OFF				
	DO8	0:OFF				
	DO9	0:OFF				
	DO10	0:OFF				
	DO11	0:OFF				
	DO12	0:OFF				
	DO13	0:OFF				
	DO14	0:OFF				
	DO15	0:OFF				
	TX	#255,SCDOS:0<CR>				
	RX	#255,OK<CR>				
<p>This command sets all digital outputs to a new state for controller restart and watchdog function. The state is saved in FRAM. This state is used after power on and after a communication watchdog timeout, if a watchdog time is configured.</p> <p>OutAllDOS The new state for the digital outputs: Bit 0: New state of DO1 (=0:OFF, =1:ON) Bit 1: New state of DO2 (=0:OFF, =1:ON) ... Bit 13: New state of DO14 (=0:OFF, =1:ON) Bit 14: New state of DO15 (=0:OFF, =1:ON)</p>						
GET INITIAL & WATCHDOG STATE FOR DIGITAL OUTPUTS	ASCII READ COMMAND	#GCDOS<CR> Result: #GCDOS:<DOSDec>,<DOSHex><CR>			ASCII	
	TX	#255,GCDOS<CR>				
	RX	#255,GDOS:0,0x0<CR>				
		Init & watchdog configuration for digital outputs:				
		DO1-DO15:000.0000.0000.0000				

Returns the actual initial and watchdog state of the digital outputs as decimal number and as hexadecimal number. This state is used after power on and after a communication watchdog timeout, if a watchdog time is configured

DOSDec, DOSHex

The current state of the digital outputs:

Bit 0: State of DO1 (=0:OFF, =1:ON)

Bit 1: State of DO2 (=0:OFF, =1:ON)

...

Bit 13: State of DO14 (=0:OFF, =1:ON)

Bit 14: State of DO15 (=0:OFF, =1:ON)

#### DIGITAL OUTPUTS: INIT & WATCHDOG ENABLE OPEN WIRE DETECTION WHILE ON

SET CONFIG DIGITAL OUTPUTS ENABLE OPEN WIRE DETECTION WHILE ON	ASCII WRITE COMMAND	#SCDOEOWDONS:<OpenWireDOS> <CR> Result: #OK<CR>	ASCII	YES
	DO1	1:ENABLE		
	DO2	1:ENABLE		
	DO3	1:ENABLE		
	DO4	1:ENABLE		
	DO5	1:ENABLE		
	DO6	1:ENABLE		
	DO7	1:ENABLE		
	DO8	1:ENABLE		
	DO9	1:ENABLE		
	DO10	1:ENABLE		
	DO11	1:ENABLE		
	DO12	1:ENABLE		
	DO13	1:ENABLE		
	DO14	1:ENABLE		
	DO15	1:ENABLE		
	TX	#255,SCDOEOWDONS:32767 <CR>		
	RX	#255,OK <CR>		

Sets the open wire mode for all digital outputs to the new mode OpenWireDOS for init & watchdog. This enables the diagnostic of open wire while the digital output is ON.

This state is used after power on and after a communication watchdog timeout, if a watchdog time is configured

The new state for all digital outputs

Bit 0: New mode for DO1 (=0:DISABLED, =1:ENABLED)

Bit 1: New mode for DO2 (=0:DISABLED, =1:ENABLED)

...

Bit 13: New mode for DO14 (=0:DISABLED, =1:ENABLED)

Bit 14: New mode for DO15 (=0:DISABLED, =1:ENABLED)

GET CONFIG DIGITAL OUTPUTS ENABLE OPEN WIRE DETECTION WHILE ON	ASCII READ COMMAND	#GCDOEOWDONS<CR> Result: #GCDOEOWDONS:<OpenWireDOSDec>,<OpenWireDOSHex> <CR>	ASCII	
	TX	#255,GCDOEOWDONS<CR>		
	RX	#255,GCDOEOWDONS:0,0x0<CR>		
		Init & watchdog configuration for open wire diagnostic while ON of digital outputs:		
		DO1-DO15:000.0000.0000.0000		

Returns the actual mode for open wire diagnostic while digital output is ON as decimal number and as hexadecimal number.

This values are used after power on of the module an after a watchdog event.

OpenWireDOSDec, OpenWireDOSHex

The current mode for open wire diagnostic while ON of the digital outputs:

Bit 0: Open wire diagnostic mode of DO1 (=0:DISABLED, =1:ENABLED)

Bit 1: Open wire diagnostic mode of DO2 (=0:DISABLED, =1:ENABLED)

...

Bit 13: Open wire diagnostic mode of DO14 (=0:DISABLED, =1:ENABLED)

Bit 14: Open wire diagnostic mode of DO15 (=0:DISABLED, =1:ENABLED)

#### DIGITAL OUTPUTS: INIT & WATCHDOG ENABLE OPEN WIRE DETECTION WHILE OFF

SET CONFIG DIGITAL OUTPUTS ENABLE OPEN WIRE DETECTION WHILE OFF	ASCII WRITE COMMAND	#SCDOEOWDOFFS:<OpenWireDOS> <CR> Result: #OK <CR>	ASCII	YES
	DO1	1:ENABLE		
	DO2	1:ENABLE		
	DO3	1:ENABLE		
	DO4	1:ENABLE		
	DO5	1:ENABLE		
	DO6	1:ENABLE		
	DO7	1:ENABLE		
	DO8	1:ENABLE		
	DO9	1:ENABLE		
	DO10	1:ENABLE		
	DO11	1:ENABLE		
	DO12	1:ENABLE		
	DO13	1:ENABLE		
	DO14	1:ENABLE		
	DO15	1:ENABLE		
	TX	#255,SCDOEOWDOFFS:32767 <CR>		
	RX	#255,OK <CR>		

Sets the open wire mode for all digital outputs to the new mode OpenWireDOS for init & watchdog. This enables the diagnostic of open wire while the digital output is OFF.

This state is used after power on and after a communication watchdog timeout, if a watchdog time is configured

The new state for all digital outputs

Bit 0: New mode for DO1 (=0:DISABLED, =1:ENABLED)

Bit 1: New mode for DO2 (=0:DISABLED, =1:ENABLED)

...

Bit 13: New mode for DO14 (=0:DISABLED, =1:ENABLED)

Bit 14: New mode for DO15 (=0:DISABLED, =1:ENABLED)

GET CONFIG DIGITAL OUTPUTS ENABLE OPEN WIRE DETECTION WHILE OFF	ASCII READ COMMAND	#GCDOEOWDOFFS <CR> Result: #GCDOEOWDOFFS:<OpenWireDOSDec>, <OpenWireDOSHex> <CR>	ASCII	
	TX	#255,GCDOEOWDOFFS <CR>		
	RX	#255,GCDOEOWDOFFS:0,0x0 <CR>		
		Init & watchdog configuration for open wire diagnostic while OFF of digital outputs:		
		DO1-DO15:000.0000.0000.0000		

Returns the actual mode for open wire diagnostic while digital output is OFF as decimal number and as hexadecimal number.

This values are used after power on of the module an after a watchdog event.

OpenWireDOSDec, OpenWireDOSHex

The current mode for open wire diagnostic while OFF of the digital outputs:

Bit 0: Open wire diagnostic mode of DO1 (=0:DISABLED, =1:ENABLED)

Bit 1: Open wire diagnostic mode of DO2 (=0:DISABLED, =1:ENABLED)

...

Bit 13: Open wire diagnostic mode of DO14 (=0:DISABLED, =1:ENABLED)

Bit 14: Open wire diagnostic mode of DO15 (=0:DISABLED, =1:ENABLED)

#### DIGITAL OUTPUTS: INIT & WATCHDOG ENABLE SHORTCUT TO VDD DETECTION WHILE OFF

SET CONFIG DIGITAL OUTPUTS ENABLE SHORTCUT TO VDD DETECTION WHILE OFF	ASCII WRITE COMMAND	#SCDOESVDDS:<ShortCutDOS> <CR> Result: #OK <CR>	ASCII	YES
	DO1	1:ENABLE		
	DO2	1:ENABLE		
	DO3	1:ENABLE		
	DO4	1:ENABLE		
	DO5	1:ENABLE		
	DO6	1:ENABLE		
	DO7	1:ENABLE		
	DO8	1:ENABLE		
	DO9	1:ENABLE		
	DO10	1:ENABLE		
	DO11	1:ENABLE		
	DO12	1:ENABLE		
	DO13	1:ENABLE		
	DO14	1:ENABLE		
	DO15	1:ENABLE		
	TX	#255,SCDOESVDDS:32767 <CR>		
	RX	#255,OK <CR>		

Sets the shortcut to VDD detection mode for all digital outputs to the new mode ShortCutDOS for init & watchdog.

This enables the diagnostic of shortcut to VDD while the digital output is OFF.

This state is used after power on and after a communication watchdog timeout, if a watchdog time is configured

The new state for all digital outputs

Bit 0: New mode for DO1 (=0:DISABLED, =1:ENABLED)

Bit 1: New mode for DO2 (=0:DISABLED, =1:ENABLED)

...

Bit 13: New mode for DO14 (=0:DISABLED, =1:ENABLED)

Bit 14: New mode for DO15 (=0:DISABLED, =1:ENABLED)

GET CONFIG DIGITAL OUTPUTS ENABLE SHORT CUT TO VDD DETECTION WHILE OFF	ASCII READ COMMAND	#GCDOESVDDS <CR> Result: #GCDOESDDS:<ShortCutDOSDec>, <ShortCutDOSHex> <CR>	ASCII	
	TX	#255,GCDOESVDDS <CR>		
	RX	#255,GCDOESVDDS:0,0x0 <CR>		
		Init & watchdog configuration for shortcut to VDD diagnostic while OFF of digital outputs:		
		DO1-DO15:000.0000.0000.0000		



Returns the actual mode for shortcut to VDD diagnostic while digital output is OFF as decimal number and as hexadecimal number.

This values are used after power on of the module an after a watchdog event.

ShortCutDOSDec, ShortCutDOSHex

The current mode for shortcut diagnostic while OFF of the digital outputs:

Bit 0: Open wire diagnostic mode of DO1 (=0:DISABLED, =1:ENABLED)

Bit 1: Open wire diagnostic mode of DO2 (=0:DISABLED, =1:ENABLED)

...

Bit 13: Open wire diagnostic mode of DO14 (=0:DISABLED, =1:ENABLED)

Bit 14: Open wire diagnostic mode of DO15 (=0:DISABLED, =1:ENABLED)

Register NAME Command NAME	MODBUS Register ASCII Command	Register VALUE ASCII Command	NEW REAL VALUE	NEW VALUE	DATA TYPE	DO WRITE
<b>STATUS DIGITAL INPUTS</b>						
DI1	1x00001 2x00001 I:0	????			BIT R/O	
Actual state of DI1:0=OFF						
Current state of the digital input DIx =0:DI is OFF, =1:DI is ON						
DI2	1x00002 2x00002 I:1	????			BIT R/O	
Actual state of DI2:0=OFF						
DI3	1x00003 2x00003 I:2	????			BIT R/O	
Actual state of DI3:0=OFF						
DI4	1x00004 2x00004 I:3	????			BIT R/O	
Actual state of DI4:0=OFF						
DI5	1x00005 2x00005 I:4	????			BIT R/O	
Actual state of DI5:0=OFF						
DI6	1x00006 2x00006 I:5	????			BIT R/O	
Actual state of DI6:0=OFF						
DI7	1x00007 2x00007 I:6	????			BIT R/O	
Actual state of DI7:0=OFF						
DI8	1x00008 2x00008 I:7	????			BIT R/O	
Actual state of DI8:0=OFF						
DI9	1x00009 2x00009 I:8	????			BIT R/O	
Actual state of DI9:0=OFF						
DI10	1x00010 2x00010 I:9	????			BIT R/O	

		Actual state of DI10:0=OFF				
DI11	1x00011 2x00011 I:10	????			BIT R/O	
		Actual state of DI11:0=OFF				
DI12	1x00012 2x00012 I:11	????			BIT R/O	
		Actual state of DI12:0=OFF				
DI13	1x00013 2x00013 I:12	????			BIT R/O	
		Actual state of DI13:0=OFF				
DI14	1x00014 2x00014 I:13	????			BIT R/O	
		Actual state of DI14:0=OFF				
DI15	1x00015 2x00015 I:14	????			BIT R/O	
		Actual state of DI15:0=OFF				
DI16	1x00016 2x00016 I:15	????			BIT R/O	
		Actual state of DI16:0=OFF				
<b>STATUS DIGITAL OUTPUTS</b>						
DO1	1x00017 2x00017 I:16	????		1	BIT R/W	NO
		Actual state of DO1:0=OFF			ENTER NEW STATE (0 or 1)	
Current state of the digital output DOx =0:DO is OFF, =1:DO is ON						
Writing on this register changes the state of the digital output						
DO2	1x00018 2x00018 I:17	????		0	BIT R/W	NO
		Actual state of DO2:0=OFF			ENTER NEW STATE (0 or 1)	
DO3	1x00019 2x00019 I:18	????		0	BIT R/W	NO
		Actual state of DO3:0=OFF			ENTER NEW STATE (0 or 1)	
DO4	1x00020 2x00020 I:19	????		0	BIT R/W	NO
		Actual state of DO4:0=OFF			ENTER NEW STATE (0 or 1)	

DO5	1x00021 2x00021 I:20	????		0	BIT R/W	NO
		Actual state of DO5:0=OFF		ENTER NEW STATE (0 or 1)		
DO6	1x00022 2x00022 I:21	????		0	BIT R/W	NO
		Actual state of DO6:0=OFF		ENTER NEW STATE (0 or 1)		
DO7	1x00023 2x00023 I:22	????		0	BIT R/W	NO
		Actual state of DO7:0=OFF		ENTER NEW STATE (0 or 1)		
DO8	1x00024 2x00024 I:23	????		0	BIT R/W	NO
		Actual state of DO8:0=OFF		ENTER NEW STATE (0 or 1)		
DO9	1x00025 2x00025 I:24	????		0	BIT R/W	NO
		Actual state of DO9:0=OFF		ENTER NEW STATE (0 or 1)		
DO10	1x00026 2x00026 I:25	????		0	BIT R/W	NO
		Actual state of DO10:0=OFF		ENTER NEW STATE (0 or 1)		
DO11	1x00027 2x00027 I:26	????		0	BIT R/W	NO
		Actual state of DO11:0=OFF		ENTER NEW STATE (0 or 1)		
DO12	1x00028 2x00028 I:27	????		0	BIT R/W	NO
		Actual state of DO12:0=OFF		ENTER NEW STATE (0 or 1)		
DO13	1x00029 2x00029 I:28	????		0	BIT R/W	NO
		Actual state of DO13:0=OFF		ENTER NEW STATE (0 or 1)		
DO14	1x00030 2x00030 I:29	????		0	BIT R/W	NO
		Actual state of DO14:0=OFF		ENTER NEW STATE (0 or 1)		
DO15	1x00031 2x00031 I:30	????		0	BIT R/W	NO
		Actual state of DO15:0=OFF		ENTER NEW STATE (0 or 1)		

DIGITAL OUTPUTS: ENABLE OPEN WIRE DETECTION ON

ENABLE OPEN WIRE DETECTION ON DO1	1x00032 2x00032 I:31	????		1		BIT R/W	NO
		Actual setup of open wire detection for state ON of DO1:0=OFF		ENTER NEW SETUP MODE (0 or 1)			
Enables/disabled detection of an open wire in DO state ON for the digital output DOx =0:Open wire detection is OFF, =1:Open wire detection is ON							
Writing on this register changes the state of the open wire detection for this output							
ENABLE OPEN WIRE DETECTION ON DO2	1x00033 2x00033 I:32	????		1		BIT R/W	NO
		Actual setup of open wire detection for state ON of DO2:0=OFF		ENTER NEW SETUP MODE (0 or 1)			
ENABLE OPEN WIRE DETECTION ON DO3	1x00034 2x00034 I:33	????		1		BIT R/W	NO
		Actual setup of open wire detection for state ON of DO3:0=OFF		ENTER NEW SETUP MODE (0 or 1)			
ENABLE OPEN WIRE DETECTION ON DO4	1x00035 2x00035 I:34	????		1		BIT R/W	NO
		Actual setup of open wire detection for state ON of DO4:0=OFF		ENTER NEW SETUP MODE (0 or 1)			
ENABLE OPEN WIRE DETECTION ON DO5	1x00036 2x00036 I:35	????		1		BIT R/W	NO
		Actual setup of open wire detection for state ON of DO5:0=OFF		ENTER NEW SETUP MODE (0 or 1)			
ENABLE OPEN WIRE DETECTION ON DO6	1x00037 2x00037 I:36	????		1		BIT R/W	NO
		Actual setup of open wire detection for state ON of DO6:0=OFF		ENTER NEW SETUP MODE (0 or 1)			
ENABLE OPEN WIRE DETECTION ON DO7	1x00038 2x00038 I:37	????		1		BIT R/W	NO
		Actual setup of open wire detection for state ON of DO7:0=OFF		ENTER NEW SETUP MODE (0 or 1)			
ENABLE OPEN WIRE DETECTION ON DO8	1x00039 2x00039 I:38	????		1		BIT R/W	NO
		Actual setup of open wire detection for state ON of DO8:0=OFF		ENTER NEW SETUP MODE (0 or 1)			
ENABLE OPEN WIRE DETECTION ON DO9	1x00040 2x00040 I:39	????		1		BIT R/W	NO

		Actual setup of open wire detection for state ON of DO9:0=OFF	ENTER NEW SETUP MODE (0 or 1)		
ENABLE OPEN WIRE DETECTION ON DO10	1x00041 2x00041 l:40	????	1	BIT R/W	NO
		Actual setup of open wire detection for state ON of DO10:0=OFF	ENTER NEW SETUP MODE (0 or 1)		
ENABLE OPEN WIRE DETECTION ON DO11	1x00042 2x00042 l:41	????	1	BIT R/W	NO
		Actual setup of open wire detection for state ON of DO11:0=OFF	ENTER NEW SETUP MODE (0 or 1)		
ENABLE OPEN WIRE DETECTION ON DO12	1x00043 2x00043 l:42	????	1	BIT R/W	NO
		Actual setup of open wire detection for state ON of DO12:0=OFF	ENTER NEW SETUP MODE (0 or 1)		
ENABLE OPEN WIRE DETECTION ON DO13	1x00044 2x00044 l:43	????	1	BIT R/W	NO
		Actual setup of open wire detection for state ON of DO13:0=OFF	ENTER NEW SETUP MODE (0 or 1)		
ENABLE OPEN WIRE DETECTION ON DO14	1x00045 2x00045 l:44	????	1	BIT R/W	NO
		Actual setup of open wire detection for state ON of DO14:0=OFF	ENTER NEW SETUP MODE (0 or 1)		
ENABLE OPEN WIRE DETECTION ON DO15	1x00046 2x00046 l:45	????	1	BIT R/W	NO
		Actual setup of open wire detection for state ON of DO15:0=OFF	ENTER NEW SETUP MODE (0 or 1)		
<b>DIGITAL OUTPUTS: ENABLE OPEN WIRE DETECTION OFF</b>					
ENABLE OPEN WIRE DETECTION OFF DO1	1x00047 2x00047 l:46	????	1	BIT R/W	NO
		Actual setup of open wire detection for state OFF of DO1:0=OFF	ENTER NEW SETUP MODE (0 or 1)		
Enables/disabled detection of an open wire in DO state OFF for the digital output DOx =0:Open wire detection is OFF, =1:Open wire detection is ON					
Writing on this register changes the state of the open wire detection for this output					
ENABLE OPEN WIRE DETECTION OFF DO2	1x00048 2x00048 l:47	????	1	BIT R/W	NO
		Actual setup of open wire detection for state OFF of DO2:0=OFF	ENTER NEW SETUP MODE (0 or 1)		

ENABLE OPEN WIRE DETECTION OFF DO3	1x00049 2x00049 I:48	????		1		BIT R/W	NO
		Actual setup of open wire detection for state OFF of DO3:0=OFF		ENTER NEW SETUP MODE (0 or 1)			
ENABLE OPEN WIRE DETECTION OFF DO4	1x00050 2x00050 I:49	????		1		BIT R/W	NO
		Actual setup of open wire detection for state OFF of DO4:0=OFF		ENTER NEW SETUP MODE (0 or 1)			
ENABLE OPEN WIRE DETECTION OFF DO5	1x00051 2x00051 I:50	????		1		BIT R/W	NO
		Actual setup of open wire detection for state OFF of DO5:0=OFF		ENTER NEW SETUP MODE (0 or 1)			
ENABLE OPEN WIRE DETECTION OFF DO6	1x00052 2x00052 I:51	????		1		BIT R/W	NO
		Actual setup of open wire detection for state OFF of DO6:0=OFF		ENTER NEW SETUP MODE (0 or 1)			
ENABLE OPEN WIRE DETECTION OFF DO7	1x00053 2x00053 I:52	????		1		BIT R/W	NO
		Actual setup of open wire detection for state OFF of DO7:0=OFF		ENTER NEW SETUP MODE (0 or 1)			
ENABLE OPEN WIRE DETECTION OFF DO8	1x00054 2x00054 I:53	????		1		BIT R/W	NO
		Actual setup of open wire detection for state OFF of DO8:0=OFF		ENTER NEW SETUP MODE (0 or 1)			
ENABLE OPEN WIRE DETECTION OFF DO9	1x00055 2x00055 I:54	????		1		BIT R/W	NO
		Actual setup of open wire detection for state OFF of DO9:0=OFF		ENTER NEW SETUP MODE (0 or 1)			
ENABLE OPEN WIRE DETECTION OFF DO10	1x00056 2x00056 I:55	????		1		BIT R/W	NO
		Actual setup of open wire detection for state OFF of DO10:0=OFF		ENTER NEW SETUP MODE (0 or 1)			
ENABLE OPEN WIRE DETECTION OFF DO11	1x00057 2x00057 I:56	????		1		BIT R/W	NO
		Actual setup of open wire detection for state OFF of DO11:0=OFF		ENTER NEW SETUP MODE (0 or 1)			

ENABLE OPEN WIRE DETECTION OFF DO12	1x00058 2x00058 l:57	????		1		BIT R/W	NO
		Actual setup of open wire detection for state OFF of DO12:0=OFF		ENTER NEW SETUP MODE (0 or 1)			
ENABLE OPEN WIRE DETECTION OFF DO13	1x00059 2x00059 l:58	????		1		BIT R/W	NO
		Actual setup of open wire detection for state OFF of DO13:0=OFF		ENTER NEW SETUP MODE (0 or 1)			
ENABLE OPEN WIRE DETECTION OFF DO14	1x00060 2x00060 l:59	????		1		BIT R/W	NO
		Actual setup of open wire detection for state OFF of DO14:0=OFF		ENTER NEW SETUP MODE (0 or 1)			
ENABLE OPEN WIRE DETECTION OFF DO15	1x00061 2x00061 l:60	????		1		BIT R/W	NO
		Actual setup of open wire detection for state OFF of DO15:0=OFF		ENTER NEW SETUP MODE (0 or 1)			
<b>DIGITAL OUTPUTS: ENABLE SHORT TO VDD DETECTION</b>							
ENABLE SHORT TO VDD DETECTION DO1	1x00062 2x00062 l:61	????		1		BIT R/W	NO
		Actual setup of open wire detection for state OFF of DO1:0=OFF		ENTER NEW SETUP MODE (0 or 1)			
Enables/disabled detection of a shortcut to VDD in DO state OFF for the digital output DOx =0:Shortcut to VDD detection is OFF, =1:Shortcut to VDD detection is ON							
Writing on this register changes the state of the shortcut detection for this output							
ENABLE SHORT TO VDD DETECTION DO2	1x00063 2x00063 l:62	????		1		BIT R/W	NO
		Actual setup of open wire detection for state OFF of DO2:0=OFF		ENTER NEW SETUP MODE (0 or 1)			
ENABLE SHORT TO VDD DETECTION DO3	1x00064 2x00064 l:63	????		1		BIT R/W	NO
		Actual setup of open wire detection for state OFF of DO3:0=OFF		ENTER NEW SETUP MODE (0 or 1)			
ENABLE SHORT TO VDD DETECTION DO4	1x00065 2x00065 l:64	????		1		BIT R/W	NO
		Actual setup of open wire detection for state OFF of DO4:0=OFF		ENTER NEW SETUP MODE (0 or 1)			
ENABLE SHORT TO VDD DETECTION DO5	1x00066 2x00066 l:65	????		1		BIT R/W	NO



		Actual setup of open wire detection for state OFF of DO5:0=OFF	ENTER NEW SETUP MODE (0 or 1)		
ENABLE SHORT TO VDD DETECTION DO6	1x00067 2x00067 I:66	????	1	BIT R/W	NO
		Actual setup of open wire detection for state OFF of DO6:0=OFF	ENTER NEW SETUP MODE (0 or 1)		
ENABLE SHORT TO VDD DETECTION DO7	1x00068 2x00068 I:67	????	1	BIT R/W	NO
		Actual setup of open wire detection for state OFF of DO7:0=OFF	ENTER NEW SETUP MODE (0 or 1)		
ENABLE SHORT TO VDD DETECTION DO8	1x00069 2x00069 I:68	????	1	BIT R/W	NO
		Actual setup of open wire detection for state OFF of DO8:0=OFF	ENTER NEW SETUP MODE (0 or 1)		
ENABLE SHORT TO VDD DETECTION DO9	1x00070 2x00070 I:69	????	1	BIT R/W	NO
		Actual setup of open wire detection for state OFF of DO9:0=OFF	ENTER NEW SETUP MODE (0 or 1)		
ENABLE SHORT TO VDD DETECTION DO10	1x00071 2x00071 I:70	????	1	BIT R/W	NO
		Actual setup of open wire detection for state OFF of DO10:0=OFF	ENTER NEW SETUP MODE (0 or 1)		
ENABLE SHORT TO VDD DETECTION DO11	1x00072 2x00072 I:71	????	1	BIT R/W	NO
		Actual setup of open wire detection for state OFF of DO11:0=OFF	ENTER NEW SETUP MODE (0 or 1)		
ENABLE SHORT TO VDD DETECTION DO12	1x00073 2x00073 I:72	????	1	BIT R/W	NO
		Actual setup of open wire detection for state OFF of DO12:0=OFF	ENTER NEW SETUP MODE (0 or 1)		
ENABLE SHORT TO VDD DETECTION DO13	1x00074 2x00074 I:73	????	1	BIT R/W	NO
		Actual setup of open wire detection for state OFF of DO13:0=OFF	ENTER NEW SETUP MODE (0 or 1)		
ENABLE SHORT TO VDD DETECTION DO14	1x00075 2x00075 I:74	????	1	BIT R/W	NO
		Actual setup of open wire detection for state OFF of DO14:0=OFF	ENTER NEW SETUP MODE (0 or 1)		

ENABLE SHORT TO VDD DETECTION DO15	1x00076 2x00076 I:75	????		1		BIT R/W	NO
		Actual setup of open wire detection for state OFF of DO15:0=OFF		ENTER NEW SETUP MODE (0 or 1)			
<b>DIGITAL OUTPUTS: OPEN WIRE DETECTION STATUS WHILE ON</b>							
OPEN WIRE FAULT WHILE ON DO1	1x00077 2x00077 I:76	????				BIT R/O	
		Actual detection state of an open wire fault in state ON for DO1:0=OK					
The current detection state of an open wire in the output state ON for the digital output DOx =0:No fault, =1:Fault-open wire detected							
OPEN WIRE FAULT WHILE ON DO2	1x00078 2x00078 I:77	????				BIT R/O	
		Actual detection state of an open wire fault in state ON for DO2:0=OK					
OPEN WIRE FAULT WHILE ON DO3	1x00079 2x00079 I:78	????				BIT R/O	
		Actual detection state of an open wire fault in state ON for DO3:0=OK					
OPEN WIRE FAULT WHILE ON DO4	1x00080 2x00080 I:79	????				BIT R/O	
		Actual detection state of an open wire fault in state ON for DO4:0=OK					
OPEN WIRE FAULT WHILE ON DO5	1x00081 2x00081 I:80	????				BIT R/O	
		Actual detection state of an open wire fault in state ON for DO5:0=OK					
OPEN WIRE FAULT WHILE ON DO6	1x00082 2x00082 I:81	????				BIT R/O	
		Actual detection state of an open wire fault in state ON for DO6:0=OK					
OPEN WIRE FAULT WHILE ON DO7	1x00083 2x00083 I:82	????				BIT R/O	
		Actual detection state of an open wire fault in state ON for DO7:0=OK					
OPEN WIRE FAULT WHILE ON DO8	1x00084 2x00084 I:83	????				BIT R/O	

		Actual detection state of an open wire fault in state ON for DO8:0=OK			
OPEN WIRE FAULT WHILE ON DO9	1x00085 2x00085 I:84	????			BIT R/O
		Actual detection state of an open wire fault in state ON for DO9:0=OK			
OPEN WIRE FAULT WHILE ON DO10	1x00086 2x00086 I:85	????			BIT R/O
		Actual detection state of an open wire fault in state ON for DO10:0=OK			
OPEN WIRE FAULT WHILE ON DO11	1x00087 2x00087 I:86	????			BIT R/O
		Actual detection state of an open wire fault in state ON for DO11:0=OK			
OPEN WIRE FAULT WHILE ON DO12	1x00088 2x00088 I:87	????			BIT R/O
		Actual detection state of an open wire fault in state ON for DO12:0=OK			
OPEN WIRE FAULT WHILE ON DO13	1x00089 2x00089 I:88	????			BIT R/O
		Actual detection state of an open wire fault in state ON for DO13:0=OK			
OPEN WIRE FAULT WHILE ON DO14	1x00090 2x00090 I:89	????			BIT R/O
		Actual detection state of an open wire fault in state ON for DO14:0=OK			
OPEN WIRE FAULT WHILE ON DO15	1x00091 2x00091 I:90	????			BIT R/O
		Actual detection state of an open wire fault in state ON for DO15:0=OK			
<b>DIGITAL OUTPUTS: OPEN WIRE DETECTION STATUS WHILE OFF</b>					
OPEN WIRE FAULT WHILE OFF DO1	1x00092 2x00092 I:91	????			BIT R/O
		Actual detection state of an open wire fault in state OFF for DO1:0=OK			
The current detection state of an open wire in the output state OFF for the digital output DOx =0:No fault, =1:Fault-open wire detected					

OPEN WIRE FAULT WHILE OFF DO2	1x00093 2x00093 I:92	????			BIT R/O	
		Actual detection state of an open wire fault in state OFF for DO2:0=OK				
OPEN WIRE FAULT WHILE OFF DO3	1x00094 2x00094 I:93	????			BIT R/O	
		Actual detection state of an open wire fault in state OFF for DO3:0=OK				
OPEN WIRE FAULT WHILE OFF DO4	1x00095 2x00095 I:94	????			BIT R/O	
		Actual detection state of an open wire fault in state OFF for DO4:0=OK				
OPEN WIRE FAULT WHILE OFF DO5	1x00096 2x00096 I:95	????			BIT R/O	
		Actual detection state of an open wire fault in state OFF for DO5:0=OK				
OPEN WIRE FAULT WHILE OFF DO6	1x00097 2x00097 I:96	????			BIT R/O	
		Actual detection state of an open wire fault in state OFF for DO6:0=OK				
OPEN WIRE FAULT WHILE OFF DO7	1x00098 2x00098 I:97	????			BIT R/O	
		Actual detection state of an open wire fault in state OFF for DO7:0=OK				
OPEN WIRE FAULT WHILE OFF DO8	1x00099 2x00099 I:98	????			BIT R/O	
		Actual detection state of an open wire fault in state OFF for DO8:0=OK				
OPEN WIRE FAULT WHILE OFF DO9	1x00100 2x00100 I:99	????			BIT R/O	
		Actual detection state of an open wire fault in state OFF for DO9:0=OK				
OPEN WIRE FAULT WHILE OFF DO10	1x00101 2x00101 I:100	????			BIT R/O	
		Actual detection state of an open wire fault in state OFF for DO10:0=OK				

OPEN WIRE FAULT WHILE OFF DO11	1x00102 2x00102 I:101	????			BIT R/O	
		Actual detection state of an open wire fault in state OFF for DO11:0=OK				
OPEN WIRE FAULT WHILE OFF DO12	1x00103 2x00103 I:102	????			BIT R/O	
		Actual detection state of an open wire fault in state OFF for DO12:0=OK				
OPEN WIRE FAULT WHILE OFF DO13	1x00104 2x00104 I:103	????			BIT R/O	
		Actual detection state of an open wire fault in state OFF for DO13:0=OK				
OPEN WIRE FAULT WHILE OFF DO14	1x00105 2x00105 I:104	????			BIT R/O	
		Actual detection state of an open wire fault in state OFF for DO14:0=OK				
OPEN WIRE FAULT WHILE OFF DO15	1x00106 2x00106 I:105	????			BIT R/O	
		Actual detection state of an open wire fault in state OFF for DO15:0=OK				
<b>DIGITAL OUTPUTS: SHORTCUT DETECTION STATUS TO VDD WHILE OFF</b>						
OPEN WIRE SHORTCUT TO VDD DO1	1x00107 2x00107 I:106	????			BIT R/O	
		Actual detection state of a shortcut to VDD in state OFF for VDD DO1:0=OK				
The current detection state of a shortcut to VDD in the output state OFF for the digital output DOx =0:No fault, =1:Fault-shortcut to VDD detected						
OPEN WIRE SHORTCUT TO VDD DO2	1x00108 2x00108 I:107	????			BIT R/O	
		Actual detection state of a shortcut to VDD in state OFF for VDD DO2:0=OK				
OPEN WIRE SHORTCUT TO VDD DO3	1x00109 2x00109 I:108	????			BIT R/O	
		Actual detection state of a shortcut to VDD in state OFF for VDD DO3:0=OK				

OPEN WIRE SHORTCUT TO VDD DO4	1x00110 2x00110 I:109	????			BIT R/O	
		Actual detection state of a shortcut to VDD in state OFF for VDD DO4:0=OK				
OPEN WIRE SHORTCUT TO VDD DO5	1x00111 2x00111 I:110	????			BIT R/O	
		Actual detection state of a shortcut to VDD in state OFF for VDD DO5:0=OK				
OPEN WIRE SHORTCUT TO VDD DO6	1x00112 2x00112 I:111	????			BIT R/O	
		Actual detection state of a shortcut to VDD in state OFF for VDD DO6:0=OK				
OPEN WIRE SHORTCUT TO VDD DO7	1x00113 2x00113 I:112	????			BIT R/O	
		Actual detection state of a shortcut to VDD in state OFF for VDD DO7:0=OK				
OPEN WIRE SHORTCUT TO VDD DO8	1x00114 2x00114 I:113	????			BIT R/O	
		Actual detection state of a shortcut to VDD in state OFF for VDD DO8:0=OK				
OPEN WIRE SHORTCUT TO VDD DO9	1x00115 2x00115 I:114	????			BIT R/O	
		Actual detection state of a shortcut to VDD in state OFF for VDD DO9:0=OK				
OPEN WIRE SHORTCUT TO VDD DO10	1x00116 2x00116 I:115	????			BIT R/O	
		Actual detection state of a shortcut to VDD in state OFF for VDD DO10:0=OK				
OPEN WIRE SHORTCUT TO VDD DO11	1x00117 2x00117 I:116	????			BIT R/O	

		Actual detection state of a shortcut to VDD in state OFF for VDD DO11:0=OK			
OPEN WIRE SHORTCUT TO VDD DO12	1x00118 2x00118 I:117	????			BIT R/O
		Actual detection state of a shortcut to VDD in state OFF for VDD DO12:0=OK			
OPEN WIRE SHORTCUT TO VDD DO13	1x00119 2x00119 I:118	????			BIT R/O
		Actual detection state of a shortcut to VDD in state OFF for VDD DO13:0=OK			
OPEN WIRE SHORTCUT TO VDD DO14	1x00120 2x00120 I:119	????			BIT R/O
		Actual detection state of a shortcut to VDD in state OFF for VDD DO14:0=OK			
OPEN WIRE SHORTCUT TO VDD DO15	1x00121 2x00121 I:120	????			BIT R/O
		Actual detection state of a shortcut to VDD in state OFF for VDD DO15:0=OK			
<b>DIGITAL OUTPUTS: THERMAL OVERLOAD DETECTION STATUS</b>					
THERMAL OVERLOAD DETECTION STATUS DO1	1x00122 2x00122 I:121	????			BIT R/O
		Actual detection state of a thermal overload for DO1:0=OK			
The current detection state of a thermal overload for the digital output DOx =0:No fault, =1:Fault-thermal overload detected					
THERMAL OVERLOAD DETECTION STATUS DO2	1x00123 2x00123 I:122	????			BIT R/O
		Actual detection state of a thermal overload for DO2:0=OK			
THERMAL OVERLOAD DETECTION STATUS DO3	1x00124 2x00124 I:123	????			BIT R/O
		Actual detection state of a thermal overload for DO3:0=OK			

THERMAL OVERLOAD DETECTION STATUS DO4	1x00125 2x00125 I:124	????			BIT R/O	
		Actual detection state of a thermal overload for DO4:0=OK				
THERMAL OVERLOAD DETECTION STATUS DO5	1x00126 2x00126 I:125	????			BIT R/O	
		Actual detection state of a thermal overload for DO5:0=OK				
THERMAL OVERLOAD DETECTION STATUS DO6	1x00127 2x00127 I:126	????			BIT R/O	
		Actual detection state of a thermal overload for DO6:0=OK				
THERMAL OVERLOAD DETECTION STATUS DO7	1x00128 2x00128 I:127	????			BIT R/O	
		Actual detection state of a thermal overload for DO7:0=OK				
THERMAL OVERLOAD DETECTION STATUS DO8	1x00129 2x00129 I:128	????			BIT R/O	
		Actual detection state of a thermal overload for DO8:0=OK				
THERMAL OVERLOAD DETECTION STATUS DO9	1x00130 2x00130 I:129	????			BIT R/O	
		Actual detection state of a thermal overload for DO9:0=OK				
THERMAL OVERLOAD DETECTION STATUS DO10	1x00131 2x00131 I:130	????			BIT R/O	
		Actual detection state of a thermal overload for DO10:0=OK				
THERMAL OVERLOAD DETECTION STATUS DO11	1x00132 2x00132 I:131	????			BIT R/O	
		Actual detection state of a thermal overload for DO11:0=OK				
THERMAL OVERLOAD DETECTION STATUS DO12	1x00133 2x00133 I:132	????			BIT R/O	
		Actual detection state of a thermal overload for DO12:0=OK				



THERMAL OVERLOAD DETECTION STATUS DO13	1x00134 2x00134 I:133	????			BIT R/O	
		Actual detection state of a thermal overload for DO13:0=OK				
THERMAL OVERLOAD DETECTION STATUS DO14	1x00135 2x00135 I:134	????			BIT R/O	
		Actual detection state of a thermal overload for DO14:0=OK				
THERMAL OVERLOAD DETECTION STATUS DO15	1x00136 2x00136 I:135	????			BIT R/O	
		Actual detection state of a thermal overload for DO15:0=OK				
<b>DIGITAL OUTPUTS: CURRENT LIMIT DETECTION STATUS WHILE ON</b>						
CURRENT LIMIT DETECTION STATUS WHILE ON DO1	1x00137 2x00137 I:136	????			BIT R/O	
		Actual detection state of a current limit while ON for DO1:0=OK				
The current detection state of a current limit while output is ON for the digital output DOx =0:No fault, =1:Fault-current limit error						
CURRENT LIMIT DETECTION STATUS WHILE ON DO2	1x00138 2x00138 I:137	????			BIT R/O	
		Actual detection state of a current limit while ON for DO2:0=OK				
CURRENT LIMIT DETECTION STATUS WHILE ON DO3	1x00139 2x00139 I:138	????			BIT R/O	
		Actual detection state of a current limit while ON for DO3:0=OK				
CURRENT LIMIT DETECTION STATUS WHILE ON DO4	1x00140 2x00140 I:139	????			BIT R/O	
		Actual detection state of a current limit while ON for DO4:0=OK				
CURRENT LIMIT DETECTION STATUS WHILE ON DO5	1x00141 2x00141 I:140	????			BIT R/O	
		Actual detection state of a current limit while ON for DO5:0=OK				
CURRENT LIMIT DETECTION STATUS WHILE ON DO6	1x00142 2x00142 I:141	????			BIT R/O	

		Actual detection state of a current limit while ON for DO6:0=OK			
CURRENT LIMIT DETECTION STATUS WHILE ON DO7	1x00143 2x00143 I:142	????			BIT R/O
		Actual detection state of a current limit while ON for DO7:0=OK			
CURRENT LIMIT DETECTION STATUS WHILE ON DO8	1x00144 2x00144 I:143	????			BIT R/O
		Actual detection state of a current limit while ON for DO8:0=OK			
CURRENT LIMIT DETECTION STATUS WHILE ON DO9	1x00145 2x00145 I:144	????			BIT R/O
		Actual detection state of a current limit while ON for DO9:0=OK			
CURRENT LIMIT DETECTION STATUS WHILE ON DO10	1x00146 2x00146 I:145	????			BIT R/O
		Actual detection state of a current limit while ON for DO10:0=OK			
CURRENT LIMIT DETECTION STATUS WHILE ON DO11	1x00147 2x00147 I:146	????			BIT R/O
		Actual detection state of a current limit while ON for DO11:0=OK			
CURRENT LIMIT DETECTION STATUS WHILE ON DO12	1x00148 2x00148 I:147	????			BIT R/O
		Actual detection state of a current limit while ON for DO12:0=OK			
CURRENT LIMIT DETECTION STATUS WHILE ON DO13	1x00149 2x00149 I:148	????			BIT R/O
		Actual detection state of a current limit while ON for DO13:0=OK			
CURRENT LIMIT DETECTION STATUS WHILE ON DO14	1x00150 2x00150 I:149	????			BIT R/O
		Actual detection state of a current limit while ON for DO14:0=OK			
CURRENT LIMIT DETECTION STATUS WHILE ON DO15	1x00151 2x00151 I:150	????			BIT R/O
		Actual detection state of a current limit while ON for DO15:0=OK			

DIGITAL OUTPUTS: GLOBAL ERRORS						
CHIP #1:DO1-DO8						
GLOBAL ERRORS BIT 0	1x00152 2x00152 I:151	????				BIT R/O
BIT 0:Internal under voltage detected:0=OK						
GLOBAL ERRORS BIT 1	1x00153 2x00153 I:152	????				BIT R/O
BIT 1:VA under voltage detected (<2.3V):0=OK						
GLOBAL ERRORS BIT 2	1x00154 2x00154 I:153	????				BIT R/O
BIT 2:VDD not good detected (<17V):0=OK						
GLOBAL ERRORS BIT 3	1x00155 2x00155 I:154	????				BIT R/O
BIT 3:VDD warning detected (<12V):0=OK						
GLOBAL ERRORS BIT 4	1x00156 2x00156 I:155	????				BIT R/O
BIT 4:VDD under voltage detected (<8V):0=OK						
GLOBAL ERRORS BIT 5	1x00157 2x00157 I:156	????				BIT R/O
BIT 5:Thermal shutdown:0=OK						
GLOBAL ERRORS BIT 6	1x00158 2x00158 I:157	????				BIT R/O
BIT 6:Synchronisation error detected:0=OK						
GLOBAL ERRORS BIT 7	1x00159 2x00159 I:158	????				BIT R/O
BIT 7:Watchdog error detected:0=OK						
The global error state for the output group. Each bit stands for a different error =0:No fault, =1:Fault						
DIGITAL OUTPUTS: GLOBAL ERRORS						
CHIP #2:DO9-DO15						
GLOBAL ERRORS BIT 0	1x00160 2x00160 I:159	????				BIT R/O
BIT 0:Internal under voltage detected:0=OK						
GLOBAL ERRORS BIT 1	1x00161 2x00161 I:160	????				BIT R/O
BIT 1:VA under voltage detected (<2.3V):0=OK						

GLOBAL ERRORS BIT 2	1x00162 2x00162 I:161	????			BIT R/O	
		BIT 2:VDD not good detected (<17V):0=OK				
GLOBAL ERRORS BIT 3	1x00163 2x00163 I:162	????			BIT R/O	
		BIT 3:VDD warning detected (<12V):0=OK				
GLOBAL ERRORS BIT 4	1x00164 2x00164 I:163	????			BIT R/O	
		BIT 4:VDD under voltage detected (<8V):0=OK				
GLOBAL ERRORS BIT 5	1x00165 2x00165 I:164	????			BIT R/O	
		BIT 5:Thermal shutdown:0=OK				
GLOBAL ERRORS BIT 6	1x00166 2x00166 I:165	????			BIT R/O	
		BIT 6:Synchronisation error detected:0=OK				
GLOBAL ERRORS BIT 7	1x00167 2x00167 I:166	????			BIT R/O	
		BIT 7:Watchdog error detected:0=OK				

The global error state for the output group. Each bit stands for a different error  
=0:No fault, =1:Fault

#### DIGITAL OUTPUTS: INTERRUPT STATUS

<b>CHIP #1:DO1-DO8</b>						
INTERRUPT STATUS BIT 0	1x00168 2x00168 I:167	????			BIT R/O	
		BIT 0:Overload detected:0=OK				
INTERRUPT STATUS BIT 1	1x00169 2x00169 I:168	????			BIT R/O	
		BIT 1:Current limit detected:0=OK				
INTERRUPT STATUS BIT 2	1x00170 2x00170 I:169	????			BIT R/O	
		BIT 2:Open wire while OFF detected:0=OK				
INTERRUPT STATUS BIT 3	1x00171 2x00171 I:170	????			BIT R/O	
		BIT 3:Open wire while ON detected:0=OK				
INTERRUPT STATUS BIT 4	1x00172 2x00172 I:171	????			BIT R/O	

		BIT 4:Short to VDD while ON detected:0=OK				
INTERRUPT STATUS BIT 5	1x00173 2x00173 I:172	????			BIT R/O	
		BIT 5:Thermal error detected-shutdown:0=OK				
INTERRUPT STATUS BIT 6	1x00174 2x00174 I:173	????			BIT R/O	
		BIT 6:Supply error detected:0=OK				
INTERRUPT STATUS BIT 7	1x00175 2x00175 I:174	????			BIT R/O	
		BIT 7:Communication error detected:0=OK				
The global interrupt error state for the output group. Each bit stands for a different error =0:No fault, =1:Fault						
<b>DIGITAL OUTPUTS: INTERRUPT STATUS</b>						
<b>CHIP #2:DO9-DO15</b>						
INTERRUPT STATUS BIT 0	1x00176 2x00176 I:175	????			BIT R/O	
		BIT 0:Overload detected:0=OK				
INTERRUPT STATUS BIT 1	1x00177 2x00177 I:176	????			BIT R/O	
		BIT 1:Current limit detected:0=OK				
INTERRUPT STATUS BIT 2	1x00178 2x00178 I:177	????			BIT R/O	
		BIT 2:Open wire while OFF detected:0=OK				
INTERRUPT STATUS BIT 3	1x00179 2x00179 I:178	????			BIT R/O	
		BIT 3:Open wire while ON detected:0=OK				
INTERRUPT STATUS BIT 4	1x00180 2x00180 I:179	????			BIT R/O	
		BIT 4:Short to VDD while ON detected:0=OK				
INTERRUPT STATUS BIT 5	1x00181 2x00181 I:180	????			BIT R/O	
		BIT 5:Thermal error detected-shutdown:0=OK				
INTERRUPT STATUS BIT 6	1x00182 2x00182 I:181	????			BIT R/O	
		BIT 6:Supply error detected:0=OK				

INTERRUPT STATUS BIT 7	1x00183 2x00183 I:182	????			BIT R/O	
BIT 7:Communication error detected:0=OK						
The global interrupt error state for the output group. Each bit stands for a different error =0:No fault, =1:Fault						
<b>SPI COMMUNICATION DIGITAL OUTPUTS</b>						
SPI COMMUNICATION CHIP #1: DO1-DO8	1x00184 2x00184 I:183	????			BIT R/O	
Actual SPI communication state:0=NO FAULT						
The current monitoring state of the SPI communication for the digital output group =0:No fault, =1:Fault						
SPI COMMUNICATION CHIP #2: DO9-DO15	1x00185 2x00185 I:184	????			BIT R/O	
Actual SPI communication state:0=NO FAULT						
The current monitoring state of the SPI communication for the digital output group =0:No fault, =1:Fault						
<b>DIGITAL INPUTS: RESET</b>						
RESET COUNTERS	1x10000 2x10000 I:9999	????		1:PERFORM RESET	BIT R/W	NO
If this register is written to 1, all internal edge counters and event counters are set to 0. 0 is always returned when reading.						
<b>STATUS REAL DIGITAL INPUTS</b>						
DI1	1x15001 2x14001 I:15000	????			BIT R/O	
Actual state of DI1:0=OFF						
Current state of the digital input DIx with the internal software filter to suppress glitches or spike on this line =0:DI is OFF, =1:DI is ON						
DI2	1x15002 2x15002 I:15001	????			BIT R/O	
Actual state of DI2:0=OFF						
DI3	1x15003 2x15003 I:15002	????			BIT R/O	
Actual state of DI3:0=OFF						
DI4	1x15004 2x15004 I:15003	????			BIT R/O	
Actual state of DI4:0=OFF						
DI5	1x15005 2x15005 I:15004	????			BIT R/O	
Actual state of DI5:0=OFF						

DI6	1x15006 2x15006 I:15005	????			BIT R/O	
		Actual state of DI6:0=OFF				
DI7	1x15007 2x15007 I:15006	????			BIT R/O	
		Actual state of DI7:0=OFF				
DI8	1x15008 2x15008 I:15007	????			BIT R/O	
		Actual state of DI8:0=OFF				
DI9	1x15009 2x15009 I:15008	????			BIT R/O	
		Actual state of DI9:0=OFF				
DI10	1x15010 2x15010 I:15009	????			BIT R/O	
		Actual state of DI10:0=OFF				
DI11	1x15011 2x15011 I:15010	????			BIT R/O	
		Actual state of DI11:0=OFF				
DI12	1x15012 2x15012 I:15011	????			BIT R/O	
		Actual state of DI12:0=OFF				
DI13	1x15013 2x15013 I:15012	????			BIT R/O	
		Actual state of DI13:0=OFF				
DI14	1x15014 2x15014 I:15013	????			BIT R/O	
		Actual state of DI14:0=OFF				
DI15	1x15015 2x15015 I:15014	????			BIT R/O	
		Actual state of DI15:0=OFF				
DI16	1x15016 2x15016 I:15015	????			BIT R/O	
		Actual state of DI16:0=OFF				
<b>STATUS DIGITAL INPUTS</b>						

UNFILTERED DI1	1x15017 2x15017 I:15016	????			BIT R/O	
		Actual state of UNFILTERED DI1:0=OFF				
Current state of the real digital input DIx without the internal software filter to suppress glitches or spike on this line =0:DI is OFF, =1:DI is ON						
UNFILTERED DI2	1x15018 2x15018 I:15017	????			BIT R/O	
		Actual state of UNFILTERED DI2:0=OFF				
UNFILTERED DI3	1x15019 2x15019 I:15018	????			BIT R/O	
		Actual state of UNFILTERED DI3:0=OFF				
UNFILTERED DI4	1x15020 2x15020 I:15019	????			BIT R/O	
		Actual state of UNFILTERED DI4:0=OFF				
UNFILTERED DI5	1x15021 2x15021 I:15020	????			BIT R/O	
		Actual state of UNFILTERED DI5:0=OFF				
UNFILTERED DI6	1x15022 2x15022 I:15021	????			BIT R/O	
		Actual state of UNFILTERED DI6:0=OFF				
UNFILTERED DI7	1x15023 2x15023 I:15022	????			BIT R/O	
		Actual state of UNFILTERED DI7:0=OFF				
UNFILTERED DI8	1x15024 2x15024 I:15023	????			BIT R/O	
		Actual state of UNFILTERED DI8:0=OFF				
UNFILTERED DI9	1x15025 2x15025 I:15024	????			BIT R/O	
		Actual state of UNFILTERED DI9:0=OFF				
UNFILTERED DI10	1x15026 2x15026 I:15025	????			BIT R/O	
		Actual state of UNFILTERED DI10:0=OFF				
UNFILTERED DI11	1x15027 2x15027 I:15026	????			BIT R/O	
		Actual state of UNFILTERED DI11:0=OFF				



UNFILTERED DI12	1x15028 2x15028 I:15027	????			BIT R/O	
		Actual state of UNFILTERED DI12:0=OFF				
UNFILTERED DI13	1x15029 2x15029 I:15028	????			BIT R/O	
		Actual state of UNFILTERED DI13:0=OFF				
UNFILTERED DI14	1x15030 2x15030 I:15029	????			BIT R/O	
		Actual state of UNFILTERED DI14:0=OFF				
UNFILTERED DI15	1x15031 2x15031 I:15030	????			BIT R/O	
		Actual state of UNFILTERED DI15:0=OFF				
UNFILTERED DI16	1x15032 2x15032 I:15031	????			BIT R/O	
		Actual state of UNFILTERED DI16:0=OFF				
<b>STATUS DIGITAL OUTPUTS</b>						
DO1	1x16001 2x16001 I:16000	????		1	BIT R/W	NO
		Actual state of DO1:0=OFF			ENTER NEW STATE (0 or 1)	
Current state of the digital output DOx =0:DO is OFF, =1:DO is ON						
Writing on this register changes the state of the digital output						
DO2	1x16002 2x16002 I:16001	????		0	BIT R/W	NO
		Actual state of DO2:0=OFF			ENTER NEW STATE (0 or 1)	
DO3	1x16003 2x16003 I:16002	????		0	BIT R/W	NO
		Actual state of DO3:0=OFF			ENTER NEW STATE (0 or 1)	
DO4	1x16004 2x16004 I:16003	????		0	BIT R/W	NO
		Actual state of DO4:0=OFF			ENTER NEW STATE (0 or 1)	
DO5	1x16005 2x16005 I:16004	????		0	BIT R/W	NO
		Actual state of DO5:0=OFF			ENTER NEW STATE (0 or 1)	

DO6	1x16006 2x16006 I:16005	????		0	BIT R/W	NO
		Actual state of DO6:0=OFF		ENTER NEW STATE (0 or 1)		
DO7	1x16007 2x16007 I:16006	????		0	BIT R/W	NO
		Actual state of DO7:0=OFF		ENTER NEW STATE (0 or 1)		
DO8	1x16008 2x16008 I:16007	????		0	BIT R/W	NO
		Actual state of DO8:0=OFF		ENTER NEW STATE (0 or 1)		
DO9	1x16009 2x16009 I:16008	????		0	BIT R/W	NO
		Actual state of DO9:0=OFF		ENTER NEW STATE (0 or 1)		
DO10	1x16010 2x16010 I:16009	????		0	BIT R/W	NO
		Actual state of DO10:0=OFF		ENTER NEW STATE (0 or 1)		
DO11	1x16011 2x16011 I:16010	????		0	BIT R/W	NO
		Actual state of DO11:0=OFF		ENTER NEW STATE (0 or 1)		
DO12	1x16012 2x16012 I:16011	????		0	BIT R/W	NO
		Actual state of DO12:0=OFF		ENTER NEW STATE (0 or 1)		
DO13	1x16013 2x16013 I:16012	????		0	BIT R/W	NO
		Actual state of DO13:0=OFF		ENTER NEW STATE (0 or 1)		
DO14	1x16014 2x16014 I:16013	????		0	BIT R/W	NO
		Actual state of DO14:0=OFF		ENTER NEW STATE (0 or 1)		
DO15	1x16015 2x16015 I:16014	????		0	BIT R/W	NO
		Actual state of DO15:0=OFF		ENTER NEW STATE (0 or 1)		

Register NAME Command NAME	MODBUS Register ASCII Command	Register VALUE ASCII Command	NEW REAL VALUE	NEW VALUE	DATA TYPE	DO WRITE
<b>DIGITAL INPUTS: DIGITAL INPUT HAS CHANGED IT'S STATE</b>						
DI HAS CHANGED DI1	1x20001 2x20001 I:20000	1,0x01 B:01			BIT R/O	
If the digital input has changed this bit inverts its last state						
DI HAS CHANGED DI2	1x20002 2x20002 I:20001	1,0x01 B:01			BIT R/O	
DI HAS CHANGED DI3	1x20003 2x20003 I:20002	0,0x00 B:00			BIT R/O	
DI HAS CHANGED DI4	1x20004 2x20004 I:20003	0,0x00 B:00			BIT R/O	
DI HAS CHANGED DI5	1x20005 2x20005 I:20004	1,0x01 B:01			BIT R/O	
DI HAS CHANGED DI6	1x20006 2x20006 I:20005	0,0x00 B:00			BIT R/O	
DI HAS CHANGED DI7	1x20007 2x20007 I:20006	0,0x00 B:00			BIT R/O	
DI HAS CHANGED DI8	1x20008 2x20008 I:20007	0,0x00 B:00			BIT R/O	
DI HAS CHANGED DI9	1x20009 2x20009 I:20008	0,0x00 B:00			BIT R/O	
DI HAS CHANGED DI10	1x20010 2x20010 I:20009	0,0x00 B:00			BIT R/O	
DI HAS CHANGED DI11	1x20011 2x20011 I:20010	0,0x00 B:00			BIT R/O	
DI HAS CHANGED DI12	1x20012 2x20012 I:20011	0,0x00 B:00			BIT R/O	
DI HAS CHANGED DI13	1x20013 2x20013 I:20012	0,0x00 B:00			BIT R/O	

DI HAS CHANGED DI14	1x20014 2x20014 I:20013	0,0x00 B:00			BIT R/O	
DI HAS CHANGED DI15	1x20015 2x20015 I:20014	0,0x00 B:00			BIT R/O	
DI HAS CHANGED DI16	1x20016 2x20016 I:20015	0,0x00 B:00			BIT R/O	
<b>DIGITAL INPUTS: SHORT KEYPRESS EVENT ON DIGITAL INPUT DETECTED</b>						
SHORT KEYPRESS ON DI1	1x20017 2x20017 I:20016	1,0x01 B:01			BIT R/O	
If a short keypress event was detected on the digital input this bit inverts its last state						
SHORT KEYPRESS ON DI2	1x20018 2x20018 I:20017	1,0x01 B:01			BIT R/O	
SHORT KEYPRESS ON DI3	1x20019 2x20019 I:20018	0,0x00 B:00			BIT R/O	
SHORT KEYPRESS ON DI4	1x20020 2x20020 I:20019	0,0x00 B:00			BIT R/O	
SHORT KEYPRESS ON DI5	1x20021 2x20021 I:20020	1,0x01 B:01			BIT R/O	
SHORT KEYPRESS ON DI6	1x20022 2x20022 I:20021	0,0x00 B:00			BIT R/O	
SHORT KEYPRESS ON DI7	1x20023 2x20023 I:20022	0,0x00 B:00			BIT R/O	
SHORT KEYPRESS ON DI8	1x20024 2x20024 I:20023	0,0x00 B:00			BIT R/O	
SHORT KEYPRESS ON DI9	1x20025 2x20025 I:20024	0,0x00 B:00			BIT R/O	
SHORT KEYPRESS ON DI10	1x20026 2x20026 I:20025	0,0x00 B:00			BIT R/O	
SHORT KEYPRESS ON DI11	1x20027 2x20027 I:20026	0,0x00 B:00			BIT R/O	

SHORT KEYPRESS ON DI12	1x20028 2x20028 I:20027	0,0x00 B:00			BIT R/O	
SHORT KEYPRESS ON DI13	1x20029 2x20029 I:20028	0,0x00 B:00			BIT R/O	
SHORT KEYPRESS ON DI14	1x20030 2x20030 I:20029	0,0x00 B:00			BIT R/O	
SHORT KEYPRESS ON DI15	1x20031 2x20031 I:20030	0,0x00 B:00			BIT R/O	
SHORT KEYPRESS ON DI16	1x20032 2x20032 I:20031	0,0x00 B:00			BIT R/O	
<b>DIGITAL INPUTS: LONG KEYPRESS START EVENT ON DIGITAL INPUT DETECTED</b>						
LONG KEYPRESS START ON DI1	1x20033 2x20033 I:20032	1,0x01 B:01			BIT R/O	
If a long keypress start event was detected on the digital input this bit inverts its last state						
LONG KEYPRESS START ON DI2	1x20034 2x20034 I:20033	1,0x01 B:01			BIT R/O	
LONG KEYPRESS START ON DI3	1x20035 2x20035 I:20034	0,0x00 B:00			BIT R/O	
LONG KEYPRESS START ON DI4	1x20036 2x20036 I:20035	0,0x00 B:00			BIT R/O	
LONG KEYPRESS START ON DI5	1x20037 2x20037 I:20036	1,0x01 B:01			BIT R/O	
LONG KEYPRESS START ON DI6	1x20038 2x20038 I:20037	0,0x00 B:00			BIT R/O	
LONG KEYPRESS START ON DI7	1x20039 2x20039 I:20038	0,0x00 B:00			BIT R/O	
LONG KEYPRESS START ON DI8	1x20040 2x20040 I:20039	0,0x00 B:00			BIT R/O	
LONG KEYPRESS START ON DI9	1x20041 2x20041 I:20040	0,0x00 B:00			BIT R/O	

LONG KEYPRESS START ON DI10	1x20042 2x20042 I:20041	0,0x00 B:00			BIT R/O	
LONG KEYPRESS START ON DI11	1x20043 2x20043 I:20042	0,0x00 B:00			BIT R/O	
LONG KEYPRESS START ON DI12	1x20044 2x20044 I:20043	0,0x00 B:00			BIT R/O	
LONG KEYPRESS START ON DI13	1x20045 2x20045 I:20044	0,0x00 B:00			BIT R/O	
LONG KEYPRESS START ON DI14	1x20046 2x20046 I:20045	0,0x00 B:00			BIT R/O	
LONG KEYPRESS START ON DI15	1x20047 2x20047 I:20046	0,0x00 B:00			BIT R/O	
LONG KEYPRESS START ON DI16	1x20048 2x20048 I:20047	0,0x00 B:00			BIT R/O	
<b>DIGITAL INPUTS: LONG KEYPRESS END EVENT ON DIGITAL INPUT DETECTED</b>						
LONG KEYPRESS END ON DI1	1x20049 2x20049 I:20048	1,0x01 B:01			BIT R/O	
If a long keypress end event was detected on the digital input this bit inverts its last state						
LONG KEYPRESS END ON DI2	1x20050 2x20050 I:20049	1,0x01 B:01			BIT R/O	
LONG KEYPRESS END ON DI3	1x20051 2x20051 I:20050	0,0x00 B:00			BIT R/O	
LONG KEYPRESS END ON DI4	1x20052 2x20052 I:20051	0,0x00 B:00			BIT R/O	
LONG KEYPRESS END ON DI5	1x20053 2x20053 I:20052	1,0x01 B:01			BIT R/O	
LONG KEYPRESS END ON DI6	1x20054 2x20054 I:20053	0,0x00 B:00			BIT R/O	
LONG KEYPRESS END ON DI7	1x20055 2x20055 I:20054	0,0x00 B:00			BIT R/O	

LONG KEYPRESS END ON DI8	1x20056 2x20056 I:20055	0,0x00 B:00			BIT R/O	
LONG KEYPRESS END ON DI9	1x20057 2x20057 I:20056	0,0x00 B:00			BIT R/O	
LONG KEYPRESS END ON DI10	1x20058 2x20058 I:20057	0,0x00 B:00			BIT R/O	
LONG KEYPRESS END ON DI11	1x20059 2x20059 I:20058	0,0x00 B:00			BIT R/O	
LONG KEYPRESS END ON DI12	1x20060 2x20060 I:20059	0,0x00 B:00			BIT R/O	
LONG KEYPRESS END ON DI13	1x20061 2x20061 I:20060	0,0x00 B:00			BIT R/O	
LONG KEYPRESS END ON DI14	1x20062 2x20062 I:20061	0,0x00 B:00			BIT R/O	
LONG KEYPRESS END ON DI15	1x20063 2x20063 I:20062	0,0x00 B:00			BIT R/O	
LONG KEYPRESS END ON DI16	1x20064 2x20064 I:20063	0,0x00 B:00			BIT R/O	
<b>DIGITAL INPUTS: RISING EDGE ON DIGITAL INPUT DETECTED</b>						
RISING EDGE ON DI1	1x20065 2x20065 I:20064	1,0x01 B:01			BIT R/O	
If a rising edge was detected on the digital input this bit inverts its last state						
RISING EDGE ON DI2	1x20066 2x20066 I:20065	1,0x01 B:01			BIT R/O	
RISING EDGE ON DI3	1x20067 2x20067 I:20066	0,0x00 B:00			BIT R/O	
RISING EDGE ON DI4	1x20068 2x20068 I:20067	0,0x00 B:00			BIT R/O	
RISING EDGE ON DI5	1x20069 2x20069 I:20068	1,0x01 B:01			BIT R/O	

RISING EDGE ON DI6	1x20070 2x20070 I:20069	0,0x00 B:00			BIT R/O	
RISING EDGE ON DI7	1x20071 2x20071 I:20070	0,0x00 B:00			BIT R/O	
RISING EDGE ON DI8	1x20072 2x20072 I:20071	0,0x00 B:00			BIT R/O	
RISING EDGE ON DI9	1x20073 2x20073 I:20072	0,0x00 B:00			BIT R/O	
RISING EDGE ON DI10	1x20074 2x20074 I:20073	0,0x00 B:00			BIT R/O	
RISING EDGE ON DI11	1x20075 2x20075 I:20074	0,0x00 B:00			BIT R/O	
RISING EDGE ON DI12	1x20076 2x20076 I:20075	0,0x00 B:00			BIT R/O	
RISING EDGE ON DI13	1x20077 2x20077 I:20076	0,0x00 B:00			BIT R/O	
RISING EDGE ON DI14	1x20078 2x20078 I:20077	0,0x00 B:00			BIT R/O	
RISING EDGE ON DI15	1x20079 2x20079 I:20078	0,0x00 B:00			BIT R/O	
RISING EDGE ON DI16	1x20080 2x20080 I:20079	0,0x00 B:00			BIT R/O	
<b>DIGITAL INPUTS: FALLING EDGE ON DIGITAL INPUT DETECTED</b>						
FALLING EDGE ON DI1	1x20081 2x20081 I:20080	1,0x01 B:01			BIT R/O	
If a falling edge was detected on the digital input this bit inverts its last state						
FALLING EDGE ON DI2	1x20082 2x20082 I:20081	1,0x01 B:01			BIT R/O	
FALLING EDGE ON DI3	1x20083 2x20083 I:20082	0,0x00 B:00			BIT R/O	



FALLING EDGE ON DI4	1x20084 2x20084 I:20083	0,0x00 B:00			BIT R/O	
FALLING EDGE ON DI5	1x20085 2x20085 I:20084	1,0x01 B:01			BIT R/O	
FALLING EDGE ON DI6	1x20086 2x20086 I:20085	0,0x00 B:00			BIT R/O	
FALLING EDGE ON DI7	1x20087 2x20087 I:20086	0,0x00 B:00			BIT R/O	
FALLING EDGE ON DI8	1x20088 2x20088 I:20087	0,0x00 B:00			BIT R/O	
FALLING EDGE ON DI9	1x20089 2x20089 I:20088	0,0x00 B:00			BIT R/O	
FALLING EDGE ON DI10	1x20090 2x20090 I:20089	0,0x00 B:00			BIT R/O	
FALLING EDGE ON DI11	1x20091 2x20091 I:20090	0,0x00 B:00			BIT R/O	
FALLING EDGE ON DI12	1x20092 2x20092 I:20091	0,0x00 B:00			BIT R/O	
FALLING EDGE ON DI13	1x20093 2x20093 I:20092	0,0x00 B:00			BIT R/O	
FALLING EDGE ON DI14	1x20094 2x20094 I:20093	0,0x00 B:00			BIT R/O	
FALLING EDGE ON DI15	1x20095 2x20095 I:20094	0,0x00 B:00			BIT R/O	
FALLING EDGE ON DI16	1x20096 2x20096 I:20095	0,0x00 B:00			BIT R/O	

Register NAME Command NAME	MODBUS Register ASCII Command	Register VALUE ASCII Command	NEW REAL VALUE	NEW VALUE	DATA TYPE	DO WRITE
<b>STATUS DIGITAL INPUTS</b>						
DI1	3x00001 4x00001 I:0	0,0x0000 B:00 00			UINT16 R/O	
Actual state of DI1:0=OFF						
Current state of the digital input DIx =0:DI is OFF, =1:DI is ON						
DI2	3x00002 4x00002 I:1	0,0x0000 B:00 00			UINT16 R/O	
Actual state of DI2:0=OFF						
DI3	3x00003 4x00003 I:2	0,0x0000 B:00 00			UINT16 R/O	
Actual state of DI3:0=OFF						
DI4	3x00004 4x00004 I:3	0,0x0000 B:00 00			UINT16 R/O	
Actual state of DI4:0=OFF						
DI5	3x00005 4x00005 I:4	0,0x0000 B:00 00			UINT16 R/O	
Actual state of DI5:0=OFF						
DI6	3x00006 4x00006 I:5	0,0x0000 B:00 00			UINT16 R/O	
Actual state of DI6:0=OFF						
DI7	3x00007 4x00007 I:6	0,0x0000 B:00 00			UINT16 R/O	
Actual state of DI7:0=OFF						
DI8	3x00008 4x00008 I:7	0,0x0000 B:00 00			UINT16 R/O	
Actual state of DI8:0=OFF						
DI9	3x00009 4x00009 I:8	0,0x0000 B:00 00			UINT16 R/O	
Actual state of DI9:0=OFF						
DI10	3x00010 4x00010 I:9	0,0x0000 B:00 00			UINT16 R/O	

		Actual state of DI10:0=OFF				
DI11	3x00011 4x00011 I:10	0,0x0000 B:00 00			UINT16 R/O	
		Actual state of DI11:0=OFF				
DI12	3x00012 4x00012 I:11	0,0x0000 B:00 00			UINT16 R/O	
		Actual state of DI12:0=OFF				
DI13	3x00013 4x00013 I:12	0,0x0000 B:00 00			UINT16 R/O	
		Actual state of DI13:0=OFF				
DI14	3x00014 4x00014 I:13	0,0x0000 B:00 00			UINT16 R/O	
		Actual state of DI14:0=OFF				
DI15	3x00015 4x00015 I:14	0,0x0000 B:00 00			UINT16 R/O	
		Actual state of DI15:0=OFF				
DI16	3x00016 4x00016 I:15	0,0x0000 B:00 00			UINT16 R/O	
		Actual state of DI16:0=OFF				
<b>STATUS DIGITAL OUTPUTS</b>						
DO1	3x00017 4x00017 I:16	0,0x0000 B:00 00		1	UINT16 R/W	NO
		Actual state of DO1:0=OFF			ENTER NEW STATE (0 or 1)	
Current state of the digital output DOx =0:DO is OFF, =1:DO is ON						
Writing on this register changes the state of the digital output						
DO2	3x00018 4x00018 I:17	0,0x0000 B:00 00		0	UINT16 R/W	NO
		Actual state of DO2:0=OFF			ENTER NEW STATE (0 or 1)	
DO3	3x00019 4x00019 I:18	0,0x0000 B:00 00		0	UINT16 R/W	NO
		Actual state of DO3:0=OFF			ENTER NEW STATE (0 or 1)	
DO4	3x00020 4x00020 I:19	0,0x0000 B:00 00		0	UINT16 R/W	NO
		Actual state of DO4:0=OFF			ENTER NEW STATE (0 or 1)	

DO5	3x00021 4x00021 I:20	0,0x0000 B:00 00		0	UINT16 R/W	NO
		Actual state of DO5:0=OFF		ENTER NEW STATE (0 or 1)		
DO6	3x00022 4x00022 I:21	0,0x0000 B:00 00		0	UINT16 R/W	NO
		Actual state of DO6:0=OFF		ENTER NEW STATE (0 or 1)		
DO7	3x00023 4x00023 I:22	0,0x0000 B:00 00		0	UINT16 R/W	NO
		Actual state of DO7:0=OFF		ENTER NEW STATE (0 or 1)		
DO8	3x00024 4x00024 I:23	0,0x0000 B:00 00		0	UINT16 R/W	NO
		Actual state of DO8:0=OFF		ENTER NEW STATE (0 or 1)		
DO9	3x00025 4x00025 I:24	0,0x0000 B:00 00		0	UINT16 R/W	NO
		Actual state of DO9:0=OFF		ENTER NEW STATE (0 or 1)		
DO10	3x00026 4x00026 I:25	0,0x0000 B:00 00		0	UINT16 R/W	NO
		Actual state of DO10:0=OFF		ENTER NEW STATE (0 or 1)		
DO11	3x00027 4x00027 I:26	0,0x0000 B:00 00		0	UINT16 R/W	NO
		Actual state of DO11:0=OFF		ENTER NEW STATE (0 or 1)		
DO12	3x00028 4x00028 I:27	0,0x0000 B:00 00		0	UINT16 R/W	NO
		Actual state of DO12:0=OFF		ENTER NEW STATE (0 or 1)		
DO13	3x00029 4x00029 I:28	0,0x0000 B:00 00		0	UINT16 R/W	NO
		Actual state of DO13:0=OFF		ENTER NEW STATE (0 or 1)		
DO14	3x00030 4x00030 I:29	0,0x0000 B:00 00		0	UINT16 R/W	NO
		Actual state of DO14:0=OFF		ENTER NEW STATE (0 or 1)		
DO15	3x00031 4x00031 I:30	0,0x0000 B:00 00		0	UINT16 R/W	NO
		Actual state of DO15:0=OFF		ENTER NEW STATE (0 or 1)		

DIGITAL OUTPUTS: ENABLE OPEN WIRE DETECTION ON

ENABLE OPEN WIRE DETECTION ON DO1	3x00032 4x00032 I:31	1,0x0001 B:00 01		1	UINT16 R/W	NO
		Actual setup of open wire detection for state ON of DO1:1=ON		ENTER NEW SETUP MODE (0 or 1)		
Enables/disabled detection of an open wire in DO state ON for the digital output DOx =0:Open wire detection is OFF, =1:Open wire detection is ON						
Writing on this register changes the state of the open wire detection for this output						
ENABLE OPEN WIRE DETECTION ON DO2	3x00033 4x00033 I:32	1,0x0001 B:00 01		1	UINT16 R/W	NO
		Actual setup of open wire detection for state ON of DO2:1=ON		ENTER NEW SETUP MODE (0 or 1)		
ENABLE OPEN WIRE DETECTION ON DO3	3x00034 4x00034 I:33	1,0x0001 B:00 01		1	UINT16 R/W	NO
		Actual setup of open wire detection for state ON of DO3:1=ON		ENTER NEW SETUP MODE (0 or 1)		
ENABLE OPEN WIRE DETECTION ON DO4	3x00035 4x00035 I:34	1,0x0001 B:00 01		1	UINT16 R/W	NO
		Actual setup of open wire detection for state ON of DO4:1=ON		ENTER NEW SETUP MODE (0 or 1)		
ENABLE OPEN WIRE DETECTION ON DO5	3x00036 4x00036 I:35	1,0x0001 B:00 01		1	UINT16 R/W	NO
		Actual setup of open wire detection for state ON of DO5:1=ON		ENTER NEW SETUP MODE (0 or 1)		
ENABLE OPEN WIRE DETECTION ON DO6	3x00037 4x00037 I:36	1,0x0001 B:00 01		1	UINT16 R/W	NO
		Actual setup of open wire detection for state ON of DO6:1=ON		ENTER NEW SETUP MODE (0 or 1)		
ENABLE OPEN WIRE DETECTION ON DO7	3x00038 4x00038 I:37	1,0x0001 B:00 01		1	UINT16 R/W	NO
		Actual setup of open wire detection for state ON of DO7:1=ON		ENTER NEW SETUP MODE (0 or 1)		
ENABLE OPEN WIRE DETECTION ON DO8	3x00039 4x00039 I:38	1,0x0001 B:00 01		1	UINT16 R/W	NO
		Actual setup of open wire detection for state ON of DO8:1=ON		ENTER NEW SETUP MODE (0 or 1)		
ENABLE OPEN WIRE DETECTION ON DO9	3x00040 4x00040 I:39	1,0x0001 B:00 01		1	UINT16 R/W	NO

		Actual setup of open wire detection for state ON of DO9:1=ON	ENTER NEW SETUP MODE (0 or 1)		
ENABLE OPEN WIRE DETECTION ON DO10	3x00041 4x00041 I:40	1,0x0001 B:00 01	1	UINT16 R/W	NO
		Actual setup of open wire detection for state ON of DO10:1=ON	ENTER NEW SETUP MODE (0 or 1)		
ENABLE OPEN WIRE DETECTION ON DO11	3x00042 4x00042 I:41	1,0x0001 B:00 01	1	UINT16 R/W	NO
		Actual setup of open wire detection for state ON of DO11:1=ON	ENTER NEW SETUP MODE (0 or 1)		
ENABLE OPEN WIRE DETECTION ON DO12	3x00043 4x00043 I:42	1,0x0001 B:00 01	1	UINT16 R/W	NO
		Actual setup of open wire detection for state ON of DO12:1=ON	ENTER NEW SETUP MODE (0 or 1)		
ENABLE OPEN WIRE DETECTION ON DO13	3x00044 4x00044 I:43	1,0x0001 B:00 01	1	UINT16 R/W	NO
		Actual setup of open wire detection for state ON of DO13:1=ON	ENTER NEW SETUP MODE (0 or 1)		
ENABLE OPEN WIRE DETECTION ON DO14	3x00045 4x00045 I:44	1,0x0001 B:00 01	1	UINT16 R/W	NO
		Actual setup of open wire detection for state ON of DO14:1=ON	ENTER NEW SETUP MODE (0 or 1)		
ENABLE OPEN WIRE DETECTION ON DO15	3x00046 4x00046 I:45	1,0x0001 B:00 01	1	UINT16 R/W	NO
		Actual setup of open wire detection for state ON of DO15:1=ON	ENTER NEW SETUP MODE (0 or 1)		
<b>DIGITAL OUTPUTS: ENABLE OPEN WIRE DETECTION OFF</b>					
ENABLE OPEN WIRE DETECTION OFF DO1	3x00047 4x00047 I:46	1,0x0001 B:00 01	1	UINT16 R/W	NO
		Actual setup of open wire detection for state OFF of DO1:1=ON	ENTER NEW SETUP MODE (0 or 1)		
Enables/disabled detection of an open wire in DO state OFF for the digital output DOx =0:Open wire detection is OFF, =1:Open wire detection is ON					
Writing on this register changes the state of the open wire detection for this output					
ENABLE OPEN WIRE DETECTION OFF DO2	3x00048 4x00048 I:47	1,0x0001 B:00 01	1	UINT16 R/W	NO
		Actual setup of open wire detection for state OFF of DO2:1=ON	ENTER NEW SETUP MODE (0 or 1)		

ENABLE OPEN WIRE DETECTION OFF DO3	3x00049 4x00049 I:48	1,0x0001 B:00 01		1		UINT16 R/W	NO
		Actual setup of open wire detection for state OFF of DO3:1=ON		ENTER NEW SETUP MODE (0 or 1)			
ENABLE OPEN WIRE DETECTION OFF DO4	3x00050 4x00050 I:49	1,0x0001 B:00 01		1		UINT16 R/W	NO
		Actual setup of open wire detection for state OFF of DO4:1=ON		ENTER NEW SETUP MODE (0 or 1)			
ENABLE OPEN WIRE DETECTION OFF DO5	3x00051 4x00051 I:50	1,0x0001 B:00 01		1		UINT16 R/W	NO
		Actual setup of open wire detection for state OFF of DO5:1=ON		ENTER NEW SETUP MODE (0 or 1)			
ENABLE OPEN WIRE DETECTION OFF DO6	3x00052 4x00052 I:51	1,0x0001 B:00 01		1		UINT16 R/W	NO
		Actual setup of open wire detection for state OFF of DO6:1=ON		ENTER NEW SETUP MODE (0 or 1)			
ENABLE OPEN WIRE DETECTION OFF DO7	3x00053 4x00053 I:52	1,0x0001 B:00 01		1		UINT16 R/W	NO
		Actual setup of open wire detection for state OFF of DO7:1=ON		ENTER NEW SETUP MODE (0 or 1)			
ENABLE OPEN WIRE DETECTION OFF DO8	3x00054 4x00054 I:53	1,0x0001 B:00 01		1		UINT16 R/W	NO
		Actual setup of open wire detection for state OFF of DO8:1=ON		ENTER NEW SETUP MODE (0 or 1)			
ENABLE OPEN WIRE DETECTION OFF DO9	3x00055 4x00055 I:54	1,0x0001 B:00 01		1		UINT16 R/W	NO
		Actual setup of open wire detection for state OFF of DO9:1=ON		ENTER NEW SETUP MODE (0 or 1)			
ENABLE OPEN WIRE DETECTION OFF DO10	3x00056 4x00056 I:55	1,0x0001 B:00 01		1		UINT16 R/W	NO
		Actual setup of open wire detection for state OFF of DO10:1=ON		ENTER NEW SETUP MODE (0 or 1)			
ENABLE OPEN WIRE DETECTION OFF DO11	3x00057 4x00057 I:56	1,0x0001 B:00 01		1		UINT16 R/W	NO
		Actual setup of open wire detection for state OFF of DO11:1=ON		ENTER NEW SETUP MODE (0 or 1)			

ENABLE OPEN WIRE DETECTION OFF DO12	3x00058 4x00058 I:57	1,0x0001 B:00 01		1	UINT16 R/W	NO
		Actual setup of open wire detection for state OFF of DO12:1=ON		ENTER NEW SETUP MODE (0 or 1)		
ENABLE OPEN WIRE DETECTION OFF DO13	3x00059 4x00059 I:58	1,0x0001 B:00 01		1	UINT16 R/W	NO
		Actual setup of open wire detection for state OFF of DO13:1=ON		ENTER NEW SETUP MODE (0 or 1)		
ENABLE OPEN WIRE DETECTION OFF DO14	3x00060 4x00060 I:59	1,0x0001 B:00 01		1	UINT16 R/W	NO
		Actual setup of open wire detection for state OFF of DO14:1=ON		ENTER NEW SETUP MODE (0 or 1)		
ENABLE OPEN WIRE DETECTION OFF DO15	3x00061 4x00061 I:60	1,0x0001 B:00 01		1	UINT16 R/W	NO
		Actual setup of open wire detection for state OFF of DO15:1=ON		ENTER NEW SETUP MODE (0 or 1)		
<b>DIGITAL OUTPUTS: ENABLE SHORT TO VDD DETECTION</b>						
ENABLE SHORT TO VDD DETECTION DO1	3x00062 4x00062 I:61	1,0x0001 B:00 01		1	UINT16 R/W	NO
		Actual setup of open wire detection for state OFF of DO1:1=ON		ENTER NEW SETUP MODE (0 or 1)		
Enables/disabled detection of a shortcut to VDD in DO state OFF for the digital output DOx =0:Shortcut to VDD detection is OFF, =1:Shortcut to VDD detection is ON						
Writing on this register changes the state of the shortcut detection for this output						
ENABLE SHORT TO VDD DETECTION DO2	3x00063 4x00063 I:62	1,0x0001 B:00 01		1	UINT16 R/W	NO
		Actual setup of open wire detection for state OFF of DO2:1=ON		ENTER NEW SETUP MODE (0 or 1)		
ENABLE SHORT TO VDD DETECTION DO3	3x00064 4x00064 I:63	1,0x0001 B:00 01		1	UINT16 R/W	NO
		Actual setup of open wire detection for state OFF of DO3:1=ON		ENTER NEW SETUP MODE (0 or 1)		
ENABLE SHORT TO VDD DETECTION DO4	3x00065 4x00065 I:64	1,0x0001 B:00 01		1	UINT16 R/W	NO
		Actual setup of open wire detection for state OFF of DO4:1=ON		ENTER NEW SETUP MODE (0 or 1)		
ENABLE SHORT TO VDD DETECTION DO5	3x00066 4x00066 I:65	1,0x0001 B:00 01		1	UINT16 R/W	NO



		Actual setup of open wire detection for state OFF of DO5:1=ON	ENTER NEW SETUP MODE (0 or 1)		
ENABLE SHORT TO VDD DETECTION DO6	3x00067 4x00067 I:66	1,0x0001 B:00 01	1	UINT16 R/W	NO
		Actual setup of open wire detection for state OFF of DO6:1=ON	ENTER NEW SETUP MODE (0 or 1)		
ENABLE SHORT TO VDD DETECTION DO7	3x00068 4x00068 I:67	1,0x0001 B:00 01	1	UINT16 R/W	NO
		Actual setup of open wire detection for state OFF of DO7:1=ON	ENTER NEW SETUP MODE (0 or 1)		
ENABLE SHORT TO VDD DETECTION DO8	3x00069 4x00069 I:68	1,0x0001 B:00 01	1	UINT16 R/W	NO
		Actual setup of open wire detection for state OFF of DO8:1=ON	ENTER NEW SETUP MODE (0 or 1)		
ENABLE SHORT TO VDD DETECTION DO9	3x00070 4x00070 I:69	1,0x0001 B:00 01	1	UINT16 R/W	NO
		Actual setup of open wire detection for state OFF of DO9:1=ON	ENTER NEW SETUP MODE (0 or 1)		
ENABLE SHORT TO VDD DETECTION DO10	3x00071 4x00071 I:70	1,0x0001 B:00 01	1	UINT16 R/W	NO
		Actual setup of open wire detection for state OFF of DO10:1=ON	ENTER NEW SETUP MODE (0 or 1)		
ENABLE SHORT TO VDD DETECTION DO11	3x00072 4x00072 I:71	1,0x0001 B:00 01	1	UINT16 R/W	NO
		Actual setup of open wire detection for state OFF of DO11:1=ON	ENTER NEW SETUP MODE (0 or 1)		
ENABLE SHORT TO VDD DETECTION DO12	3x00073 4x00073 I:72	1,0x0001 B:00 01	1	UINT16 R/W	NO
		Actual setup of open wire detection for state OFF of DO12:1=ON	ENTER NEW SETUP MODE (0 or 1)		
ENABLE SHORT TO VDD DETECTION DO13	3x00074 4x00074 I:73	1,0x0001 B:00 01	1	UINT16 R/W	NO
		Actual setup of open wire detection for state OFF of DO13:1=ON	ENTER NEW SETUP MODE (0 or 1)		
ENABLE SHORT TO VDD DETECTION DO14	3x00075 4x00075 I:74	1,0x0001 B:00 01	1	UINT16 R/W	NO
		Actual setup of open wire detection for state OFF of DO14:1=ON	ENTER NEW SETUP MODE (0 or 1)		

ENABLE SHORT TO VDD DETECTION DO15	3x00076 4x00076 I:75	1,0x0001 B:00 01		1	UINT16 R/W	NO
		Actual setup of open wire detection for state OFF of DO15:1=ON		ENTER NEW SETUP MODE (0 or 1)		
<b>DIGITAL OUTPUTS: OPEN WIRE DETECTION STATUS WHILE ON</b>						
OPEN WIRE FAULT WHILE ON DO1	3x00077 4x00077 I:76	0,0x0000 B:00 00			UINT16 R/O	
		Actual detection state of an open wire fault in state ON for DO1:0=OK				
The current detection state of an open wire in the output state ON for the digital output DOx =0:No fault, =1:Fault-open wire detected						
OPEN WIRE FAULT WHILE ON DO2	3x00078 4x00078 I:77	0,0x0000 B:00 00			UINT16 R/O	
		Actual detection state of an open wire fault in state ON for DO2:0=OK				
OPEN WIRE FAULT WHILE ON DO3	3x00079 4x00079 I:78	0,0x0000 B:00 00			UINT16 R/O	
		Actual detection state of an open wire fault in state ON for DO3:0=OK				
OPEN WIRE FAULT WHILE ON DO4	3x00080 4x00080 I:79	0,0x0000 B:00 00			UINT16 R/O	
		Actual detection state of an open wire fault in state ON for DO4:0=OK				
OPEN WIRE FAULT WHILE ON DO5	3x00081 4x00081 I:80	0,0x0000 B:00 00			UINT16 R/O	
		Actual detection state of an open wire fault in state ON for DO5:0=OK				
OPEN WIRE FAULT WHILE ON DO6	3x00082 4x00082 I:81	0,0x0000 B:00 00			UINT16 R/O	
		Actual detection state of an open wire fault in state ON for DO6:0=OK				
OPEN WIRE FAULT WHILE ON DO7	3x00083 4x00083 I:82	0,0x0000 B:00 00			UINT16 R/O	
		Actual detection state of an open wire fault in state ON for DO7:0=OK				
OPEN WIRE FAULT WHILE ON DO8	3x00084 4x00084 I:83	0,0x0000 B:00 00			UINT16 R/O	

		Actual detection state of an open wire fault in state ON for DO8:0=OK				
OPEN WIRE FAULT WHILE ON DO9	3x00085 4x00085 I:84	0,0x0000 B:00 00			UINT16 R/O	
		Actual detection state of an open wire fault in state ON for DO9:0=OK				
OPEN WIRE FAULT WHILE ON DO10	3x00086 4x00086 I:85	0,0x0000 B:00 00			UINT16 R/O	
		Actual detection state of an open wire fault in state ON for DO10:0=OK				
OPEN WIRE FAULT WHILE ON DO11	3x00087 4x00087 I:86	0,0x0000 B:00 00			UINT16 R/O	
		Actual detection state of an open wire fault in state ON for DO11:0=OK				
OPEN WIRE FAULT WHILE ON DO12	3x00088 4x00088 I:87	0,0x0000 B:00 00			UINT16 R/O	
		Actual detection state of an open wire fault in state ON for DO12:0=OK				
OPEN WIRE FAULT WHILE ON DO13	3x00089 4x00089 I:88	0,0x0000 B:00 00			UINT16 R/O	
		Actual detection state of an open wire fault in state ON for DO13:0=OK				
OPEN WIRE FAULT WHILE ON DO14	3x00090 4x00090 I:89	0,0x0000 B:00 00			UINT16 R/O	
		Actual detection state of an open wire fault in state ON for DO14:0=OK				
OPEN WIRE FAULT WHILE ON DO15	3x00091 4x00091 I:90	0,0x0000 B:00 00			UINT16 R/O	
<b>DIGITAL OUTPUTS: OPEN WIRE DETECTION STATUS WHILE OFF</b>						
OPEN WIRE FAULT WHILE OFF DO1	3x00092 4x00092 I:91	0,0x0000 B:00 00			UINT16 R/O	
		Actual detection state of an open wire fault in state OFF for DO1:0=OK				
The current detection state of an open wire in the output state OFF for the digital output DOx =0:No fault, =1:Fault-open wire detected						
OPEN WIRE FAULT WHILE OFF DO2	3x00093 4x00093 I:92	0,0x0000 B:00 00			UINT16 R/O	

		Actual detection state of an open wire fault in state OFF for DO2:0=OK			
OPEN WIRE FAULT WHILE OFF DO3	3x00094 4x00094 I:93	0,0x0000 B:00 00			UINT16 R/O
		Actual detection state of an open wire fault in state OFF for DO3:0=OK			
OPEN WIRE FAULT WHILE OFF DO4	3x00095 4x00095 I:94	0,0x0000 B:00 00			UINT16 R/O
		Actual detection state of an open wire fault in state OFF for DO4:0=OK			
OPEN WIRE FAULT WHILE OFF DO5	3x00096 4x00096 I:95	0,0x0000 B:00 00			UINT16 R/O
		Actual detection state of an open wire fault in state OFF for DO5:0=OK			
OPEN WIRE FAULT WHILE OFF DO6	3x00097 4x00097 I:96	0,0x0000 B:00 00			UINT16 R/O
		Actual detection state of an open wire fault in state OFF for DO6:0=OK			
OPEN WIRE FAULT WHILE OFF DO7	3x00098 4x00098 I:97	0,0x0000 B:00 00			UINT16 R/O
		Actual detection state of an open wire fault in state OFF for DO7:0=OK			
OPEN WIRE FAULT WHILE OFF DO8	3x00099 4x00099 I:98	0,0x0000 B:00 00			UINT16 R/O
		Actual detection state of an open wire fault in state OFF for DO8:0=OK			
OPEN WIRE FAULT WHILE OFF DO9	3x00100 4x00100 I:99	1,0x0001 B:00 01			UINT16 R/O
		Actual detection state of an open wire fault in state OFF for DO9:1=FAULT			
OPEN WIRE FAULT WHILE OFF DO10	3x00101 4x00101 I:100	1,0x0001 B:00 01			UINT16 R/O
		Actual detection state of an open wire fault in state OFF for DO10:1=FAULT			
OPEN WIRE FAULT WHILE OFF DO11	3x00102 4x00102 I:101	1,0x0001 B:00 01			UINT16 R/O
		Actual detection state of an open wire fault in state OFF for DO11:1=FAULT			

OPEN WIRE FAULT WHILE OFF DO12	3x00103 4x00103 I:102	1,0x0001 B:00 01			UINT16 R/O	
		Actual detection state of an open wire fault in state OFF for DO12:1=FAULT				
OPEN WIRE FAULT WHILE OFF DO13	3x00104 4x00104 I:103	1,0x0001 B:00 01			UINT16 R/O	
		Actual detection state of an open wire fault in state OFF for DO13:1=FAULT				
OPEN WIRE FAULT WHILE OFF DO14	3x00105 4x00105 I:104	1,0x0001 B:00 01			UINT16 R/O	
		Actual detection state of an open wire fault in state OFF for DO14:1=FAULT				
OPEN WIRE FAULT WHILE OFF DO15	3x00106 4x00106 I:105	1,0x0001 B:00 01			UINT16 R/O	
		Actual detection state of an open wire fault in state OFF for DO15:1=FAULT				
<b>DIGITAL OUTPUTS: SHORTCUT DETECTION STATUS TO VDD WHILE OFF</b>						
OPEN WIRE SHORTCUT TO VDD DO1	3x00107 4x00107 I:106	0,0x0000 B:00 00			UINT16 R/O	
		Actual detection state of a shortcut to VDD in state OFF for VDD DO1:0=OK				
The current detection state of a shortcut to VDD in the output state OFF for the digital output DOx =0:No fault, =1:Fault-shortcut to VDD detected						
OPEN WIRE SHORTCUT TO VDD DO2	3x00108 4x00108 I:107	0,0x0000 B:00 00			UINT16 R/O	
		Actual detection state of a shortcut to VDD in state OFF for VDD DO2:0=OK				
OPEN WIRE SHORTCUT TO VDD DO3	3x00109 4x00109 I:108	0,0x0000 B:00 00			UINT16 R/O	
		Actual detection state of a shortcut to VDD in state OFF for VDD DO3:0=OK				
OPEN WIRE SHORTCUT TO VDD DO4	3x00110 4x00110 I:109	0,0x0000 B:00 00			UINT16 R/O	
		Actual detection state of a shortcut to VDD in state OFF for VDD DO4:0=OK				

OPEN WIRE SHORTCUT TO VDD DO5	3x00111 4x00111 I:110	0,0x0000 B:00 00			UINT16 R/O	
		Actual detection state of a shortcut to VDD in state OFF for VDD DO5:0=OK				
OPEN WIRE SHORTCUT TO VDD DO6	3x00112 4x00112 I:111	0,0x0000 B:00 00			UINT16 R/O	
		Actual detection state of a shortcut to VDD in state OFF for VDD DO6:0=OK				
OPEN WIRE SHORTCUT TO VDD DO7	3x00113 4x00113 I:112	0,0x0000 B:00 00			UINT16 R/O	
		Actual detection state of a shortcut to VDD in state OFF for VDD DO7:0=OK				
OPEN WIRE SHORTCUT TO VDD DO8	3x00114 4x00114 I:113	0,0x0000 B:00 00			UINT16 R/O	
		Actual detection state of a shortcut to VDD in state OFF for VDD DO8:0=OK				
OPEN WIRE SHORTCUT TO VDD DO9	3x00115 4x00115 I:114	0,0x0000 B:00 00			UINT16 R/O	
		Actual detection state of a shortcut to VDD in state OFF for VDD DO9:0=OK				
OPEN WIRE SHORTCUT TO VDD DO10	3x00116 4x00116 I:115	0,0x0000 B:00 00			UINT16 R/O	
		Actual detection state of a shortcut to VDD in state OFF for VDD DO10:0=OK				
OPEN WIRE SHORTCUT TO VDD DO11	3x00117 4x00117 I:116	0,0x0000 B:00 00			UINT16 R/O	
		Actual detection state of a shortcut to VDD in state OFF for VDD DO11:0=OK				
OPEN WIRE SHORTCUT TO VDD DO12	3x00118 4x00118 I:117	0,0x0000 B:00 00			UINT16 R/O	

		Actual detection state of a shortcut to VDD in state OFF for VDD DO12:0=OK			
OPEN WIRE SHORTCUT TO VDD DO13	3x00119 4x00119 I:118	0,0x0000 B:00 00			UINT16 R/O
		Actual detection state of a shortcut to VDD in state OFF for VDD DO13:0=OK			
OPEN WIRE SHORTCUT TO VDD DO14	3x00120 4x00120 I:119	0,0x0000 B:00 00			UINT16 R/O
		Actual detection state of a shortcut to VDD in state OFF for VDD DO14:0=OK			
OPEN WIRE SHORTCUT TO VDD DO15	3x00121 4x00121 I:120	0,0x0000 B:00 00			UINT16 R/O
		Actual detection state of a shortcut to VDD in state OFF for VDD DO15:0=OK			
<b>DIGITAL OUTPUTS: THERMAL OVERLOAD DETECTION STATUS</b>					
THERMAL OVERLOAD DETECTION STATUS DO1	3x00122 4x00122 I:121	0,0x0000 B:00 00			UINT16 R/O
		Actual detection state of a thermal overload for DO1:0=OK			
The current detection state of a thermal overload for the digital output DOx =0:No fault, =1:Fault-thermal overload detected					
THERMAL OVERLOAD DETECTION STATUS DO2	3x00123 4x00123 I:122	0,0x0000 B:00 00			UINT16 R/O
		Actual detection state of a thermal overload for DO2:0=OK			
THERMAL OVERLOAD DETECTION STATUS DO3	3x00124 4x00124 I:123	0,0x0000 B:00 00			UINT16 R/O
		Actual detection state of a thermal overload for DO3:0=OK			
THERMAL OVERLOAD DETECTION STATUS DO4	3x00125 4x00125 I:124	0,0x0000 B:00 00			UINT16 R/O
		Actual detection state of a thermal overload for DO4:0=OK			
THERMAL OVERLOAD DETECTION STATUS DO5	3x00126 4x00126 I:125	0,0x0000 B:00 00			UINT16 R/O

		Actual detection state of a thermal overload for DO5:0=OK				
THERMAL OVERLOAD DETECTION STATUS DO6	3x00127 4x00127 I:126	0,0x0000 B:00 00			UINT16 R/O	
		Actual detection state of a thermal overload for DO6:0=OK				
THERMAL OVERLOAD DETECTION STATUS DO7	3x00128 4x00128 I:127	0,0x0000 B:00 00			UINT16 R/O	
		Actual detection state of a thermal overload for DO7:0=OK				
THERMAL OVERLOAD DETECTION STATUS DO8	3x00129 4x00129 I:128	0,0x0000 B:00 00			UINT16 R/O	
		Actual detection state of a thermal overload for DO8:0=OK				
THERMAL OVERLOAD DETECTION STATUS DO9	3x00130 4x00130 I:129	0,0x0000 B:00 00			UINT16 R/O	
		Actual detection state of a thermal overload for DO9:0=OK				
THERMAL OVERLOAD DETECTION STATUS DO10	3x00131 4x00131 I:130	0,0x0000 B:00 00			UINT16 R/O	
		Actual detection state of a thermal overload for DO10:0=OK				
THERMAL OVERLOAD DETECTION STATUS DO11	3x00132 4x00132 I:131	0,0x0000 B:00 00			UINT16 R/O	
		Actual detection state of a thermal overload for DO11:0=OK				
THERMAL OVERLOAD DETECTION STATUS DO12	3x00133 4x00133 I:132	0,0x0000 B:00 00			UINT16 R/O	
		Actual detection state of a thermal overload for DO12:0=OK				
THERMAL OVERLOAD DETECTION STATUS DO13	3x00134 4x00134 I:133	0,0x0000 B:00 00			UINT16 R/O	
		Actual detection state of a thermal overload for DO13:0=OK				
THERMAL OVERLOAD DETECTION STATUS DO14	3x00135 4x00135 I:134	0,0x0000 B:00 00			UINT16 R/O	
		Actual detection state of a thermal overload for DO14:0=OK				



THERMAL OVERLOAD DETECTION STATUS DO15	3x00136 4x00136 I:135	0,0x0000 B:00 00			UINT16 R/O	
		Actual detection state of a thermal overload for DO15:0=OK				
<b>DIGITAL OUTPUTS: CURRENT LIMIT DETECTION STATUS WHILE ON</b>						
CURRENT LIMIT DETECTION STATUS WHILE ON DO1	3x00137 4x00137 I:136	0,0x0000 B:00 00			UINT16 R/O	
		Actual detection state of a current limit while ON for DO1:0=OK				
The current detection state of a current limit while output is ON for the digital output DOx =0:No fault, =1:Fault-current limit error						
CURRENT LIMIT DETECTION STATUS WHILE ON DO2	3x00138 4x00138 I:137	0,0x0000 B:00 00			UINT16 R/O	
		Actual detection state of a current limit while ON for DO2:0=OK				
CURRENT LIMIT DETECTION STATUS WHILE ON DO3	3x00139 4x00139 I:138	0,0x0000 B:00 00			UINT16 R/O	
		Actual detection state of a current limit while ON for DO3:0=OK				
CURRENT LIMIT DETECTION STATUS WHILE ON DO4	3x00140 4x00140 I:139	0,0x0000 B:00 00			UINT16 R/O	
		Actual detection state of a current limit while ON for DO4:0=OK				
CURRENT LIMIT DETECTION STATUS WHILE ON DO5	3x00141 4x00141 I:140	0,0x0000 B:00 00			UINT16 R/O	
		Actual detection state of a current limit while ON for DO5:0=OK				
CURRENT LIMIT DETECTION STATUS WHILE ON DO6	3x00142 4x00142 I:141	0,0x0000 B:00 00			UINT16 R/O	
		Actual detection state of a current limit while ON for DO6:0=OK				
CURRENT LIMIT DETECTION STATUS WHILE ON DO7	3x00143 4x00143 I:142	0,0x0000 B:00 00			UINT16 R/O	
		Actual detection state of a current limit while ON for DO7:0=OK				
CURRENT LIMIT DETECTION STATUS WHILE ON DO8	3x00144 4x00144 I:143	0,0x0000 B:00 00			UINT16 R/O	

		Actual detection state of a current limit while ON for DO8:0=OK			
CURRENT LIMIT DETECTION STATUS WHILE ON DO9	3x00145 4x00145 I:144	0,0x0000 B:00 00		UINT16 R/O	
		Actual detection state of a current limit while ON for DO9:0=OK			
CURRENT LIMIT DETECTION STATUS WHILE ON DO10	3x00146 4x00146 I:145	0,0x0000 B:00 00		UINT16 R/O	
		Actual detection state of a current limit while ON for DO10:0=OK			
CURRENT LIMIT DETECTION STATUS WHILE ON DO11	3x00147 4x00147 I:146	0,0x0000 B:00 00		UINT16 R/O	
		Actual detection state of a current limit while ON for DO11:0=OK			
CURRENT LIMIT DETECTION STATUS WHILE ON DO12	3x00148 4x00148 I:147	0,0x0000 B:00 00		UINT16 R/O	
		Actual detection state of a current limit while ON for DO12:0=OK			
CURRENT LIMIT DETECTION STATUS WHILE ON DO13	3x00149 4x00149 I:148	0,0x0000 B:00 00		UINT16 R/O	
		Actual detection state of a current limit while ON for DO13:0=OK			
CURRENT LIMIT DETECTION STATUS WHILE ON DO14	3x00150 4x00150 I:149	0,0x0000 B:00 00		UINT16 R/O	
		Actual detection state of a current limit while ON for DO14:0=OK			
CURRENT LIMIT DETECTION STATUS WHILE ON DO15	3x00151 4x00151 I:150	0,0x0000 B:00 00		UINT16 R/O	
		Actual detection state of a current limit while ON for DO15:0=OK			
<b>DIGITAL OUTPUTS: GLOBAL ERRORS</b>					
<b>CHIP #1:DO1-DO8</b>					
GLOBAL ERRORS BIT 0	3x00152 4x00152 I:151	0,0x0000 B:00 00		UINT16 R/O	
		BIT 0:Internal under voltage detected:0=OK			
GLOBAL ERRORS BIT 1	3x00153 4x00153 I:152	0,0x0000 B:00 00		UINT16 R/O	
		BIT 1:VA under voltage detected (<2.3V):0=OK			

GLOBAL ERRORS BIT 2	3x00154 4x00154 I:153	0,0x0000 B:00 00			UINT16 R/O	
BIT 2:VDD not good detected (<17V):0=OK						
GLOBAL ERRORS BIT 3	3x00155 4x00155 I:154	0,0x0000 B:00 00			UINT16 R/O	
BIT 3:VDD warning detected (<12V):0=OK						
GLOBAL ERRORS BIT 4	3x00156 4x00156 I:155	0,0x0000 B:00 00			UINT16 R/O	
BIT 4:VDD under voltage detected (<8V):0=OK						
GLOBAL ERRORS BIT 5	3x00157 4x00157 I:156	0,0x0000 B:00 00			UINT16 R/O	
BIT 5:Thermal shutdown:0=OK						
GLOBAL ERRORS BIT 6	3x00158 4x00158 I:157	0,0x0000 B:00 00			UINT16 R/O	
BIT 6:Synchronisation error detected:0=OK						
GLOBAL ERRORS BIT 7	3x00159 4x00159 I:158	0,0x0000 B:00 00			UINT16 R/O	
BIT 7:Watchdog error detected:0=OK						

The global error state for the output group. Each bit stands for a different error  
=0:No fault, =1:Fault

**DIGITAL OUTPUTS: GLOBAL ERRORS****CHIP #2:DO9-DO15**

GLOBAL ERRORS BIT 0	3x00160 4x00160 I:159	0,0x0000 B:00 00			UINT16 R/O	
BIT 0:Internal under voltage detected:0=OK						
GLOBAL ERRORS BIT 1	3x00161 4x00161 I:160	0,0x0000 B:00 00			UINT16 R/O	
BIT 1:VA under voltage detected (<2.3V):0=OK						
GLOBAL ERRORS BIT 2	3x00162 4x00162 I:161	0,0x0000 B:00 00			UINT16 R/O	
BIT 2:VDD not good detected (<17V):0=OK						
GLOBAL ERRORS BIT 3	3x00163 4x00163 I:162	0,0x0000 B:00 00			UINT16 R/O	
BIT 3:VDD warning detected (<12V):0=OK						
GLOBAL ERRORS BIT 4	3x00164 4x00164 I:163	0,0x0000 B:00 00			UINT16 R/O	

		BIT 4:VDD under voltage detected (<8V):0=OK				
GLOBAL ERRORS BIT 5	3x00165 4x00165 I:164	0,0x0000 B:00 00			UINT16 R/O	
		BIT 5:Thermal shutdown:0=OK				
GLOBAL ERRORS BIT 6	3x00166 4x00166 I:165	0,0x0000 B:00 00			UINT16 R/O	
		BIT 6:Synchronisation error detected:0=OK				
GLOBAL ERRORS BIT 7	3x00167 4x00167 I:166	0,0x0000 B:00 00			UINT16 R/O	
		BIT 7:Watchdog error detected:0=OK				
The global error state for the output group. Each bit stands for a different error =0:No fault, =1:Fault						
<b>DIGITAL OUTPUTS: INTERRUPT STATUS</b>						
<b>CHIP #1:DO1-DO8</b>						
INTERRUPT STATUS BIT 0	3x00168 4x00168 I:167	0,0x0000 B:00 00			UINT16 R/O	
		BIT 0:Overload detected:0=OK				
INTERRUPT STATUS BIT 1	3x00169 4x00169 I:168	0,0x0000 B:00 00			UINT16 R/O	
		BIT 1:Current limit detected:0=OK				
INTERRUPT STATUS BIT 2	3x00170 4x00170 I:169	0,0x0000 B:00 00			UINT16 R/O	
		BIT 2:Open wire while OFF detected:0=OK				
INTERRUPT STATUS BIT 3	3x00171 4x00171 I:170	0,0x0000 B:00 00			UINT16 R/O	
		BIT 3:Open wire while ON detected:0=OK				
INTERRUPT STATUS BIT 4	3x00172 4x00172 I:171	0,0x0000 B:00 00			UINT16 R/O	
		BIT 4:Short to VDD while ON detected:0=OK				
INTERRUPT STATUS BIT 5	3x00173 4x00173 I:172	0,0x0000 B:00 00			UINT16 R/O	
		BIT 5:Thermal error detected-shutdown:0=OK				
INTERRUPT STATUS BIT 6	3x00174 4x00174 I:173	0,0x0000 B:00 00			UINT16 R/O	
		BIT 6:Supply error detected:0=OK				

INTERRUPT STATUS BIT 7	3x00175 4x00175 I:174	0,0x0000 B:00 00			UINT16 R/O	
BIT 7:Communication error detected:0=OK						
The global interrupt error state for the output group. Each bit stands for a different error =0:No fault, =1:Fault						
<b>DIGITAL OUTPUTS: INTERRUPT STATUS</b>						
<b>CHIP #2:DO9-DO15</b>						
INTERRUPT STATUS BIT 0	3x00176 4x00176 I:175	0,0x0000 B:00 00			UINT16 R/O	
BIT 0:Overload detected:0=OK						
INTERRUPT STATUS BIT 1	3x00177 4x00177 I:176	0,0x0000 B:00 00			UINT16 R/O	
BIT 1:Current limit detected:0=OK						
INTERRUPT STATUS BIT 2	3x00178 4x00178 I:177	1,0x0001 B:00 01			UINT16 R/O	
BIT 2:Open wire while OFF detected:1=FAULT						
INTERRUPT STATUS BIT 3	3x00179 4x00179 I:178	0,0x0000 B:00 00			UINT16 R/O	
BIT 3:Open wire while ON detected:0=OK						
INTERRUPT STATUS BIT 4	3x00180 4x00180 I:179	0,0x0000 B:00 00			UINT16 R/O	
BIT 4:Short to VDD while ON detected:0=OK						
INTERRUPT STATUS BIT 5	3x00181 4x00181 I:180	0,0x0000 B:00 00			UINT16 R/O	
BIT 5:Thermal error detected-shutdown:0=OK						
INTERRUPT STATUS BIT 6	3x00182 4x00182 I:181	0,0x0000 B:00 00			UINT16 R/O	
BIT 6:Supply error detected:0=OK						
INTERRUPT STATUS BIT 7	3x00183 4x00183 I:182	0,0x0000 B:00 00			UINT16 R/O	
BIT 7:Communication error detected:0=OK						
The global interrupt error state for the output group. Each bit stands for a different error =0:No fault, =1:Fault						
<b>SPI COMMUNICATION DIGITAL OUTPUTS</b>						
SPI COMMUNICATION CHIP #1: DO1-DO8	3x00184 4x00184 I:183	0,0x0000 B:00 00			UINT16 R/O	
Actual SPI communication state:0=NO FAULT						

The current monitoring state of the SPI communication for the digital output group

=0:No fault, =1:Fault

SPI COMMUNICATION CHIP #2: DO9-DO15	3x00185 4x00185 l:184	0,0x0000 B:00 00			UINT16 R/O	
Actual SPI communication state:0=NO FAULT						

The current monitoring state of the SPI communication for the digital output group

=0:No fault, =1:Fault

### DIGITAL INPUTS: RESET

RESET COUNTERS	3x10000 4x10000 l:9999	0,0x0000 B:00 00		1:PERFORM RESET	UINT16 R/W	NO
----------------	------------------------------	---------------------	--	-----------------	---------------	----

If this register is written to 1, all internal edge counters and event counters are set to 0. 0 is always returned when reading.

HAS DIS CHANGED	3x10001 4x10001 l:10000	32,0x0020 B:00 20			UINT16 R/O	
32 event(s)						

As soon as the module registers an event on one of the available digital inputs, this global event counter is incremented by 1.

Possible events are:

Detection of a short keypress

Detection of the start of a long keypress

Detection of the end of a long keypress

STATUS OF ALL DIS DI1..DI16	3x10002 4x10002 l:10001	0,0x0000 B:00 00			UINT16 R/O	
Actual state of DI1:0=OFF						
Actual state of DI2:0=OFF						
Actual state of DI3:0=OFF						
Actual state of DI4:0=OFF						
Actual state of DI5:0=OFF						
Actual state of DI6:0=OFF						
Actual state of DI7:0=OFF						
Actual state of DI8:0=OFF						
Actual state of DI9:0=OFF						
Actual state of DI10:0=OFF						
Actual state of DI11:0=OFF						
Actual state of DI12:0=OFF						
Actual state of DI13:0=OFF						
Actual state of DI14:0=OFF						
Actual state of DI15:0=OFF						
Actual state of DI16:0=OFF						

Actual state of all digital inputs DI1..DI12

Bit 0: =0:DI1 is OFF, =1:DI1 is ON

Bit 1: =0:DI2 is OFF, =1:DI2 is ON

...

Bit 14: =0:DI15 is OFF, =1:DI15 is ON

Bit 15: =0:DI16 is OFF, =1:DI16 is ON

### STATUS OF DIGITAL OUTPUTS

STATUS OF ALL DOS DO1-DO15	3x10003 4x10003 l:10002	0,0x0000 B:00 00		0x7FFF	UINT16 R/W	NO
		Actual state of DO1:0=OFF	1			
		Actual state of DO2:0=OFF	1			
		Actual state of DO3:0=OFF	1			
		Actual state of DO4:0=OFF	1			
		Actual state of DO5:0=OFF	1			
		Actual state of DO6:0=OFF	1			
		Actual state of DO7:0=OFF	1			
		Actual state of DO8:0=OFF	1			
		Actual state of DO9:0=OFF	1			
		Actual state of DO10:0=OFF	1			
		Actual state of DO11:0=OFF	1			
		Actual state of DO12:0=OFF	1			
		Actual state of DO13:0=OFF	1			
		Actual state of DO14:0=OFF	1			
		Actual state of DO15:0=OFF	1			

Actual state of all digital outputs  
 Bit 0: =0:DO1 is OFF, =1:DO1 is ON  
 Bit 1: =0:DO2 is OFF, =1:DO2 is ON  
 ...  
 Bit 13: =0:DO14 is OFF, =1:DO14 is ON  
 Bit 14: =0:DO15 is OFF, =1:DO15 is ON

Write on this register sets all digital outputs to a new state

#### DIGITAL OUTPUTS:ENABLE OPEN WIRE DETECTION WHILE ON

ENABLE OPEN WIRE DETECTION WHILE ON DO1-DO15	3x10004 4x10004 l:10003	65535,0xFFFF B:FF FF		0x7FFF	UINT16 R/W	NO
		Actual setup of open wire detection while ON for DO1:1=ENABLED	1			
		Actual setup of open wire detection while ON for DO2:1=ENABLED	1			
		Actual setup of open wire detection while ON for DO3:1=ENABLED	1			
		Actual setup of open wire detection while ON for DO4:1=ENABLED	1			
		Actual setup of open wire detection while ON for DO5:1=ENABLED	1			
		Actual setup of open wire detection while ON for DO6:1=ENABLED	1			
		Actual setup of open wire detection while ON for DO7:1=ENABLED	1			
		Actual setup of open wire detection while ON for DO8:1=ENABLED	1			
		Actual setup of open wire detection while ON for DO9:1=ENABLED	1			

		Actual setup of open wire detection while ON for DO10:1=ENABLED	1		
		Actual setup of open wire detection while ON for DO11:1=ENABLED	1		
		Actual setup of open wire detection while ON for DO12:1=ENABLED	1		
		Actual setup of open wire detection while ON for DO13:1=ENABLED	1		
		Actual setup of open wire detection while ON for DO14:1=ENABLED	1		
		Actual setup of open wire detection while ON for DO15:1=ENABLED	1		

Actual setup state for open wire detection while ON for digital output DOx

Bit 0: =0:Open wire detection for DO1 is DISABLED, =1:Open wire detection for DO1 is ENABLED

Bit 1: =0:Open wire detection for DO2 is DISABLED, =1:Open wire detection for DO2 is ENABLED

...

Bit 13: =0:Open wire detection for DO14 is DISABLED, =1:Open wire detection for DO14 is ENABLED

Bit 14: =0:Open wire detection for DO15 is DISABLED, =1:Open wire detection for DO15 is ENABLED

Write on this register sets for all digital outputs a new setup state

#### DIGITAL OUTPUTS:ENABLE OPEN WIRE DETECTION WHILE OFF

ENABLE OPEN WIRE DETECTION WHILE OFF DO1-DO15	3x10005 4x10005 1:10004	65535,0xFFFF B:FF FF		0x7FFF	UINT16 R/W	NO
		Actual setup of open wire detection while OFF for DO1:1=ENABLED	1			
		Actual setup of open wire detection while OFF for DO2:1=ENABLED	1			
		Actual setup of open wire detection while OFF for DO3:1=ENABLED	1			
		Actual setup of open wire detection while OFF for DO4:1=ENABLED	1			
		Actual setup of open wire detection while OFF for DO5:1=ENABLED	1			
		Actual setup of open wire detection while OFF for DO6:1=ENABLED	1			
		Actual setup of open wire detection while OFF for DO7:1=ENABLED	1			
		Actual setup of open wire detection while OFF for DO8:1=ENABLED	1			
		Actual setup of open wire detection while OFF for DO9:1=ENABLED	1			
		Actual setup of open wire detection while OFF for DO10:1=ENABLED	1			
		Actual setup of open wire detection while OFF for DO11:1=ENABLED	1			
		Actual setup of open wire detection while OFF for DO12:1=ENABLED	1			



		Actual setup of open wire detection while OFF for DO13:1=ENABLED	1		
		Actual setup of open wire detection while OFF for DO14:1=ENABLED	1		
		Actual setup of open wire detection while OFF for DO15:1=ENABLED	1		
Actual setup state for open wire detection while OFF for digital output DOx Bit 0: =0:Open wire detection for DO1 is DISABLED, =1:Open wire detection for DO1 is ENABLED Bit 1: =0:Open wire detection for DO2 is DISABLED, =1:Open wire detection for DO2 is ENABLED ... Bit 14: =0:Open wire detection for DO15 is DISABLED, =1:Open wire detection for DO15 is ENABLED Bit 15: =0:Open wire detection for DO16 is DISABLED, =1:Open wire detection for DO16 is ENABLED					
Write on this register sets for all digital outputs a new setup state					
<b>DIGITAL OUTPUTS:ENABLE SHORTCUT TO VDD DETECTION WHILE OFF</b>					
ENABLE SHORTCUT TO VDD DETECTION WHILE OFF DO1-DO15	3x10006 4x10006 1:10005	65535,0xFFFF B:FF FF		0x7FFF	UINT16 R/W
		Actual setup of shortcut detection to VDD while OFF for DO1:1=ENABLED	1		
		Actual setup of shortcut detection to VDD while OFF for DO2:1=ENABLED	1		
		Actual setup of shortcut detection to VDD while OFF for DO3:1=ENABLED	1		
		Actual setup of shortcut detection to VDD while OFF for DO4:1=ENABLED	1		
		Actual setup of shortcut detection to VDD while OFF for DO5:1=ENABLED	1		
		Actual setup of shortcut detection to VDD while OFF for DO6:1=ENABLED	1		
		Actual setup of shortcut detection to VDD while OFF for DO7:1=ENABLED	1		
		Actual setup of shortcut detection to VDD while OFF for DO8:1=ENABLED	1		
		Actual setup of shortcut detection to VDD while OFF for DO9:1=ENABLED	1		
		Actual setup of shortcut detection to VDD while OFF for DO10:1=ENABLED	1		
		Actual setup of shortcut detection to VDD while OFF for DO11:1=ENABLED	1		
		Actual setup of shortcut detection to VDD while OFF for DO12:1=ENABLED	1		
		Actual setup of shortcut detection to VDD while OFF for DO13:1=ENABLED	1		
		Actual setup of shortcut detection to VDD while OFF for DO14:1=ENABLED	1		
		Actual setup of shortcut detection to VDD while OFF for DO15:1=ENABLED	1		

Actual setup state for shortcut to VDD detection while OFF for digital output DOx

Bit 0: =0:Shortcut to VDD detection for DO1 is DISABLED, =1:Shortcut to VDD detection for DO1 is ENABLED

Bit 1: =0:Shortcut to VDD detection for DO2 is DISABLED, =1:Shortcut to VDD detection for DO2 is ENABLED

...

Bit 13: =0:Shortcut to VDD detection for DO14 is DISABLED, =1:Shortcut to VDD detection for DO14 is ENABLED

Bit 14: =0:Shortcut to VDD detection for DO15 is DISABLED, =1:Shortcut to VDD detection for DO15 is ENABLED

Write on this register sets for all digital outputs a new setup state

### DIGITAL OUTPUTS:OPEN WIRE WHILE ON DETECTION STATE

OPEN WIRE DETECTION STATE WHILE ON DO1-DO15	3x10007 4x10007 l:10006	0,0x0000 B:00 00			UINT16 R/O
		Actual state of open wire detection while ON for DO1:0=OFF			
		Actual state of open wire detection while ON for DO2:0=OFF			
		Actual state of open wire detection while ON for DO3:0=OFF			
		Actual state of open wire detection while ON for DO4:0=OFF			
		Actual state of open wire detection while ON for DO5:0=OFF			
		Actual state of open wire detection while ON for DO6:0=OFF			
		Actual state of open wire detection while ON for DO7:0=OFF			
		Actual state of open wire detection while ON for DO8:0=OFF			
		Actual state of open wire detection while ON for DO9:0=OFF			
		Actual state of open wire detection while ON for DO10:0=OFF			
		Actual state of open wire detection while ON for DO11:0=OFF			
		Actual state of open wire detection while ON for DO12:0=OFF			
		Actual state of open wire detection while ON for DO13:0=OFF			
		Actual state of open wire detection while ON for DO14:0=OFF			
		Actual state of open wire detection while ON for DO15:0=OFF			

Actual diagnostic state for open wire detection while ON for digital output DOx

Bit 0: =0:Output DO1 is OK, =1:Fault-Open wire detected on DO1

Bit 1: =0:Output DO2 is OK, =1:Fault-Open wire detected on DO2

...

Bit 13: =0:Output DO14 is OK, =1:Fault-Open wire detected on DO14

Bit 14: =0:Output DO15 is OK, =1:Fault-Open wire detected on DO15

### DIGITAL OUTPUTS:OPEN WIRE WHILE OFF DETECTION STATE

OPEN WIRE DETECTION STATE WHILE OFF DO1-DO15	3x10008 4x10008 l:10007	32512,0x7F00 B:7F 00		UINT16 R/O	
		Actual state of open wire detection while OFF for DO1:0=OFF			
		Actual state of open wire detection while OFF for DO2:0=OFF			
		Actual state of open wire detection while OFF for DO3:0=OFF			
		Actual state of open wire detection while OFF for DO4:0=OFF			
		Actual state of open wire detection while OFF for DO5:0=OFF			
		Actual state of open wire detection while OFF for DO6:0=OFF			
		Actual state of open wire detection while OFF for DO7:0=OFF			
		Actual state of open wire detection while OFF for DO8:0=OFF			
		Actual state of open wire detection while OFF for DO9:1=ON			
		Actual state of open wire detection while OFF for DO10:1=ON			
		Actual state of open wire detection while OFF for DO11:1=ON			
		Actual state of open wire detection while OFF for DO12:1=ON			
		Actual state of open wire detection while OFF for DO13:1=ON			
		Actual state of open wire detection while OFF for DO14:1=ON			
		Actual state of open wire detection while OFF for DO15:1=ON			
Actual diagnostic state for open wire detection while OFF for digital output DOx Bit 0: =0:Output DO1 is OK, =1:Fault-Open wire detected on DO1 Bit 1: =0:Output DO2 is OK, =1:Fault-Open wire detected on DO2 ... Bit 13: =0:Output DO14 is OK, =1:Fault-Open wire detected on DO14 Bit 14: =0:Output DO15 is OK, =1:Fault-Open wire detected on DO15					
<b>DIGITAL OUTPUTS:SHORTCUT TO VDD WHILE OFF DETECTION STATE</b>					
SHORTCUT TO VDD WHILE OFF DETECTION STATE DO1-DO15	3x10009 4x10009 l:10008	0,0x0000 B:00 00		UINT16 R/O	
		Actual state of shortcut to VDD detection while OFF for DO1:0=OFF			
		Actual state of shortcut to VDD detection while OFF for DO2:0=OFF			

		Actual state of shortcut to VDD detection while OFF for DO3:0=OFF			
		Actual state of shortcut to VDD detection while OFF for DO4:0=OFF			
		Actual state of shortcut to VDD detection while OFF for DO5:0=OFF			
		Actual state of shortcut to VDD detection while OFF for DO6:0=OFF			
		Actual state of shortcut to VDD detection while OFF for DO7:0=OFF			
		Actual state of shortcut to VDD detection while OFF for DO8:0=OFF			
		Actual state of shortcut to VDD detection while OFF for DO9:0=OFF			
		Actual state of shortcut to VDD detection while OFF for DO10:0=OFF			
		Actual state of shortcut to VDD detection while OFF for DO11:0=OFF			
		Actual state of shortcut to VDD detection while OFF for DO12:0=OFF			
		Actual state of shortcut to VDD detection while OFF for DO13:0=OFF			
		Actual state of shortcut to VDD detection while OFF for DO14:0=OFF			
		Actual state of shortcut to VDD detection while OFF for DO15:0=OFF			

Actual diagnostic state for shortcut to VDD detection while OFF for digital output DOx

Bit 0: =0:Output DO1 is OK, =1:Fault-shortcut detected on DO1

Bit 1: =0:Output DO2 is OK, =1:Fault-shortcut detected on DO2

...

Bit 13: =0:Output DO14 is OK, =1:Fault-shortcut detected on DO14

Bit 14: =0:Output DO15 is OK, =1:Fault-shortcut detected on DO15

#### DIGITAL OUTPUTS:THERMAL OVERLOAD DETECTION STATE

THERMAL OVERLOAD DETECTION STATE DO1-DO15	3x10010 4x10010 1:10009	0,0x0000 B:00 00			UINT16 R/O
		Actual thermal overload detection state for DO1:0=OFF			
		Actual thermal overload detection state for DO2:0=OFF			
		Actual thermal overload detection state for DO3:0=OFF			
		Actual thermal overload detection state for DO4:0=OFF			
		Actual thermal overload detection state for DO5:0=OFF			

		Actual thermal overload detection state for DO6:0=OFF			
		Actual thermal overload detection state for DO7:0=OFF			
		Actual thermal overload detection state for DO8:0=OFF			
		Actual thermal overload detection state for DO9:0=OFF			
		Actual thermal overload detection state for DO10:0=OFF			
		Actual thermal overload detection state for DO11:0=OFF			
		Actual thermal overload detection state for DO12:0=OFF			
		Actual thermal overload detection state for DO13:0=OFF			
		Actual thermal overload detection state for DO14:0=OFF			
		Actual thermal overload detection state for DO15:0=OFF			

Actual thermal overload detection state for digital output DOx  
 Bit 0: =0:Output DO1 is OK, =1:Fault-Thermal overload on DO1  
 Bit 1: =0:Output DO2 is OK, =1:Fault-Thermal overload on DO2

...  
 Bit 13: =0:Output DO14 is OK, =1:Fault-Thermal overload on DO14  
 Bit 14: =0:Output DO15 is OK, =1:Fault-Thermal overload on DO15

#### DIGITAL OUTPUTS:CURRENT LIMIT DETECTION STATE

CURRENT LIMIT	3x10011	0,0x0000			UINT16
DETECTION STATE	4x10011	B:00 00			R/O
DO1-DO15	l:10010				
		Actual current limit detection state for DO1:0=OFF			
		Actual current limit detection state for DO2:0=OFF			
		Actual current limit detection state for DO3:0=OFF			
		Actual current limit detection state for DO4:0=OFF			
		Actual current limit detection state for DO5:0=OFF			
		Actual current limit detection state for DO6:0=OFF			
		Actual current limit detection state for DO7:0=OFF			
		Actual current limit detection state for DO8:0=OFF			

		Actual current limit detection state for DO9:0=OFF			
		Actual current limit detection state for DO10:0=OFF			
		Actual current limit detection state for DO11:0=OFF			
		Actual current limit detection state for DO12:0=OFF			
		Actual current limit detection state for DO13:0=OFF			
		Actual current limit detection state for DO14:0=OFF			
		Actual current limit detection state for DO15:0=OFF			

Actual current limit detection state for digital output DOx  
 Bit 0: =0:Output DO1 is OK, =1:Fault-Current limit on DO1  
 Bit 1: =0:Output DO2 is OK, =1:Fault-Current limit on DO2  
 ...  
 Bit 13: =0:Output DO14 is OK, =1:Fault-Current limit on DO14  
 Bit 14: =0:Output DO15 is OK, =1:Fault-Current limit on DO15

**DIGITAL OUTPUTS: GLOBAL ERRORS**

CHIP #1:DO1-DO8

CHIP #2:DO9-DO15

GLOBAL ERRORS FOR CHIP #1+#2	3x10012 4x10012 l:10011	0,0x0000 B:00 00		UINT16 R/O	
		BIT 0:CHIP#1:Internal under voltage detected:0=OK			
		BIT 1:CHIP#1:VA under voltage detected (<2.3V):0=OK			
		BIT 2:CHIP#1:VDD not good detected (<17V):0=OK			
		BIT 3:CHIP#1:VDD warning detected (<12V):0=OK			
		BIT 4:CHIP#1:VDD under voltage detected (<8V):0=OK			
		BIT 5:CHIP#1:Thermal shutdown:0=OK			
		BIT 6:CHIP#1:Synchronisation error detected:0=OK			
		BIT 7:CHIP#1:Watchdog error detected:0=OK			
		BIT 8:CHIP#2:Internal under voltage detected:0=OK			
		BIT 9:CHIP#2:VA under voltage detected (<2.3V):0=OK			
		BIT 10:CHIP#2:VDD not good detected (<17V):0=OK			
		BIT 11:CHIP#2:VDD warning detected (<12V):0=OK			
		BIT 12:CHIP#2:VDD under voltage detected (<8V):0=OK			
		BIT 13:CHIP#2:Thermal shutdown:0=OK			
		BIT 14:CHIP#2:Synchronisation error detected:0=OK			
		BIT 15:CHIP#2:Watchdog error detected:0=OK			

The global error state for the output group. Each bit stands for a different error  
 =0:No fault, =1:Fault

**DIGITAL OUTPUTS: INTERRUPT STATUS**

CHIP #1:DO1-DO8

CHIP #2:DO9-DO15

INTERRUPT STATUS FOR CHIP#1+#2	3x10013 4x10013 I:10012	1024,0xFFFF B:04 00			UINT16 R/O		
		BIT 0:CHIP#1:Overload detected:1=FAULT					
		BIT 1:CHIP#1:Current limit detected:1=FAULT					
		BIT 2:CHIP#1:Open wire while OFF detected:1=FAULT					
		BIT 3:CHIP#1:Open wire while ON detected:1=FAULT					
		BIT 4:CHIP#1:Shortcut to VDD detected:1=FAULT					
		BIT 5:CHIP#1:Thermal shutdown:1=FAULT					
		BIT 6:CHIP#1:Supply error detected:1=FAULT					
		BIT 7:CHIP#1:Communication error detected:1=FAULT					
		BIT 8:CHIP#2:Overload detected:1=FAULT					
		BIT 9:CHIP#2:Current limit detected:1=FAULT					
		BIT 10:CHIP#2:Open wire while OFF detected:1=FAULT					
		BIT 11:CHIP#2:Open wire while ON detected:1=FAULT					
		BIT 12:CHIP#2:Shortcut to VDD detected:1=FAULT					
		BIT 13:CHIP#2:Thermal shutdown:1=FAULT					
		BIT 14:CHIP#2:Supply error detected:1=FAULT					
		BIT 15:CHIP#2:Communication error detected:1=FAULT					

The interrupt state for the output group. Each bit stands for a different error  
=0:No fault, =1:Fault

#### SPI COMMUNICATION DIGITAL OUTPUTS

CHIP #1:DO1-DO8

CHIP #2:DO9-DO15

SPI COMMUNICATION DIGITAL OUTPUTS	#BEZUG!	0,0x0000 B:00 00			UINT16 R/O		
		Actual SPI communication state of CHIP#1:0=OK					
		Actual SPI communication state of CHIP#2:0=OK					

The current monitoring state of the SPI communication for the digital output group  
=0:No fault, =1:Fault

Current SPI communication state of all digital output groups  
Bit x: =0:CHIP x has no fault, =1:CHIP x SPI Fault

#### DIGITAL OUTPUTS: NUMBER OF CHIPSET

NUMBER OF DIGITAL OUTPUT CHIPS	3x10099 4x10099 I:10098	4,0x0004 B:00 04			UINT16 R/O		
		Actual number of installed DO CHIPS:4					

The actual number of used output chips

#### DIGITAL OUTPUTS: CHIPSET TYPE

DIGITAL OUTPUTS CHIPSET TYPE	3x10100 4x10100 I:10099	1,0x0001 B:00 01			UINT16 R/O		
		Actual chipset for DOs:1=MAX14915					

The current chipset for the digital outputs:  
=0: NCV7608  
=1: MAX14915

**STATUS OF DIGITAL OUTPUTS**

REAL STATUS OF ALL DOS DO1-DO15	3x10501 4x10501 I:10500	0,0x0000 B:00 00			UINT16 R/O	
		Real state of DO1:0=OFF				
		Real state of DO2:0=OFF				
		Real state of DO3:0=OFF				
		Real state of DO4:0=OFF				
		Real state of DO5:0=OFF				
		Real state of DO6:0=OFF				
		Real state of DO7:0=OFF				
		Real state of DO8:0=OFF				
		Real state of DO9:0=OFF				
		Real state of DO10:0=OFF				
		Real state of DO11:0=OFF				
		Real state of DO12:0=OFF				
		Real state of DO13:0=OFF				
		Real state of DO14:0=OFF				
		Real state of DO15:0=OFF				

Actual state of all digital outputs in the DO chips

Bit 0: =0:DO1 is OFF, =1:DO1 is ON

Bit 1: =0:DO2 is OFF, =1:DO2 is ON

...

Bit 13: =0:DO14 is OFF, =1:DO14 is ON

Bit 14: =0:DO15 is OFF, =1:DO15 is ON

Write on this register sets all digital outputs to a new state

**STATUS REAL DIGITAL INPUTS**

DI1	3x15001 4x15001 I:15000	0,0x0000 B:00			UINT16 R/O	
		Actual state of DI1:0=OFF				
Current state of the digital input DIx with the internal software filter to suppress glitches or spike on this line =0:DI is OFF, =1:DI is ON						
DI2	3x15002 4x15002 I:15001	1,0x0001 B:00			UINT16 R/O	
		Actual state of DI2:1=ON				
DI3	3x15003 4x15003 I:15002	2,0x0002 B:00			UINT16 R/O	
		Actual state of DI3:2=ON				
DI4	3x15004 4x15004 I:15003	3,0x0003 B:00			UINT16 R/O	
		Actual state of DI4:3=ON				



DI5	3x15005 4x15005 I:15004	4,0x0004 B:00			UINT16 R/O	
		Actual state of DI5:4=ON				
DI6	3x15006 4x15006 I:15005	5,0x0005 B:00			UINT16 R/O	
		Actual state of DI6:5=ON				
DI7	3x15007 4x15007 I:15006	6,0x0006 B:00			UINT16 R/O	
		Actual state of DI7:6=ON				
DI8	3x15008 4x15008 I:15007	7,0x0007 B:00			UINT16 R/O	
		Actual state of DI8:7=ON				
DI9	3x15009 4x15009 I:15008	0,0x0000 B:00			UINT16 R/O	
		Actual state of DI9:0=OFF				
DI10	3x15010 4x15010 I:15009	1,0x0001 B:00			UINT16 R/O	
		Actual state of DI10:1=ON				
DI11	3x15011 4x15011 I:15010	2,0x0002 B:00			UINT16 R/O	
		Actual state of DI11:2=ON				
DI12	3x15012 4x15012 I:15011	3,0x0003 B:00			UINT16 R/O	
		Actual state of DI12:3=ON				
DI13	3x15013 4x15013 I:15012	4,0x0004 B:00			UINT16 R/O	
		Actual state of DI13:4=ON				
DI14	3x15014 4x15014 I:15013	5,0x0005 B:00			UINT16 R/O	
		Actual state of DI14:5=ON				
DI15	3x15015 4x15015 I:15014	6,0x0006 B:00			UINT16 R/O	
		Actual state of DI15:6=ON				
DI16	3x15016 4x15016 I:15015	7,0x0007 B:00			UINT16 R/O	

		Actual state of DI16:7=ON				
<b>STATUS DIGITAL INPUTS</b>						
UNFILTERED DI1	3x15017 4x15017 I:15016	5,0x0005 B:00			UINT16 R/O	
		Actual state of UNFILTERED DI1:5=ON				
Current state of the real digital input DIx without the internal software filter to suppress glitches or spike on this line =0:DI is OFF, =1:DI is ON						
UNFILTERED DI2	3x15018 4x15018 I:15017	6,0x0006 B:00			UINT16 R/O	
		Actual state of UNFILTERED DI2:6=ON				
UNFILTERED DI3	3x15019 4x15019 I:15018	7,0x0007 B:00			UINT16 R/O	
		Actual state of UNFILTERED DI3:7=ON				
UNFILTERED DI4	3x15020 4x15020 I:15019	0,0x0000 B:00			UINT16 R/O	
		Actual state of UNFILTERED DI4:0=OFF				
UNFILTERED DI5	3x15021 4x15021 I:15020	1,0x0001 B:00			UINT16 R/O	
		Actual state of UNFILTERED DI5:1=ON				
UNFILTERED DI6	3x15022 4x15022 I:15021	2,0x0002 B:00			UINT16 R/O	
		Actual state of UNFILTERED DI6:2=ON				
UNFILTERED DI7	3x15023 4x15023 I:15022	0,0x0000 B:00			UINT16 R/O	
		Actual state of UNFILTERED DI7:0=OFF				
UNFILTERED DI8	3x15024 4x15024 I:15023	1,0x0001 B:00			UINT16 R/O	
		Actual state of UNFILTERED DI8:1=ON				
UNFILTERED DI9	3x15025 4x15025 I:15024	2,0x0002 B:00			UINT16 R/O	
		Actual state of UNFILTERED DI9:2=ON				
UNFILTERED DI10	3x15026 4x15026 I:15025	3,0x0003 B:00			UINT16 R/O	
		Actual state of UNFILTERED DI10:3=ON				
UNFILTERED DI11	3x15027 4x15027 I:15026	4,0x0004 B:00			UINT16 R/O	

		Actual state of UNFILTERED DI11:4=ON				
UNFILTERED DI12	3x15028 4x15028 I:15027	5,0x0005 B:00			UINT16 R/O	
		Actual state of UNFILTERED DI12:5=ON				
UNFILTERED DI13	3x15029 4x15029 I:15028	6,0x0006 B:00			UINT16 R/O	
		Actual state of UNFILTERED DI13:6=ON				
UNFILTERED DI14	3x15030 4x15030 I:15029	7,0x0007 B:00			UINT16 R/O	
		Actual state of UNFILTERED DI14:7=ON				
UNFILTERED DI15	3x15031 4x15031 I:15030	0,0x0000 B:00			UINT16 R/O	
		Actual state of UNFILTERED DI15:0=OFF				
UNFILTERED DI16	3x15032 4x15032 I:15031	1,0x0001 B:00			UINT16 R/O	
		Actual state of UNFILTERED DI16:1=ON				
<b>STATUS DIGITAL OUTPUTS</b>						
DO1	3x16001 4x16001 I:16000	0,0x0000 B:00 00		1	UINT16 R/W	NO
		Actual state of DO1:0=OFF		ENTER NEW STATE (0 or 1)		
Current state of the digital output DOx =0:DO is OFF, =1:DO is ON						
Writing on this register changes the state of the digital output						
DO2	3x16002 4x16002 I:16001	0,0x0000 B:00 00		0	UINT16 R/W	NO
		Actual state of DO2:0=OFF		ENTER NEW STATE (0 or 1)		
DO3	3x16003 4x16003 I:16002	0,0x0000 B:00 00		0	UINT16 R/W	NO
		Actual state of DO3:0=OFF		ENTER NEW STATE (0 or 1)		
DO4	3x16004 4x16004 I:16003	0,0x0000 B:00 00		0	UINT16 R/W	NO
		Actual state of DO4:0=OFF		ENTER NEW STATE (0 or 1)		
DO5	3x16005 4x16005 I:16004	0,0x0000 B:00 00		0	UINT16 R/W	NO
		Actual state of DO5:0=OFF		ENTER NEW STATE (0 or 1)		

DO6	3x16006 4x16006 I:16005	0,0x0000 B:00 00		0	UINT16 R/W	NO
		Actual state of DO6:0=OFF		ENTER NEW STATE (0 or 1)		
DO7	3x16007 4x16007 I:16006	0,0x0000 B:00 00		0	UINT16 R/W	NO
		Actual state of DO7:0=OFF		ENTER NEW STATE (0 or 1)		
DO8	3x16008 4x16008 I:16007	0,0x0000 B:00 00		0	UINT16 R/W	NO
		Actual state of DO8:0=OFF		ENTER NEW STATE (0 or 1)		
DO9	3x16009 4x16009 I:16008	0,0x0000 B:00 00		0	UINT16 R/W	NO
		Actual state of DO9:0=OFF		ENTER NEW STATE (0 or 1)		
DO10	3x16010 4x16010 I:16009	0,0x0000 B:00 00		0	UINT16 R/W	NO
		Actual state of DO10:0=OFF		ENTER NEW STATE (0 or 1)		
DO11	3x16011 4x16011 I:16010	0,0x0000 B:00 00		0	UINT16 R/W	NO
		Actual state of DO11:0=OFF		ENTER NEW STATE (0 or 1)		
DO12	3x16012 4x16012 I:16011	0,0x0000 B:00 00		0	UINT16 R/W	NO
		Actual state of DO12:0=OFF		ENTER NEW STATE (0 or 1)		
DO13	3x16013 4x16013 I:16012	0,0x0000 B:00 00		0	UINT16 R/W	NO
		Actual state of DO13:0=OFF		ENTER NEW STATE (0 or 1)		
DO14	3x16014 4x16014 I:16013	0,0x0000 B:00 00		0	UINT16 R/W	NO
		Actual state of DO14:0=OFF		ENTER NEW STATE (0 or 1)		
DO15	3x16015 4x16015 I:16014	0,0x0000 B:00 00		0	UINT16 R/W	NO
		Actual state of DO15:0=OFF		ENTER NEW STATE (0 or 1)		

Register NAME Command NAME	MODBUS Register ASCII Command	Register VALUE ASCII Command	NEW REAL VALUE	NEW VALUE	DATA TYPE	DO WRITE
<b>PULSE TIME FOR DIGITAL OUTPUTS</b>						
PULSE TIME DO1	3x20001 4x20001 I:20000	0,0x0000 B:00 00	200	20,0	UINT16 R/W	YES
Generate a pulse on digital output x in 100ms units (0,1 to 6553,5 Seconds selectable) If you write onto this register, the digital output will be switched on for the desired time in 100ms units.						
PULSE TIME DO2	3x20002 4x20002 I:20001	0,0x0000 B:00 00	300	30,0	UINT16 R/W	NO
PULSE TIME DO3	3x20003 4x20003 I:20002	0,0x0000 B:00 00	400	40,0	UINT16 R/W	NO
PULSE TIME DO4	3x20004 4x20004 I:20003	0,0x0000 B:00 00	500	50,0	UINT16 R/W	NO
PULSE TIME DO5	3x20005 4x20005 I:20004	0,0x0000 B:00 00	20	2,0	UINT16 R/W	NO
PULSE TIME DO6	3x20006 4x20006 I:20005	0,0x0000 B:00 00	20	2,0	UINT16 R/W	NO
PULSE TIME DO7	3x20007 4x20007 I:20006	0,0x0000 B:00 00	20	2,0	UINT16 R/W	NO
PULSE TIME DO8	3x20008 4x20008 I:20007	0,0x0000 B:00 00	20	2,0	UINT16 R/W	NO
PULSE TIME DO9	3x20009 4x20009 I:20008	0,0x0000 B:00 00	20	2,0	UINT16 R/W	NO
PULSE TIME DO10	3x20010 4x20010 I:20009	0,0x0000 B:00 00	20	2,0	UINT16 R/W	NO
PULSE TIME DO11	3x20011 4x20011 I:20010	0,0x0000 B:00 00	20	2,0	UINT16 R/W	NO
PULSE TIME DO12	3x20012 4x20012 I:20011	0,0x0000 B:00 00	20	2,0	UINT16 R/W	NO

PULSE TIME DO13	3x20013 4x20013 I:20012	0,0x0000 B:00 00	400	40,0	UINT16 R/W	NO
PULSE TIME DO14	3x20014 4x20014 I:20013	0,0x0000 B:00 00	500	50,0	UINT16 R/W	NO
PULSE TIME DO15	3x20015 4x20015 I:20014	0,0x0000 B:00 00	20	2,0	UINT16 R/W	NO
<b>PULSE STATUS FOR DIGITAL OUTPUTS</b>						
PULSE TIMER DO1	3x21001 4x21001 I:21000	0,0x00000000 B:00 00 00 00			UINT32 R/O	
		0,0 seconds				
Remaining time of the pulse on digital output x in Milliseconds.						
PULSE TIMER DO2	3x21003 4x21003 I:21002	0,0x00000000 B:00 00 00 00			UINT32 R/O	
		0,0 seconds				
PULSE TIMER DO3	3x21005 4x21005 I:21004	0,0x00000000 B:00 00 00 00			UINT32 R/O	
		0,0 seconds				
PULSE TIMER DO4	3x21007 4x21007 I:21006	0,0x00000000 B:00 00 00 00			UINT32 R/O	
		0,0 seconds				
PULSE TIMER DO5	3x21009 4x21009 I:21008	0,0x00000000 B:00 00 00 00			UINT32 R/O	
		0,0 seconds				
PULSE TIMER DO6	3x21011 4x21011 I:21010	0,0x00000000 B:00 00 00 00			UINT32 R/O	
		0,0 seconds				
PULSE TIMER DO7	3x21013 4x21013 I:21012	0,0x00000000 B:00 00 00 00			UINT32 R/O	
		0,0 seconds				
PULSE TIMER DO8	3x21015 4x21015 I:21014	0,0x00000000 B:00 00 00 00			UINT32 R/O	
		0,0 seconds				
PULSE TIMER DO9	3x21017 4x21017 I:21016	0,0x00000000 B:00 00 00 00			UINT32 R/O	

		0,0 seconds				
PULSE TIMER DO10	3x21019 4x21019 I:21018	0,0x00000000 B:00 00 00 00			UINT32 R/O	
		0,0 seconds				
PULSE TIMER DO11	3x21021 4x21021 I:21020	0,0x00000000 B:00 00 00 00			UINT32 R/O	
		0,0 seconds				
PULSE TIMER DO12	3x21023 4x21023 I:21022	0,0x00000000 B:00 00 00 00			UINT32 R/O	
		0,0 seconds				
PULSE TIMER DO13	3x21025 4x21025 I:21024	0,0x00000000 B:00 00 00 00			UINT32 R/O	
		0,0 seconds				
PULSE TIMER DO14	3x21027 4x21027 I:21026	0,0x00000000 B:00 00 00 00			UINT32 R/O	
		0,0 seconds				
PULSE TIMER DO15	3x21029 4x21029 I:21028	0,0x00000000 B:00 00 00 00			UINT32 R/O	
		0,0 seconds				
<b>PULSE STATUS FOR DIGITAL OUTPUTS</b>						
PULSE TIMER DO1	3x21031 4x21031 I:21030	0,0x00000000 B:00 00 00 00			UINT32R R/O	
		0,0 seconds				
Remaining time of the pulse on digital output x in Milliseconds.						
PULSE TIMER DO2	3x21033 4x21033 I:21032	0,0x00000000 B:00 00 00 00			UINT32R R/O	
		0,0 seconds				
PULSE TIMER DO3	3x21035 4x21035 I:21034	0,0x00000000 B:00 00 00 00			UINT32R R/O	
		0,0 seconds				
PULSE TIMER DO4	3x21037 4x21037 I:21036	0,0x00000000 B:00 00 00 00			UINT32R R/O	
		0,0 seconds				

PULSE TIMER DO5	3x21039 4x21039 I:21038	0,0x00000000 B:00 00 00 00			UINT32R R/O	
		0,0 seconds				
PULSE TIMER DO6	3x21041 4x21041 I:21040	0,0x00000000 B:00 00 00 00			UINT32R R/O	
		0,0 seconds				
PULSE TIMER DO7	3x21043 4x21043 I:21042	0,0x00000000 B:00 00 00 00			UINT32R R/O	
		0,0 seconds				
PULSE TIMER DO8	3x21045 4x21045 I:21044	0,0x00000000 B:00 00 00 00			UINT32R R/O	
		0,0 seconds				
PULSE TIMER DO9	3x21047 4x21047 I:21046	0,0x00000000 B:00 00 00 00			UINT32R R/O	
		0,0 seconds				
PULSE TIMER DO10	3x21049 4x21049 I:21048	0,0x00000000 B:00 00 00 00			UINT32R R/O	
		0,0 seconds				
PULSE TIMER DO11	3x21051 4x21051 I:21050	0,0x00000000 B:00 00 00 00			UINT32R R/O	
		0,0 seconds				
PULSE TIMER DO12	3x21053 4x21053 I:21052	0,0x00000000 B:00 00 00 00			UINT32R R/O	
		0,0 seconds				
PULSE TIMER DO13	3x21055 4x21055 I:21054	0,0x00000000 B:00 00 00 00			UINT32R R/O	
		0,0 seconds				
PULSE TIMER DO14	3x21057 4x21057 I:21056	0,0x00000000 B:00 00 00 00			UINT32R R/O	
		0,0 seconds				
PULSE TIMER DO15	3x21059 4x21059 I:21058	0,0x00000000 B:00 00 00 00			UINT32R R/O	
		0,0 seconds				



Register NAME Command NAME	MODBUS Register ASCII Command	Register VALUE ASCII Command	NEW REAL VALUE	NEW VALUE	DATA TYPE	DO WRITE
<b>DIGITAL INPUTS</b>						
STATUS DI1 A	3x05001 4x05001 I:5000	0,0x0000 B:00 00			UINT16 R/O	
		DI:0,CC:0,REC:0,FEC:0				
Status for the digital input DIx Bit 0-4: Lower 5 bits of CHANGE COUNTER Bit 5-9: Lower 5 bits of RISING EDGE COUNTER Bit 10-14: Lower 5 bits of FALLING EDGE COUNTER Bit 15: Current Status of DIx =0: DIx si OFF, =1: DIx is ON						
STATUS DI1 B	3x05002 4x05002 I:5001	0,0x0000 B:00 00			UINT16 R/O	
		DI:0,SKE:0,LKSE:0,LKEE:0				
Status for the digital input DIx Bit 0-4: Lower 5 bits of SHORT KEYPRESS EVENTS Bit 5-9: Lower 5 bits of LONG KEYPRESS START EVENTS Bit 10-14: Lower 5 bits of LONG KEYPRESS END EVENTS Bit 15: Current Status of DIx =0: DIx si OFF, =1: DIx is ON						
STATUS DI2 A	3x05003 4x05003 I:5002	0,0x0000 B:00 00			UINT16 R/O	
		DI:0,CC:0,REC:0,FEC:0				
STATUS DI2 B	3x05004 4x05004 I:5003	0,0x0000 B:00 00			UINT16 R/O	
		DI:0,SKE:0,LKSE:0,LKEE:0				
STATUS DI3 A	3x05005 4x05005 I:5004	0,0x0000 B:00 00			UINT16 R/O	
		DI:0,CC:0,REC:0,FEC:0				
STATUS DI3 B	3x05006 4x05006 I:5005	0,0x0000 B:00 00			UINT16 R/O	
		DI:0,SKE:0,LKSE:0,LKEE:0				
STATUS DI4 A	3x05007 4x05007 I:5006	0,0x0000 B:00 00			UINT16 R/O	
		DI:0,CC:0,REC:0,FEC:0				
STATUS DI4 B	3x05008 4x05008 I:5007	0,0x0000 B:00 00			UINT16 R/O	

		DI:0,SKE:0,LKSE:0,LKEE:0			
STATUS DI5 A	3x05009 4x05009 I:5008	0,0x0000 B:00 00			UINT16 R/O
		DI:0,CC:0,REC:0,FEC:0			
STATUS DI5 B	3x05010 4x05010 I:5009	0,0x0000 B:00 00			UINT16 R/O
		DI:0,SKE:0,LKSE:0,LKEE:0			
STATUS DI6 A	3x05011 4x05011 I:5010	0,0x0000 B:00 00			UINT16 R/O
		DI:0,CC:0,REC:0,FEC:0			
STATUS DI6 B	3x05012 4x05012 I:5011	0,0x0000 B:00 00			UINT16 R/O
		DI:0,SKE:0,LKSE:0,LKEE:0			
STATUS DI7 A	3x05013 4x05013 I:5012	0,0x0000 B:00 00			UINT16 R/O
		DI:0,CC:0,REC:0,FEC:0			
STATUS DI7 B	3x05014 4x05014 I:5013	0,0x0000 B:00 00			UINT16 R/O
		DI:0,SKE:0,LKSE:0,LKEE:0			
STATUS DI8 A	3x05015 4x05015 I:5014	0,0x0000 B:00 00			UINT16 R/O
		DI:0,CC:0,REC:0,FEC:0			
STATUS DI8 B	3x05016 4x05016 I:5015	0,0x0000 B:00 00			UINT16 R/O
		DI:0,SKE:0,LKSE:0,LKEE:0			
STATUS DI9 A	3x05017 4x05017 I:5016	0,0x0000 B:00 00			UINT16 R/O
		DI:0,CC:0,REC:0,FEC:0			
STATUS DI9 B	3x05018 4x05018 I:5017	0,0x0000 B:00 00			UINT16 R/O
		DI:0,SKE:0,LKSE:0,LKEE:0			
STATUS DI10 A	3x05019 4x05019 I:5018	0,0x0000 B:00 00			UINT16 R/O
		DI:0,CC:0,REC:0,FEC:0			

STATUS DI10 B	3x05020 4x05020 I:5019	0,0x0000 B:00 00			UINT16 R/O	
		DI:0,SKE:0,LKSE:0,LKEE:0				
STATUS DI11 A	3x05021 4x05021 I:5020	0,0x0000 B:00 00			UINT16 R/O	
		DI:0,CC:0,REC:0,FEC:0				
STATUS DI11 B	3x05022 4x05022 I:5021	0,0x0000 B:00 00			UINT16 R/O	
		DI:0,SKE:0,LKSE:0,LKEE:0				
STATUS DI12 A	3x05023 4x05023 I:5022	0,0x0000 B:00 00			UINT16 R/O	
		DI:0,CC:0,REC:0,FEC:0				
STATUS DI12 B	3x05024 4x05024 I:5023	0,0x0000 B:00 00			UINT16 R/O	
		DI:0,SKE:0,LKSE:0,LKEE:0				
STATUS DI13 A	3x05025 4x05025 I:5024	0,0x0000 B:00 00			UINT16 R/O	
		DI:0,CC:0,REC:0,FEC:0				
STATUS DI13 B	3x05026 4x05026 I:5025	0,0x0000 B:00 00			UINT16 R/O	
		DI:0,SKE:0,LKSE:0,LKEE:0				
STATUS DI14 A	3x05027 4x05027 I:5026	0,0x0000 B:00 00			UINT16 R/O	
		DI:0,CC:0,REC:0,FEC:0				
STATUS DI14 B	3x05028 4x05028 I:5027	0,0x0000 B:00 00			UINT16 R/O	
		DI:0,SKE:0,LKSE:0,LKEE:0				
STATUS DI15 A	3x05029 4x05029 I:5028	0,0x0000 B:00 00			UINT16 R/O	
		DI:0,CC:0,REC:0,FEC:0				
STATUS DI15 B	3x05030 4x05030 I:5029	0,0x0000 B:00 00			UINT16 R/O	
		DI:0,SKE:0,LKSE:0,LKEE:0				

STATUS DI16 A	3x05031 4x05031 I:5030	0,0x0000 B:00 00			UINT16 R/O	
		DI:0,CC:0,REC:0,FEC:0				
STATUS DI16 B	3x05032 4x05032 I:5031	0,0x0000 B:00 00			UINT16 R/O	
		DI:0,SKE:0,LKSE:0,LKEE:0				
<b>STATUS</b>						
FILTER PATTERN DI1	3x05033 4x05033 I:5032	0,0x00000000 B:00 00 00 00			UINT32 R/O	
The internal pattern for corresponding digital input for AC/DC filtering. The internal used state is created out of this internal pattern via oversampling.						
FILTER PATTERN DI2	3x05035 4x05035 I:5034	0,0x00000000 B:00 00 00 00			UINT32 R/O	
FILTER PATTERN DI3	3x05037 4x05037 I:5036	0,0x00000000 B:00 00 00 00			UINT32 R/O	
FILTER PATTERN DI4	3x05039 4x05039 I:5038	0,0x00000000 B:00 00 00 00			UINT32 R/O	
FILTER PATTERN DI5	3x05041 4x05041 I:5040	0,0x00000000 B:00 00 00 00			UINT32 R/O	
FILTER PATTERN DI6	3x05043 4x05043 I:5042	0,0x00000000 B:00 00 00 00			UINT32 R/O	
FILTER PATTERN DI7	3x05045 4x05045 I:5044	0,0x00000000 B:00 00 00 00			UINT32 R/O	
FILTER PATTERN DI8	3x05047 4x05047 I:5046	0,0x00000000 B:00 00 00 00			UINT32 R/O	
FILTER PATTERN DI9	3x05049 4x05049 I:5048	0,0x00000000 B:00 00 00 00			UINT32 R/O	
FILTER PATTERN DI10	3x05051 4x05051 I:5050	0,0x00000000 B:00 00 00 00			UINT32 R/O	
FILTER PATTERN DI11	3x05053 4x05053 I:5052	0,0x00000000 B:00 00 00 00			UINT32 R/O	
FILTER PATTERN DI12	3x05055 4x05055 I:5054	0,0x00000000 B:00 00 00 00			UINT32 R/O	

FILTER PATTERN DI13	3x05057 4x05057 I:5056	0,0x00000000 B:00 00 00 00			UINT32 R/O	
FILTER PATTERN DI14	3x05059 4x05059 I:5058	0,0x00000000 B:00 00 00 00			UINT32 R/O	
FILTER PATTERN DI15	3x05061 4x05061 I:5060	0,0x00000000 B:00 00 00 00			UINT32 R/O	
FILTER PATTERN DI16	3x05063 4x05063 I:5062	0,0x00000000 B:00 00 00 00			UINT32 R/O	
<b>DIGITAL INPUTS: STATUS FOR DIGITAL INPUT DI1</b>						
RISE DI1	3x07001 4x07001 I:7000	3,0x0003 B:00 03			UINT16 R/O	
		3 event(s)				
Counter for rising edges on the digital input DIx. If the module detects a rising edge on the digital input, this counter is incremented by 1. After power on or a soft reset this counter is set always to 0. With the function RESET COUNTER this counter is also set to 0.						
FALL DI1	3x07002 4x07002 I:7001	3,0x0003 B:00 03			UINT16 R/O	
		3 event(s)				
Counter for falling edges on the digital input DIx. If the module detects a falling edge on the digital input, this counter is incremented by 1. After power on or a soft reset this counter is set always to 0. With the function RESET COUNTER this counter is also set to 0.						
CHANGE DI1	3x07003 4x07003 I:7002	4,0x0004 B:00 04			UINT16 R/O	
		4 event(s)				
Counter for events on the digital input DIx. If the module detects an event on the digital input, this counter is incremented by 1. After power on or a soft reset this counter is set always to 0. With the function RESET COUNTER this counter is also set to 0. The following events are available: Detection of a short keypress Detection of the start of a long keypress Detection of the end of a long keypress						
SHORT KEYPRESS DI1	3x07004 4x07004 I:7003	2,0x0002 B:00 02			UINT16 R/O	
		2 event(s)				
Counter for short keypress events on the digital input DIx. If the module detects a short keypress on the digital input, this counter is incremented by 1. After power on or a soft reset this counter is set always to 0. With the function RESET COUNTER this counter is also set to 0.						
LONG KEYPRESS START DI1	3x07005 4x07005 I:7004	1,0x0001 B:00 01			UINT16 R/O	
		1 event(s)				

Counter for start events of long keypress actions on the digital input DIx. If the module detects the start of a long keypress action on the digital input, this counter is incremented by 1.

After power on or a soft reset this counter is set always to 0.

With the function RESET COUNTER this counter is also set to 0.

LONG KEYPRESS END DI1	3x07006 4x07006 I:7005	1,0x0001 B:00 01			UINT16 R/O	
		1 event(s)				

Counter for end events of long keypress actions on the digital input DIx. If the module detects the end of a long keypress action on the digital input, this counter is incremented by 1.

After power on or a soft reset this counter is set always to 0.

With the function RESET COUNTER this counter is also set to 0.

#### DIGITAL INPUTS: STATUS FOR DIGITAL INPUT DI2

RISE DI2	3x07011 4x07011 I:7010	4,0x0004 B:00 04			UINT16 R/O	
		4 event(s)				
FALL DI2	3x07012 4x07012 I:7011	4,0x0004 B:00 04			UINT16 R/O	
		4 event(s)				
CHANGE DI2	3x07013 4x07013 I:7012	6,0x0006 B:00 06			UINT16 R/O	
		6 event(s)				
SHORT KEYPRESS DI2	3x07014 4x07014 I:7013	2,0x0002 B:00 02			UINT16 R/O	
		2 event(s)				
LONG KEYPRESS START DI2	3x07015 4x07015 I:7014	2,0x0002 B:00 02			UINT16 R/O	
		2 event(s)				
LONG KEYPRESS END DI2	3x07016 4x07016 I:7015	2,0x0002 B:00 02			UINT16 R/O	
		2 event(s)				

#### DIGITAL INPUTS: STATUS FOR DIGITAL INPUT DI3

RISE DI3	3x07021 4x07021 I:7020	4,0x0004 B:00 04			UINT16 R/O	
		4 event(s)				
FALL DI3	3x07022 4x07022 I:7021	4,0x0004 B:00 04			UINT16 R/O	
		4 event(s)				

CHANGE DI3	3x07023 4x07023 I:7022	6,0x0006 B:00 06			UINT16 R/O	
		6 event(s)				
SHORT KEYPRESS DI3	3x07024 4x07024 I:7023	2,0x0002 B:00 02			UINT16 R/O	
		2 event(s)				
LONG KEYPRESS START DI3	3x07025 4x07025 I:7024	2,0x0002 B:00 02			UINT16 R/O	
		2 event(s)				
LONG KEYPRESS END DI3	3x07026 4x07026 I:7025	2,0x0002 B:00 02			UINT16 R/O	
		2 event(s)				
<b>DIGITAL INPUTS: STATUS FOR DIGITAL INPUT DI4</b>						
RISE DI4	3x07031 4x07031 I:7030	4,0x0004 B:00 04			UINT16 R/O	
		4 event(s)				
FALL DI4	3x07032 4x07032 I:7031	4,0x0004 B:00 04			UINT16 R/O	
		4 event(s)				
CHANGE DI4	3x07033 4x07033 I:7032	6,0x0006 B:00 06			UINT16 R/O	
		6 event(s)				
SHORT KEYPRESS DI4	3x07034 4x07034 I:7033	2,0x0002 B:00 02			UINT16 R/O	
		2 event(s)				
LONG KEYPRESS START DI4	3x07035 4x07035 I:7034	2,0x0002 B:00 02			UINT16 R/O	
		2 event(s)				
LONG KEYPRESS END DI4	3x07036 4x07036 I:7035	2,0x0002 B:00 02			UINT16 R/O	
		2 event(s)				
<b>DIGITAL INPUTS: STATUS FOR DIGITAL INPUT DI5</b>						
RISE DI5	3x07041 4x07041 I:7040	4,0x0004 B:00 04			UINT16 R/O	

		4 event(s)				
FALL DI5	3x07042 4x07042 I:7041	4,0x0004 B:00 04			UINT16 R/O	
		4 event(s)				
CHANGE DI5	3x07043 4x07043 I:7042	6,0x0006 B:00 06			UINT16 R/O	
		6 event(s)				
SHORT KEYPRESS DI5	3x07044 4x07044 I:7043	2,0x0002 B:00 02			UINT16 R/O	
		2 event(s)				
LONG KEYPRESS START DI5	3x07045 4x07045 I:7044	2,0x0002 B:00 02			UINT16 R/O	
		2 event(s)				
LONG KEYPRESS END DI5	3x07046 4x07046 I:7045	2,0x0002 B:00 02			UINT16 R/O	
		2 event(s)				
<b>DIGITAL INPUTS: STATUS FOR DIGITAL INPUT DI6</b>						
RISE DI6	3x07051 4x07051 I:7050	4,0x0004 B:00 04			UINT16 R/O	
		4 event(s)				
FALL DI6	3x07052 4x07052 I:7051	4,0x0004 B:00 04			UINT16 R/O	
		4 event(s)				
CHANGE DI6	3x07053 4x07053 I:7052	6,0x0006 B:00 06			UINT16 R/O	
		6 event(s)				
SHORT KEYPRESS DI6	3x07054 4x07054 I:7053	2,0x0002 B:00 02			UINT16 R/O	
		2 event(s)				
LONG KEYPRESS START DI6	3x07055 4x07055 I:7054	2,0x0002 B:00 02			UINT16 R/O	
		2 event(s)				
LONG KEYPRESS END DI6	3x07056 4x07056 I:7055	2,0x0002 B:00 02			UINT16 R/O	



		2 event(s)			
<b>DIGITAL INPUTS: STATUS FOR DIGITAL INPUT DI7</b>					
RISE DI7	3x07061 4x07061 I:7060	4,0x0004 B:00 04			UINT16 R/O
		4 event(s)			
FALL DI7	3x07062 4x07062 I:7061	4,0x0004 B:00 04			UINT16 R/O
		4 event(s)			
CHANGE DI7	3x07063 4x07063 I:7062	6,0x0006 B:00 06			UINT16 R/O
		6 event(s)			
SHORT KEYPRESS DI7	3x07064 4x07064 I:7063	2,0x0002 B:00 02			UINT16 R/O
		2 event(s)			
LONG KEYPRESS START DI7	3x07065 4x07065 I:7064	2,0x0002 B:00 02			UINT16 R/O
		2 event(s)			
LONG KEYPRESS END DI7	3x07066 4x07066 I:7065	2,0x0002 B:00 02			UINT16 R/O
		2 event(s)			
<b>DIGITAL INPUTS: STATUS FOR DIGITAL INPUT DI8</b>					
RISE DI8	3x07071 4x07071 I:7070	4,0x0004 B:00 04			UINT16 R/O
		4 event(s)			
FALL DI8	3x07072 4x07072 I:7071	4,0x0004 B:00 04			UINT16 R/O
		4 event(s)			
CHANGE DI8	3x07073 4x07073 I:7072	6,0x0006 B:00 06			UINT16 R/O
		6 event(s)			
SHORT KEYPRESS DI8	3x07074 4x07074 I:7073	2,0x0002 B:00 02			UINT16 R/O
		2 event(s)			
LONG KEYPRESS START DI8	3x07075 4x07075 I:7074	2,0x0002 B:00 02			UINT16 R/O

		2 event(s)				
LONG KEYPRESS END DI8	3x07076 4x07076 I:7075	2,0x0002 B:00 02			UINT16 R/O	
		2 event(s)				
<b>DIGITAL INPUTS: STATUS FOR DIGITAL INPUT DI9</b>						
RISE DI9	3x07081 4x07081 I:7080	4,0x0004 B:00 04			UINT16 R/O	
		4 event(s)				
FALL DI9	3x07082 4x07082 I:7081	4,0x0004 B:00 04			UINT16 R/O	
		4 event(s)				
CHANGE DI9	3x07083 4x07083 I:7082	6,0x0006 B:00 06			UINT16 R/O	
		6 event(s)				
SHORT KEYPRESS DI9	3x07084 4x07084 I:7083	2,0x0002 B:00 02			UINT16 R/O	
		2 event(s)				
LONG KEYPRESS START DI9	3x07085 4x07085 I:7084	2,0x0002 B:00 02			UINT16 R/O	
		2 event(s)				
LONG KEYPRESS END DI9	3x07086 4x07086 I:7085	2,0x0002 B:00 02			UINT16 R/O	
		2 event(s)				
<b>DIGITAL INPUTS: STATUS FOR DIGITAL INPUT DI10</b>						
RISE DI10	3x07091 4x07091 I:7090	4,0x0004 B:00 04			UINT16 R/O	
		4 event(s)				
FALL DI10	3x07092 4x07092 I:7091	4,0x0004 B:00 04			UINT16 R/O	
		4 event(s)				
CHANGE DI10	3x07093 4x07093 I:7092	6,0x0006 B:00 06			UINT16 R/O	
		6 event(s)				
SHORT KEYPRESS DI10	3x07094 4x07094 I:7093	2,0x0002 B:00 02			UINT16 R/O	

		2 event(s)				
LONG KEYPRESS START DI10	3x07095 4x07095 I:7094	2,0x0002 B:00 02			UINT16 R/O	
		2 event(s)				
LONG KEYPRESS END DI10	3x07096 4x07096 I:7095	2,0x0002 B:00 02			UINT16 R/O	
		2 event(s)				
<b>DIGITAL INPUTS: STATUS FOR DIGITAL INPUT DI11</b>						
RISE DI11	3x07101 4x07101 I:7100	4,0x0004 B:00 04			UINT16 R/O	
		4 event(s)				
FALL DI11	3x07102 4x07102 I:7101	4,0x0004 B:00 04			UINT16 R/O	
		4 event(s)				
CHANGE DI11	3x07103 4x07103 I:7102	6,0x0006 B:00 06			UINT16 R/O	
		6 event(s)				
SHORT KEYPRESS DI11	3x07104 4x07104 I:7103	2,0x0002 B:00 02			UINT16 R/O	
		2 event(s)				
LONG KEYPRESS START DI11	3x07105 4x07105 I:7104	2,0x0002 B:00 02			UINT16 R/O	
		2 event(s)				
LONG KEYPRESS END DI11	3x07106 4x07106 I:7105	2,0x0002 B:00 02			UINT16 R/O	
		2 event(s)				
<b>DIGITAL INPUTS: STATUS FOR DIGITAL INPUT DI12</b>						
RISE DI12	3x07111 4x07111 I:7110	4,0x0004 B:00 04			UINT16 R/O	
		4 event(s)				
FALL DI12	3x07112 4x07112 I:7111	4,0x0004 B:00 04			UINT16 R/O	
		4 event(s)				
CHANGE DI12	3x07113 4x07113 I:7112	6,0x0006 B:00 06			UINT16 R/O	

		6 event(s)				
SHORT KEYPRESS DI12	3x07114 4x07114 I:7113	2,0x0002 B:00 02			UINT16 R/O	
		2 event(s)				
LONG KEYPRESS START DI12	3x07115 4x07115 I:7114	2,0x0002 B:00 02			UINT16 R/O	
		2 event(s)				
LONG KEYPRESS END DI12	3x07116 4x07116 I:7115	2,0x0002 B:00 02			UINT16 R/O	
		2 event(s)				
<b>DIGITAL INPUTS: STATUS FOR DIGITAL INPUT DI13</b>						
RISE DI13	3x07121 4x07121 I:7120	4,0x0004 B:00 04			UINT16 R/O	
		4 event(s)				
FALL DI13	3x07122 4x07122 I:7121	4,0x0004 B:00 04			UINT16 R/O	
		4 event(s)				
CHANGE DI13	3x07123 4x07123 I:7122	6,0x0006 B:00 06			UINT16 R/O	
		6 event(s)				
SHORT KEYPRESS DI13	3x07124 4x07124 I:7123	2,0x0002 B:00 02			UINT16 R/O	
		2 event(s)				
LONG KEYPRESS START DI13	3x07125 4x07125 I:7124	2,0x0002 B:00 02			UINT16 R/O	
		2 event(s)				
LONG KEYPRESS END DI13	3x07126 4x07126 I:7125	2,0x0002 B:00 02			UINT16 R/O	
		2 event(s)				
<b>DIGITAL INPUTS: STATUS FOR DIGITAL INPUT DI14</b>						
RISE DI14	3x07131 4x07131 I:7130	4,0x0004 B:00 04			UINT16 R/O	
		4 event(s)				
FALL DI14	3x07132 4x07132 I:7131	4,0x0004 B:00 04			UINT16 R/O	

		4 event(s)				
CHANGE DI14	3x07133 4x07133 I:7132	6,0x0006 B:00 06			UINT16 R/O	
		6 event(s)				
SHORT KEYPRESS DI14	3x07134 4x07134 I:7133	2,0x0002 B:00 02			UINT16 R/O	
		2 event(s)				
LONG KEYPRESS START DI14	3x07135 4x07135 I:7134	2,0x0002 B:00 02			UINT16 R/O	
		2 event(s)				
LONG KEYPRESS END DI14	3x07136 4x07136 I:7135	2,0x0002 B:00 02			UINT16 R/O	
		2 event(s)				
<b>DIGITAL INPUTS: STATUS FOR DIGITAL INPUT DI15</b>						
RISE DI15	3x07141 4x07141 I:7140	4,0x0004 B:00 04			UINT16 R/O	
		4 event(s)				
FALL DI15	3x07142 4x07142 I:7141	4,0x0004 B:00 04			UINT16 R/O	
		4 event(s)				
CHANGE DI15	3x07143 4x07143 I:7142	6,0x0006 B:00 06			UINT16 R/O	
		6 event(s)				
SHORT KEYPRESS DI15	3x07144 4x07144 I:7143	2,0x0002 B:00 02			UINT16 R/O	
		2 event(s)				
LONG KEYPRESS START DI15	3x07145 4x07145 I:7144	2,0x0002 B:00 02			UINT16 R/O	
		2 event(s)				
LONG KEYPRESS END DI15	3x07146 4x07146 I:7145	2,0x0002 B:00 02			UINT16 R/O	
		2 event(s)				
<b>DIGITAL INPUTS: STATUS FOR DIGITAL INPUT DI16</b>						
RISE DI16	3x07151 4x07151 I:7150	4,0x0004 B:00 04			UINT16 R/O	

		4 event(s)				
FALL DI16	3x07152 4x07152 I:7151	4,0x0004 B:00 04			UINT16 R/O	
		4 event(s)				
CHANGE DI16	3x07153 4x07153 I:7152	6,0x0006 B:00 06			UINT16 R/O	
		6 event(s)				
SHORT KEYPRESS DI16	3x07154 4x07154 I:7153	2,0x0002 B:00 02			UINT16 R/O	
		2 event(s)				
LONG KEYPRESS START DI16	3x07155 4x07155 I:7154	2,0x0002 B:00 02			UINT16 R/O	
		2 event(s)				
LONG KEYPRESS END DI16	3x07156 4x07156 I:7155	2,0x0002 B:00 02			UINT16 R/O	
		2 event(s)				

Register NAME Command NAME	MODBUS Register ASCII Command	Register VALUE ASCII Command	NEW REAL VALUE	NEW VALUE	DATA TYPE	DO WRITE
<b>INITIAL &amp; WATCHDOG STATUS FOR ALL DIGITAL OUTPUTS</b>						
FRAM INTIAL & WATCHDOG STATUS OF DO1-DO15	3x59001 4x59001 l:59000	????		0x7FFF	UINT16 R/W	NO
		Actual init & watchdog state of DO1:0=OFF	1			
		Actual init & watchdog state of DO2:0=OFF	1			
		Actual init & watchdog state of DO3:0=OFF	1			
		Actual init & watchdog state of DO4:0=OFF	1			
		Actual init & watchdog state of DO5:0=OFF	1			
		Actual init & watchdog state of DO6:0=OFF	1			
		Actual init & watchdog state of DO7:0=OFF	1			
		Actual init & watchdog state of DO8:0=OFF	1			
		Actual init & watchdog state of DO9:0=OFF	1			
		Actual init & watchdog state of DO10:0=OFF	1			
		Actual init & watchdog state of DO11:0=OFF	1			
		Actual init & watchdog state of DO12:0=OFF	1			
		Actual init & watchdog state of DO13:0=OFF	1			
		Actual init & watchdog state of DO14:0=OFF	1			
		Actual init & watchdog state of DO15:0=OFF	1			
Current FRAM setting of initial and watchdog state of all digital outputs. This state is used after power on and after a communication watchdog timeout, if a watchdog time is configured Bit 0: =0:DO1 is OFF, =1:DO1 is ON Bit 1: =0:DO2 is OFF, =1:DO2 is ON ... Bit 13: =0:DO14 is OFF, =1:DO14 is ON Bit 14: =0:DO15 is OFF, =1:DO15 is ON						
Write on this register sets all digital outputs to a new state for module restart and watchdog function. The state is saved in FRAM						
<b>DIGITAL OUTPUTS:ENABLE OPEN WIRE DETECTION WHILE ON</b>						
INITIAL & WATCHDOG SETUP ENABLE OPEN WIRE DETECTION WHILE ON DO1-DO15	3x59002 4x59002 l:59001	????		0x7FFF	UINT16 R/W	NO
		Initial setup of open wire detection while ON for DO1:0=DISABLED	1			
		Initial setup of open wire detection while ON for DO2:0=DISABLED	1			
		Initial setup of open wire detection while ON for DO3:0=DISABLED	1			
		Initial setup of open wire detection while ON for DO4:0=DISABLED	1			
		Initial setup of open wire detection while ON for DO5:0=DISABLED	1			

		Initial setup of open wire detection while ON for DO6:0=DISABLED	1		
		Initial setup of open wire detection while ON for DO7:0=DISABLED	1		
		Initial setup of open wire detection while ON for DO8:0=DISABLED	1		
		Initial setup of open wire detection while ON for DO9:0=DISABLED	1		
		Initial setup of open wire detection while ON for DO10:0=DISABLED	1		
		Initial setup of open wire detection while ON for DO11:0=DISABLED	1		
		Initial setup of open wire detection while ON for DO12:0=DISABLED	1		
		Initial setup of open wire detection while ON for DO13:0=DISABLED	1		
		Initial setup of open wire detection while ON for DO14:0=DISABLED	1		
		Initial setup of open wire detection while ON for DO15:0=DISABLED	1		

Current FRAM setting for intial and watchdog state for open wire detection while ON for digital output DOx. This state is used after power on and after a communication watchdog timeout, if a watchdog time is configured

Bit 0: =0:Open wire detection for DO1 is DISABLED, =1:Open wire detection for DO1 is ENABLED

Bit 1: =0:Open wire detection for DO2 is DISABLED, =1:Open wire detection for DO2 is ENABLED

...

Bit 13: =0:Open wire detection for DO14 is DISABLED, =1:Open wire detection for DO14 is ENABLED

Bit 14: =0:Open wire detection for DO15 is DISABLED, =1:Open wire detection for DO15 is ENABLED

Write on this register sets all digital outputs to a new state for module restart and watchdog function. The state is saved in FRAM

#### DIGITAL OUTPUTS:ENABLE OPEN WIRE DETECTION WHILE OFF

INITIAL & WATCHDOG SETUP ENABLE OPEN WIRE DETECTION WHILE OFF DO1-DO15	3x59003 4x59003 1:59002	????		0x7FFF	UINT16 R/W	NO
		Initial setup of open wire detection while OFF for DO1:0=DISABLED	1			
		Initial setup of open wire detection while OFF for DO2:0=DISABLED	1			
		Initial setup of open wire detection while OFF for DO3:0=DISABLED	1			
		Initial setup of open wire detection while OFF for DO4:0=DISABLED	1			
		Initial setup of open wire detection while OFF for DO5:0=DISABLED	1			
		Initial setup of open wire detection while OFF for DO6:0=DISABLED	1			
		Initial setup of open wire detection while OFF for DO7:0=DISABLED	1			



		Initial setup of open wire detection while OFF for DO8:0=DISABLED	1		
		Initial setup of open wire detection while OFF for DO9:0=DISABLED	1		
		Initial setup of open wire detection while OFF for DO10:0=DISABLED	1		
		Initial setup of open wire detection while OFF for DO11:0=DISABLED	1		
		Initial setup of open wire detection while OFF for DO12:0=DISABLED	1		
		Initial setup of open wire detection while OFF for DO13:0=DISABLED	1		
		Initial setup of open wire detection while OFF for DO14:0=DISABLED	1		
		Initial setup of open wire detection while OFF for DO15:0=DISABLED	1		

Current FRAM setting for intial and watchdog state for open wire detection while OFF for digital output DOx. This state is used after power on and after a communcation watchdog timeout, if a watchdog time is configured

Bit 0: =0:Open wire detection for DO1 is DISABLED, =1:Open wire detection for DO1 is ENABLED

Bit 1: =0:Open wire detection for DO2 is DISABLED, =1:Open wire detection for DO2 is ENABLED

...

Bit 13: =0:Open wire detection for DO14 is DISABLED, =1:Open wire detection for DO14 is ENABLED

Bit 14: =0:Open wire detection for DO15 is DISABLED, =1:Open wire detection for DO15 is ENABLED

Write on this register sets all digital outputs to a new state for module restart and watchdog function. The state is saved in FRAM

#### DIGITAL OUTPUTS:ENABLE SHORTCUT DETECTION WHILE OFF

INITIAL & WATCHDOG SETUP ENABLE SHORTCUT TO VDD DETECTION WHILE OFF DO1-DO15	3x59004 4x59004 1:59003	????		0x7FFF	UINT16 R/W	NO
		Initial setup of shortcut to VDD detection while OFF for DO1:0=DISABLED	1			
		Initial setup of shortcut to VDD detection while OFF for DO2:0=DISABLED	1			
		Initial setup of shortcut to VDD detection while OFF for DO3:0=DISABLED	1			
		Initial setup of shortcut to VDD detection while OFF for DO4:0=DISABLED	1			
		Initial setup of shortcut to VDD detection while OFF for DO5:0=DISABLED	1			
		Initial setup of shortcut to VDD detection while OFF for DO6:0=DISABLED	1			
		Initial setup of shortcut to VDD detection while OFF for DO7:0=DISABLED	1			
		Initial setup of shortcut to VDD detection while OFF for DO8:0=DISABLED	1			
		Initial setup of shortcut to VDD detection while OFF for DO9:0=DISABLED	1			

		Initial setup of shortcut to VDD detection while OFF for DO10:0=DISABLED	1		
		Initial setup of shortcut to VDD detection while OFF for DO11:0=DISABLED	1		
		Initial setup of shortcut to VDD detection while OFF for DO12:0=DISABLED	1		
		Initial setup of shortcut to VDD detection while OFF for DO13:0=DISABLED	1		
		Initial setup of shortcut to VDD detection while OFF for DO14:0=DISABLED	1		
		Initial setup of shortcut to VDD detection while OFF for DO15:0=DISABLED	1		

Current FRAM setting for initial and watchdog state for shortcut to VDD detection while OFF for digital output DOx. This state is used after power on and after a communication watchdog timeout, if a watchdog time is configured

Bit 0: =0:Shortcut detection for DO1 is DISABLED, =1:Shortcut detection for DO1 is ENABLED

Bit 1: =0:Shortcut detection for DO2 is DISABLED, =1:Shortcut detection for DO2 is ENABLED

...

Bit 13: =0:Shortcut detection for DO14 is DISABLED, =1:Shortcut detection for DO14 is ENABLED

Bit 14: =0:Shortcut detection for DO15 is DISABLED, =1:Shortcut detection for DO15 is ENABLED

Write on this register sets all digital outputs to a new state for module restart and watchdog function. The state is saved in FRAM

Register NAME Command NAME	MODBUS Register ASCII Command	Register VALUE ASCII Command	NEW REAL VALUE	NEW VALUE	DATA TYPE	DO WRITE
-------------------------------	--	---------------------------------	-------------------	--------------	-----------	-------------

## ASCII COMMANDS

## AIOX CONFIGURATION

SET IO TYPES	ASCII WRITE COMMAND	#SIOTYPS:<IOTyp1>,<IOTyp2>,<IOTyp3>,<IOTyp4>,<IOTyp5>,<IOTyp6>,<IOTyp7>,<IOTyp8><CR> Result: #OK<CR>			ASCII	YES
	IOTyp1	VO[0-10V]				
	IOTyp2	VO[0-10V]				
	IOTyp3	VO[0-10V]				
	IOTyp4	VO[0-10V]				
	IOTyp5	VO[0-10V]				
	IOTyp6	VO[0-10V]				
	IOTyp7	VO[0-10V]				
	IOTyp8	VO[0-10V]				
	TX	#1,SIOTYPS:VO[0-10V],VO[0-10V],VO[0-10V],VO[0-10V],VO[0-10V],VO[0-10V],VO[0-10V],VO[0-10V]<CR>				
	RX	#1,OK<CR>				

This command defines for all 8 universal IOs a new type of IO:

IOTypx stands for the new type:

UU: Unused – high impedance

VI[0-10V]: VOLTAGE INPUT for 0 to 10V Signals

VI[2-10V]: VOLTAGE INPUT for 2 to 10V Signals

VO[0-10V]: VOLTAGE OUTPUT for 0 to 10V Signals

VO[2-10V]: VOLTAGE OUTPUT for 2 to 10V Signals

CI[0-20mA;LP]: CURRENT INPUT for 0 to 20mA Signals – loop powered

CI[4-20mA;LP]: CURRENT INPUT for 4 to 20mA Signals – loop powered

CI[0-20mA;EP]: CURRENT INPUT for 0 to 20mA Signals – external powered

CI[4-20mA;EP]: CURRENT INPUT for 4 to 20mA Signals – external powered

CO[0-20mA]: CURRENT OUTPUT for 0 to 20mA Signals

CO[4-20mA]: CURRENT OUTPUT for 4 to 20mA Signals

RTDI[OHM]: RTD SENSOR INPUT for Ohm measurement between 0 and 1MOhm

DI[24V;L]: DIGITAL INPUT for 24Vdc – logic, threshold 12V

DI[24V;LP]: DIGITAL INPUT for 24Vdc – loop powered

HINT: The last IO type is automatically stored in FRAM and will be used after a system restart.

SET IO TYPx	ASCII WRITE COMMAND	#SIOTYP<IONR>:<IOTypx><CR> Result: #OK<CR>			ASCII	YES
	IONR	1				
	IOTypx	VO[0-10V]				
	TX	#1,SIOTYP1:VO[0-10V]<CR>				
	RX	#1,OK<CR>				

This command defines for the universal IO IONR a new type of IO:

IOTypx stands for the new type:

UU: Unused – high impedance

VI[0-10V]: VOLTAGE INPUT for 0 to 10V Signals

VI[2-10V]: VOLTAGE INPUT for 2 to 10V Signals

VO[0-10V]: VOLTAGE OUTPUT for 0 to 10V Signals

VO[2-10V]: VOLTAGE OUTPUT for 2 to 10V Signals

CI[0-20mA;LP]: CURRENT INPUT for 0 to 20mA Signals – loop powered

CI[4-20mA;LP]: CURRENT INPUT for 4 to 20mA Signals – loop powered

CI[0-20mA;EP]: CURRENT INPUT for 0 to 20mA Signals – external powered

CI[4-20mA;EP]: CURRENT INPUT for 4 to 20mA Signals – external powered

CO[0-20mA]: CURRENT OUTPUT for 0 to 20mA Signals

CO[4-20mA]: CURRENT OUTPUT for 4 to 20mA Signals

RTDI[OHM]: RTD SENSOR INPUT for Ohm measurement between 0 and 1MOhm

DI[24V;L]: DIGITAL INPUT for 24Vdc – logic, threshold 12V

DI[24V;LP]: DIGITAL INPUT for 24Vdc – loop powered

HINT: The last IO type is automatically stored in FRAM and will be used after a system restart.

GET IO TYPES	ASCII READ COMMAND	#GIOTYPS<CR> Result: #GIOTYPS:<IOTyp1Txt>,<IOTyp2Txt>,...,<IOTyp8Txt> <CR>	ASCII	
	TX	#1,GIOTYPS<CR>		
	RX	#1,GIOTYPS:VO[0-10V],VO[0-10V],VO[0-10V],VO[0-10V],VO[0-10V],VO[0-10V],VO[0-10V],VO[0-10V]<CR>		
		Actual type of IO1:VO[0-10V]		
		Actual type of IO2:VO[0-10V]		
		Actual type of IO3:VO[0-10V]		
		Actual type of IO4:VO[0-10V]		
		Actual type of IO5:VO[0-10V]		
		Actual type of IO6:VO[0-10V]		
		Actual type of IO7:VO[0-10V]		
		Actual type of IO8:VO[0-10V]		

This command shows for all 8 universal IOs the current selected type of IO:

IOTypx stands for the types:

UU: Unused – high impedance

VI[0-10V]: VOLTAGE INPUT for 0 to 10V Signals

VI[2-10V]: VOLTAGE INPUT for 2 to 10V Signals

VO[0-10V]: VOLTAGE OUTPUT for 0 to 10V Signals

VO[2-10V]: VOLTAGE OUTPUT for 2 to 10V Signals

CI[0-20mA;LP]: CURRENT INPUT for 0 to 20mA Signals – loop powered

CI[4-20mA;LP]: CURRENT INPUT for 4 to 20mA Signals – loop powered

CI[0-20mA;EP]: CURRENT INPUT for 0 to 20mA Signals – external powered

CI[4-20mA;EP]: CURRENT INPUT for 4 to 20mA Signals – external powered

CO[0-20mA]: CURRENT OUTPUT for 0 to 20mA Signals

CO[4-20mA]: CURRENT OUTPUT for 4 to 20mA Signals

RTDI[OHM]: RTD SENSOR INPUT for Ohm measurement between 0 and 1MOhm

DI[24V;L]: DIGITAL INPUT for 24Vdc – logic, threshold 12V

DI[24V;LP]: DIGITAL INPUT for 24Vdc – loop powered

GET IO TYPx	ASCII READ COMMAND	#GIOTYP<IONR><CR> Result: #GIOTYP<IONR>:<IOTypTxt><CR>	ASCII	
-------------	--------------------------	--	-------	--

	IONR	1		
	TX	#1,GIOTYP1<CR>		
	RX	#1,GIOTYP1:VO[0-10V]<CR>		
		Actual type of IO1:VO[0-10V]		

This command shows for the universal IO IONR the current selected type:

IOTypx stands for the types:

UU: Unused – high impedance

VI[0-10V]: VOLTAGE INPUT for 0 to 10V Signals

VI[2-10V]: VOLTAGE INPUT for 2 to 10V Signals

VO[0-10V]: VOLTAGE OUTPUT for 0 to 10V Signals

VO[2-10V]: VOLTAGE OUTPUT for 2 to 10V Signals

CI[0-20mA;LP]: CURRENT INPUT for 0 to 20mA Signals – loop powered

CI[4-20mA;LP]: CURRENT INPUT for 4 to 20mA Signals – loop powered

CI[0-20mA;EP]: CURRENT INPUT for 0 to 20mA Signals – external powered

CI[4-20mA;EP]: CURRENT INPUT for 4 to 20mA Signals – external powered

CO[0-20mA]: CURRENT OUTPUT for 0 to 20mA Signals

CO[4-20mA]: CURRENT OUTPUT for 4 to 20mA Signals

RTDI[OHM]: RTD SENSOR INPUT for Ohm measurement between 0 and 1MOhm

DI[24V;L]: DIGITAL INPUT for 24Vdc – logic, threshold 12V

DI[24V;LP]: DIGITAL INPUT for 24Vdc – loop powered

#### VOLTAGE INPUTS

GET VOLTAGE INPUTS IN VOLT	ASCII READ COMMAND	#GVISV<CR> Result: #GVISV:<IOVolt1DbI>,<IOVolt2DbI>.....<IOVolt8DbI><CR>	ASCII	
	TX	#1,GVISV<CR>		
	RX	#1,GVISV:999.99,999.99,999.99,999.99,999.99,999.99,999.99,999.99,999.99,999.99<CR>		
		Actual voltage on IO1:999.99V		
		Actual voltage on IO2:999.99V		
		Actual voltage on IO3:999.99V		
		Actual voltage on IO4:999.99V		
		Actual voltage on IO5:999.99V		
		Actual voltage on IO6:999.99V		
		Actual voltage on IO7:999.99V		
		Actual voltage on IO8:999.99V		

This command shows for all VOLTAGE INPUT IOs the current measurement in Volt.

The measurement range is 0.0 to 10.00V.

All IOs with a different usage type will return 999.99 to indicate, that no measurement is done.

GET VOLTAGE INPUT IN VOLT	ASCII READ COMMAND	#GVIV<IONR><CR> Result: #GVIV<IONR>:<IOxVoltDbI><CR>	ASCII	
	IONR	1		
	TX	#1,GVIV1<CR>		
	RX	#1,GVIV1:999.99<CR>		
		Actual voltage on IO1:999.99V		

This command shows for the VOLTAGE INPUT IO <IONR> the current measurement in Volt.

The measurement range is 0.0 to 10.00V.

All IOs with a different usage type will return 999.99 to indicate, that no measurement is done.

GET VOLTAGE INPUTS IN PERCENT	ASCII READ COMMAND	#GVISP<CR> Result: #GVISP:<IOPercent1DbI>,<IOPercent2DbI>,...,<IOPercent8DbI><CR>	ASCII	
	TX	#1,GVISP<CR>		
	RX	#1,GVISP:999.99,999.99,999.99,999.99,999.99,999.99,999.99,999.99<CR>		
		Actual percentage on IO1:999.99%		
		Actual percentage on IO2:999.99%		
		Actual percentage on IO3:999.99%		
		Actual percentage on IO4:999.99%		
		Actual percentage on IO5:999.99%		
		Actual percentage on IO6:999.99%		
		Actual percentage on IO7:999.99%		
		Actual percentage on IO8:999.99%		

This command shows for all VOLTAGE INPUT IOs the current measurement in Percent.

The measurement range is 0.0V -> 0.0% to 10.00V -> 100.0%.

All IOs with a different usage type will return 999.99 to indicate, that no measurement is done.

GET VOLTAGE INPUT IN PERCENT	ASCII READ COMMAND	#GVIP<IONR><CR> Result: #GVIP<IONR>:<IOxPercentDbI><CR>	ASCII	
	IONR	1		
	TX	#1,GVIP1<CR>		
	RX	#1,GVIP1:999.99<CR>		
		Actual percentage on IO1:999.99%		

This command shows for VOLTAGE INPUT IO <IONR> the current measurement in Percent.

The measurement range is 0.0V -> 0.0% to 10.00V -> 100.0%.

All IOs with a different usage type will return 999.99 to indicate, that no measurement is done.

### VOLTAGE DIGITAL INPUTS

GET VOLTAGE DIGITAL INPUTS	ASCII READ COMMAND	#GVDIS<CR> Result: #GVDIS:<IODI1Dec>,<IODI2Dec>,...,<IODI8Dec><CR>	ASCII	
	TX	#1,GVDIS<CR>		
	RX	#1,GVDIS:X,X,X,X,X,X,X,X<CR>		
		Actual voltage digital input state on IO1:X		
		Actual voltage digital input state on IO2:X		
		Actual voltage digital input state on IO3:X		
		Actual voltage digital input state on IO4:X		
		Actual voltage digital input state on IO5:X		
		Actual voltage digital input state on IO6:X		
		Actual voltage digital input state on IO7:X		
		Actual voltage digital input state on IO8:X		

This command shows for all VOLTAGE DIGITAL INPUT IOs the current state.

The digital input can have the values 0 and 1.

All IOs with a different usage type will return X to indicate, that no measurement is done.

GET VOLTAGE DIGITAL INPUT	ASCII READ COMMAND	#GVDI<IONR><CR> Result: #GVDI<IONR>:<IOxDIDec><CR>	ASCII	
	IONR	1		

	TX	#1,GVDI1<CR>		
	RX	#1,GVDI3:X<CR>		
		Actual voltage digital input state on IO1:X		
This command shows for VOLTAGE DIGITAL INPUT IO <IONR> the current state. The digital input can have the values 0 and 1. All IOs with a different usage type will return X to indicate, that no measurement is done.				
GET VOLTAGE DIGITAL INPUTS CURRENT	ASCII READ COMMAND	#GVDISC<CR> Result: #GVDISC:<IOmA1DbI>,<IOmA2DbI>,...,<IOmA8DbI><CR>	ASCII	
	TX	#1,GVDISC<CR>		
	RX	#1,GVDISC:999.99,999.99,999.99,999.99,999.99,999.99,999.99,999.99<CR>		
		Actual input current on IO1:999.99mA		
		Actual input current on IO2:999.99mA		
		Actual input current on IO3:999.99mA		
		Actual input current on IO4:999.99mA		
		Actual input current on IO5:999.99mA		
		Actual input current on IO6:999.99mA		
		Actual input current on IO7:999.99mA		
		Actual input current on IO8:999.99mA		
This command shows for all VOLTAGE DIGITAL INPUT IOs the actual current in mA. The measurement range is 0.0mA to 35mA. All IOs with a different usage type will return 999.99 to indicate, that no measurement is done.				
GET VOLTAGE DIGITAL INPUT CURRENT	ASCII READ COMMAND	#GVDIC<IONR><CR> Result: #GVDIC<IONR>:<IOxmADbl><CR>	ASCII	
	IONR	1		
	TX	#1,GVDIC1<CR>		
	RX	#1,GVDIC1:999.99<CR>		
		Actual input current on IO1:999.99mA		
This command shows for VOLTAGE DIGITAL INPUT IO <IONR> the actual current in mA. The measurement range is 0.0mA to 35mA. All IOs with a different usage type will return 999.99 to indicate, that no measurement is done.				
<b>VOLTAGE OUTPUTS</b>				
SET VOLTAGE OUTPUTS IN VOLT	ASCII WRITE COMMAND	#SVOSV:<IO1VoltDbI>,<IO2VoltDbI>,<IO3VoltDbI>,<IO4VoltDbI>,<IO5VoltDbI>,<IO6VoltDbI>,<IO7 VoltDbI>,<IO8VoltDbI><CR> Result: #OK<CR>	ASCII	YES
	IO1Volt	10,000		
	IO2Volt	7,500		
	IO3Volt	5,500		
	IO4Volt	2,500		
	IO5Volt	10,000		
	IO6Volt	7,500		
	IO7Volt	5,500		
	IO8Volt	2,500		
	TX	#1,SVOSV:10,7.5,5.5,2.5,10,7.5,5.5,2.5<CR>		
	RX	#1,OK<CR>		

This command sets for all VOLTAGE OUTPUT IOs the current output voltage in Volt.

The range is 0.0 to 11.00V.

SET VOLTAGE OUTPUTx IN VOLT	ASCII WRITE COMMAND	#SVOV<IONR>:<IOxVoltDbl> <CR> Result: #OK<CR>	ASCII	NO
	IONR	1		
	IOxVolt	2,000		
	TX	#1,SVOV1:2<CR>		
	RX	N/A		

This command sets for VOLTAGE OUTPUT IO <IONR> the current output voltage in Volt.

The range is 0.0 to 11.00V.

SET VOLTAGE OUTPUTS IN PERCENT	ASCII WRITE COMMAND	#SVOSP:<IO1PercentDbl>,<IO2PercentDbl>,<IO3PercentDbl>,<IO4PercentDbl>,<IO5PercentDbl>,<IO6PercentDbl>,<IO7PercentDbl>,<IO8PercentDbl> <CR> Result: #OK<CR>	ASCII	NO
	IO1Percent	110,000		
	IO2Percent	100,000		
	IO3Percent	75,000		
	IO4Percent	50,000		
	IO5Percent	110,000		
	IO6Percent	100,000		
	IO7Percent	75,000		
	IO8Percent	50,000		
	TX	#1,SVOSP:110,100,75,50,110,100,75,50<CR>		
	RX	N/A		

This command sets for all VOLTAGE OUTPUT IOs the current output voltage in Percent.

The range is 0.0V -> 0.00% to 11.00V -> 110.00%.

SET VOLTAGE OUTPUTx IN PERCENT	ASCII WRITE COMMAND	#SVOP<IONR>:<IOxPercentDbl> <CR> Result: #OK<CR>	ASCII	NO
	IONR	1		
	IOxPercent	2,000		
	TX	#1,SVOP1:2<CR>		
	RX	N/A		

This command sets for VOLTAGE OUTPUT IO <IONR> the current output voltage in Percent.

The range is 0.0V -> 0.00% to 11.00V -> 110.00%.

GET VOLTAGE OUTPUTS IN VOLT	ASCII READ COMMAND	#GVOSV<CR> Result: #GVOSV:<IO1VoltDbl>,<IO2VoltDbl>,...,<IO8VoltDbl> <CR>	ASCII	
	TX	#1,GVOSV<CR>		
	RX	#1,GVOSV:0.00,0.00,0.00,0.00,0.00,0.00,0.00,0.00<CR>		
		Actual voltage output on IO1:0.00V		
		Actual voltage output on IO2:0.00V		
		Actual voltage output on IO3:0.00V		
		Actual voltage output on IO4:0.00V		
		Actual voltage output on IO5:0.00V		
		Actual voltage output on IO6:0.00V		



		Actual voltage output on IO7:0.00V		
		Actual voltage output on IO8:0.00V		
This command shows for all VOLTAGE OUTPUT IOs the current output voltage in Volt. The range is 0.0V to 11.00V. All IOs with a different usage type will return 999.99 to indicate, that no measurement is done.				
GET VOLTAGE OUTPUT IN VOLT	ASCII READ COMMAND	#GVOV<IONR> <CR> Result: #GVOV<IONR>:<IOxVoltDbl> <CR>	ASCII	
	IONR	1		
	TX	#1,GVOV1<CR>		
	RX	#1,GVOV3:5.50<CR>		
		Actual voltage output on IO1:5.50V		
This command shows for VOLTAGE OUTPUT IO <IONR> the current output voltage in Volt. The range is 0.0V to 11.00V. All IOs with a different usage type will return 999.99 to indicate, that no measurement is done.				
GET VOLTAGE OUTPUTS IN PERCENT	ASCII READ COMMAND	#GVOSP<CR> Result: #GVOSP:<IO1PercentDbl>,<IO2PercentDbl>,<IO3PercentDbl>,<IO4PercentDbl>,<IO5PercentDbl>,<IO6PercentDbl>,<IO7PercentDbl>,<IO8PercentDbl> <CR>	ASCII	
	TX	#1,GVOSP<CR>		
	RX	#1,GVOSP:100.00,75.00,55.00,25.00,100.00,75.00,55.00,25.00 <CR>		
		Actual percentage voltage output on IO1:100.00%		
		Actual percentage voltage output on IO2:75.00%		
		Actual percentage voltage output on IO3:55.00%		
		Actual percentage voltage output on IO4:25.00%		
		Actual percentage voltage output on IO5:100.00%		
		Actual percentage voltage output on IO6:75.00%		
		Actual percentage voltage output on IO7:55.00%		
		Actual percentage voltage output on IO8:25.00%		
This command shows for all VOLTAGE OUTPUT IOs the current output voltage in Percent. The range is 0.0V -> 0.00% to 11.00V -> 110.00% (10.00V -> 100.00%). All IOs with a different usage type will return 999.99 to indicate, that no measurement is done.				
GET VOLTAGE OUTPUT IN PERCENT	ASCII READ COMMAND	#GVOP<IONR> <CR> Result: #GVOP<IONR>:<IOxPercentDbl> <CR>	ASCII	
	IONR	1		
	TX	#1,GVOP1<CR>		
	RX	#1,GVOP3:55.00<CR>		
		Actual percentage voltage output on IO1:55.00%		
This command shows for VOLTAGE OUTPUT IO <IONR> the current output voltage in Percent. The range is 0.0V -> 0.00% to 11.00V -> 110.00% (10.00V -> 100.00%). All IOs with a different usage type will return 999.99 to indicate, that no measurement is done.				
GET VOLTAGE OUTPUTS CURRENT	ASCII READ COMMAND	#GVOSC <CR> Result: #GVOSC:<IOmA1Dbl>,<IOmA2Dbl>,<IOmA3Dbl>,<IOmA4Dbl>,<IOmA5Dbl>,<IOmA6Dbl>,<IOmA7Dbl>,<IOmA8Dbl> <CR>	ASCII	
	TX	#1,GVOSC<CR>		
	RX	#1,GVOSC:0.00,0.00,0.00,-0.00,-0.00,0.00,0.00,0.00<CR>		
		Actual output current on IO1:0.00mA		

		Actual output current on IO2:0.00mA		
		Actual output current on IO3:0.00mA		
		Actual output current on IO4:-0.00mA		
		Actual output current on IO5:-0.00mA		
		Actual output current on IO6:0.00mA		
		Actual output current on IO7:0.00mA		
		Actual output current on IO8:0.00mA		

This command shows for all VOLTAGE OUTPUT IOs the actual current in mA.

The measurement range is 0.0mA to 35mA.

All IOs with a different usage type will return 999.99 to indicate, that no measurement is done.

GET VOLTAGE OUTPUT CURRENT	ASCII READ COMMAND	#GVOC<IONR><CR> Result: #GVOC<IONR>:<IOxmADbl><CR>	ASCII	
	IONR	1		
	TX	#1,GVOC1<CR>		
	RX	#1,GVOC1:0.00<CR>		
		Actual output current on IO1:0.00mA		

This command shows for VOLTAGE OUTPUT IO <IONR> the actual current in mA.

The measurement range is 0.0mA to 35mA.

All IOs with a different usage type will return 999.99 to indicate, that no measurement is done.

#### CURRENT INPUTS

GET CURRENT INPUTS IN mA	ASCII READ COMMAND	#GCISMA<CR> Result: #GCISMA:<IO1mADbl>,<IO2mADbl>,...,<IO8mADbl><CR>	ASCII	
	TX	#1,GCISMA<CR>		
	RX	#1,GCISMA:999.99,999.99,999.99,999.99,999.99,999.99,999.99,999.99<CR>		
		Actual current input on IO1:999.99mA		
		Actual current input on IO2:999.99mA		
		Actual current input on IO3:999.99mA		
		Actual current input on IO4:999.99mA		
		Actual current input on IO5:999.99mA		
		Actual current input on IO6:999.99mA		
		Actual current input on IO7:999.99mA		
		Actual current input on IO8:999.99mA		

This command shows for all CURRENT INPUT IOs the current measured input current in mA.

The range is 0.00 to 25.00mA

All IOs with a different usage type will return 999.99 to indicate, that no measurement is done.

GET CURRENT INPUT IN mA	ASCII READ COMMAND	#GCIMA<IONR><CR> Result: #GCIMA<IONR>:<IOxmADbl><CR>	ASCII	
	IONR	1		
	TX	#1,GCIMA1<CR>		
	RX	#1,GCIMA3:999.99<CR>		
		Actual current input on IO1:999.99mA		

This command shows for CURRENT INPUT IO <IONR> the current measured input current in mA.

The range is 0.00 to 25.00mA

All IOs with a different usage type will return 999.99 to indicate, that no measurement is done.

GET CURRENT INPUTS IN PERCENT	ASCII READ COMMAND	#GCISP<CR> Result: #GCISP:<IO1PercentDbl>,<IO2PercentDbl>,...,<IO8PercentDbl><CR>	ASCII	
	TX	#1,GCISP<CR>		
	RX	#1,GCISP:999.99,999.99,999.99,999.99,999.99,999.99,999.99,999.99<CR>		
		Actual percentage for current input on IO1:999.99%		
		Actual percentage for current input on IO2:999.99%		
		Actual percentage for current input on IO3:999.99%		
		Actual percentage for current input on IO4:999.99%		
		Actual percentage for current input on IO5:999.99%		
		Actual percentage for current input on IO6:999.99%		
		Actual percentage for current input on IO7:999.99%		
		Actual percentage for current input on IO8:999.99%		

This command shows for all CURRENT INPUT IOs the current measured input current in Percent.

The range is 0.00mA -> 0.00% to 25.00mA -> 125.00% (20mA=100%)

All IOs with a different usage type will return 999.99 to indicate, that no measurement is done.

GET CURRENT INPUT IN PERCENT	ASCII READ COMMAND	#GCIP<IONR><CR> Result: #GCIP<IONR>:<IOxPercentDbl><CR>	ASCII	
	IONR	1		
	TX	#1,GCIP1<CR>		
	RX	#1,GCIP3:999.99<CR>		
		Actual percentage for current input on IO1:999.99%		

This command shows for CURRENT INPUT IO <IONR> the current measured input current in Percent.

The range is 0.00mA -> 0.00% to 25.00mA -> 125.00% (20mA=100%)

All IOs with a different usage type will return 999.99 to indicate, that no measurement is done.

### CURRENT OUTPUTS

SET CURRENT OUTPUTS IN mA	ASCII WRITE COMMAND	#SCOSMA:<IO1mADbl>,<IO2mADbl>,<IO3mADbl>,<IO4mADbl>,<IO5mADbl>,<IO6mADbl>,<IO7mADbl>,<IO8mADbl><CR> Result: #OK<CR>	ASCII	NO
	IO1mA	2,000		
	IO2mA	4,000		
	IO3mA	6,000		
	IO4mA	25,000		
	IO5mA	,000		
	IO6mA	,000		
	IO7mA	,000		
	IO8mA	,000		
	TX	#1,SCOSMA:2,4,6,25,0,0,0,0<CR>		
	RX	N/A		

This command sets for all CURRENT OUTPUT IOs the actual output current in mA.

The range is 0.00mA to 25.00mA

SET CURRENT OUTPUTx IN mA	ASCII WRITE COMMAND	#SCOMA<IONR>:<IOxMADbl> <CR> Result: #OK<CR>	ASCII	NO
	IONR	1		
	IOxVolt	2,000		
	TX	#1,SCOMA1:<IOxMADbl> <CR>		
	RX	N/A		
This command sets for CURRENT OUTPUT <IONR> IOs the actual output current in mA. The range is 0.00mA to 25.00mA				
SET CURRENT OUTPUTS IN PERCENT	ASCII WRITE COMMAND	#SCOSP:<IO1PercentDbl>,<IO2PercentDbl>,<IO3PercentDbl>,<IO4PercentDbl>,<IO5PercentDbl>,<IO6PercentDbl>,<IO7PercentDbl>,<IO8PercentDbl> <CR> Result: #OK<CR>	ASCII	NO
	IO1Percent	125,000		
	IO2Percent	100,000		
	IO3Percent	75,000		
	IO4Percent	50,000		
	IO5Percent	,000		
	IO6Percent	,000		
	IO7Percent	,000		
	IO8Percent	,000		
	TX	#1,SCOSP:125,100,75,50,0,0,0,0 <CR>		
	RX	N/A		
This command sets for all CURRENT OUTPUT IOs the new output current in Percent. The range is 0.00mA -> 0.00% to 25.00mA -> 125.00% (20mA -> 100.00%)				
SET CURRENT OUTPUTx IN PERCENT	ASCII WRITE COMMAND	#SCOP<IONR>:<IOxPercentDbl> <CR> Result: #OK<CR>	ASCII	NO
	IONR	1		
	IOxPercent	,000		
	TX	#1,SCOP1:0 <CR>		
	RX	N/A		
This command sets for CURRENT OUTPUT IO <IONR> the new output current in Percent. The range is 0.00mA -> 0.00% to 25.00mA -> 125.00% (20mA -> 100.00%)				
GET CURRENT OUTPUTS IN mA	ASCII READ COMMAND	#GCOSMA<CR> Result: #GCOSMA:<IO1mADbl>,<IO2mADbl>,...,<IO8mADbl> <CR>	ASCII	
	TX	#1,GCOSMA<CR>		
	RX	#1,GCOSMA:999.99,999.99,999.99,999.99,999.99,999.99,999.99,999.99 <CR>		
		Actual value of current output on IO1:999.99mA		
		Actual value of current output on IO2:999.99mA		
		Actual value of current output on IO3:999.99mA		
		Actual value of current output on IO4:999.99mA		
		Actual value of current output on IO5:999.99mA		
		Actual value of current output on IO6:999.99mA		
		Actual value of current output on IO7:999.99mA		

		Actual value of current output on IO8:999.99mA		
This command shows for all CURRENT OUTPUT IOs the actual output current in mA. The range is 0.00mA to 25.00mA All IOs with a different usage type will return 999.99 to indicate, that no measurement is done.				
GET CURRENT OUTPUT IN mA	ASCII READ COMMAND	#GCOMA<IONR><CR> Result: #GCOMA<IONR>:<IOxmADbl><CR>	ASCII	
	IONR	1		
	TX	#1,GCOMA1<CR>		
	RX	#1,GCOMA3:999.99<CR>		
		Actual value of current output on IO1:999.99mA		
This command shows for CURRENT OUTPUT IO <IONR> the actual output current in mA. The range is 0.00mA to 25.00mA All IOs with a different usage type will return 999.99 to indicate, that no measurement is done.				
GET CURRENT OUTPUTS IN PERCENT	ASCII READ COMMAND	#GCOSP<CR> Result: #GCOSP:<IO1PercentDbl>,<IO2PercentDbl>,...,<IO8PercentDbl><CR>	ASCII	
	TX	#1,GCOSP<CR>		
	RX	#1,GCOSP:999.99,999.99,999.99,999.99,999.99,999.99,999.99,999.99,999.99,999.99<CR>		
		Actual percentage of current output on IO1:999.99%		
		Actual percentage of current output on IO2:999.99%		
		Actual percentage of current output on IO3:999.99%		
		Actual percentage of current output on IO4:999.99%		
		Actual percentage of current output on IO5:999.99%		
		Actual percentage of current output on IO6:999.99%		
		Actual percentage of current output on IO7:999.99%		
		Actual percentage of current output on IO8:999.99%		
This command shows for all CURRENT OUTPUT IOs the actual output current in Percent. The range is 0.00mA -> 0.00% to 25.00mA -> 125.00% (20mA -> 100.00%) All IOs with a different usage type will return 999.99 to indicate, that no measurement is done.				
GET CURRENT OUTPUT IN PERCENT	ASCII READ COMMAND	#GCOP<IONR><CR> Result: #GCOP<IONR>:<IOxPercentDbl><CR>	ASCII	
	IONR	1		
	TX	#1,GCOP1<CR>		
	RX	#1,GCOP3:999.99<CR>		
		Actual percentage of current output on IO1:999.99%		
This command shows for CURRENT OUTPUT IO <IONR> the actual output current in Percent. The range is 0.00mA -> 0.00% to 25.00mA -> 125.00% (20mA -> 100.00%) All IOs with a different usage type will return 999.99 to indicate, that no measurement is done.				
GET CURRENT OUTPUTS VOLTAGE	ASCII READ COMMAND	#GCOSV<CR> Result: #GCOSV:<IO1VoltsDbl>,<IO2VoltsDbl>,...,<IO8VoltsDbl><CR>	ASCII	
	TX	#1,GCOSV<CR>		
	RX	#1,GCOSV:999.99,999.99,999.99,999.99,999.99,999.99,999.99,999.99,999.99,999.99<CR>		
		Measured voltage of current output on IO1:999.99V		

		Measured voltage of current output on IO2:999.99V		
		Measured voltage of current output on IO3:999.99V		
		Measured voltage of current output on IO4:999.99V		
		Measured voltage of current output on IO5:999.99V		
		Measured voltage of current output on IO6:999.99V		
		Measured voltage of current output on IO7:999.99V		
		Measured voltage of current output on IO8:999.99V		

This command shows for all CURRENT OUTPUT IOs the actual output voltage in Volt.

The range is 0-10V

All IOs with a different usage type will return 999.99 to indicate, that no measurement is done.

GET CURRENT OUTPUT VOLTAGE	ASCII READ COMMAND	#GCOV<IONR><CR> Result: #GCOV<IONR>:<IOxVoltDbI><CR>	ASCII	
	IONR	1		
	TX	#1,GCOV1<CR>		
	RX	#1,GCOV3:999.99<CR>		
		Measured voltage of current output on IO1:999.99V		

This command shows for CURRENT OUTPUT IO <IONR> the actual output voltage in Volt.

The range is 0-10V

All IOs with a different usage type will return 999.99 to indicate, that no measurement is done.

#### RTD INPUTS OHM

GET RTD INPUTS IN OHM	ASCII READ COMMAND	#GRTDISOHM<CR> Result: #GRTDISOHM:<IO1OhmDbI>,<IO2OhmDbI>,...,<IO8OhmDbI><CR>	ASCII	
	TX	#1,GRTDISOHM<CR>		
	RX	#1,GRTDISOHM:99999999.999,99999999.999,99999999.999,99999999.999,99999999.999,99999999.999,99999999.999,99999999.999<CR>		
		Actual measured RTD input on IO1:99999999.999Ohm		
		Actual measured RTD input on IO2:99999999.999Ohm		
		Actual measured RTD input on IO3:99999999.999Ohm		
		Actual measured RTD input on IO4:99999999.999Ohm		
		Actual measured RTD input on IO5:99999999.999Ohm		
		Actual measured RTD input on IO6:99999999.999Ohm		
		Actual measured RTD input on IO7:99999999.999Ohm		
		Actual measured RTD input on IO8:99999999.999Ohm		

This command shows for RTD INPUT IOs the actual measured RTD value in Ohm.

The range is 0.0000Ohm to 1000000.000Ohm

All IOs with a different usage type will return 99999999.999 to indicate, that no measurement is done.

GET RTD INPUT IN OHM	ASCII READ COMMAND	#GRTDIOHM<IONR><CR> Result: #GRTDIOHM<IONR>:<IOxOhmDbI><CR>	ASCII	
	IONR	1		
	TX	#1,GRTDIOHM1<CR>		
	RX	#1,GRTDIOHM3:99999999.999<CR>		
		Actual measured RTD input on IO1:99999999.999Ohm		

This command shows for RTD INPUT IO <IONR> the actual measured RTD value in Ohm.

The range is 0.000Ohm to 1000000.00Ohm

All IOs with a different usage type will return 99999999.999 to indicate, that no measurement is done.

GET AVERAGE RTD INPUTS IN OHM	ASCII READ COMMAND	#GAVGRTDISOHM<CR> Result: #GAVGRTDISOHM:<IO1OhmDbl>,<IO2OhmDbl>,...,<IO8OhmDbl><CR>	ASCII	
	TX	#1,GAVGRTDISOHM<CR>		
	RX	#1,GAVGRTDISOHM:99999999.999,99999999.999,99999999.999,99999999.999,99999999.999,99999999.999,99999999.999,99999999.999<CR>		
		Average measured RTD input on IO1:99999999.999Ohm		
		Average measured RTD input on IO2:99999999.999Ohm		
		Average measured RTD input on IO3:99999999.999Ohm		
		Average measured RTD input on IO4:99999999.999Ohm		
		Average measured RTD input on IO5:99999999.999Ohm		
		Average measured RTD input on IO6:99999999.999Ohm		
		Average measured RTD input on IO7:99999999.999Ohm		
		Average measured RTD input on IO8:99999999.999Ohm		

This command shows for RTD INPUT IOs the average measured RTD value in Ohm.

The range is 0.000Ohm to 1000000.00Ohm

All IOs with a different usage type will return 99999999.999 to indicate, that no measurement is done.

GET AVG RTD INPUT IN OHM	ASCII READ COMMAND	#GAVGRTDIOHM<IONR> <CR> Result: #GAVGRTDIOHM<IONR>:<IOxOhmDbl> <CR>	ASCII	
	IONR	1		
	TX	#1,GAVGRTDIOHM1<CR>		
	RX	#1,GAVGRTDIOHM3:99999999.999<CR>		
		Average measured RTD input on IO1:99999999.999Ohm		

This command shows for RTD INPUT IO <IONR> the average measured RTD value in Ohm.

The range is 0.000Ohm to 1000000.00Ohm

All IOs with a different usage type will return 99999999.999 to indicate, that no measurement is done.

#### RTD INPUTS PT100 CELSIUS

GET RTD INPUTS AS PT100 CELSIUS	ASCII READ COMMAND	#GRTDISPT100C <CR> Result: #GRTDISPT100C:<RTD1Dbl>,<RTD2Dbl>,...,<RTD8Dbl> <CR>	ASCII	
	TX	#1,GRTDISPT100C <CR>		
	RX	#1,GRTDISPT100C:9999.990,9999.990,9999.990,9999.990,9999.990,9999.990,9999.990,9999.990 <CR>		
		Actual measured RTD input as PT100 on IO1:9999.990°C		
		Actual measured RTD input as PT100 on IO2:9999.990°C		
		Actual measured RTD input as PT100 on IO3:9999.990°C		
		Actual measured RTD input as PT100 on IO4:9999.990°C		
		Actual measured RTD input as PT100 on IO5:9999.990°C		
		Actual measured RTD input as PT100 on IO6:9999.990°C		
		Actual measured RTD input as PT100 on IO7:9999.990°C		
		Actual measured RTD input as PT100 on IO8:9999.990°C		

This command shows for RTD INPUT IOs the actual measured RTD value linearized as PT100 sensor in °Celsius.

-999.990: Temperature is lower than 50°C

+999.990: Temperature is higher than 130°C

All IOs with a different usage type will return 9999.990 to indicate, that no measurement is done.

GET RTD INPUT AS PT100 CELSIUS	ASCII READ COMMAND	#GRTDIPT100C <IONR> <CR> Result: #GRTDIPT100C <IONR> : <IOxDbl> <CR>	ASCII	
	IONR	1		
	TX	#1,GRTDIPT100C1<CR>		
	RX	#1,GRTDIPT100C3:9999.990<CR>		
		Actual measured RTD input as PT100 on IO1:9999.990°C		

This command shows for RTD INPUT IO <IONR> the actual measured RTD value linearized as PT100 sensor in °Celsius

-999.990: Temperature is lower than 50°C

+999.990: Temperature is higher than 130°C

All IOs with a different usage type will return 9999.990 to indicate, that no measurement is done.

GET AVERAGE RTD INPUTS AS PT100 CELSIUS	ASCII READ COMMAND	#GAVGRTDISPT100C <CR> Result: #GAVGRTDISPT100C:<RTD1Dbl>,<RTD2Dbl>,...,<RTD8Dbl> <CR>	ASCII	
	TX	#1,GAVGRTDISPT100C <CR>		
	RX	#1,GAVGRTDISPT100C:9999.990,9999.990,9999.990,9999.990,9999.990,9999.990,9999.990,9999.990 <CR>		
		Average measured RTD input as PT100 on IO1:9999.990°C		
		Average measured RTD input as PT100 on IO2:9999.990°C		
		Average measured RTD input as PT100 on IO3:9999.990°C		
		Average measured RTD input as PT100 on IO4:9999.990°C		
		Average measured RTD input as PT100 on IO5:9999.990°C		
		Average measured RTD input as PT100 on IO6:9999.990°C		
		Average measured RTD input as PT100 on IO7:9999.990°C		
		Average measured RTD input as PT100 on IO8:9999.990°C		

This command shows for RTD INPUT IOs the average measured RTD value linearized as PT100 sensor in °Celsius.

-999.990: Temperature is lower than 50°C

+999.990: Temperature is higher than 130°C

All IOs with a different usage type will return 9999.990 to indicate, that no measurement is done.

GET AVG RTD INPUT AS PT100 CELSIUS	ASCII READ COMMAND	#GAVGRTDIPT100C <IONR> <CR> Result: #GAVGRTDIPT100C <IONR> : <IOxDbl> <CR>	ASCII	
	IONR	1		
	TX	#1,GAVGRTDIPT100C1<CR>		
	RX	#1,GAVGRTDIPT100C1:9999.990<CR>		
		Average measured RTD input as PT100 on IO1:9999.990°C		

This command shows for RTD INPUT IO <IONR> the average measured RTD value linearized as PT100 sensor in °Celsius

-999.990: Temperature is lower than 50°C

+999.990: Temperature is higher than 130°C

All IOs with a different usage type will return 9999.990 to indicate, that no measurement is done.

### RTD INPUTS PT1000 CELSIUS

GET RTD INPUTS AS PT1000 CELSIUS	ASCII READ COMMAND	#GRTDISPT1000C <CR> Result: #GRTDISPT1000C:<RTD1Dbl>,<RTD2Dbl>,...,<RTD8Dbl> <CR>	ASCII	
-------------------------------------	--------------------------	---	-------	--



	TX	#1,GRTDISPT1000C<CR>		
	RX	#1,GRTDISPT1000C:9999.990,9999.990,9999.990,9999.990,9999.990,9999.990,9999.990,9999.990<CR>		
		Actual measured RTD input as PT1000 on IO1:9999.990°C		
		Actual measured RTD input as PT1000 on IO2:9999.990°C		
		Actual measured RTD input as PT1000 on IO3:9999.990°C		
		Actual measured RTD input as PT1000 on IO4:9999.990°C		
		Actual measured RTD input as PT1000 on IO5:9999.990°C		
		Actual measured RTD input as PT1000 on IO6:9999.990°C		
		Actual measured RTD input as PT1000 on IO7:9999.990°C		
		Actual measured RTD input as PT1000 on IO8:9999.990°C		

This command shows for RTD INPUT IOs the actual measured RTD value linearized as PT1000 sensor in °Celsius.

-999.990: Temperature is lower than 50°C

+999.990: Temperature is higher than 130°C

All IOs with a different usage type will return 9999.990 to indicate, that no measurement is done.

GET RTD INPUT AS PT1000 CELSIUS	ASCII READ COMMAND	#GRTDIPT1000C<IONR><CR> Result: #GRTDIPT1000C<IONR>:<IOxDbl><CR>	ASCII	
	IONR	1		
	TX	#1,GRTDIPT1000C1<CR>		
	RX	#1,GRTDIPT1000C3:9999.990<CR>		
		Actual measured RTD input as PT1000 on IO1:9999.990°C		

This command shows for RTD INPUT IO <IONR> the actual measured RTD value linearized as PT1000 sensor in °Celsius

-999.990: Temperature is lower than 50°C

+999.990: Temperature is higher than 130°C

All IOs with a different usage type will return 9999.990 to indicate, that no measurement is done.

GET AVERAGE RTD INPUTS AS PT1000 CELSIUS	ASCII READ COMMAND	#GAVGRTDISPT1000C<CR> Result: #GAVGRTDISPT1000C:<RTD1Dbl>,<RTD2Dbl>,...,<RTD8Dbl><CR>	ASCII	
	TX	#1,GAVGRTDISPT1000C<CR>		
	RX	#1,GAVGRTDISPT1000C:9999.990,9999.990,9999.990,9999.990,9999.990,9999.990,9999.990,9999.990<CR>		
		Average measured RTD input as PT1000 on IO1:9999.990°C		
		Average measured RTD input as PT1000 on IO2:9999.990°C		
		Average measured RTD input as PT1000 on IO3:9999.990°C		
		Average measured RTD input as PT1000 on IO4:9999.990°C		
		Average measured RTD input as PT1000 on IO5:9999.990°C		
		Average measured RTD input as PT1000 on IO6:9999.990°C		
		Average measured RTD input as PT1000 on IO7:9999.990°C		
		Average measured RTD input as PT1000 on IO8:9999.990°C		

This command shows for RTD INPUT IOs the average measured RTD value linearized as PT1000 sensor in °Celsius.

-999.990: Temperature is lower than 50°C

+999.990: Temperature is higher than 130°C

All IOs with a different usage type will return 9999.990 to indicate, that no measurement is done.

GET AVG RTD INPUT AS PT1000 CELSIUS	ASCII READ COMMAND	#GAVGRTDIPT1000C<IONR><CR> Result: #GAVGRTDIPT1000C<IONR>:<IOxDbl><CR>	ASCII	
	IONR	1		

	TX	#1,GAVGRDIPRT1000C1<CR>		
	RX	#1,GAVGRDIPRT1000C1:9999.990<CR>		
		Average measured RTD input as PT1000 on IO1:9999.990°C		
This command shows for RTD INPUT IO <IONR> the average measured RTD value linearized as PT1000 sensor in °Celsius -999.990: Temperature is lower than 50°C +999.990: Temperature is higher than 130°C All IOs with a different usage type will return 9999.990 to indicate, that no measurement is done.				
<b>RTD INPUTS NI1000-DIN43760 CELSIUS</b>				
GET RTD INPUTS AS NI1000 DIN43760 CELSIUS	ASCII READ COMMAND	#GRTDISNI1000DIN43760C<CR> Result: #GRTDISNI1000DIN43760C:<RTD1DbI>,<RTD2DbI>,<RTD8DbI> <CR>	ASCII	
	TX	#1,GRTDISNI1000DIN43760C<CR>		
	RX	#1,GRTDISNI1000DIN43760C:9999.990,9999.990,9999.990,9999.990,9999.990,9999.990,9999.990,9999.990,9999.990<CR>		
		Actual measured RTD input as NI1000-DIN43760 on IO1:9999.990°C		
		Actual measured RTD input as NI1000-DIN43760 on IO2:9999.990°C		
		Actual measured RTD input as NI1000-DIN43760 on IO3:9999.990°C		
		Actual measured RTD input as NI1000-DIN43760 on IO4:9999.990°C		
		Actual measured RTD input as NI1000-DIN43760 on IO5:9999.990°C		
		Actual measured RTD input as NI1000-DIN43760 on IO6:9999.990°C		
		Actual measured RTD input as NI1000-DIN43760 on IO7:9999.990°C		
		Actual measured RTD input as NI1000-DIN43760 on IO8:9999.990°C		
This command shows for RTD INPUT IOs the actual measured RTD value linearized as NI1000 DIN43760 sensor in °Celsius. -999.990: Temperature is lower than 50°C +999.990: Temperature is higher than 130°C All IOs with a different usage type will return 9999.990 to indicate, that no measurement is done.				
GET RTD INPUT AS NI1000 DIN43760 CELSIUS	ASCII READ COMMAND	#GRTDINI1000DIN43760C<IONR> <CR> Result: #GRTDINI1000DIN43760C<IONR>:<IOxDbI> <CR>	ASCII	
	IONR	1		
	TX	#1,GRTDINI1000DIN43760C1<CR>		
	RX	#1,GRTDINI1000DIN43760C3:9999.990<CR>		
		Actual measured RTD input as NI1000-DIN43760 on IO1:9999.990°C		
This command shows for RTD INPUT IO <IONR> the actual measured RTD value linearized as NI1000 DIN43760 sensor in °Celsius. -999.990: Temperature is lower than 50°C +999.990: Temperature is higher than 130°C All IOs with a different usage type will return 9999.990 to indicate, that no measurement is done.				
GET AVERAGE RTD INPUTS AS NI1000 DIN43760 CELSIUS	ASCII READ COMMAND	#GAVGRDISNI1000DIN43760C<CR> Result: #GAVGRDISNI1000DIN43760C:<RTD1DbI>,<RTD2DbI>,<RTD8DbI> <CR>	ASCII	
	TX	#1,GAVGRDISNI1000DIN43760C<CR>		
	RX	#1,GAVGRDISNI1000DIN43760C:9999.990,9999.990,9999.990,9999.990,9999.990,9999.990,9999.990,9999.990,9999.990<CR>		
		Average measured RTD input as NI1000-DIN43760 on IO1:9999.990°C		
		Average measured RTD input as NI1000-DIN43760 on IO2:9999.990°C		
		Average measured RTD input as NI1000-DIN43760 on IO3:9999.990°C		
		Average measured RTD input as NI1000-DIN43760 on IO4:9999.990°C		

		Average measured RTD input as NI1000-DIN43760 on IO5:9999.990°C		
		Average measured RTD input as NI1000-DIN43760 on IO6:9999.990°C		
		Average measured RTD input as NI1000-DIN43760 on IO7:9999.990°C		
		Average measured RTD input as NI1000-DIN43760 on IO8:9999.990°C		

This command shows for RTD INPUT IOs the average measured RTD value linearized as NI1000 DIN43760 sensor in °Celsius.

-999.990: Temperature is lower than 50°C

+999.990: Temperature is higher than 130°C

All IOs with a different usage type will return 9999.990 to indicate, that no measurement is done.

GET AVG RTD INPUT AS NI1000 DIN43760 CELSIUS	ASCII READ COMMAND	#GAVGRTDINI1000DIN43760C<IONR> <CR> Result: #GAVGRTDINI1000DIN43760C<IONR>:<IOxDbl> <CR>	ASCII	
	IONR	1		
	TX	#1,GAVGRTDINI1000DIN43760C1<CR>		
	RX	#1,GAVGRTDINI1000DIN43760C1:9999.990<CR>		
		Average measured RTD input as NI1000-DIN43760 on IO1:9999.990°C		

This command shows for RTD INPUT IO <IONR> the average measured RTD value linearized as NI1000 DIN43760 sensor in °Celsius

-999.990: Temperature is lower than 50°C

+999.990: Temperature is higher than 130°C

All IOs with a different usage type will return 9999.990 to indicate, that no measurement is done.

#### RTD INPUTS PT100 KELVIN

GET RTD INPUTS AS PT100 KELVIN	ASCII READ COMMAND	#GRTDISPT100K<CR> Result: #GRTDISPT100K:<RTD1Dbl>,<RTD2Dbl>,...,<RTD8Dbl> <CR>	ASCII	
	TX	#1,GRTDISPT100K<CR>		
	RX	#1,GRTDISPT100K:9999.990,9999.990,9999.990,9999.990,9999.990,9999.990,9999.990,9999.990<CR>		
		Actual measured RTD input as PT100 on IO1:9999.990°K		
		Actual measured RTD input as PT100 on IO2:9999.990°K		
		Actual measured RTD input as PT100 on IO3:9999.990°K		
		Actual measured RTD input as PT100 on IO4:9999.990°K		
		Actual measured RTD input as PT100 on IO5:9999.990°K		
		Actual measured RTD input as PT100 on IO6:9999.990°K		
		Actual measured RTD input as PT100 on IO7:9999.990°K		
		Actual measured RTD input as PT100 on IO8:9999.990°K		

This command shows for RTD INPUT IOs the actual measured RTD value linearized as PT100 sensor in °Kelvin

-999.990: Temperature is lower than 223.15°K

+999.990: Temperature is higher than 403.15°K

All IOs with a different usage type will return 9999.990 to indicate, that no measurement is done.

GET RTD INPUT AS PT100 KELVIN	ASCII READ COMMAND	#GRTDIPT100K<IONR> <CR> Result: #GRTDIPT100K<IONR>:<IOxDbl> <CR>	ASCII	
	IONR	1		
	TX	#1,GRTDIPT100K1<CR>		
	RX	#1,GRTDIPT100K3:9999.990<CR>		
		Actual measured RTD input as PT100 on IO1:9999.990°K		

This command shows for RTD INPUT IO <IONR> the actual measured RTD value linearized as PT100 sensor in °Kelvin

-999.990: Temperature is lower than 223.15°K

+999.990: Temperature is higher than 403.15°K

All IOs with a different usage type will return 9999.990 to indicate, that no measurement is done.

GET AVERAGE RTD INPUTS AS PT100 KELVIN	ASCII READ COMMAND	#GAVGRTDISPT100K<CR> Result: #GAVGRTDISPT100K:<RTD1Dbl>,<RTD2Dbl>,,,,,<RTD8Dbl> <CR>	ASCII	
	TX	#1,GAVGRTDISPT100K<CR>		
	RX	#1,GAVGRTDISPT100K:9999.990,9999.990,9999.990,9999.990,9999.990,9999.990,9999.990,9999.990<CR>		
		Average measured RTD input as PT100 on IO1:9999.990°K		
		Average measured RTD input as PT100 on IO2:9999.990°K		
		Average measured RTD input as PT100 on IO3:9999.990°K		
		Average measured RTD input as PT100 on IO4:9999.990°K		
		Average measured RTD input as PT100 on IO5:9999.990°K		
		Average measured RTD input as PT100 on IO6:9999.990°K		
		Average measured RTD input as PT100 on IO7:9999.990°K		
		Average measured RTD input as PT100 on IO8:9999.990°K		

This command shows for RTD INPUT IOs the average measured RTD value linearized as PT100 sensor in °Kelvin

-999.990: Temperature is lower than 223.15°K

+999.990: Temperature is higher than 403.15°K

All IOs with a different usage type will return 9999.990 to indicate, that no measurement is done.

GET AVG RTD INPUT AS PT100 KELVIN	ASCII READ COMMAND	#GAVGRTDIPT100K<IONR> <CR> Result: #GAVGRTDIPT100K<IONR>:<IOxDbl> <CR>	ASCII	
	IONR	1		
	TX	#1,GAVGRTDIPT100K1<CR>		
	RX	#1,GAVGRTDIPT100K1:9999.990<CR>		
		Average measured RTD input as PT100 on IO1:9999.990°K		

This command shows for RTD INPUT IO <IONR> the average measured RTD value linearized as PT100 sensor in °Kelvin

-999.990: Temperature is lower than 223.15°K

+999.990: Temperature is higher than 403.15°K

All IOs with a different usage type will return 9999.990 to indicate, that no measurement is done.

#### RTD INPUTS PT1000 KELVIN

GET RTD INPUTS AS PT1000 KELVIN	ASCII READ COMMAND	#GRTDISPT1000K<CR> Result: #GRTDISPT1000K:<RTD1Dbl>,<RTD2Dbl>,,,,,<RTD8Dbl> <CR>	ASCII	
	TX	#1,GRTDISPT1000K<CR>		
	RX	#1,GRTDISPT1000K:9999.990,9999.990,9999.990,9999.990,9999.990,9999.990,9999.990,9999.990<CR>		
		Actual measured RTD input as PT1000 on IO1:9999.990°K		
		Actual measured RTD input as PT1000 on IO2:9999.990°K		
		Actual measured RTD input as PT1000 on IO3:9999.990°K		
		Actual measured RTD input as PT1000 on IO4:9999.990°K		
		Actual measured RTD input as PT1000 on IO5:9999.990°K		
		Actual measured RTD input as PT1000 on IO6:9999.990°K		
		Actual measured RTD input as PT1000 on IO7:9999.990°K		

		Actual measured RTD input as PT1000 on IO8:9999.990°K		
<p>This command shows for RTD INPUT IOs the actual measured RTD value linearized as PT1000 sensor in °Kelvin  -999.990: Temperature is lower than 223.15°K  +999.990: Temperature is higher than 403.15°K  All IOs with a different usage type will return 9999.990 to indicate, that no measurement is done.</p>				
GET RTD INPUT AS PT1000 KELVIN	ASCII READ COMMAND	#GRTDIPT1000K<IONR> <CR> Result: #GRTDIPT1000K<IONR>:<IOxDbl> <CR>	ASCII	
	IONR	1		
	TX	#1,GRTDIPT1000K1<CR>		
	RX	#1,GRTDIPT1000K3:9999.990<CR>		
		Actual measured RTD input as PT1000 on IO1:9999.990°K		
<p>This command shows for RTD INPUT IO &lt;IONR&gt; the actual measured RTD value linearized as PT1000 sensor in °Kelvin  -999.990: Temperature is lower than 223.15°K  +999.990: Temperature is higher than 403.15°K  All IOs with a different usage type will return 9999.990 to indicate, that no measurement is done.</p>				
GET AVERAGE RTD INPUTS AS PT1000 KELVIN	ASCII READ COMMAND	#GAVGRTDISPT1000K<CR> Result: #GAVGRTDISPT1000K:<RTD1Dbl>,<RTD2Dbl>,...,<RTD8Dbl> <CR>	ASCII	
	TX	#1,GAVGRTDISPT1000K<CR>		
	RX	#1,GAVGRTDISPT1000K:9999.990,9999.990,9999.990,9999.990,9999.990,9999.990,9999.990,9999.990<CR>		
		Average measured RTD input as PT1000 on IO1:9999.990°K		
		Average measured RTD input as PT1000 on IO2:9999.990°K		
		Average measured RTD input as PT1000 on IO3:9999.990°K		
		Average measured RTD input as PT1000 on IO4:9999.990°K		
		Average measured RTD input as PT1000 on IO5:9999.990°K		
		Average measured RTD input as PT1000 on IO6:9999.990°K		
		Average measured RTD input as PT1000 on IO7:9999.990°K		
		Average measured RTD input as PT1000 on IO8:9999.990°K		
<p>This command shows for RTD INPUT IOs the average measured RTD value linearized as PT1000 sensor in °Kelvin  -999.990: Temperature is lower than 223.15°K  +999.990: Temperature is higher than 403.15°K  All IOs with a different usage type will return 9999.990 to indicate, that no measurement is done.</p>				
GET AVG RTD INPUT AS PT1000 KELVIN	ASCII READ COMMAND	#GAVGRTDIPT1000K<IONR> <CR> Result: #GAVGRTDIPT1000K<IONR>:<IOxDbl> <CR>	ASCII	
	IONR	1		
	TX	#1,GAVGRTDIPT1000K1<CR>		
	RX	#1,GAVGRTDIPT1000K1:9999.990<CR>		
		Average measured RTD input as PT1000 on IO1:9999.990°K		
<p>This command shows for RTD INPUT IO &lt;IONR&gt; the average measured RTD value linearized as PT1000 sensor in °Kelvin  -999.990: Temperature is lower than 223.15°K  +999.990: Temperature is higher than 403.15°K  All IOs with a different usage type will return 9999.990 to indicate, that no measurement is done.</p>				
RTD INPUTS NI1000-DIN43760 KELVIN				

GET RTD INPUTS AS NI1000 DIN43760 KELVIN	ASCII READ COMMAND	#GRTDISNI1000DIN43760K<CR> Result: #GRTDISNI1000DIN43760K:<RTD1DbI>,<RTD2DbI>,...,<RTD8DbI><CR>	ASCII	
	TX	#1,GRTDISNI1000DIN43760K<CR>		
	RX	#1,GRTDISNI1000DIN43760K:9999.990,9999.990,9999.990,9999.990,9999.990,9999.990,9999.990,9999.990<CR>		
		Actual measured RTD input as NI1000-DIN43760 on IO1:9999.990°K		
		Actual measured RTD input as NI1000-DIN43760 on IO2:9999.990°K		
		Actual measured RTD input as NI1000-DIN43760 on IO3:9999.990°K		
		Actual measured RTD input as NI1000-DIN43760 on IO4:9999.990°K		
		Actual measured RTD input as NI1000-DIN43760 on IO5:9999.990°K		
		Actual measured RTD input as NI1000-DIN43760 on IO6:9999.990°K		
		Actual measured RTD input as NI1000-DIN43760 on IO7:9999.990°K		
		Actual measured RTD input as NI1000-DIN43760 on IO8:9999.990°K		

This command shows for RTD INPUT IOs the actual measured RTD value linearized as NI1000 DIN43760 sensor in °Kelvin

-999.990: Temperature is lower than 223.15°K

+999.990: Temperature is higher than 403.15°K

All IOs with a different usage type will return 9999.990 to indicate, that no measurement is done.

GET RTD INPUT AS NI1000 DIN43760 KELVIN	ASCII READ COMMAND	#GRTDINI1000DIN43760K<IONR><CR> Result: #GRTDINI1000DIN43760K<IONR>:<IOxDbI><CR>	ASCII	
	IONR	1		
	TX	#1,GRTDINI1000DIN43760K1<CR>		
	RX	#1,GRTDINI1000DIN43760K3:9999.990<CR>		
		Actual measured RTD input as NI1000-DIN43760 on IO1:9999.990°K		

This command shows for RTD INPUT IO <IONR> the actual measured RTD value linearized as NI1000 DIN43760 sensor in °Kelvin

-999.990: Temperature is lower than 223.15°K

+999.990: Temperature is higher than 403.15°K

All IOs with a different usage type will return 9999.990 to indicate, that no measurement is done.

GET AVERAGE RTD INPUTS AS NI1000 DIN43760 KELVIN	ASCII READ COMMAND	#GAVGRTDISNI1000DIN43760K<CR> Result: #GAVGRTDISNI1000DIN43760K:<RTD1DbI>,<RTD2DbI>,...,<RTD8DbI><CR>	ASCII	
	TX	#1,GAVGRTDISNI1000DIN43760K<CR>		
	RX	#1,GAVGRTDISNI1000DIN43760K:9999.990,9999.990,9999.990,9999.990,9999.990,9999.990,9999.990,9999.990<CR>		
		Average measured RTD input as NI1000-DIN43760 on IO1:9999.990°K		
		Average measured RTD input as NI1000-DIN43760 on IO2:9999.990°K		
		Average measured RTD input as NI1000-DIN43760 on IO3:9999.990°K		
		Average measured RTD input as NI1000-DIN43760 on IO4:9999.990°K		
		Average measured RTD input as NI1000-DIN43760 on IO5:9999.990°K		
		Average measured RTD input as NI1000-DIN43760 on IO6:9999.990°K		
		Average measured RTD input as NI1000-DIN43760 on IO7:9999.990°K		
		Average measured RTD input as NI1000-DIN43760 on IO8:9999.990°K		

This command shows for RTD INPUT IOs the average measured RTD value linearized as NI1000 DIN43760 sensor in °Kelvin

-999.990: Temperature is lower than 223.15°K

+999.990: Temperature is higher than 403.15°K

All IOs with a different usage type will return 9999.990 to indicate, that no measurement is done.

GET AVG RTD INPUT AS NI1000 DIN43760 KELVIN	ASCII READ COMMAND	#GAVGRTDINI1000DIN43760K<IONR><CR> Result: #GAVGRTDINI1000DIN43760K<IONR>:<IOxDbl><CR>	ASCII	
	IONR	1		
	TX	#1,GAVGRTDINI1000DIN43760K1<CR>		
	RX	#1,GAVGRTDINI1000DIN43760K1.9999.990<CR>		
		Average measured RTD input as NI1000-DIN43760 on IO1:9999.990°K		
This command shows for RTD INPUT IO <IONR> the average measured RTD value linearized as NI1000 DIN43760 sensor in °Kelvin -999.990: Temperature is lower than 223.15°K +999.990: Temperature is higher than 403.15°K All IOs with a different usage type will return 9999.990 to indicate, that no measurement is done.				
<b>RTD INPUTS PT100 FAHRENHEIT</b>				
GET RTD INPUTS AS PT100 FAHRENHEIT	ASCII READ COMMAND	#GRTDISPT100F<CR> Result: #GRTDISPT100F:<RTD1Dbl>,<RTD2Dbl>,<RTD8Dbl><CR>	ASCII	
	TX	#1,GRTDISPT100F<CR>		
	RX	#1,GRTDISPT100F:9999.990,9999.990,9999.990,9999.990,9999.990,9999.990,9999.990,9999.990<CR>		
		Actual measured RTD input as PT100 on IO1:9999.990°F		
		Actual measured RTD input as PT100 on IO2:9999.990°F		
		Actual measured RTD input as PT100 on IO3:9999.990°F		
		Actual measured RTD input as PT100 on IO4:9999.990°F		
		Actual measured RTD input as PT100 on IO5:9999.990°F		
		Actual measured RTD input as PT100 on IO6:9999.990°F		
		Actual measured RTD input as PT100 on IO7:9999.990°F		
		Actual measured RTD input as PT100 on IO8:9999.990°F		
This command shows for RTD INPUT IOs the actual measured RTD value linearized as PT100 sensor in °Fahrenheit -999.990: Temperature is lower than -58°F +999.990: Temperature is higher than 266°F All IOs with a different usage type will return 9999.990 to indicate, that no measurement is done.				
GET RTD INPUT AS PT100 FAHRENHEIT	ASCII READ COMMAND	#GRTDIPT100F<IONR><CR> Result: #GRTDIPT100F<IONR>:<IOxDbl><CR>	ASCII	
	IONR	1		
	TX	#1,GRTDIPT100F1<CR>		
	RX	#1,GRTDIPT100F3:9999.990<CR>		
		Actual measured RTD input as PT100 on IO1:9999.990°F		
This command shows for RTD INPUT IO <IONR> the actual measured RTD value linearized as PT100 sensor in °Fahrenheit -999.990: Temperature is lower than -58°F +999.990: Temperature is higher than 266°F All IOs with a different usage type will return 9999.990 to indicate, that no measurement is done.				
GET AVERAGE RTD INPUTS AS PT100 FAHRENHEIT	ASCII READ COMMAND	#GAVGRTDISPT100F<CR> Result: #GAVGRTDISPT100F:<RTD1Dbl>,<RTD2Dbl>,<RTD8Dbl><CR>	ASCII	
	TX	#1,GAVGRTDISPT100F<CR>		
	RX	#1,GAVGRTDISPT100F:9999.990,9999.990,9999.990,9999.990,9999.990,9999.990,9999.990,9999.990<CR>		

		Average measured RTD input as PT100 on IO1:9999.990°F		
		Average measured RTD input as PT100 on IO2:9999.990°F		
		Average measured RTD input as PT100 on IO3:9999.990°F		
		Average measured RTD input as PT100 on IO4:9999.990°F		
		Average measured RTD input as PT100 on IO5:9999.990°F		
		Average measured RTD input as PT100 on IO6:9999.990°F		
		Average measured RTD input as PT100 on IO7:9999.990°F		
		Average measured RTD input as PT100 on IO8:9999.990°F		

This command shows for RTD INPUT IOs the average measured RTD value linearized as PT100 sensor in °Fahrenheit

-999.990: Temperature is lower than -58°F

+999.990: Temperature is higher than 266°F

All IOs with a different usage type will return 9999.990 to indicate, that no measurement is done.

GET AVG RTD INPUT AS PT100 FAHRENHEIT	ASCII READ COMMAND	#GAVGRTDIPT100F<IONR> <CR> Result: #GAVGRTDIPT100F<IONR>:<IOxDbl> <CR>	ASCII	
	IONR	1		
	TX	#1,GAVGRTDIPT100F1<CR>		
	RX	#1,GAVGRTDIPT100F1:9999.990<CR>		
		Average measured RTD input as PT100 on IO1:9999.990°F		

This command shows for RTD INPUT IO <IONR> the average measured RTD value linearized as PT100 sensor in °Fahrenheit

-999.990: Temperature is lower than -58°F

+999.990: Temperature is higher than 266°F

All IOs with a different usage type will return 9999.990 to indicate, that no measurement is done.

#### RTD INPUTS PT1000 FAHRENHEIT

GET RTD INPUTS AS PT1000 FAHRENHEIT	ASCII READ COMMAND	#GRTDISPT1000F<CR> Result: #GRTDISPT1000F:<RTD1DbI>,<RTD2DbI>,...,<RTD8DbI> <CR>	ASCII	
	TX	#1,GRTDISPT1000F<CR>		
	RX	#1,GRTDISPT1000F:9999.990,9999.990,9999.990,9999.990,9999.990,9999.990,9999.990,9999.990<CR>		
		Actual measured RTD input as PT1000 on IO1:9999.990°F		
		Actual measured RTD input as PT1000 on IO2:9999.990°F		
		Actual measured RTD input as PT1000 on IO3:9999.990°F		
		Actual measured RTD input as PT1000 on IO4:9999.990°F		
		Actual measured RTD input as PT1000 on IO5:9999.990°F		
		Actual measured RTD input as PT1000 on IO6:9999.990°F		
		Actual measured RTD input as PT1000 on IO7:9999.990°F		
		Actual measured RTD input as PT1000 on IO8:9999.990°F		

This command shows for RTD INPUT IOs the actual measured RTD value linearized as PT1000 sensor in °Fahrenheit

-999.990: Temperature is lower than -58°F

+999.990: Temperature is higher than 266°F

All IOs with a different usage type will return 9999.990 to indicate, that no measurement is done.

GET RTD INPUT AS PT1000 FAHRENHEIT	ASCII READ COMMAND	#GRTDIPT1000F<IONR> <CR> Result: #GRTDIPT1000F<IONR>:<IOxDbl> <CR>	ASCII	
	IONR	1		
	TX	#1,GRTDIPT1000F1<CR>		



	RX	#1,GRTDIPT1000F3:9999.990<CR>		
		Actual measured RTD input as PT1000 on IO1:9999.990°F		
This command shows for RTD INPUT IO <IONR> the actual measured RTD value linearized as PT1000 sensor in °Fahrenheit -999.990: Temperature is lower than -58°F +999.990: Temperature is higher than 266°F All IOs with a different usage type will return 9999.990 to indicate, that no measurement is done.				
GET AVERAGE RTD INPUTS AS PT1000 FAHRENHEIT	ASCII READ COMMAND	#GAVGRTDISPT1000F<CR> Result: #GAVGRTDISPT1000F:<RTD1DbI>,<RTD2DbI>,...,<RTD8DbI> <CR>	ASCII	
	TX	#1,GAVGRTDISPT1000F<CR>		
	RX	#1,GAVGRTDISPT1000F:9999.990,9999.990,9999.990,9999.990,9999.990,9999.990,9999.990,9999.990<CR>		
		Average measured RTD input as PT1000 on IO1:9999.990°F		
		Average measured RTD input as PT1000 on IO2:9999.990°F		
		Average measured RTD input as PT1000 on IO3:9999.990°F		
		Average measured RTD input as PT1000 on IO4:9999.990°F		
		Average measured RTD input as PT1000 on IO5:9999.990°F		
		Average measured RTD input as PT1000 on IO6:9999.990°F		
		Average measured RTD input as PT1000 on IO7:9999.990°F		
		Average measured RTD input as PT1000 on IO8:9999.990°F		
This command shows for RTD INPUT IOs the average measured RTD value linearized as PT1000 sensor in °Fahrenheit -999.990: Temperature is lower than -58°F +999.990: Temperature is higher than 266°F All IOs with a different usage type will return 9999.990 to indicate, that no measurement is done.				
GET AVG RTD INPUT AS PT1000 FAHRENHEIT	ASCII READ COMMAND	#GAVGRTDIPT1000F<IONR> <CR> Result: #GAVGRTDIPT1000F<IONR>:<IOxDbI> <CR>	ASCII	
	IONR	1		
	TX	#1,GAVGRTDIPT1000F1<CR>		
	RX	#1,GAVGRTDIPT1000F1:9999.990<CR>		
		Average measured RTD input as PT1000 on IO1:9999.990°F		
This command shows for RTD INPUT IO <IONR> the average measured RTD value linearized as PT1000 sensor in °Fahrenheit -999.990: Temperature is lower than -58°F +999.990: Temperature is higher than 266°F All IOs with a different usage type will return 9999.990 to indicate, that no measurement is done.				
<b>RTD INPUTS NI1000-DIN43760 FAHRENHEIT</b>				
GET RTD INPUTS AS NI1000 DIN43760 FAHRENHEIT	ASCII READ COMMAND	#GRTDISNI1000DIN43760F<CR> Result: #GRTDISNI1000DIN43760F:<RTD1DbI>,<RTD2DbI>,...,<RTD8DbI> <CR>	ASCII	
	TX	#1,GRTDISNI1000DIN43760F<CR>		
	RX	#1,GRTDISNI1000DIN43760F:9999.990,9999.990,9999.990,9999.990,9999.990,9999.990,9999.990,9999.990<CR>		
		Actual measured RTD input as NI1000-DIN43760 on IO1:9999.990°F		
		Actual measured RTD input as NI1000-DIN43760 on IO2:9999.990°F		
		Actual measured RTD input as NI1000-DIN43760 on IO3:9999.990°F		
		Actual measured RTD input as NI1000-DIN43760 on IO4:9999.990°F		
		Actual measured RTD input as NI1000-DIN43760 on IO5:9999.990°F		

		Actual measured RTD input as NI1000-DIN43760 on IO6:9999.990°F		
		Actual measured RTD input as NI1000-DIN43760 on IO7:9999.990°F		
		Actual measured RTD input as NI1000-DIN43760 on IO8:9999.990°F		
This command shows for RTD INPUT IOs the actual measured RTD value linearized as NI1000 DIN43760 sensor in °Fahrenheit -999.990: Temperature is lower than -58°F +999.990: Temperature is higher than 266°F All IOs with a different usage type will return 9999.990 to indicate, that no measurement is done.				
GET RTD INPUT AS NI1000 DIN43760 FARENEHEIT	ASCII READ COMMAND	#GRTDINI1000DIN43760F<IONR><CR> Result: #GRTDINI1000DIN43760F<IONR>:<IOxDBl><CR>	ASCII	
	IONR	1		
	TX	#1,GRTDINI1000DIN43760F1<CR>		
	RX	#1,GRTDINI1000DIN43760F3:9999.990<CR>		
		Actual measured RTD input as NI1000-DIN43760 on IO1:9999.990°F		
This command shows for RTD INPUT IO <IONR> the actual measured RTD value linearized as NI1000 DIN43760 sensor in °Fahrenheit -999.990: Temperature is lower than -58°F +999.990: Temperature is higher than 266°F All IOs with a different usage type will return 9999.990 to indicate, that no measurement is done.				
GET AVERAGE RTD INPUTS AS NI1000 DIN43760 FARENEHEIT	ASCII READ COMMAND	#GAVGRTDISNI1000DIN43760F<CR> Result: #GAVGRTDISNI1000DIN43760F:<RTD1DbI>,<RTD2DbI>,...,<RTD8DbI><CR>	ASCII	
	TX	#1,GAVGRTDISNI1000DIN43760F<CR>		
	RX	#1,GAVGRTDISNI1000DIN43760F:9999.990,9999.990,9999.990,9999.990,9999.990,9999.990,9999.990,9999.990<CR>		
		Average measured RTD input as NI1000-DIN43760 on IO1:9999.990°F		
		Average measured RTD input as NI1000-DIN43760 on IO2:9999.990°F		
		Average measured RTD input as NI1000-DIN43760 on IO3:9999.990°F		
		Average measured RTD input as NI1000-DIN43760 on IO4:9999.990°F		
		Average measured RTD input as NI1000-DIN43760 on IO5:9999.990°F		
		Average measured RTD input as NI1000-DIN43760 on IO6:9999.990°F		
		Average measured RTD input as NI1000-DIN43760 on IO7:9999.990°F		
		Average measured RTD input as NI1000-DIN43760 on IO8:9999.990°F		
This command shows for RTD INPUT IOs the average measured RTD value linearized as NI1000 DIN43760 sensor in °Fahrenheit -999.990: Temperature is lower than -58°F +999.990: Temperature is higher than 266°F All IOs with a different usage type will return 9999.990 to indicate, that no measurement is done.				
GET AVG RTD INPUT AS NI1000 DIN43760 FARENEHEIT	ASCII READ COMMAND	#GAVGRTDINI1000DIN43760F<IONR><CR> Result: #GAVGRTDINI1000DIN43760F<IONR>:<IOxDBl><CR>	ASCII	
	IONR	1		
	TX	#1,GAVGRTDINI1000DIN43760F1<CR>		
	RX	#1,GAVGRTDINI1000DIN43760F1:9999.990<CR>		
		Average measured RTD input as NI1000-DIN43760 on IO1:9999.990°F		
This command shows for RTD INPUT IO <IONR> the average measured RTD value linearized as NI1000 DIN43760 sensor in °Fahrenheit -999.990: Temperature is lower than -58°F +999.990: Temperature is higher than 266°F All IOs with a different usage type will return 9999.990 to indicate, that no measurement is done.				

Register NAME Command NAME	MODBUS Register ASCII Command	Register VALUE ASCII Command	NEW REAL VALUE	NEW VALUE	DATA TYPE	DO WRITE
<b>ASCII COMMANDS</b>						
<b>INTER PROCESSOR COMMUNICATION</b>						
AIOX IS ONLINE	ASCII READ COMMAND	#G16AIOXISONLINE<CR> Result: #G16AIOXISONLINE:<YesNo><CR>			ASCII	
	TX	#1,G16AIOXISONLINE<CR>				
	RX	#1,G16AIOXISONLINE:YES<CR>				
		Actual communication state co-processor to AIOX processor:YES				
This command returns the actual state of the serial communication between the ARM co-processor and the additional processor for the AIOX. YES: Currently the communication is fine NO: There is a mayor problem/hardware fault between the two processors						
<b>CHIP COMMUNICATION</b>						
ARE CHIPS ONLINE	ASCII READ COMMAND	#ARECHIPSONLINE<CR> Result: #ARECHIPSONLINE:<Chip1IsOnline>,<Chip2IsOnline><CR>			ASCII	
	TX	#1,ARECHIPSONLINE<CR>				
	RX	#1,ARECHIPSONLINE:1,1<CR>				
		Actual state of CHIP1:1				
		Actual state of CHIP2:1				
This command shows the current SPI communication status with each chip. ChipxIsOnline: =0: Currently there is a SPI error in the communication and the chip is offline =1: The SPI communication with the chip is ok						
IS CHIPx ONLINE	ASCII READ COMMAND	#ISCHIPONLINE<CHIPNR><CR> Result: #ISCHIPONLINE<CHIPNR>:<ChipxIsOnline><CR>			ASCII	
	CHIPNR	1				
	TX	#1,ISCHIPONLINE1<CR>				
	RX	#1,ISCHIPONLINE1:1<CR>				
		Actual state of CHIP1:1				
This command shows the current SPI communication status with chip <CHIPNR>. =0: Currently there is a SPI error in the communication and the chip is offline =1: The SPI communication with the chip is ok						
GET ALL SPI ERRORS	ASCII READ COMMAND	#GASPIERRS<CR> Result: #GASPIERRS:<SPI1ErrDec>,<SPI2ErrDec>,<SPI1ErrHex>,<SPI2ErrHex><CR>			ASCII	
	TX	#1,GASPIERRS<CR>				
	RX	#1,GASPIERRS:0,0,0x0,0x0<CR>				
		Actual SPI errors of CHIP1:0				
		Actual SPI errors of CHIP2:0				
This command shows the acutal SPI errors since power up for every chip						

GET SPI ERROR	ASCII READ COMMAND	#GSPERR<CHIPNR><CR> Result: #GSPERR<CHIPNR>:<SPlexErrDec>,<SPlexErrHex><CR>	ASCII	
	CHIPNR	1		
	TX	#1,GSPERR1<CR>		
	RX	#1,GSPERR1:0,0x0<CR>		
		Actual SPI errors of CHIP1:0		
This command shows the actual SPI errors since power up for chip <CHIPNR>				
GET CHIP STATEMACHINES	ASCII READ COMMAND	#GCHIPSMS<CR> Result: #GCHIPSMS:<Chip1StateMachine>,<Chip2StateMachine><CR>	ASCII	
	TX	#1,GCHIPSMS<CR>		
	RX	#1,GCHIPSMS:12090,12090<CR>		
		Actual state of CHIP1:12090		
		Actual state of CHIP2:12090		
This command shows the actual state of the internal communication state machine for all chips				
GET CHIP STATEMACHINE	ASCII READ COMMAND	#GCHIPSM<CHIPNR><CR> Result: #GCHIPSM<CHIPNR>:<ChipxStateMachine><CR>	ASCII	
	CHIPNR	1		
	TX	#1,GCHIPSM1<CR>		
	RX	#1,GCHIPSM1:12010<CR>		
		Actual state of CHIP1:12010		
This command shows the actual state of the internal communication state machine for chip <CHIPNR>				
RESET CHIP STATEMACHINE	ASCII WRITE COMMAND	#RCHIPSM<CHIPNR><CR> Result: #OK<CR>	ASCII	YES
	CHIPNR	1		
	TX	#1,RCHIPSM1<CR>		
	RX	N/A		
This command restarts the state machine for chip <CHIPNR>. The affected chip will be resetted & initialized completely				
<b>CHIP STATUS</b>				
GET ALL LIVE STATES	ASCII READ COMMAND	#GALSTATES<CR> Result: #GALSTATE:<Chip1LiveStateDec>,<Chip2LiveStateDec>, <Chip1LiveStateHex>,<Chip2LiveStateHex><CR>	ASCII	
	TX	#1,GALSTATES<CR>		
	RX	#1,GALSTATES:27648,30720,0x6C00,0x7800<CR>		
		Actual live state of CHIP1:27648,0x6C00		
		Actual live state of CHIP2:30720,0x7800		

Returns the actual chip status of all chips.

Each result bit stands for a different state:

Bit 0: VI\_ERR\_CURR\_A: Status of channel A:Voltage or current error detected on Channel A. This bit is interpreted differently depending on which of the following IO function selected:

Voltage output: short-circuit error. The error condition is debounced for 2 ms before the status bit is set.

Current output: open circuit error. The error condition is debounced for 2 ms before the status bit is set.

Current input, loop powered: short-circuit error. A short to ground is detected

Current input, externally powered: short-circuit error. A current source >25 mA is detected

Bit 1: VI\_ERR\_CURR\_B: Status of voltage input B. Same like VI\_ERR\_CURR\_A

Bit 2: VI\_ERR\_CURR\_C: Status of voltage input C. Same like VI\_ERR\_CURR\_A

Bit 3: VI\_ERR\_CURR\_D: Status of voltage input D. Same like VI\_ERR\_CURR\_A

Bit 4: HI\_TEMP\_STATUS: If the die temperature is typically at or above 115°C, the HI\_TEMP\_STATUS bit is asserted

Bit 5: CHARGE\_PUMP\_STATUS: Charge pump error detected.

Bit 6: ALDO5V\_STATUS: ALDO5V Power Supply Monitor Error. This bit is asserted when the ALDO5V pin falls below 4.05 V. Usually ~5V.

Bit 7: AVDD\_STATUS: AVDD Power Supply Monitor Error. This bit is asserted when the AVDD pin falls below 9.26 V. Usually ~17V.

Bit 8: DVCC\_STATUS: DVCC Power Supply Monitor Error. This bit is asserted when the DVCC pin falls below 1.93 V. Usually ~3.3V.

Bit 9: ALDO1V8\_STATUS: ALDO1V8 Power Supply Monitor Error. This bit is asserted when the ALDO1V8 pin falls below 1.35 V. Usually ~1.8V.

Bit 10-12: ADC\_CH\_CURR: Current converted channel of the ADC (0:A, 1:B, 2:C, 3:D, 4:Diagnostic 0, 5:Diagnostic 1, 6:Diagnostic 2, 7:Diagnostic 3)

Bit 13: ADC\_BUSY: ADC busy status bit.

Bit 14: ADC\_DATA\_RDY:ADC data ready. The ADC\_DATA\_RDY bit asserts when a conversion cycle has completed. The bit stays asserted until a user writes 1 to clear the bit. In single conversion mode, the ADC\_RDY pin follows the ADC\_DATA\_RDY bit and only deasserts when the ADC\_DATA\_RDY bit is cleared. In continuous conversion mode, the ADC\_RDY pin returns high after 24 µs.

Bit 15: RESERVED: Reserved

GET LIVE STATE	ASCII READ COMMAND	#GLSTATE<CHIPNR> <CR> Result: #GLSTATE<CHIPNR>:<ChipxLiveDataDec>,<ChipxLiveDataHex> <CR>	ASCII
	CHIPNR	1	
	TX	#1,GLSTATE1<CR>	
	RX	#1,GLSTATE4:29696,0x7400<CR>	
		Actual live state of CHIP1:29696,0x7400	
		Live state bit 0: VI_ERR_CURR_A:0	
		Live state bit 1: VI_ERR_CURR_B:0	
		Live state bit 2: VI_ERR_CURR_C:0	
		Live state bit 3: VI_ERR_CURR_D:0	
		Live state bit 4: HI_TEMP_STATUS:0	
		Live state bit 5: CHARGE_PUMP_STATUS:0	
		Live state bit 6: ALDO5V_STATUS:0	
		Live state bit 7: AVDD_STATUS:0	
		Live state bit 8: DVCC_STATUS:0	
		Live state bit 9: ALDO1V8_STATUS:0	
		Live state bit 10-12: ADC_CH_CURR:5	
		Live state bit 13: ADC_BUSY:1	
		Live state bit 14: ADC_DATA_RDY:0	
		Live state bit 15: RESERVED:0	

Returns the actual chip status of chip <CHIPNR>

Each result bit stands for a different state:

Bit 0: VI\_ERR\_CURR\_A: Status of channel A:Voltage or current error detected on Channel A. This bit is interpreted differently depending on which of the following IO function selected:

Voltage output: short-circuit error. The error condition is debounced for 2 ms before the status bit is set.

Current output: open circuit error. The error condition is debounced for 2 ms before the status bit is set.

Current input, loop powered: short-circuit error. A short to ground is detected

Current input, externally powered: short-circuit error. A current source >25 mA is detected

Bit 1: VI\_ERR\_CURR\_B: Status of voltage input B. Same like VI\_ERR\_CURR\_A

Bit 2: VI\_ERR\_CURR\_C: Status of voltage input C. Same like VI\_ERR\_CURR\_A

Bit 3: VI\_ERR\_CURR\_D: Status of voltage input D. Same like VI\_ERR\_CURR\_A

Bit 4: HI\_TEMP\_STATUS: If the die temperature is typically at or above 115°C, the HI\_TEMP\_STATUS bit is asserted

Bit 5: CHARGE\_PUMP\_STATUS: Charge pump error detected.

Bit 6: ALDO5V\_STATUS: ALDO5V Power Supply Monitor Error. This bit is asserted when the ALDO5V pin falls below 4.05 V. Usually ~5V.

Bit 7: AVDD\_STATUS: AVDD Power Supply Monitor Error. This bit is asserted when the AVDD pin falls below 9.26 V. Usually ~17V.

Bit 8: DVCC\_STATUS: DVCC Power Supply Monitor Error. This bit is asserted when the DVCC pin falls below 1.93 V. Usually ~3.3V.

Bit 9: ALDO1V8\_STATUS: ALDO1V8 Power Supply Monitor Error. This bit is asserted when the ALDO1V8 pin falls below 1.35 V. Usually ~1.8V.

Bit 10-12: ADC\_CH\_CURR: Current converted channel of the ADC (0:A, 1:B, 2:C, 3:D, 4:Diagnostic 0, 5:Diagnostic 1, 6:Diagnostic 2, 7:Diagnostic 3)

Bit 13: ADC\_BUSY: ADC busy status bit.

Bit 14: ADC\_DATA\_RDY:ADC data ready. The ADC\_DATA\_RDY bit asserts when a conversion cycle has completed. The bit stays asserted until a user writes 1 to clear the bit. In single conversion mode, the ADC\_RDY pin follows the ADC\_DATA\_RDY bit and only deasserts when the ADC\_DATA\_RDY bit is cleared. In continuous conversion mode, the ADC\_RDY pin returns high after 24 µs.

Bit 15: RESERVED: Reserved

GET ALL ALERT STATES	ASCII READ COMMAND	#GAASTATES<CR> Result: #GAASTATES:<Chip1AlertStateDec>,<Chip2AlertStateDec>, <Chip1AlertStateHex>,<Chip2AlertStateHex> <CR>	ASCII	
	TX	#1,GAASTATES<CR>		
	RX	#1,GAASTATES:33792,33792,0x8400,0x8400<CR>		
		Actual alert state of CHIP1:33792,0x8400		
		Actual alert state of CHIP2:33792,0x8400		

Returns the actual alert states for all chips.

Each result bit stands for a different state:

Bit 0: VI\_ERR\_CURR\_A: Status of channel A:Voltage or current error detected on Channel A. This bit is interpreted differently depending on which of the following IO function selected:

Voltage output: short-circuit error. The error condition is debounced for 2 ms before the status bit is set.

Current output: open circuit error. The error condition is debounced for 2 ms before the status bit is set.

Current input, loop powered: short-circuit error. A short to ground is detected

Current input, externally powered: short-circuit error. A current source >25 mA is detected

Bit 1: VI\_ERR\_CURR\_B: Status of voltage input B. Same like VI\_ERR\_CURR\_A

Bit 2: VI\_ERR\_CURR\_C: Status of voltage input C. Same like VI\_ERR\_CURR\_A

Bit 3: VI\_ERR\_CURR\_D: Status of voltage input D. Same like VI\_ERR\_CURR\_A

Bit 4: HI\_TEMP\_STATUS: If the die temperature is typically at or above 115°C, the HI\_TEMP\_STATUS bit is asserted

Bit 5: CHARGE\_PUMP\_STATUS: Charge pump error detected.

Bit 6: ALDO5V\_STATUS: ALDO5V Power Supply Monitor Error. This bit is asserted when the ALDO5V pin falls below 4.05 V. Usually ~5V.

Bit 7: AVDD\_STATUS: AVDD Power Supply Monitor Error. This bit is asserted when the AVDD pin falls below 9.26 V. Usually ~17V.

Bit 8: DVCC\_STATUS: DVCC Power Supply Monitor Error. This bit is asserted when the DVCC pin falls below 1.93 V. Usually ~3.3V.

Bit 9: ALDO1V8\_STATUS: ALDO1V8 Power Supply Monitor Error. This bit is asserted when the ALDO1V8 pin falls below 1.35 V. Usually ~1.8V.

Bit 10: ADC\_CONV\_ERR: ADC Conversion Error. ADC results may be outside the selected measurement range.

Bit 11: ADC\_SAT\_ERR: ADC Saturation Error. ADC may be outside the user selected measurement range.

Bit 12: SPI\_SCLK\_CNT\_ERR: SPI SCLK count error detected. This bit is asserted if an SPI command is applied but 32 SCLKs are not provided.

Bit 13: SPI\_CRC\_ERR: SPI CRC error detected. This bit is asserted if an invalid CRC is received.

Bit 14: CAL\_MEM\_ERR: Calibration Memory Error. This flag asserts under the following two conditions: When a calibration memory CRC error or an uncorrectable error correcting code (ECC) error is detected on the calibration memory upload. It is not possible to clear this bit if there is a CRC error or uncorrectable ECC error. It is recommended to reset the device and check the supplies in this situation. When there is an attempted SPI access to a register before the calibration memory refresh is complete. Do not address the device until the calibration memory is refreshed. Writing 1 to this bit clears the flag, if the flag is asserted due to this condition.

Bit 15: RESET\_OCCURRED: Reset occurred. This bit is asserted after a reset event, which asserts the ALERT pin after the reset. Write a 1 to this bit to clear the flag. Note that a mask bit is not provided for this bit.

GET ALERT STATE	ASCII READ COMMAND	#GASTATE<CHIPNR><CR> Result: #GASTATE<CHIPNR>:<ChipxAlertState><CR>	ASCII	
	CHIPNR	1		
	TX	#1,GASTATE1<CR>		
	RX	#1,GASTATE4:33792,0x8400<CR>		
		Actual alert state of CHIP1:33792,0x8400		
		Alert state bit 0: VI_ERR_A:0		
		Alert state bit 1: VI_ERR_B:0		
		Alert state bit 2: VI_ERR_C:0		
		Alert state bit 3: VI_ERR_D:0		
		Alert state bit 4: HI_TEMP_ERR:0		
		Alert state bit 5: CHARGE_PUMP_ERR:0		
		Alert state bit 6: ALDO5V_ERR:0		
		Alert state bit 7: AVDD_ERR:0		
		Alert state bit 8: DVCC_ERR:0		
		Alert state bit 9: ALDO1V8_ERR:0		
		Alert state bit 10: ADC_CONV_ERR:1		
		Alert state bit 11: ADC_SAT_ERR:0		
		Alert state bit 12: SPI_SCLK_CNT_ERR:0		
		Alert state bit 13: SPI_CRC_ERR:0		
		Alert state bit 14: CAL_MEM_ERR:0		
		Alert state bit 15: RESET OCCURED:0		

Returns the actual alert states for chip <CHIPNR>.

Each result bit stands for a different state:

Bit 0: VI\_ERR\_CURR\_A: Status of channel A: Voltage or current error detected on Channel A. This bit is interpreted differently depending on which of the following IO function selected:

Voltage output: short-circuit error. The error condition is debounced for 2 ms before the status bit is set.

Current output: open circuit error. The error condition is debounced for 2 ms before the status bit is set.

Current input, loop powered: short-circuit error. A short to ground is detected

Current input, externally powered: short-circuit error. A current source >25 mA is detected

Bit 1: VI\_ERR\_CURR\_B: Status of voltage input B. Same like VI\_ERR\_CURR\_A

Bit 2: VI\_ERR\_CURR\_C: Status of voltage input C. Same like VI\_ERR\_CURR\_A

Bit 3: VI\_ERR\_CURR\_D: Status of voltage input D. Same like VI\_ERR\_CURR\_A

Bit 4: HI\_TEMP\_STATUS: If the die temperature is typically at or above 115°C, the HI\_TEMP\_STATUS bit is asserted

Bit 5: CHARGE\_PUMP\_STATUS: Charge pump error detected.

Bit 6: ALDO5V\_STATUS: ALDO5V Power Supply Monitor Error. This bit is asserted when the ALDO5V pin falls below 4.05 V. Usually ~5V.

Bit 7: AVDD\_STATUS: AVDD Power Supply Monitor Error. This bit is asserted when the AVDD pin falls below 9.26 V. Usually ~17V.

Bit 8: DVCC\_STATUS: DVCC Power Supply Monitor Error. This bit is asserted when the DVCC pin falls below 1.93 V. Usually ~3.3V.

Bit 9: ALDO1V8\_STATUS: ALDO1V8 Power Supply Monitor Error. This bit is asserted when the ALDO1V8 pin falls below 1.35 V. Usually ~1.8V.

Bit 10: ADC\_CONV\_ERR: ADC Conversion Error. ADC results may be outside the selected measurement range.

Bit 11: ADC\_SAT\_ERR: ADC Saturation Error. ADC may be outside the user selected measurement range.

Bit 12: SPI\_SCLK\_CNT\_ERR: SPI SCLK count error detected. This bit is asserted if an SPI command is applied but 32 SCLKs are not provided.

Bit 13: SPI\_CRC\_ERR: SPI CRC error detected. This bit is asserted if an invalid CRC is received.

Bit 14: CAL\_MEM\_ERR: Calibration Memory Error. This flag asserts under the following two conditions: When a calibration memory CRC error or an uncorrectable error correcting code (ECC) error is detected on the calibration memory upload. It is not possible to clear this bit if there is a CRC error or uncorrectable ECC error. It is recommended to reset the device and check the supplies in this situation. When there is an attempted SPI access to a register before the calibration memory refresh is complete. Do not address the device until the calibration memory is refreshed. Writing 1 to this bit clears the flag, if the flag is asserted due to this condition.

Bit 15: RESET\_OCCURRED: Reset occurred. This bit is asserted after a reset event, which asserts the ALERT pin after the reset. Write a 1 to this bit to clear the flag. Note that a mask bit is not provided for this bit.

CLEAR ALERT STATE	ASCII WRITE COMMAND	#CALERTS<CHIPNR>:<AlertState> <CR> Result: #OK<CR>	ASCII	YES
	CHIPNR	1		
	Bit 0	1:RESET FLAG	0:VI_ERR_A	
	Bit 1	1:RESET FLAG	1:VI_ERR_B	
	Bit 2	1:RESET FLAG	2:VI_ERR_C	
	Bit 3	1:RESET FLAG	3:VI_ERR_D	
	Bit 4	1:RESET FLAG	4:HI_TEMP_ERR	
	Bit 5	1:RESET FLAG	5:CHARGE_PUMP_ERR	
	Bit 6	1:RESET FLAG	6:ALDO5V_ERR	
	Bit 7	1:RESET FLAG	7:AVDD_ERR	
	Bit 8	1:RESET FLAG	8:DVCC_ERR	
	Bit 9	1:RESET FLAG	9:ALDO1V8_ERR	
	Bit 10	1:RESET FLAG	10:ADC_CONV_ERR	
	Bit 11	1:RESET FLAG	11:ADC_SAT_ERR	
	Bit 12	1:RESET FLAG	12:SPI_SCLK_ERR	
	Bit 13	1:RESET FLAG	13:SPI_CRC_ERR	
	Bit 14	1:RESET FLAG	14:CAL_MEM_ERR	
	Bit 15	1:RESET FLAG	15:RESET_OCCURED	
	TX	#1,CALERTS1:65535<CR>		
	RX	N/A		

With this command you can reset individual alert bits in the alert status register

### CHIP TEMPERATURES

GET CHIP TEMPERATURES	ASCII READ COMMAND	#GCHIPTemps<CR> Result: #GCHIPTemps:<Chip1TempDbl>, <Chip2TempDbl> <CR>	ASCII	
	TX	#1,GCHIPTemps<CR>		
	RX	#1,GCHIPTemps:46.37,47.49<CR>		
		Actual temperature of CHIP1:46.37°C		
		Actual temperature of CHIP2:47.49°C		

This command returns for every AIOX chip the actual chip temperature in °C

GET CHIP TEMPERATURE	ASCII READ COMMAND	#GCHIPTemp<CHIPNR> <CR> Result: #GCHIPTemp<CHIPNR>:<ChipxTempDbl> <CR>	ASCII	
	CHIPNR	1		
	TX	#1,GCHIPTemp1<CR>		
	RX	#1,GCHIPTemp1:46.37<CR>		
		Actual temperature of CHIP1:46.37°C		

This command returns for AIOX chip <CHIPNR> the actual chip temperature in °C

### AVERAGE CHIP TEMPERATURES

GET AVERAGE CHIP TEMPERATURES	ASCII READ COMMAND	#GAVGCHIPTemps<CR> Result: #GAVGCHIPTemps:<Chip1AvgTempDbl>, <Chip2AvgTempDbl> <CR>	ASCII	
-------------------------------	--------------------------	---	-------	--



	TX	#1,GAVGCHIPTemps<CR>		
	RX	#1,GAVGCHIPTemps:46.36,47.47<CR>		
		Average temperature of CHIP1:46.36°C		
		Average temperature of CHIP2:47.47°C		
This command returns for every AIOX chip the average chip temperature in °C				
GET AVERAGE CHIP TEMPERATURE	ASCII READ COMMAND	#GAVGCHIPTemp<CHIPNR><CR> Result: #GAVGCHIPTemp<CHIPNR>:<ChipxAvgTempDbl><CR>	ASCII	
	CHIPNR	1		
	TX	#1,GAVGCHIPTemp1<CR>		
	RX	#1,GAVGCHIPTemp1:46.36<CR>		
		Average temperature of CHIP1:46.36°C		
This command returns for AIOX chip <CHIPNR> the average chip temperature in °C				
<b>CHIP SUPPLY VOLTAGES</b>				
GET SUPPLY VOLTAGES	ASCII READ COMMAND	#GVAVDDS<CR> Result: #GVAVDDS:<Chip1VAVDDDBl>,<Chip2VAVDDDBl><CR>	ASCII	
	TX	#1,GVAVDDS<CR>		
	RX	#1,GVAVDDS:14.61,14.62<CR>		
		Actual supply voltage of CHIP1:14.61V		
		Actual supply voltage of CHIP2:14.62V		
This command returns for every AIOX chip the actual supply voltage in Volts. This must be >14.5V, if not, there is a severe wiring or other hardware issue!				
GET SUPPLY VOLTAGE	ASCII READ COMMAND	#GVAVDD<CHIPNR><CR> Result: #GVAVDD<CHIPNR>:<ChipxVAVDD><CR>	ASCII	
	CHIPNR	1		
	TX	#1,GVAVDD1<CR>		
	RX	#1,GVAVDD1:14.61<CR>		
		Actual supply voltage of CHIP1:14.61V		
This command returns for AIOX chip <CHIPNR> the actual supply voltage in Volts. This must be >14.5V, if not, there is a severe wiring or other hardware issue!				
<b>AVERAGE CHIP SUPPLY VOLTAGES</b>				
GET AVERAGE SUPPLY VOLTAGES	ASCII READ COMMAND	#GAVGVAVDDS<CR> Result: #GAVGVAVDDS:<Chip1AvgVAVDDDBl>,<Chip2AvgVAVDDDBl><CR>	ASCII	
	TX	#1,GAVGVAVDDS<CR>		
	RX	#1,GAVGVAVDDS:14.61,14.60<CR>		
		Average supply voltage of CHIP1:14.61V		
		Average supply voltage of CHIP2:14.60V		
This command returns for every AIOX chip the average supply voltage in Volts. This must be >14.5V, if not, there is a severe wiring or other hardware issue!				
GET AVERAGE SUPPLY VOLTAGE	ASCII READ COMMAND	#GAVGVAVDD<CHIPNR><CR> Result: #GAVGVAVDD<CHIPNR>:<ChipxAvgVAVDD><CR>	ASCII	
	CHIPNR	1		

	TX	#1,GAVGVAVDD1<CR>		
	RX	#1,GAVGVAVDD1:14.61<CR>		
		Average supply voltage of CHIP1:14.61V		

This command returns for AIOX chip <CHIPNR> the average supply voltage in Volts.  
This must be >14.5V, if not, there is a severe wiring or other hardware issue!

**CHIP GROUND VOLTAGES**

GET GROUND VOLTAGES	ASCII READ COMMAND	#GVAGNDS<CR> Result: #GVAGNDS:<Chip1VAGNDDbl>,<Chip2VAGNDDbl><CR>	ASCII	
	TX	#1,GVAGNDS<CR>		
	RX	#1,GVAGNDS:0.00,0.00<CR>		
		Actual ground voltage of CHIP1:0.00V		
		Actual ground voltage of CHIP2:0.00V		

This command returns for every AIOX chip the actual ground voltage in Volts.  
This must be 0, if not, there is a severe wiring or other hardware issue!

GET GROUND VOLTAGE	ASCII READ COMMAND CHIPNR	#GVAGND<CHIPNR><CR> Result: #GVAGND<CHIPNR>:<ChipxVAGNDDbl><CR> 1	ASCII	
	TX	#1,GVAGND1<CR>		
	RX	#1,GVAGND1:0.00<CR>		
		Actual ground voltage of CHIP1:0.00V		

This command returns for AIOX chip <CHIPNR> the actual ground voltage in Volts.  
This must be 0, if not, there is a severe wiring or other hardware issue!

**AVERAGE CHIP GROUND VOLTAGES**

GET AVERAGE GROUND VOLTAGES	ASCII READ COMMAND	#GAVGVAGNDS<CR> Result: #GAVGVAGNDS:<Chip1AvgVAGNDDbl>,<Chip2AvgVAGNDDbl><CR>	ASCII	
	TX	#1,GAVGVAGNDS<CR>		
	RX	#1,GAVGVAGNDS:0.00,0.00<CR>		
		Average ground voltage of CHIP1:0.00V		
		Average ground voltage of CHIP2:0.00V		

This command returns for every AIOX chip the average ground voltage in Volts.  
This must be 0, if not, there is a severe wiring or other hardware issue!

GET AVERAGE GROUND VOLTAGE	ASCII READ COMMAND CHIPNR	#GAVGVAGND<CHIPNR><CR> Result: #GAVGVAGND<CHIPNR>:<ChipxAvgVAVGNDDbl><CR> 1	ASCII	
	TX	#1,GAVGVAGND1<CR>		
	RX	#1,GAVGVAGND1:0.00<CR>		
		Average ground voltage of CHIP1:0.00V		

This command returns for AIOX chip <CHIPNR> the average ground voltage in Volts.  
This must be 0, if not, there is a severe wiring or other hardware issue!

Register NAME Command NAME	MODBUS Register ASCII Command	Register VALUE ASCII Command	NEW REAL VALUE	NEW VALUE	DATA TYPE	DO WRITE
<b>ASCII COMMANDS</b>						
SET CONFIG OUTPUT VALUES	ASCII WRITE COMMAND	#SCFGOVs:<IO1CfgValDbI>,<IO2CfgValDbI>,<IO3CfgValDbI>,<IO4CfgValDbI>,<IO5CfgValDbI>,<IO6CfgValDbI>,<IO7CfgValDbI>,<IO8CfgValDbI><CR> Result: #OK<CR>			ASCII	YES
	IO1Value	,000				
	IO2Value	,000				
	IO3Value	,000				
	IO4Value	,000				
	IO5Value	,000				
	IO6Value	,000				
	IO7Value	,000				
	IO8Value	,000				
	TX	#1,SCFGOVs:0,0,0,0,0,0,0,0<CR>				
	RX	N/A				
This command sets for all outputs the standard value in Volt or in mA, which are used when the controller is restartet or performing a watchdog reset and the channel is used as voltage output or current output. For voltage outputs the range is 0 to 11,0V. For current outputs the range is 0 to 25mA.						
SET CONFIG OUTPUT VALUEx	ASCII WRITE COMMAND	#SCFGOV<IONR>:<IOxCfgValueDbI><CR> Result: #OK<CR>			ASCII	YES
	IONR	1				
	IOxCfgValue	,000				
	TX	#1,SCFGOV1:0<CR>				
	RX	N/A				
This command sets for one outputs the standard value in Volt or in mA, which is used when the controller is restartet and the channel is used as voltage output or current output. For voltage outputs the range is 0 to 11,0V. For current outputs the range is 0 to 25mA.						
GET CONFIG OUTPUT VALUES	ASCII READ COMMAND	#GCFGOVs<CR> Result: #GCFGOVs:<IOVolt1DbI>,<IOVolt2DbI>,...<IOVolt8DbI><CR>			ASCII	
	TX	#1,GCFGOVs<CR>				
	RX	#1,GCFGOVs:999.99,999.99,999.99,999.99,999.99,999.99,999.99,999.99<CR>				
		Actual config value on IO1:999.99V or mA				
		Actual config value on IO2:999.99V or mA				
		Actual config value on IO3:999.99V or mA				
		Actual config value on IO4:999.99V or mA				
		Actual config value on IO5:999.99V or mA				
		Actual config value on IO6:999.99V or mA				
		Actual config value on IO7:999.99V or mA				
		Actual config value on IO8:999.99V or mA				

This command shows for all channels the current saved startup values for use as voltage or current outputs

For voltage outputs the range is 0 to 11,0V.

For current outputs the range is 0 to 25mA.

All IOs with a different usage type will return 999.99.

GET CONFIG OUTPUT VALUE	ASCII READ COMMAND	#GCFGOV<IONR><CR> Result: #GCFGOV<IONR>:<IOxValueDbI><CR>	ASCII	
	IONR	1		
	TX	#1,GCFGOV1<CR>		
	RX	#1,GCFGOV1:999.99<CR>		
		Actual config value on IO1:999.99V or mA		

This command shows for one channel the current saved startup value for use as voltage or current output.

For voltage outputs the range is 0 to 11,0V.

For current outputs the range is 0 to 25mA.

All IOs with a different usage type will return 999.99.

RESET 16AIOXCPU	ASCII WRITE COMMAND	#R16AIOXCPU<CR> Result: #OK<CR>	ASCII	NO
	TX	#1,R16AIOXCPU<CR>		
	RX	N/A		

This command restarts the internal CPU of the 16AIOX addon print. All channels will be resetted & initialized completely

Register NAME Command NAME	MODBUS Register ASCII Command	Register VALUE ASCII Command	NEW REAL VALUE	NEW VALUE	DATA TYPE	DO WRITE
<b>AIOX IO TYPES</b>						
IO TYPE1	3x40001 4x40001 I:40000	0,0x0000 B:00 00		13:RTDI[OHM]	UINT16 R/W	YES
		Actual IO type of AIOx:0:UU		CHOOSE NEW IO TYPE FROM LIST		
<p>Current configured IO type for AIOXx            =0: UNUSED            =1: VOLTAGE INPUT[0-10V]            =2: VOLTAGE INPUT[2-10V]            =3: VOLTAGE OUTPUT[0-10V]            =4: VOLTAGE OUTPUT[2-10V]            =5: CURRENT INPUT LOOP POWERED[0-20mA]            =6: CURRENT INPUT LOOP POWERED[4-20mA]            =7: CURRENT INPUT EXTERNAL POWERED[0-20mA]            =8: CURRENT INPUT EXTERNAL POWERED[4-20mA]            =9: CURRENT OUTPUT[0-20mA]            =10: CURRENT OUTPUT[4-20mA]            =11: DIGITAL INPUT LOGIC 24V=            =12: DIGITAL INPUT LOOP POWERED            =13: RESISTANCE MEASUREMENT</p>						
HINT: The last IO type is automatically stored in FRAM and will be used after a system restart.						
IO TYPE2	3x40002 4x40002 I:40001	0,0x0000 B:00 00		12:DI[24V;LP]	UINT16 R/W	YES
		Actual IO type of AIOx:0:UU		CHOOSE NEW IO TYPE FROM LIST		
IO TYPE3	3x40003 4x40003 I:40002	0,0x0000 B:00 00		1:VI[0-10V]	UINT16 R/W	NO
		Actual IO type of AIOx:0:UU		CHOOSE NEW IO TYPE FROM LIST		
IO TYPE4	3x40004 4x40004 I:40003	0,0x0000 B:00 00		1:VI[0-10V]	UINT16 R/W	NO
		Actual IO type of AIOx:0:UU		CHOOSE NEW IO TYPE FROM LIST		
IO TYPE5	3x40005 4x40005 I:40004	0,0x0000 B:00 00		3:VO[0-10V]	UINT16 R/W	NO
		Actual IO type of AIOx:0:UU		CHOOSE NEW IO TYPE FROM LIST		
IO TYPE6	3x40006 4x40006 I:40005	0,0x0000 B:00 00		3:VO[0-10V]	UINT16 R/W	NO
		Actual IO type of AIOx:0:UU		CHOOSE NEW IO TYPE FROM LIST		

IO TYPE7	3x40007 4x40007 I:40006	0,0x0000 B:00 00		3:VO[0-10V]	UINT16 R/W	NO
		Actual IO type of AIOx:0:UU		CHOOSE NEW IO TYPE FROM LIST		
IO TYPE8	3x40008 4x40008 I:40007	0,0x0000 B:00 00		3:VO[0-10V]	UINT16 R/W	NO
		Actual IO type of AIOx:0:UU		CHOOSE NEW IO TYPE FROM LIST		
<b>AIOX:VOLTAGE INPUTS</b>						
VOLTAGE INPUT1 IN VOLTS	3x40009 4x40009 I:40008	65535,0xFFFF B:FF FF			UINT16 R/O	
		Actual value of Vlx:65535=N/V				
Current value of voltage input in x*100V, range 0-10V =65535,0xFFFF: The channel is not configured as voltage input						
VOLTAGE INPUT2 IN VOLTS	3x40010 4x40010 I:40009	65535,0xFFFF B:FF FF			UINT16 R/O	
		Actual value of Vlx:65535=N/V				
VOLTAGE INPUT3 IN VOLTS	3x40011 4x40011 I:40010	65535,0xFFFF B:FF FF			UINT16 R/O	
		Actual value of Vlx:65535=N/V				
VOLTAGE INPUT4 IN VOLTS	3x40012 4x40012 I:40011	65535,0xFFFF B:FF FF			UINT16 R/O	
		Actual value of Vlx:65535=N/V				
VOLTAGE INPUT5 IN VOLTS	3x40013 4x40013 I:40012	65535,0xFFFF B:FF FF			UINT16 R/O	
		Actual value of Vlx:65535=N/V				
VOLTAGE INPUT6 IN VOLTS	3x40014 4x40014 I:40013	65535,0xFFFF B:FF FF			UINT16 R/O	
		Actual value of Vlx:65535=N/V				
VOLTAGE INPUT7 IN VOLTS	3x40015 4x40015 I:40014	65535,0xFFFF B:FF FF			UINT16 R/O	
		Actual value of Vlx:65535=N/V				
VOLTAGE INPUT8 IN VOLTS	3x40016 4x40016 I:40015	65535,0xFFFF B:FF FF			UINT16 R/O	
		Actual value of Vlx:65535=N/V				
<b>AIOX:VOLTAGE INPUTS</b>						

VOLTAGE INPUT1 IN PERCENT	3x40017 4x40017 I:40016	65535,0xFFFF B:FF FF			UINT16 R/O	
		Actual value of Vlx:65535=N/V				
Current value of voltage input in x*100%, range 0-100% =65535,0xFFFF: The channel is not configured as voltage input						
VOLTAGE INPUT3 IN PERCENT	3x40018 4x40018 I:40017	65535,0xFFFF B:FF FF			UINT16 R/O	
		Actual value of Vlx:65535=N/V				
VOLTAGE INPUT3 IN PERCENT	3x40019 4x40019 I:40018	65535,0xFFFF B:FF FF			UINT16 R/O	
		Actual value of Vlx:65535=N/V				
VOLTAGE INPUT4 IN PERCENT	3x40020 4x40020 I:40019	65535,0xFFFF B:FF FF			UINT16 R/O	
		Actual value of Vlx:65535=N/V				
VOLTAGE INPUT5 IN PERCENT	3x40021 4x40021 I:40020	65535,0xFFFF B:FF FF			UINT16 R/O	
		Actual value of Vlx:65535=N/V				
VOLTAGE INPUT6 IN PERCENT	3x40022 4x40022 I:40021	65535,0xFFFF B:FF FF			UINT16 R/O	
		Actual value of Vlx:65535=N/V				
VOLTAGE INPUT7 IN PERCENT	3x40023 4x40023 I:40022	65535,0xFFFF B:FF FF			UINT16 R/O	
		Actual value of Vlx:65535=N/V				
VOLTAGE INPUT8 IN PERCENT	3x40024 4x40024 I:40023	65535,0xFFFF B:FF FF			UINT16 R/O	
		Actual value of Vlx:65535=N/V				
<b>AIOX:VOLTAGE OUTPUTS</b>						
VOLTAGE OUTPUT1 IN VOLTS	3x40025 4x40025 I:40024	65535,0xFFFF B:FF FF	1100	11	UINT16 R/W	NO
		Actual value of VOx:65535=N/V			ENTER NEW VALUE FOR VOx	
Current value of voltage output in x*100V, range 0-11V =65535,0xFFFF: The channel is not configured as voltage output						
Writing a new value onto this register sets voltage output x to a new output value in Volt						
VOLTAGE OUTPUT2 IN VOLTS	3x40026 4x40026 I:40025	65535,0xFFFF B:FF FF	1100	11	UINT16 R/W	NO

		Actual value of VOx:65535=N/V		ENTER NEW VALUE FOR VOx			
VOLTAGE OUTPUT3 IN VOLTS	3x40027 4x40027 I:40026	65535,0xFFFF B:FF FF	1100	11	UINT16 R/W	NO	
		Actual value of VOx:65535=N/V		ENTER NEW VALUE FOR VOx			
VOLTAGE OUTPUT4 IN VOLTS	3x40028 4x40028 I:40027	65535,0xFFFF B:FF FF	1100	11	UINT16 R/W	NO	
		Actual value of VOx:65535=N/V		ENTER NEW VALUE FOR VOx			
VOLTAGE OUTPUT5 IN VOLTS	3x40029 4x40029 I:40028	65535,0xFFFF B:FF FF	1100	11	UINT16 R/W	NO	
		Actual value of VOx:65535=N/V		ENTER NEW VALUE FOR VOx			
VOLTAGE OUTPUT6 IN VOLTS	3x40030 4x40030 I:40029	65535,0xFFFF B:FF FF	1100	11	UINT16 R/W	NO	
		Actual value of VOx:65535=N/V		ENTER NEW VALUE FOR VOx			
VOLTAGE OUTPUT7 IN VOLTS	3x40031 4x40031 I:40030	65535,0xFFFF B:FF FF	1100	11	UINT16 R/W	NO	
		Actual value of VOx:65535=N/V		ENTER NEW VALUE FOR VOx			
VOLTAGE OUTPUT8 IN VOLTS	3x40032 4x40032 I:40031	65535,0xFFFF B:FF FF	1100	11	UINT16 R/W	NO	
		Actual value of VOx:65535=N/V		ENTER NEW VALUE FOR VOx			
<b>AIOX:VOLTAGE OUTPUTS</b>							
VOLTAGE OUTPUT1 IN PERCENT	3x40033 4x40033 I:40032	65535,0xFFFF B:FF FF	11000	110	UINT16 R/W	NO	
		Actual value of VOx:65535=N/V		ENTER NEW VALUE FOR VOx			
Current value of voltage output in x*100%, range 0-110% (100%=10V) =65535,0xFFFF: The channel is not configured as voltage output							
Writing a new value onto this register sets voltage output x to a new output value in percent							
VOLTAGE OUTPUT2 IN PERCENT	3x40034 4x40034 I:40033	65535,0xFFFF B:FF FF	5000	50	UINT16 R/W	NO	
		Actual value of VOx:65535=N/V		ENTER NEW VALUE FOR VOx			
VOLTAGE OUTPUT3 IN PERCENT	3x40035 4x40035 I:40034	65535,0xFFFF B:FF FF	3000	30	UINT16 R/W	NO	
		Actual value of VOx:65535=N/V		ENTER NEW VALUE FOR VOx			
VOLTAGE OUTPUT4 IN PERCENT	3x40036 4x40036 I:40035	65535,0xFFFF B:FF FF	7500	75	UINT16 R/W	NO	
		Actual value of VOx:65535=N/V		ENTER NEW VALUE FOR VOx			



VOLTAGE OUTPUT5 IN PERCENT	3x40037 4x40037 I:40036	65535,0xFFFF B:FF FF	0	0	UINT16 R/W	NO
		Actual value of VOx:65535=N/V		ENTER NEW VALUE FOR VOx		
VOLTAGE OUTPUT6 IN PERCENT	3x40038 4x40038 I:40037	65535,0xFFFF B:FF FF	0	0	UINT16 R/W	NO
		Actual value of VOx:65535=N/V		ENTER NEW VALUE FOR VOx		
VOLTAGE OUTPUT7 IN PERCENT	3x40039 4x40039 I:40038	65535,0xFFFF B:FF FF	0	0	UINT16 R/W	NO
		Actual value of VOx:65535=N/V		ENTER NEW VALUE FOR VOx		
VOLTAGE OUTPUT8 IN PERCENT	3x40040 4x40040 I:40039	65535,0xFFFF B:FF FF	0	0	UINT16 R/W	NO
		Actual value of VOx:65535=N/V		ENTER NEW VALUE FOR VOx		
<b>AIOX:VOLTAGE OUTPUTS</b>						
VOLTAGE OUTPUT1 MEASURED CURRENT	3x40041 4x40041 I:40040	-32768,0x8000 B:80 00			SINT16 R/O	
		Actual measured output current of VOx:-32768=N/V				
Returns the measured output current in x*100mA on voltage output VOx, Range -25mA..+25mA =-32768,0x8000: The channel is not configured as voltage output						
VOLTAGE OUTPUT2 MEASURED CURRENT	3x40042 4x40042 I:40041	-32768,0x8000 B:80 00			SINT16 R/O	
		Actual measured output current of VOx:-32768=N/V				
VOLTAGE OUTPUT3 MEASURED CURRENT	3x40043 4x40043 I:40042	-32768,0x8000 B:80 00			SINT16 R/O	
		Actual measured output current of VOx:-32768=N/V				
VOLTAGE OUTPUT4 MEASURED CURRENT	3x40044 4x40044 I:40043	-32768,0x8000 B:80 00			SINT16 R/O	
		Actual measured output current of VOx:-32768=N/V				
VOLTAGE OUTPUT5 MEASURED CURRENT	3x40045 4x40045 I:40044	-32768,0x8000 B:80 00			SINT16 R/O	
		Actual measured output current of VOx:-32768=N/V				
VOLTAGE OUTPUT6 MEASURED CURRENT	3x40046 4x40046 I:40045	-32768,0x8000 B:80 00			SINT16 R/O	
		Actual measured output current of VOx:-32768=N/V				
VOLTAGE OUTPUT7 MEASURED CURRENT	3x40047 4x40047 I:40046	-32768,0x8000 B:80 00			SINT16 R/O	

		Actual measured output current of VOx:-32768=N/V				
VOLTAGE OUTPUT8 MEASURED CURRENT	3x40048 4x40048 I:40047	-32768,0x8000 B:80 00			SINT16 R/O	
		Actual measured output current of VOx:-32768=N/V				
<b>AIOX:CURRENT INPUTS</b>						
CURRENT INPUT1 IN MILLIAMPERE	3x40049 4x40049 I:40048	65535,0xFFFF B:FF FF			UINT16 R/O	
		Actual value of CIx:65535=N/V				
Current value of current input in x*100mA, range 0-25mA =65535,0xFFFF: The channel is not configured as current input						
CURRENT INPUT2 IN MILLIAMPERE	3x40050 4x40050 I:40049	65535,0xFFFF B:FF FF			UINT16 R/O	
		Actual value of VIx:65535=N/V				
CURRENT INPUT3 IN MILLIAMPERE	3x40051 4x40051 I:40050	65535,0xFFFF B:FF FF			UINT16 R/O	
		Actual value of VIx:65535=N/V				
CURRENT INPUT4 IN MILLIAMPERE	3x40052 4x40052 I:40051	65535,0xFFFF B:FF FF			UINT16 R/O	
		Actual value of VIx:65535=N/V				
CURRENT INPUT5 IN MILLIAMPERE	3x40053 4x40053 I:40052	65535,0xFFFF B:FF FF			UINT16 R/O	
		Actual value of VIx:65535=N/V				
CURRENT INPUT6 IN MILLIAMPERE	3x40054 4x40054 I:40053	65535,0xFFFF B:FF FF			UINT16 R/O	
		Actual value of VIx:65535=N/V				
CURRENT INPUT7 IN MILLIAMPERE	3x40055 4x40055 I:40054	65535,0xFFFF B:FF FF			UINT16 R/O	
		Actual value of VIx:65535=N/V				
CURRENT INPUT8 IN MILLIAMPERE	3x40056 4x40056 I:40055	65535,0xFFFF B:FF FF			UINT16 R/O	
		Actual value of VIx:65535=N/V				
<b>AIOX:CURRENT INPUTS</b>						
CURRENT INPUT1 IN PERCENT	3x40057 4x40057 I:40056	65535,0xFFFF B:FF FF			UINT16 R/O	
		Actual value of CIx:65535=N/V				

Current value of current input in x*100%, range 0-125% (100%=20mA) =65535,0xFFFF: The channel is not configured as current input						
CURRENT INPUT2 IN PERCENT	3x40058 4x40058 I:40057	65535,0xFFFF B:FF FF				UINT16 R/O
		Actual value of CIx:65535=N/V				
CURRENT INPUT3 IN PERCENT	3x40059 4x40059 I:40058	65535,0xFFFF B:FF FF				UINT16 R/O
		Actual value of CIx:65535=N/V				
CURRENT INPUT4 IN PERCENT	3x40060 4x40060 I:40059	65535,0xFFFF B:FF FF				UINT16 R/O
		Actual value of CIx:65535=N/V				
CURRENT INPUT5 IN PERCENT	3x40061 4x40061 I:40060	65535,0xFFFF B:FF FF				UINT16 R/O
		Actual value of CIx:65535=N/V				
CURRENT INPUT6 IN PERCENT	3x40062 4x40062 I:40061	65535,0xFFFF B:FF FF				UINT16 R/O
		Actual value of CIx:65535=N/V				
CURRENT INPUT7 IN PERCENT	3x40063 4x40063 I:40062	65535,0xFFFF B:FF FF				UINT16 R/O
		Actual value of CIx:65535=N/V				
CURRENT INPUT8 IN PERCENT	3x40064 4x40064 I:40063	65535,0xFFFF B:FF FF				UINT16 R/O
		Actual value of CIx:65535=N/V				
<b>AIOX:CURRENT OUTPUTS</b>						
CURRENT OUTPUT1 IN MILIAMPERE	3x40065 4x40065 I:40064	65535,0xFFFF B:FF FF	500	5		UINT16 R/W NO
		Actual value of COx:65535=N/V			ENTER NEW VALUE FOR COx	
Current value of current output in x*100mA, range 0-25mA =65535,0xFFFF: The channel is not configured as current output						
Writing a new value onto this register sets current output x to a new output value in Milliampere						
CURRENT OUTPUT2 IN MILIAMPERE	3x40066 4x40066 I:40065	65535,0xFFFF B:FF FF	500	5		UINT16 R/W NO
		Actual value of COx:65535=N/V			ENTER NEW VALUE FOR COx	
CURRENT OUTPUT3 IN MILIAMPERE	3x40067 4x40067 I:40066	65535,0xFFFF B:FF FF	500	5		UINT16 R/W NO

		Actual value of COx:65535=N/V		ENTER NEW VALUE FOR COx		
CURRENT OUTPUT4 IN MILIAMPERE	3x40068 4x40068 I:40067	65535,0xFFFF B:FF FF	500	5	UINT16 R/W	NO
		Actual value of COx:65535=N/V		ENTER NEW VALUE FOR COx		
CURRENT OUTPUT5 IN MILIAMPERE	3x40069 4x40069 I:40068	65535,0xFFFF B:FF FF	500	5	UINT16 R/W	NO
		Actual value of COx:65535=N/V		ENTER NEW VALUE FOR COx		
CURRENT OUTPUT6 IN MILIAMPERE	3x40070 4x40070 I:40069	65535,0xFFFF B:FF FF	500	5	UINT16 R/W	NO
		Actual value of COx:65535=N/V		ENTER NEW VALUE FOR COx		
CURRENT OUTPUT7 IN MILIAMPERE	3x40071 4x40071 I:40070	65535,0xFFFF B:FF FF	500	5	UINT16 R/W	NO
		Actual value of COx:65535=N/V		ENTER NEW VALUE FOR COx		
CURRENT OUTPUT8 IN MILIAMPERE	3x40072 4x40072 I:40071	65535,0xFFFF B:FF FF	500	5	UINT16 R/W	NO
		Actual value of COx:65535=N/V		ENTER NEW VALUE FOR COx		
<b>AIOX:CURRENT OUTPUTS</b>						
CURRENT OUTPUT1 IN PERCENT	3x40073 4x40073 I:40072	65535,0xFFFF B:FF FF	5000	50	UINT16 R/W	NO
		Actual value of COx:65535=N/V		ENTER NEW VALUE FOR COx		
Current value of current output in x*100%, range 0-125% (100%=20mA) =65535,0xFFFF: The channel is not configured as current output						
Writing a new value onto this register sets current output x to a new output value in percent						
CURRENT OUTPUT2 IN PERCENT	3x40074 4x40074 I:40073	65535,0xFFFF B:FF FF	5000	50	UINT16 R/W	NO
		Actual value of COx:65535=N/V		ENTER NEW VALUE FOR COx		
CURRENT OUTPUT3 IN PERCENT	3x40075 4x40075 I:40074	65535,0xFFFF B:FF FF	5000	50	UINT16 R/W	NO
		Actual value of COx:65535=N/V		ENTER NEW VALUE FOR COx		
CURRENT OUTPUT4 IN PERCENT	3x40076 4x40076 I:40075	65535,0xFFFF B:FF FF	5000	50	UINT16 R/W	NO
		Actual value of COx:65535=N/V		ENTER NEW VALUE FOR COx		
CURRENT OUTPUT5 IN PERCENT	3x40077 4x40077 I:40076	65535,0xFFFF B:FF FF	5000	50	UINT16 R/W	NO
		Actual value of COx:65535=N/V		ENTER NEW VALUE FOR COx		

CURRENT OUTPUT6 IN PERCENT	3x40078 4x40078 I:40077	65535,0xFFFF B:FF FF	5000	50	UINT16 R/W	NO
		Actual value of COx:65535=N/V		ENTER NEW VALUE FOR COx		
CURRENT OUTPUT7 IN PERCENT	3x40079 4x40079 I:40078	65535,0xFFFF B:FF FF	5000	50	UINT16 R/W	NO
		Actual value of COx:65535=N/V		ENTER NEW VALUE FOR COx		
CURRENT OUTPUT8 IN PERCENT	3x40080 4x40080 I:40079	65535,0xFFFF B:FF FF	5000	50	UINT16 R/W	NO
		Actual value of COx:65535=N/V		ENTER NEW VALUE FOR COx		
<b>AIOX:CURRENT OUTPUTS</b>						
CURRENT OUTPUT1 MEASURED VOLTS	3x40081 4x40081 I:40080	65535,0xFFFF B:FF FF			UINT16 R/O	
		Actual measured output voltage COx:65535=N/V				
Current measured output voltage for current output x*100V, range 0-10V =65535,0xFFFF: The channel is not configured as current output						
CURRENT OUTPUT2 MEASURED VOLTS	3x40082 4x40082 I:40081	65535,0xFFFF B:FF FF			UINT16 R/O	
		Actual measured output voltage COx:65535=N/V				
CURRENT OUTPUT3 MEASURED VOLTS	3x40083 4x40083 I:40082	65535,0xFFFF B:FF FF			UINT16 R/O	
		Actual measured output voltage COx:65535=N/V				
CURRENT OUTPUT4 MEASURED VOLTS	3x40084 4x40084 I:40083	65535,0xFFFF B:FF FF			UINT16 R/O	
		Actual measured output voltage COx:65535=N/V				
CURRENT OUTPUT5 MEASURED VOLTS	3x40085 4x40085 I:40084	65535,0xFFFF B:FF FF			UINT16 R/O	
		Actual measured output voltage COx:65535=N/V				
CURRENT OUTPUT6 MEASURED VOLTS	3x40086 4x40086 I:40085	65535,0xFFFF B:FF FF			UINT16 R/O	
		Actual measured output voltage COx:65535=N/V				
CURRENT OUTPUT7 MEASURED VOLTS	3x40087 4x40087 I:40086	65535,0xFFFF B:FF FF			UINT16 R/O	
		Actual measured output voltage COx:65535=N/V				
CURRENT OUTPUT8 MEASURED VOLTS	3x40088 4x40088 I:40087	65535,0xFFFF B:FF FF			UINT16 R/O	

		Actual measured output voltage COx:65535=N/V				
<b>AIOX:DIGITAL INPUTS</b>						
DIGITAL INPUT1	3x40089 4x40089 I:40088	65535,0xFFFF B:FF FF			UINT16 R/O	
		Actual state of digital input DIx:65535=N/V				
Current measured state of digital input DIx =0: Digital input is OFF or loop is closed =1: Digital input is ON (+24V attached) or loop is open =65535,0xFFFF: The channel is not configured as digital input						
DIGITAL INPUT2	3x40090 4x40090 I:40089	65535,0xFFFF B:FF FF			UINT16 R/O	
		Actual state of digital input DIx:65535=N/V				
DIGITAL INPUT3	3x40091 4x40091 I:40090	65535,0xFFFF B:FF FF			UINT16 R/O	
		Actual measured output voltage COx:65535=N/V				
DIGITAL INPUT4	3x40092 4x40092 I:40091	65535,0xFFFF B:FF FF			UINT16 R/O	
		Actual measured output voltage COx:65535=N/V				
DIGITAL INPUT5	3x40093 4x40093 I:40092	65535,0xFFFF B:FF FF			UINT16 R/O	
		Actual measured output voltage COx:65535=N/V				
DIGITAL INPUT6	3x40094 4x40094 I:40093	65535,0xFFFF B:FF FF			UINT16 R/O	
		Actual measured output voltage COx:65535=N/V				
DIGITAL INPUT7	3x40095 4x40095 I:40094	65535,0xFFFF B:FF FF			UINT16 R/O	
		Actual measured output voltage COx:65535=N/V				
DIGITAL INPUT8	3x40096 4x40096 I:40095	65535,0xFFFF B:FF FF			UINT16 R/O	
		Actual measured output voltage COx:65535=N/V				
<b>AIOX:DIGITAL INPUTS</b>						
DIGITAL INPUT1 MEASURED CURRENT	3x40097 4x40097 I:40096	-32768,0x8000 B:80 00			SINT16 R/O	
		Actual measured output current of DIx:-32768=N/V				
Returns the measured output current in x*100mA on DIGITAL INPUT VOx, Range -25mA..+25mA =-32768,0x8000: The channel is not configured as DIGITAL INPUT						

DIGITAL INPUT2 MEASURED CURRENT	3x40098 4x40098 I:40097	-32768,0x8000 B:80 00			SINT16 R/O	
		Actual measured output current of DIx:-32768=N/V				
DIGITAL INPUT3 MEASURED CURRENT	3x40099 4x40099 I:40098	-32768,0x8000 B:80 00			SINT16 R/O	
		Actual measured output current of DIx:-32768=N/V				
DIGITAL INPUT4 MEASURED CURRENT	3x40100 4x40100 I:40099	-32768,0x8000 B:80 00			SINT16 R/O	
		Actual measured output current of DIx:-32768=N/V				
DIGITAL INPUT5 MEASURED CURRENT	3x40101 4x40101 I:40100	-32768,0x8000 B:80 00			SINT16 R/O	
		Actual measured output current of DIx:-32768=N/V				
DIGITAL INPUT6 MEASURED CURRENT	3x40102 4x40102 I:40101	-32768,0x8000 B:80 00			SINT16 R/O	
		Actual measured output current of DIx:-32768=N/V				
DIGITAL INPUT7 MEASURED CURRENT	3x40103 4x40103 I:40102	-32768,0x8000 B:80 00			SINT16 R/O	
		Actual measured output current of DIx:-32768=N/V				
DIGITAL INPUT8 MEASURED CURRENT	3x40104 4x40104 I:40103	-32768,0x8000 B:80 00			SINT16 R/O	
		Actual measured output current of DIx:-32768=N/V				

Register NAME Command NAME	MODBUS Register ASCII Command	Register VALUE ASCII Command	NEW REAL VALUE	NEW VALUE	DATA TYPE	DO WRITE
<b>AIOX:RTD INPUTS OHM*10</b>						
RTD INPUT1 IN OHM*10	3x41001 4x41001 I:41000	65534,0xFFFE B:FF FE			UINT16 R/O	
Actual measured ohm value of RTDIx:65534=OPEN						
Current measured RTD in Ohm*10 between 0 and 600000 =0..60000: Current measured resistance in Ohm*10 =65534,0xFFFE: The sensor or cabling is open (broken, not connected, or out of range) =65535,0xFFFF: The channel is not configured as RTD input						
RTD INPUT2 IN OHM*10	3x41002 4x41002 I:41001	65534,0xFFFE B:FF FE			UINT16 R/O	
Actual measured ohm value of RTDIx:65534=OPEN						
RTD INPUT3 IN OHM*10	3x41003 4x41003 I:41002	65534,0xFFFE B:FF FE			UINT16 R/O	
Actual measured ohm value of RTDIx:65534=OPEN						
RTD INPUT4 IN OHM*10	3x41004 4x41004 I:41003	65534,0xFFFE B:FF FE			UINT16 R/O	
Actual measured ohm value of RTDIx:65534=OPEN						
RTD INPUT5 IN OHM*10	3x41005 4x41005 I:41004	65534,0xFFFE B:FF FE			UINT16 R/O	
Actual measured ohm value of RTDIx:65534=OPEN						
RTD INPUT6 IN OHM*10	3x41006 4x41006 I:41005	65534,0xFFFE B:FF FE			UINT16 R/O	
Actual measured ohm value of RTDIx:65534=OPEN						
RTD INPUT7 IN OHM*10	3x41007 4x41007 I:41006	65534,0xFFFE B:FF FE			UINT16 R/O	
Actual measured ohm value of RTDIx:65534=OPEN						
RTD INPUT8 IN OHM*10	3x41008 4x41008 I:41007	65534,0xFFFE B:FF FE			UINT16 R/O	
Actual measured ohm value of RTDIx:65534=OPEN						
<b>AIOX:RTD INPUTS OHM*1</b>						
RTD INPUT1 IN OHM	3x41009 4x41009 I:41008	65535,0xFFFF B:FF FF			UINT16 R/O	



		Actual measured ohm value of RTDIx:65535=N/V				
Current measured RTD in Ohm*1 between 0 and 60000 =0..60000: Current measured resistance in Ohm*1 =65534,0xFFFF: The sensor or cabling is open (broken, not connected, or out of range) =65535,0xFFFF: The channel is not configured as RTD input						
RTD INPUT2 IN OHM	3x41010 4x41010 I:41009	65535,0xFFFF B:FF FF			UINT16 R/O	
		Actual measured ohm value of RTDIx:65535=N/V				
RTD INPUT3 IN OHM	3x41011 4x41011 I:41010	65535,0xFFFF B:FF FF			UINT16 R/O	
		Actual measured ohm value of RTDIx:65535=N/V				
RTD INPUT4 IN OHM	3x41012 4x41012 I:41011	65535,0xFFFF B:FF FF			UINT16 R/O	
		Actual measured ohm value of RTDIx:65535=N/V				
RTD INPUT5 IN OHM	3x41013 4x41013 I:41012	65535,0xFFFF B:FF FF			UINT16 R/O	
		Actual measured ohm value of RTDIx:65535=N/V				
RTD INPUT6 IN OHM	3x41014 4x41014 I:41013	65535,0xFFFF B:FF FF			UINT16 R/O	
		Actual measured ohm value of RTDIx:65535=N/V				
RTD INPUT7 IN OHM	3x41015 4x41015 I:41014	65535,0xFFFF B:FF FF			UINT16 R/O	
		Actual measured ohm value of RTDIx:65535=N/V				
RTD INPUT8 IN OHM	3x41016 4x41016 I:41015	65535,0xFFFF B:FF FF			UINT16 R/O	
		Actual measured ohm value of RTDIx:65535=N/V				
<b>AIOX:RTD INPUTS OHM/10</b>						
RTD INPUT1 IN OHM/10	3x41017 4x41017 I:41016	65535,0xFFFF B:FF FF			UINT16 R/O	
		Actual measured ohm value of RTDIx:65535=N/V				
Current measured RTD in Ohm/10 between 0 and 60000 =0..60000: Current measured resistance in Ohm/10 =65534,0xFFFF: The sensor or cabling is open (broken, not connected, or out of range) =65535,0xFFFF: The channel is not configured as RTD input						
RTD INPUT2 IN OHM/10	3x41018 4x41018 I:41017	65535,0xFFFF B:FF FF			UINT16 R/O	
		Actual measured ohm value of RTDIx:65535=N/V				

RTD INPUT3 IN OHM/10	3x41019 4x41019 I:41018	65535,0xFFFF B:FF FF			UINT16 R/O	
Actual measured ohm value of RTDIx:65535=N/V						
RTD INPUT4 IN OHM/10	3x41020 4x41020 I:41019	65535,0xFFFF B:FF FF			UINT16 R/O	
Actual measured ohm value of RTDIx:65535=N/V						
RTD INPUT5 IN OHM/10	3x41021 4x41021 I:41020	65535,0xFFFF B:FF FF			UINT16 R/O	
Actual measured ohm value of RTDIx:65535=N/V						
RTD INPUT6 IN OHM/10	3x41022 4x41022 I:41021	65535,0xFFFF B:FF FF			UINT16 R/O	
Actual measured ohm value of RTDIx:65535=N/V						
RTD INPUT7 IN OHM/10	3x41023 4x41023 I:41022	65535,0xFFFF B:FF FF			UINT16 R/O	
Actual measured ohm value of RTDIx:65535=N/V						
RTD INPUT8 IN OHM/10	3x41024 4x41024 I:41023	65535,0xFFFF B:FF FF			UINT16 R/O	
Actual measured ohm value of RTDIx:65535=N/V						
<b>AIOX:RTD INPUTS PT100 CELSIUS</b>						
RTD INPUT1 AS PT100 IN CELSIUS	3x41025 4x41025 I:41024	-32768,0x8000 B:80 00			SINT16 R/O	
Actual measured PT100 temperature RTDIx:-32768=N/V						
Current measured RTD sensor value linearized as PT100 sensor in Celsius*100 in the range of -5000 to +13000 for -50.0 to +130.0 °C -32766,0x8002: Measured value is below -50°C -32767,0x8001: Measured value is above +130°C -32768,0x8000: The channel is not configured as RTD input						
RTD INPUT2 AS PT100 IN CELSIUS	3x41026 4x41026 I:41025	-32768,0x8000 B:80 00			SINT16 R/O	
Actual measured PT100 temperature RTDIx:-32768=N/V						
RTD INPUT3 AS PT100 IN CELSIUS	3x41027 4x41027 I:41026	-32768,0x8000 B:80 00			SINT16 R/O	
Actual measured PT100 temperature RTDIx:-32768=N/V						
RTD INPUT4 AS PT100 IN CELSIUS	3x41028 4x41028 I:41027	-32768,0x8000 B:80 00			SINT16 R/O	
Actual measured PT100 temperature RTDIx:-32768=N/V						

RTD INPUT5 AS PT100 IN CELSIUS	3x41029 4x41029 I:41028	-32768,0x8000 B:80 00		SINT16 R/O	
Actual measured PT100 temperature RTDIx:-32768=N/V					
RTD INPUT6 AS PT100 IN CELSIUS	3x41030 4x41030 I:41029	-32768,0x8000 B:80 00		SINT16 R/O	
Actual measured PT100 temperature RTDIx:-32768=N/V					
RTD INPUT7 AS PT100 IN CELSIUS	3x41031 4x41031 I:41030	-32768,0x8000 B:80 00		SINT16 R/O	
Actual measured PT100 temperature RTDIx:-32768=N/V					
RTD INPUT8 AS PT100 IN CELSIUS	3x41032 4x41032 I:41031	-32768,0x8000 B:80 00		SINT16 R/O	
Actual measured PT100 temperature RTDIx:-32768=N/V					
<b>AIOX:RTD INPUTS PT1000 CELSIUS</b>					
RTD INPUT1 AS PT1000 IN CELSIUS	3x41033 4x41033 I:41032	-32768,0x8000 B:80 00		SINT16 R/O	
Actual measured PT1000 temperature RTDIx:-32768=N/V					
Current measured RTD sensor value linearized as PT1000 sensor in Celsius*100 in the range of -5000 to +13000 for -50.0 to +130.0 °C -32766,0x8002: Measured value is below -50°C -32767,0x8001: Measured value is above +130°C -32768,0x8000: The channel is not configured as RTD input					
RTD INPUT2 AS PT1000 IN CELSIUS	3x41034 4x41034 I:41033	-32768,0x8000 B:80 00		SINT16 R/O	
Actual measured PT1000 temperature RTDIx:-32768=N/V					
RTD INPUT3 AS PT1000 IN CELSIUS	3x41035 4x41035 I:41034	-32768,0x8000 B:80 00		SINT16 R/O	
Actual measured PT1000 temperature RTDIx:-32768=N/V					
RTD INPUT4 AS PT1000 IN CELSIUS	3x41036 4x41036 I:41035	-32768,0x8000 B:80 00		SINT16 R/O	
Actual measured PT1000 temperature RTDIx:-32768=N/V					
RTD INPUT5 AS PT1000 IN CELSIUS	3x41037 4x41037 I:41036	-32768,0x8000 B:80 00		SINT16 R/O	
Actual measured PT1000 temperature RTDIx:-32768=N/V					
RTD INPUT6 AS PT1000 IN CELSIUS	3x41038 4x41038 I:41037	-32768,0x8000 B:80 00		SINT16 R/O	
Actual measured PT1000 temperature RTDIx:-32768=N/V					

RTD INPUT7 AS PT1000 IN CELSIUS	3x41039 4x41039 I:41038	-32768,0x8000 B:80 00		SINT16 R/O	
Actual measured PT1000 temperature RTDlx:-32768=N/V					
RTD INPUT8 AS PT1000 IN CELSIUS	3x41040 4x41040 I:41039	-32768,0x8000 B:80 00		SINT16 R/O	
Actual measured PT1000 temperature RTDlx:-32768=N/V					
<b>AIOX:RTD INPUTS NI1000-DIN43760 CELSIUS</b>					
RTD INPUT1 AS NI1000-DIN43760 IN CELSIUS	3x41041 4x41041 I:41040	-32768,0x8000 B:80 00		SINT16 R/O	
Actual measured NI1000-DIN43760 temperature RTDlx:-32768=N/V					
Current measured RTD sensor value linearized as NI1000-DIN43760 sensor in Celsius*100 in the range of -5000 to +13000 for -50.0 to +130.0 °C -32766,0x8002: Measured value is below -50°C -32767,0x8001: Measured value is above +130°C -32768,0x8000: The channel is not configured as RTD input					
RTD INPUT2 AS NI1000-DIN43760 IN CELSIUS	3x41042 4x41042 I:41041	-32768,0x8000 B:80 00		SINT16 R/O	
Actual measured NI1000-DIN43760 temperature RTDlx:-32768=N/V					
RTD INPUT3 AS NI1000-DIN43760 IN CELSIUS	3x41043 4x41043 I:41042	-32768,0x8000 B:80 00		SINT16 R/O	
Actual measured NI1000-DIN43760 temperature RTDlx:-32768=N/V					
RTD INPUT4 AS NI1000-DIN43760 IN CELSIUS	3x41044 4x41044 I:41043	-32768,0x8000 B:80 00		SINT16 R/O	
Actual measured NI1000-DIN43760 temperature RTDlx:-32768=N/V					
RTD INPUT5 AS NI1000-DIN43760 IN CELSIUS	3x41045 4x41045 I:41044	-32768,0x8000 B:80 00		SINT16 R/O	
Actual measured NI1000-DIN43760 temperature RTDlx:-32768=N/V					
RTD INPUT6 AS NI1000-DIN43760 IN CELSIUS	3x41046 4x41046 I:41045	-32768,0x8000 B:80 00		SINT16 R/O	
Actual measured NI1000-DIN43760 temperature RTDlx:-32768=N/V					
RTD INPUT7 AS NI1000-DIN43760 IN CELSIUS	3x41047 4x41047 I:41046	-32768,0x8000 B:80 00		SINT16 R/O	
Actual measured NI1000-DIN43760 temperature RTDlx:-32768=N/V					
RTD INPUT8 AS NI1000-DIN43760 IN CELSIUS	3x41048 4x41048 I:41047	-32768,0x8000 B:80 00		SINT16 R/O	
Actual measured NI1000-DIN43760 temperature RTDlx:-32768=N/V					
<b>AIOX:RTD INPUTS PT100 KELVIN</b>					

RTD INPUT1 AS PT100 IN KELVIN	3x41049 4x41049 I:41048	65535,0xFFFF B:FF FF			UINT16 R/O	
Actual measured PT100 temperature RTDIx:65535=655,35°K						
Current measured RTD sensor value linearized as PT100 sensor in Kelvin*100 in the range of 22315 to 40315 for 223.15 to 403.15 °K 65533,0xFFFFD: Measured value is below 223,15°K 65534,0xFFFFE: Measured value is above 403,15°K 65535,0xFFFFF: The channel is not configured as RTD input						
RTD INPUT2 AS PT100 IN KELVIN	3x41050 4x41050 I:41049	65535,0xFFFF B:FF FF			UINT16 R/O	
Actual measured PT100 temperature RTDIx:65535=655,35°K						
RTD INPUT3 AS PT100 IN KELVIN	3x41051 4x41051 I:41050	65535,0xFFFF B:FF FF			UINT16 R/O	
Actual measured PT100 temperature RTDIx:65535=655,35°K						
RTD INPUT4 AS PT100 IN KELVIN	3x41052 4x41052 I:41051	65535,0xFFFF B:FF FF			UINT16 R/O	
Actual measured PT100 temperature RTDIx:65535=655,35°K						
RTD INPUT5 AS PT100 IN KELVIN	3x41053 4x41053 I:41052	65535,0xFFFF B:FF FF			UINT16 R/O	
Actual measured PT100 temperature RTDIx:65535=655,35°K						
RTD INPUT6 AS PT100 IN KELVIN	3x41054 4x41054 I:41053	65535,0xFFFF B:FF FF			UINT16 R/O	
Actual measured PT100 temperature RTDIx:65535=655,35°K						
RTD INPUT7 AS PT100 IN KELVIN	3x41055 4x41055 I:41054	65535,0xFFFF B:FF FF			UINT16 R/O	
Actual measured PT100 temperature RTDIx:65535=655,35°K						
RTD INPUT8 AS PT100 IN KELVIN	3x41056 4x41056 I:41055	65535,0xFFFF B:FF FF			UINT16 R/O	
Actual measured PT100 temperature RTDIx:65535=655,35°K						
<b>AIOX:RTD INPUTS PT1000 KELVIN</b>						
RTD INPUT1 AS PT1000 IN KELVIN	3x41057 4x41057 I:41056	65535,0xFFFF B:FF FF			UINT16 R/O	
Actual measured PT1000 temperature RTDIx:65535=655,35°K						
Current measured RTD sensor value linearized as PT1000 sensor in Kelvin*100 in the range of 22315 to 40315 for 223.15 to 403.15 °K 65533,0xFFFFD: Measured value is below 223,15°K 65534,0xFFFFE: Measured value is above 403,15°K 65535,0xFFFFF: The channel is not configured as RTD input						

RTD INPUT2 AS PT1000 IN KELVIN	3x41058 4x41058 I:41057	65535,0xFFFF B:FF FF			UINT16 R/O	
Actual measured PT1000 temperature RTDIx:65535=655,35°K						
RTD INPUT3 AS PT1000 IN KELVIN	3x41059 4x41059 I:41058	65535,0xFFFF B:FF FF			UINT16 R/O	
Actual measured PT1000 temperature RTDIx:65535=655,35°K						
RTD INPUT4 AS PT1000 IN KELVIN	3x41060 4x41060 I:41059	65535,0xFFFF B:FF FF			UINT16 R/O	
Actual measured PT1000 temperature RTDIx:65535=655,35°K						
RTD INPUT5 AS PT1000 IN KELVIN	3x41061 4x41061 I:41060	65535,0xFFFF B:FF FF			UINT16 R/O	
Actual measured PT1000 temperature RTDIx:65535=655,35°K						
RTD INPUT6 AS PT1000 IN KELVIN	3x41062 4x41062 I:41061	65535,0xFFFF B:FF FF			UINT16 R/O	
Actual measured PT1000 temperature RTDIx:65535=655,35°K						
RTD INPUT7 AS PT1000 IN KELVIN	3x41063 4x41063 I:41062	65535,0xFFFF B:FF FF			UINT16 R/O	
Actual measured PT1000 temperature RTDIx:65535=655,35°K						
RTD INPUT8 AS PT1000 IN KELVIN	3x41064 4x41064 I:41063	65535,0xFFFF B:FF FF			UINT16 R/O	
Actual measured PT1000 temperature RTDIx:65535=655,35°K						
<b>AIOX:RTD INPUTS NI1000-DIN43760 KELVIN</b>						
RTD INPUT1 AS NI1000-DIN43760 IN KELVIN	3x41065 4x41065 I:41064	65535,0xFFFF B:FF FF			UINT16 R/O	
Actual measured NI1000-DIN43760 temperature RTDIx:65535=655,35°K						
Current measured RTD sensor value linearized as NI1000-DIN43760 sensor in Kelvin*100 in the range of 22315 to 40315 for 223.15 to 403.15 °K 65533,0xFFFF: Measured value is below 223,15°K 65534,0xFFFF: Measured value is above 403,15°K 65535,0xFFFF: The channel is not configured as RTD input						
RTD INPUT2 AS NI1000-DIN43760 IN KELVIN	3x41066 4x41066 I:41065	65535,0xFFFF B:FF FF			UINT16 R/O	
Actual measured NI1000-DIN43760 temperature RTDIx:65535=655,35°K						
RTD INPUT3 AS NI1000-DIN43760 IN KELVIN	3x41067 4x41067 I:41066	65535,0xFFFF B:FF FF			UINT16 R/O	
Actual measured NI1000-DIN43760 temperature RTDIx:65535=655,35°K						

RTD INPUT4 AS NI1000-DIN43760 IN KELVIN	3x41068 4x41068 I:41067	65535,0xFFFF B:FF FF		UINT16 R/O	
Actual measured NI1000-DIN43760 temperature RTDIx:65535=655,35°K					
RTD INPUT5 AS NI1000-DIN43760 IN KELVIN	3x41069 4x41069 I:41068	65535,0xFFFF B:FF FF		UINT16 R/O	
Actual measured NI1000-DIN43760 temperature RTDIx:65535=655,35°K					
RTD INPUT6 AS NI1000-DIN43760 IN KELVIN	3x41070 4x41070 I:41069	65535,0xFFFF B:FF FF		UINT16 R/O	
Actual measured NI1000-DIN43760 temperature RTDIx:65535=655,35°K					
RTD INPUT7 AS NI1000-DIN43760 IN KELVIN	3x41071 4x41071 I:41070	65535,0xFFFF B:FF FF		UINT16 R/O	
Actual measured NI1000-DIN43760 temperature RTDIx:65535=655,35°K					
RTD INPUT8 AS NI1000-DIN43760 IN KELVIN	3x41072 4x41072 I:41071	65535,0xFFFF B:FF FF		UINT16 R/O	
Actual measured NI1000-DIN43760 temperature RTDIx:65535=655,35°K					
<b>AIOX:RTD INPUTS PT100 FAHRENHEIT</b>					
RTD INPUT1 AS PT100 IN FAHRENHEIT	3x41073 4x41073 I:41072	-32768,0x8000 B:80 00		SINT16 R/O	
Actual measured PT100 temperature RTDIx:-32768=N/V					
Current measured RTD sensor value linearized as PT100 sensor in Fahrenheit*100 in the range of -5800 to +26600 for -58.0 to +266.0 °F -32766,0x8002: Measured value is below -58°C -32767,0x8001: Measured value is above +266°C -32768,0x8000: The channel is not configured as RTD input					
RTD INPUT2 AS PT100 IN FAHRENHEIT	3x41074 4x41074 I:41073	-32768,0x8000 B:80 00		SINT16 R/O	
Actual measured PT100 temperature RTDIx:-32768=N/V					
RTD INPUT3 AS PT100 IN FAHRENHEIT	3x41075 4x41075 I:41074	-32768,0x8000 B:80 00		SINT16 R/O	
Actual measured PT100 temperature RTDIx:-32768=N/V					
RTD INPUT4 AS PT100 IN FAHRENHEIT	3x41076 4x41076 I:41075	-32768,0x8000 B:80 00		SINT16 R/O	
Actual measured PT100 temperature RTDIx:-32768=N/V					
RTD INPUT5 AS PT100 IN FAHRENHEIT	3x41077 4x41077 I:41076	-32768,0x8000 B:80 00		SINT16 R/O	
Actual measured PT100 temperature RTDIx:-32768=N/V					

RTD INPUT6 AS PT100 IN FAHRENHEIT	3x41078 4x41078 I:41077	-32768,0x8000 B:80 00		SINT16 R/O	
Actual measured PT100 temperature RTDIx:-32768=N/V					
RTD INPUT7 AS PT100 IN FAHRENHEIT	3x41079 4x41079 I:41078	-32768,0x8000 B:80 00		SINT16 R/O	
Actual measured PT100 temperature RTDIx:-32768=N/V					
RTD INPUT8 AS PT100 IN FAHRENHEIT	3x41080 4x41080 I:41079	-32768,0x8000 B:80 00		SINT16 R/O	
Actual measured PT100 temperature RTDIx:-32768=N/V					
<b>AIOX:RTD INPUTS PT1000 FAHRENHEIT</b>					
RTD INPUT1 AS PT1000 IN FAHRENHEIT	3x41081 4x41081 I:41080	-32768,0x8000 B:80 00		SINT16 R/O	
Actual measured PT1000 temperature RTDIx:-32768=N/V					
Current measured RTD sensor value linearized as PT1000 sensor in Fahrenheit*100 in the range of -5800 to +26600 for -58.0 to +266.0 °F -32766,0x8002: Measured value is below -58°C -32767,0x8001: Measured value is above +266°C -32768,0x8000: The channel is not configured as RTD input					
RTD INPUT2 AS PT1000 IN FAHRENHEIT	3x41082 4x41082 I:41081	-32768,0x8000 B:80 00		SINT16 R/O	
Actual measured PT1000 temperature RTDIx:-32768=N/V					
RTD INPUT3 AS PT1000 IN FAHRENHEIT	3x41083 4x41083 I:41082	-32768,0x8000 B:80 00		SINT16 R/O	
Actual measured PT1000 temperature RTDIx:-32768=N/V					
RTD INPUT4 AS PT1000 IN FAHRENHEIT	3x41084 4x41084 I:41083	-32768,0x8000 B:80 00		SINT16 R/O	
Actual measured PT1000 temperature RTDIx:-32768=N/V					
RTD INPUT5 AS PT1000 IN FAHRENHEIT	3x41085 4x41085 I:41084	-32768,0x8000 B:80 00		SINT16 R/O	
Actual measured PT1000 temperature RTDIx:-32768=N/V					
RTD INPUT6 AS PT1000 IN FAHRENHEIT	3x41086 4x41086 I:41085	-32768,0x8000 B:80 00		SINT16 R/O	
Actual measured PT1000 temperature RTDIx:-32768=N/V					
RTD INPUT7 AS PT1000 IN FAHRENHEIT	3x41087 4x41087 I:41086	-32768,0x8000 B:80 00		SINT16 R/O	
Actual measured PT1000 temperature RTDIx:-32768=N/V					



RTD INPUT8 AS PT1000 IN FAHRENHEIT	3x41088 4x41088 I:41087	-32768,0x8000 B:80 00			SINT16 R/O	
Actual measured PT1000 temperature RTDlx:-32768=N/V						
<b>AIOX:RTD INPUTS NI1000-DIN43760 FAHRENHEIT</b>						
RTD INPUT1 AS NI1000-DIN43760 IN FAHRENHEIT	3x41089 4x41089 I:41088	-32768,0x8000 B:80 00			SINT16 R/O	
Actual measured NI1000-DIN43760 temperature RTDlx:-32768=N/V						
Current measured RTD sensor value linearized as NI1000-DIN43760 sensor in Fahrenheit*100 in the range of -5800 to +26600 for -58.0 to +266.0 °F -32766,0x8002: Measured value is below -58°C -32767,0x8001: Measured value is above +266°C -32768,0x8000: The channel is not configured as RTD input						
RTD INPUT2 AS NI1000-DIN43760 IN FAHRENHEIT	3x41090 4x41090 I:41089	-32768,0x8000 B:80 00			SINT16 R/O	
Actual measured NI1000-DIN43760 temperature RTDlx:-32768=N/V						
RTD INPUT3 AS NI1000-DIN43760 IN FAHRENHEIT	3x41091 4x41091 I:41090	-32768,0x8000 B:80 00			SINT16 R/O	
Actual measured NI1000-DIN43760 temperature RTDlx:-32768=N/V						
RTD INPUT4 AS NI1000-DIN43760 IN FAHRENHEIT	3x41092 4x41092 I:41091	-32768,0x8000 B:80 00			SINT16 R/O	
Actual measured NI1000-DIN43760 temperature RTDlx:-32768=N/V						
RTD INPUT5 AS NI1000-DIN43760 IN FAHRENHEIT	3x41093 4x41093 I:41092	-32768,0x8000 B:80 00			SINT16 R/O	
Actual measured NI1000-DIN43760 temperature RTDlx:-32768=N/V						
RTD INPUT6 AS NI1000-DIN43760 IN FAHRENHEIT	3x41094 4x41094 I:41093	-32768,0x8000 B:80 00			SINT16 R/O	
Actual measured NI1000-DIN43760 temperature RTDlx:-32768=N/V						
RTD INPUT7 AS NI1000-DIN43760 IN FAHRENHEIT	3x41095 4x41095 I:41094	-32768,0x8000 B:80 00			SINT16 R/O	
Actual measured NI1000-DIN43760 temperature RTDlx:-32768=N/V						
RTD INPUT8 AS NI1000-DIN43760 IN FAHRENHEIT	3x41096 4x41096 I:41095	-32768,0x8000 B:80 00			SINT16 R/O	
Actual measured NI1000-DIN43760 temperature RTDlx:-32768=N/V						
<b>AIOX:RTD INPUTS OHM*100</b>						
RTD INPUT1 IN OHM*100	3x41501 4x41501 I:41500	4294967295,0xFFFFFFFF B:FF FF FF FF			UINT32 R/O	
Actual measured ohm value of RTDlx:-1=N/V						

Current measured RTD in Ohm*100 =0xFFFFFFFF: The channel is not configured as RTD input						
RTD INPUT2 IN OHM*100	3x41503 4x41503 I:41502	4294967295,0xFFFFFFFF B:FF FF FF FF			UINT32 R/O	
Actual measured ohm value of RTDIx:-1=N/V						
RTD INPUT3 IN OHM*100	3x41505 4x41505 I:41504	4294967295,0xFFFFFFFF B:FF FF FF FF			UINT32 R/O	
Actual measured ohm value of RTDIx:-1=N/V						
RTD INPUT4 IN OHM*100	3x41507 4x41507 I:41506	4294967295,0xFFFFFFFF B:FF FF FF FF			UINT32 R/O	
Actual measured ohm value of RTDIx:-1=N/V						
RTD INPUT5 IN OHM*100	3x41509 4x41509 I:41508	4294967295,0xFFFFFFFF B:FF FF FF FF			UINT32 R/O	
Actual measured ohm value of RTDIx:-1=N/V						
RTD INPUT6 IN OHM*100	3x41511 4x41511 I:41510	4294967295,0xFFFFFFFF B:FF FF FF FF			UINT32 R/O	
Actual measured ohm value of RTDIx:-1=N/V						
RTD INPUT7 IN OHM*100	3x41513 4x41513 I:41512	4294967295,0xFFFFFFFF B:FF FF FF FF			UINT32 R/O	
Actual measured ohm value of RTDIx:-1=N/V						
RTD INPUT8 IN OHM*100	3x41515 4x41515 I:41514	4294967295,0xFFFFFFFF B:FF FF FF FF			UINT32 R/O	
Actual measured ohm value of RTDIx:-1=N/V						
<b>AIOX:RTD INPUTS OHM*100</b>						
RTD INPUT1 IN OHM*100	3x41517 4x41517 I:41516	4294967295,0xFFFFFFFF B:FF FF FF FF			UINT32R R/O	
Actual measured ohm value of RTDIx:-1=N/V						
Current measured RTD in Ohm*100 =0xFFFFFFFF: The channel is not configured as RTD input						
RTD INPUT2 IN OHM*100	3x41519 4x41519 I:41518	4294967295,0xFFFFFFFF B:FF FF FF FF			UINT32R R/O	
Actual measured ohm value of RTDIx:-1=N/V						
RTD INPUT3 IN OHM*100	3x41521 4x41521 I:41520	4294967295,0xFFFFFFFF B:FF FF FF FF			UINT32R R/O	
Actual measured ohm value of RTDIx:-1=N/V						

RTD INPUT4 IN OHM*100	3x41523 4x41523 I:41522	4294967295,0xFFFFFFFF B:FF FF FF FF			UINT32R R/O	
		Actual measured ohm value of RTDlx:-1=N/V				
RTD INPUT5 IN OHM*100	3x41525 4x41525 I:41524	4294967295,0xFFFFFFFF B:FF FF FF FF			UINT32R R/O	
		Actual measured ohm value of RTDlx:-1=N/V				
RTD INPUT6 IN OHM*100	3x41527 4x41527 I:41526	4294967295,0xFFFFFFFF B:FF FF FF FF			UINT32R R/O	
		Actual measured ohm value of RTDlx:-1=N/V				
RTD INPUT7 IN OHM*100	3x41529 4x41529 I:41528	4294967295,0xFFFFFFFF B:FF FF FF FF			UINT32R R/O	
		Actual measured ohm value of RTDlx:-1=N/V				
RTD INPUT8 IN OHM*100	3x41531 4x41531 I:41530	4294967295,0xFFFFFFFF B:FF FF FF FF			UINT32R R/O	
		Actual measured ohm value of RTDlx:-1=N/V				

Register NAME Command NAME	MODBUS Register ASCII Command	Register VALUE ASCII Command	NEW REAL VALUE	NEW VALUE	DATA TYPE	DO WRITE
<b>AIOX:AVERAGE RTD INPUTS OHM*10</b>						
AVERAGE RTD INPUT1 IN OHM*10	3x42001 4x42001 l:42000	65535,0xFFFF B:FF FF			UINT16 R/O	
Measured average ohm value of RTDix:65535=N/V						
Measured average RTD in Ohm*10 between 0 and 600000 =0..60000: Measured average resistance in Ohm*10 =65534,0xFFFF: The sensor or cabling is open (broken, not connected, or out of range) =65535,0xFFFF: The channel is not configured as RTD input						
AVERAGE RTD INPUT2 IN OHM*10	3x42002 4x42002 l:42001	65535,0xFFFF B:FF FF			UINT16 R/O	
Measured average ohm value of RTDix:65535=N/V						
AVERAGE RTD INPUT3 IN OHM*10	3x42003 4x42003 l:42002	65535,0xFFFF B:FF FF			UINT16 R/O	
Measured average ohm value of RTDix:65535=N/V						
AVERAGE RTD INPUT4 IN OHM*10	3x42004 4x42004 l:42003	65535,0xFFFF B:FF FF			UINT16 R/O	
Measured average ohm value of RTDix:65535=N/V						
AVERAGE RTD INPUT5 IN OHM*10	3x42005 4x42005 l:42004	65535,0xFFFF B:FF FF			UINT16 R/O	
Measured average ohm value of RTDix:65535=N/V						
AVERAGE RTD INPUT6 IN OHM*10	3x42006 4x42006 l:42005	65535,0xFFFF B:FF FF			UINT16 R/O	
Measured average ohm value of RTDix:65535=N/V						
AVERAGE RTD INPUT7 IN OHM*10	3x42007 4x42007 l:42006	65535,0xFFFF B:FF FF			UINT16 R/O	
Measured average ohm value of RTDix:65535=N/V						
AVERAGE RTD INPUT8 IN OHM*10	3x42008 4x42008 l:42007	65535,0xFFFF B:FF FF			UINT16 R/O	
Measured average ohm value of RTDix:65535=N/V						
<b>AIOX:AVERAGE RTD INPUTS OHM*1</b>						
AVERAGE RTD INPUT1 IN OHM	3x42009 4x42009 l:42008	65535,0xFFFF B:FF FF			UINT16 R/O	

		Measured average ohm value of RTDix:65535=N/V				
Measured average RTD in Ohm*1 between 0 and 60000 =0..60000: Measured average resistance in Ohm*1 =65534,0xFFFF: The sensor or cabling is open (broken, not connected, or out of range) =65535,0xFFFF: The channel is not configured as RTD input						
AVERAGE RTD INPUT2 IN OHM	3x42010 4x42010 I:42009	65535,0xFFFF B:FF FF			UINT16 R/O	
Measured average ohm value of RTDix:65535=N/V						
AVERAGE RTD INPUT3 IN OHM	3x42011 4x42011 I:42010	65535,0xFFFF B:FF FF			UINT16 R/O	
Measured average ohm value of RTDix:65535=N/V						
AVERAGE RTD INPUT4 IN OHM	3x42012 4x42012 I:42011	65535,0xFFFF B:FF FF			UINT16 R/O	
Measured average ohm value of RTDix:65535=N/V						
AVERAGE RTD INPUT5 IN OHM	3x42013 4x42013 I:42012	65535,0xFFFF B:FF FF			UINT16 R/O	
Measured average ohm value of RTDix:65535=N/V						
AVERAGE RTD INPUT6 IN OHM	3x42014 4x42014 I:42013	65535,0xFFFF B:FF FF			UINT16 R/O	
Measured average ohm value of RTDix:65535=N/V						
AVERAGE RTD INPUT7 IN OHM	3x42015 4x42015 I:42014	65535,0xFFFF B:FF FF			UINT16 R/O	
Measured average ohm value of RTDix:65535=N/V						
AVERAGE RTD INPUT8 IN OHM	3x42016 4x42016 I:42015	65535,0xFFFF B:FF FF			UINT16 R/O	
Measured average ohm value of RTDix:65535=N/V						
<b>AIOX:AVERAGE RTD INPUTS OHM/10</b>						
AVERAGE RTD INPUT1 IN OHM/10	3x42017 4x42017 I:42016	65535,0xFFFF B:FF FF			UINT16 R/O	
Measured average ohm value of RTDix:65535=N/V						
Measured average RTD in Ohm/10 between 0 and 60000 =0..60000: Measured average resistance in Ohm/10 =65534,0xFFFF: The sensor or cabling is open (broken, not connected, or out of range) =65535,0xFFFF: The channel is not configured as RTD input						
AVERAGE RTD INPUT2 IN OHM/10	3x42018 4x42018 I:42017	65535,0xFFFF B:FF FF			UINT16 R/O	
Measured average ohm value of RTDix:65535=N/V						

AVERAGE RTD INPUT3 IN OHM/10	3x42019 4x42019 I:42018	65535,0xFFFF B:FF FF			UINT16 R/O	
		Measured average ohm value of RTDix:65535=N/V				
AVERAGE RTD INPUT4 IN OHM/10	3x42020 4x42020 I:42019	65535,0xFFFF B:FF FF			UINT16 R/O	
		Measured average ohm value of RTDix:65535=N/V				
AVERAGE RTD INPUT5 IN OHM/10	3x42021 4x42021 I:42020	65535,0xFFFF B:FF FF			UINT16 R/O	
		Measured average ohm value of RTDix:65535=N/V				
AVERAGE RTD INPUT6 IN OHM/10	3x42022 4x42022 I:42021	65535,0xFFFF B:FF FF			UINT16 R/O	
		Measured average ohm value of RTDix:65535=N/V				
AVERAGE RTD INPUT7 IN OHM/10	3x42023 4x42023 I:42022	65535,0xFFFF B:FF FF			UINT16 R/O	
		Measured average ohm value of RTDix:65535=N/V				
AVERAGE RTD INPUT8 IN OHM/10	3x42024 4x42024 I:42023	65535,0xFFFF B:FF FF			UINT16 R/O	
		Measured average ohm value of RTDix:65535=N/V				
<b>AIOX:AVERAGE RTD INPUTS PT100 CELSIUS</b>						
AVERAGE RTD INPUT1 AS PT100 IN CELSIUS	3x42025 4x42025 I:42024	-32768,0x8000 B:80 00			SINT16 R/O	
		Measured average PT100 temperature RTDix:-32768=N/V				
Calculated average value of RTD sensor value linearized as PT100 sensor in Celsius*100 in the range of -5000 to +13000 for -50.0 to +130.0 °C -32766,0x8002: Measured value is below -50°C -32767,0x8001: Measured value is above +130°C -32768,0x8000: The channel is not configured as RTD input						
AVERAGE RTD INPUT2 AS PT100 IN CELSIUS	3x42026 4x42026 I:42025	-32768,0x8000 B:80 00			SINT16 R/O	
		Measured average PT100 temperature RTDix:-32768=N/V				
AVERAGE RTD INPUT3 AS PT100 IN CELSIUS	3x42027 4x42027 I:42026	-32768,0x8000 B:80 00			SINT16 R/O	
		Measured average PT100 temperature RTDix:-32768=N/V				
AVERAGE RTD INPUT4 AS PT100 IN CELSIUS	3x42028 4x42028 I:42027	-32768,0x8000 B:80 00			SINT16 R/O	
		Measured average PT100 temperature RTDix:-32768=N/V				

AVERAGE RTD INPUT5 AS PT100 IN CELSIUS	3x42029 4x42029 I:42028	-32768,0x8000 B:80 00		SINT16 R/O	
Measured average PT100 temperature RTDIx:-32768=N/V					
AVERAGE RTD INPUT6 AS PT100 IN CELSIUS	3x42030 4x42030 I:42029	-32768,0x8000 B:80 00		SINT16 R/O	
Measured average PT100 temperature RTDIx:-32768=N/V					
AVERAGE RTD INPUT7 AS PT100 IN CELSIUS	3x42031 4x42031 I:42030	-32768,0x8000 B:80 00		SINT16 R/O	
Measured average PT100 temperature RTDIx:-32768=N/V					
AVERAGE RTD INPUT8 AS PT100 IN CELSIUS	3x42032 4x42032 I:42031	-32768,0x8000 B:80 00		SINT16 R/O	
Measured average PT100 temperature RTDIx:-32768=N/V					
<b>AIOX:AVERAGE RTD INPUTS PT1000 CELSIUS</b>					
AVERAGE RTD INPUT1 AS PT1000 IN CELSIUS	3x42033 4x42033 I:42032	-32768,0x8000 B:80 00		SINT16 R/O	
Measured average PT1000 temperature RTDIx:-32768=N/V					
Calculated average value of RTD sensor value linearized as PT1000 sensor in Celsius*100 in the range of -5000 to +13000 for -50.0 to +130.0 °C -32766,0x8002: Measured value is below -50°C -32767,0x8001: Measured value is above +130°C -32768,0x8000: The channel is not configured as RTD input					
AVERAGE RTD INPUT2 AS PT1000 IN CELSIUS	3x42034 4x42034 I:42033	-32768,0x8000 B:80 00		SINT16 R/O	
Measured average PT1000 temperature RTDIx:-32768=N/V					
AVERAGE RTD INPUT3 AS PT1000 IN CELSIUS	3x42035 4x42035 I:42034	-32768,0x8000 B:80 00		SINT16 R/O	
Measured average PT1000 temperature RTDIx:-32768=N/V					
AVERAGE RTD INPUT4 AS PT1000 IN CELSIUS	3x42036 4x42036 I:42035	-32768,0x8000 B:80 00		SINT16 R/O	
Measured average PT1000 temperature RTDIx:-32768=N/V					
AVERAGE RTD INPUT5 AS PT1000 IN CELSIUS	3x42037 4x42037 I:42036	-32768,0x8000 B:80 00		SINT16 R/O	
Measured average PT1000 temperature RTDIx:-32768=N/V					
AVERAGE RTD INPUT6 AS PT1000 IN CELSIUS	3x42038 4x42038 I:42037	-32768,0x8000 B:80 00		SINT16 R/O	
Measured average PT1000 temperature RTDIx:-32768=N/V					

AVERAGE RTD INPUT7 AS PT1000 IN CELSIUS	3x42039 4x42039 I:42038	-32768,0x8000 B:80 00			SINT16 R/O	
Measured average PT1000 temperature RTDix:-32768=N/V						
AVERAGE RTD INPUT8 AS PT1000 IN CELSIUS	3x42040 4x42040 I:42039	-32768,0x8000 B:80 00			SINT16 R/O	
Measured average PT1000 temperature RTDix:-32768=N/V						
<b>AIOX:AVERAGE RTD INPUTS NI1000-DIN43760 CELSIUS</b>						
AVERAGE RTD INPUT1 AS NI1000-DIN43760 IN CELSIUS	3x42041 4x42041 I:42040	-32768,0x8000 B:80 00			SINT16 R/O	
Measured average NI1000-DIN43760 temperature RTDix:-32768=N/V						
Calculated average value of RTD sensor value linearized as NI1000-DIN43760 sensor in Celsius*100 in the range of -5000 to +13000 for -50.0 to +130.0 °C -32766,0x8002: Measured value is below -50°C -32767,0x8001: Measured value is above +130°C -32768,0x8000: The channel is not configured as RTD input						
AVERAGE RTD INPUT2 AS NI1000-DIN43760 IN CELSIUS	3x42042 4x42042 I:42041	-32768,0x8000 B:80 00			SINT16 R/O	
Measured average NI1000-DIN43760 temperature RTDix:-32768=N/V						
AVERAGE RTD INPUT3 AS NI1000-DIN43760 IN CELSIUS	3x42043 4x42043 I:42042	-32768,0x8000 B:80 00			SINT16 R/O	
Measured average NI1000-DIN43760 temperature RTDix:-32768=N/V						
AVERAGE RTD INPUT4 AS NI1000-DIN43760 IN CELSIUS	3x42044 4x42044 I:42043	-32768,0x8000 B:80 00			SINT16 R/O	
Measured average NI1000-DIN43760 temperature RTDix:-32768=N/V						
AVERAGE RTD INPUT5 AS NI1000-DIN43760 IN CELSIUS	3x42045 4x42045 I:42044	-32768,0x8000 B:80 00			SINT16 R/O	
Measured average NI1000-DIN43760 temperature RTDix:-32768=N/V						
AVERAGE RTD INPUT6 AS NI1000-DIN43760 IN CELSIUS	3x42046 4x42046 I:42045	-32768,0x8000 B:80 00			SINT16 R/O	
Measured average NI1000-DIN43760 temperature RTDix:-32768=N/V						
AVERAGE RTD INPUT7 AS NI1000-DIN43760 IN CELSIUS	3x42047 4x42047 I:42046	-32768,0x8000 B:80 00			SINT16 R/O	
Measured average NI1000-DIN43760 temperature RTDix:-32768=N/V						
AVERAGE RTD INPUT8 AS NI1000-DIN43760 IN CELSIUS	3x42048 4x42048 I:42047	-32768,0x8000 B:80 00			SINT16 R/O	
Measured average NI1000-DIN43760 temperature RTDix:-32768=N/V						
<b>AIOX:AVERAGE RTD INPUTS PT100 KELVIN</b>						



AVERAGE RTD INPUT1 AS PT100 IN KELVIN	3x42049 4x42049 I:42048	65535,0xFFFF B:FF FF			UINT16 R/O	
Measured average PT100 temperature RTDIx:65535=655,35°K						
Average value of measured RTD sensor linearized as PT100 sensor in Kelvin*100 in the range of 22315 to 40315 for 223.15 to 403.15 °K 65533,0xFFFFD: Measured value is below 223,15°K 65534,0xFFFFE: Measured value is above 403,15°K 65535,0xFFFFF: The channel is not configured as RTD input						
AVERAGE RTD INPUT2 AS PT100 IN KELVIN	3x42050 4x42050 I:42049	65535,0xFFFF B:FF FF			UINT16 R/O	
Measured average PT100 temperature RTDIx:65535=655,35°K						
AVERAGE RTD INPUT3 AS PT100 IN KELVIN	3x42051 4x42051 I:42050	65535,0xFFFF B:FF FF			UINT16 R/O	
Measured average PT100 temperature RTDIx:65535=655,35°K						
AVERAGE RTD INPUT4 AS PT100 IN KELVIN	3x42052 4x42052 I:42051	65535,0xFFFF B:FF FF			UINT16 R/O	
Measured average PT100 temperature RTDIx:65535=655,35°K						
AVERAGE RTD INPUT5 AS PT100 IN KELVIN	3x42053 4x42053 I:42052	65535,0xFFFF B:FF FF			UINT16 R/O	
Measured average PT100 temperature RTDIx:65535=655,35°K						
AVERAGE RTD INPUT6 AS PT100 IN KELVIN	3x42054 4x42054 I:42053	65535,0xFFFF B:FF FF			UINT16 R/O	
Measured average PT100 temperature RTDIx:65535=655,35°K						
AVERAGE RTD INPUT7 AS PT100 IN KELVIN	3x42055 4x42055 I:42054	65535,0xFFFF B:FF FF			UINT16 R/O	
Measured average PT100 temperature RTDIx:65535=655,35°K						
AVERAGE RTD INPUT8 AS PT100 IN KELVIN	3x42056 4x42056 I:42055	65535,0xFFFF B:FF FF			UINT16 R/O	
Measured average PT100 temperature RTDIx:65535=655,35°K						
<b>AIOX:AVERAGE RTD INPUTS PT1000 KELVIN</b>						
AVERAGE RTD INPUT1 AS PT1000 IN KELVIN	3x42057 4x42057 I:42056	65535,0xFFFF B:FF FF			UINT16 R/O	
Measured average PT1000 temperature RTDIx:65535=655,35°K						
Average value of measured RTD sensor linearized as PT1000 sensor in Kelvin*100 in the range of 22315 to 40315 for 223.15 to 403.15 °K 65533,0xFFFFD: Measured value is below 223,15°K 65534,0xFFFFE: Measured value is above 403,15°K 65535,0xFFFFF: The channel is not configured as RTD input						

AVERAGE RTD INPUT2 AS PT1000 IN KELVIN	3x42058 4x42058 I:42057	65535,0xFFFF B:FF FF			UINT16 R/O	
Measured average PT1000 temperature RTDIx:65535=655,35°K						
AVERAGE RTD INPUT3 AS PT1000 IN KELVIN	3x42059 4x42059 I:42058	65535,0xFFFF B:FF FF			UINT16 R/O	
Measured average PT1000 temperature RTDIx:65535=655,35°K						
AVERAGE RTD INPUT4 AS PT1000 IN KELVIN	3x42060 4x42060 I:42059	65535,0xFFFF B:FF FF			UINT16 R/O	
Measured average PT1000 temperature RTDIx:65535=655,35°K						
AVERAGE RTD INPUT5 AS PT1000 IN KELVIN	3x42061 4x42061 I:42060	65535,0xFFFF B:FF FF			UINT16 R/O	
Measured average PT1000 temperature RTDIx:65535=655,35°K						
AVERAGE RTD INPUT6 AS PT1000 IN KELVIN	3x42062 4x42062 I:42061	65535,0xFFFF B:FF FF			UINT16 R/O	
Measured average PT1000 temperature RTDIx:65535=655,35°K						
AVERAGE RTD INPUT7 AS PT1000 IN KELVIN	3x42063 4x42063 I:42062	65535,0xFFFF B:FF FF			UINT16 R/O	
Measured average PT1000 temperature RTDIx:65535=655,35°K						
AVERAGE RTD INPUT8 AS PT1000 IN KELVIN	3x42064 4x42064 I:42063	65535,0xFFFF B:FF FF			UINT16 R/O	
Measured average PT1000 temperature RTDIx:65535=655,35°K						
<b>AIOX:AVERAGE RTD INPUTS NI1000-DIN43760 KELVIN</b>						
AVERAGE RTD INPUT1 AS NI1000-DIN43760 IN KELVIN	3x42065 4x42065 I:42064	65535,0xFFFF B:FF FF			UINT16 R/O	
Measured average NI1000-DIN43760 temperature RTDIx:65535=655,35°K						
Average value of measured RTD sensor linearized as NI1000-DIN43760 sensor in Kelvin*100 in the range of 22315 to 40315 for 223.15 to 403.15 °K 65533,0xFFFF: Measured value is below 223,15°K 65534,0xFFFFE: Measured value is above 403,15°K 65535,0xFFFF: The channel is not configured as RTD input						
AVERAGE RTD INPUT2 AS NI1000-DIN43760 IN KELVIN	3x42066 4x42066 I:42065	65535,0xFFFF B:FF FF			UINT16 R/O	
Measured average NI1000-DIN43760 temperature RTDIx:65535=655,35°K						
AVERAGE RTD INPUT3 AS NI1000-DIN43760 IN KELVIN	3x42067 4x42067 I:42066	65535,0xFFFF B:FF FF			UINT16 R/O	
Measured average NI1000-DIN43760 temperature RTDIx:65535=655,35°K						

AVERAGE RTD INPUT4 AS NI1000-DIN43760 IN KELVIN	3x42068 4x42068 I:42067	65535,0xFFFF B:FF FF			UINT16 R/O	
Measured average NI1000-DIN43760 temperature RTDlx:65535=655,35°K						
AVERAGE RTD INPUT5 AS NI1000-DIN43760 IN KELVIN	3x42069 4x42069 I:42068	65535,0xFFFF B:FF FF			UINT16 R/O	
Measured average NI1000-DIN43760 temperature RTDlx:65535=655,35°K						
AVERAGE RTD INPUT6 AS NI1000-DIN43760 IN KELVIN	3x42070 4x42070 I:42069	65535,0xFFFF B:FF FF			UINT16 R/O	
Measured average NI1000-DIN43760 temperature RTDlx:65535=655,35°K						
AVERAGE RTD INPUT7 AS NI1000-DIN43760 IN KELVIN	3x42071 4x42071 I:42070	65535,0xFFFF B:FF FF			UINT16 R/O	
Measured average NI1000-DIN43760 temperature RTDlx:65535=655,35°K						
AVERAGE RTD INPUT8 AS NI1000-DIN43760 IN KELVIN	3x42072 4x42072 I:42071	65535,0xFFFF B:FF FF			UINT16 R/O	
Measured average NI1000-DIN43760 temperature RTDlx:65535=655,35°K						
<b>AIOX:AVERAGE RTD INPUTS PT100 FAHRENHEIT</b>						
AVERAGE RTD INPUT1 AS PT100 IN FAHRENHEIT	3x42073 4x42073 I:42072	-32768,0x8000 B:80 00			SINT16 R/O	
Measured average PT100 temperature RTDlx:-32768=N/V						
Average value of measured RTD sensor value linearized as PT100 sensor in Fahrenheit*100 in the range of -5800 to +26600 for -58.0 to +266.0 °F -32766,0x8002: Measured value is below -58°C -32767,0x8001: Measured value is above +266°C -32768,0x8000: The channel is not configured as RTD input						
AVERAGE RTD INPUT2 AS PT100 IN FAHRENHEIT	3x42074 4x42074 I:42073	-32768,0x8000 B:80 00			SINT16 R/O	
Measured average PT100 temperature RTDlx:-32768=N/V						
AVERAGE RTD INPUT3 AS PT100 IN FAHRENHEIT	3x42075 4x42075 I:42074	-32768,0x8000 B:80 00			SINT16 R/O	
Measured average PT100 temperature RTDlx:-32768=N/V						
AVERAGE RTD INPUT4 AS PT100 IN FAHRENHEIT	3x42076 4x42076 I:42075	-32768,0x8000 B:80 00			SINT16 R/O	
Measured average PT100 temperature RTDlx:-32768=N/V						
AVERAGE RTD INPUT5 AS PT100 IN FAHRENHEIT	3x42077 4x42077 I:42076	-32768,0x8000 B:80 00			SINT16 R/O	
Measured average PT100 temperature RTDlx:-32768=N/V						

AVERAGE RTD INPUT6 AS PT100 IN FAHRENHEIT	3x42078 4x42078 I:42077	-32768,0x8000 B:80 00		SINT16 R/O	
Measured average PT100 temperature RTDIx:-32768=N/V					
AVERAGE RTD INPUT7 AS PT100 IN FAHRENHEIT	3x42079 4x42079 I:42078	-32768,0x8000 B:80 00		SINT16 R/O	
Measured average PT100 temperature RTDIx:-32768=N/V					
AVERAGE RTD INPUT8 AS PT100 IN FAHRENHEIT	3x42080 4x42080 I:42079	-32768,0x8000 B:80 00		SINT16 R/O	
Measured average PT100 temperature RTDIx:-32768=N/V					
<b>AIOX:AVERAGE RTD INPUTS PT1000 FAHRENHEIT</b>					
AVERAGE RTD INPUT1 AS PT1000 IN FAHRENHEIT	3x42081 4x42081 I:42080	-32768,0x8000 B:80 00		SINT16 R/O	
Measured average PT1000 temperature RTDIx:-32768=N/V					
Average value of measured RTD sensor value linearized as PT1000 sensor in Fahrenheit*100 in the range of -5800 to +26600 for -58.0 to +266.0 °F -32766,0x8002: Measured value is below -58°C -32767,0x8001: Measured value is above +266°C -32768,0x8000: The channel is not configured as RTD input					
AVERAGE RTD INPUT2 AS PT1000 IN FAHRENHEIT	3x42082 4x42082 I:42081	-32768,0x8000 B:80 00		SINT16 R/O	
Measured average PT1000 temperature RTDIx:-32768=N/V					
AVERAGE RTD INPUT3 AS PT1000 IN FAHRENHEIT	3x42083 4x42083 I:42082	-32768,0x8000 B:80 00		SINT16 R/O	
Measured average PT1000 temperature RTDIx:-32768=N/V					
AVERAGE RTD INPUT4 AS PT1000 IN FAHRENHEIT	3x42084 4x42084 I:42083	-32768,0x8000 B:80 00		SINT16 R/O	
Measured average PT1000 temperature RTDIx:-32768=N/V					
AVERAGE RTD INPUT5 AS PT1000 IN FAHRENHEIT	3x42085 4x42085 I:42084	-32768,0x8000 B:80 00		SINT16 R/O	
Measured average PT1000 temperature RTDIx:-32768=N/V					
AVERAGE RTD INPUT6 AS PT1000 IN FAHRENHEIT	3x42086 4x42086 I:42085	-32768,0x8000 B:80 00		SINT16 R/O	
Measured average PT1000 temperature RTDIx:-32768=N/V					
AVERAGE RTD INPUT7 AS PT1000 IN FAHRENHEIT	3x42087 4x42087 I:42086	-32768,0x8000 B:80 00		SINT16 R/O	
Measured average PT1000 temperature RTDIx:-32768=N/V					

AVERAGE RTD INPUT8 AS PT1000 IN FAHRENHEIT	3x42088 4x42088 I:42087	-32768,0x8000 B:80 00			SINT16 R/O	
Measured average PT1000 temperature RTDix:-32768=N/V						
<b>AIOX:AVERAGE RTD INPUTS NI1000-DIN43760 FAHRENHEIT</b>						
AVERAGE RTD INPUT1 AS NI1000-DIN43760 IN FAHRENHEIT	3x42089 4x42089 I:42088	-32768,0x8000 B:80 00			SINT16 R/O	
Measured average NI1000-DIN43760 temperature RTDix:-32768=N/V						
Average value of measured RTD sensor value linearized as NI1000-DIN43760 sensor in Fahrenheit*100 in the range of -5800 to +26600 for -58.0 to +266.0 °F -32766,0x8002: Measured value is below -58°C -32767,0x8001: Measured value is above +266°C -32768,0x8000: The channel is not configured as RTD input						
AVERAGE RTD INPUT2 AS NI1000-DIN43760 IN FAHRENHEIT	3x42090 4x42090 I:42089	-32768,0x8000 B:80 00			SINT16 R/O	
Measured average NI1000-DIN43760 temperature RTDix:-32768=N/V						
AVERAGE RTD INPUT3 AS NI1000-DIN43760 IN FAHRENHEIT	3x42091 4x42091 I:42090	-32768,0x8000 B:80 00			SINT16 R/O	
Measured average NI1000-DIN43760 temperature RTDix:-32768=N/V						
AVERAGE RTD INPUT4 AS NI1000-DIN43760 IN FAHRENHEIT	3x42092 4x42092 I:42091	-32768,0x8000 B:80 00			SINT16 R/O	
Measured average NI1000-DIN43760 temperature RTDix:-32768=N/V						
AVERAGE RTD INPUT5 AS NI1000-DIN43760 IN FAHRENHEIT	3x42093 4x42093 I:42092	-32768,0x8000 B:80 00			SINT16 R/O	
Measured average NI1000-DIN43760 temperature RTDix:-32768=N/V						
AVERAGE RTD INPUT6 AS NI1000-DIN43760 IN FAHRENHEIT	3x42094 4x42094 I:42093	-32768,0x8000 B:80 00			SINT16 R/O	
Measured average NI1000-DIN43760 temperature RTDix:-32768=N/V						
AVERAGE RTD INPUT7 AS NI1000-DIN43760 IN FAHRENHEIT	3x42095 4x42095 I:42094	-32768,0x8000 B:80 00			SINT16 R/O	
Measured average NI1000-DIN43760 temperature RTDix:-32768=N/V						
AVERAGE RTD INPUT8 AS NI1000-DIN43760 IN FAHRENHEIT	3x42096 4x42096 I:42095	-32768,0x8000 B:80 00			SINT16 R/O	
Measured average NI1000-DIN43760 temperature RTDix:-32768=N/V						
<b>AIOX:RTD INPUTS OHM*100</b>						
AVERAGE RTD INPUT1 IN OHM*100	3x42501 4x42501 I:42500	4294967295,0xFFFFFFFF B:FF FF FF FF			UINT32 R/O	
Measured average ohm value of RTDix:-1=N/V						

Measured average RTD in Ohm*100 =0xFFFFFFFF: The channel is not configured as RTD input						
AVERAGE RTD INPUT2 IN OHM*100	3x42503 4x42503 I:42502	4294967295,0xFFFFFFFF B:FF FF FF FF			UINT32 R/O	
Measured average ohm value of RTDix:-1=N/V						
AVERAGE RTD INPUT3 IN OHM*100	3x42505 4x42505 I:42504	4294967295,0xFFFFFFFF B:FF FF FF FF			UINT32 R/O	
Measured average ohm value of RTDix:-1=N/V						
AVERAGE RTD INPUT4 IN OHM*100	3x42507 4x42507 I:42506	4294967295,0xFFFFFFFF B:FF FF FF FF			UINT32 R/O	
Measured average ohm value of RTDix:-1=N/V						
AVERAGE RTD INPUT5 IN OHM*100	3x42509 4x42509 I:42508	4294967295,0xFFFFFFFF B:FF FF FF FF			UINT32 R/O	
Measured average ohm value of RTDix:-1=N/V						
AVERAGE RTD INPUT6 IN OHM*100	3x42511 4x42511 I:42510	4294967295,0xFFFFFFFF B:FF FF FF FF			UINT32 R/O	
Measured average ohm value of RTDix:-1=N/V						
AVERAGE RTD INPUT7 IN OHM*100	3x42513 4x42513 I:42512	4294967295,0xFFFFFFFF B:FF FF FF FF			UINT32 R/O	
Measured average ohm value of RTDix:-1=N/V						
AVERAGE RTD INPUT8 IN OHM*100	3x42515 4x42515 I:42514	4294967295,0xFFFFFFFF B:FF FF FF FF			UINT32 R/O	
Measured average ohm value of RTDix:-1=N/V						
<b>AIOX:AVERAGE RTD INPUTS OHM*100</b>						
AVERAGE RTD INPUT1 IN OHM*100	3x42517 4x42517 I:42516	4294967295,0xFFFFFFFF B:FF FF FF FF			UINT32R R/O	
Measured average ohm value of RTDix:-1=N/V						
Measured average RTD in Ohm*100 =0xFFFFFFFF: The channel is not configured as RTD input						
AVERAGE RTD INPUT2 IN OHM*100	3x42519 4x42519 I:42518	4294967295,0xFFFFFFFF B:FF FF FF FF			UINT32R R/O	
Measured average ohm value of RTDix:-1=N/V						
AVERAGE RTD INPUT3 IN OHM*100	3x42521 4x42521 I:42520	4294967295,0xFFFFFFFF B:FF FF FF FF			UINT32R R/O	
Measured average ohm value of RTDix:-1=N/V						

AVERAGE RTD INPUT4 IN OHM*100	3x42523 4x42523 I:42522	4294967295,0xFFFFFFFF B:FF FF FF FF			UINT32R R/O	
		Measured average ohm value of RTDix:-1=N/V				
AVERAGE RTD INPUT5 IN OHM*100	3x42525 4x42525 I:42524	4294967295,0xFFFFFFFF B:FF FF FF FF			UINT32R R/O	
		Measured average ohm value of RTDix:-1=N/V				
AVERAGE RTD INPUT6 IN OHM*100	3x42527 4x42527 I:42526	4294967295,0xFFFFFFFF B:FF FF FF FF			UINT32R R/O	
		Measured average ohm value of RTDix:-1=N/V				
AVERAGE RTD INPUT7 IN OHM*100	3x42529 4x42529 I:42528	4294967295,0xFFFFFFFF B:FF FF FF FF			UINT32R R/O	
		Measured average ohm value of RTDix:-1=N/V				
AVERAGE RTD INPUT8 IN OHM*100	3x42531 4x42531 I:42530	4294967295,0xFFFFFFFF B:FF FF FF FF			UINT32R R/O	
		Measured average ohm value of RTDix:-1=N/V				

Register NAME Command NAME	MODBUS Register ASCII Command	Register VALUE ASCII Command	NEW REAL VALUE	NEW VALUE	DATA TYPE	DO WRITE
<b>AIOX CHIP TEMPERATURE</b>						
TEMPERATURE CHIP 1 IN CELSIUS	3x43001 4x43001 l:43000	464,0x01D0 B:01 D0			UINT16 R/O	
Actual measured temperature of CHIPx:46,4°C						
Current measured chip temperature for CHIPx in x*10 °C. Each CHIP supports 4 AIOX channels.						
TEMPERATURE CHIP 2 IN CELSIUS	3x43002 4x43002 l:43001	475,0x01DB B:01 DB			UINT16 R/O	
Actual measured temperature of CHIPx:47,5°C						
<b>AIOX CHIP TEMPERATURE</b>						
AVERAGE TEMPERATURE CHIP 1 IN CELSIUS	3x43003 4x43003 l:43002	464,0x01D0 B:01 D0			UINT16 R/O	
Measured average temperature of CHIPx:46,4°C						
Measured average chip temperature for CHIPx in x*10 °C. Each CHIP supports 4 AIOX channels.						
AVERAGE TEMPERATURE CHIP 2 IN CELSIUS	3x43004 4x43004 l:43003	475,0x01DB B:01 DB			UINT16 R/O	
Measured average temperature of CHIPx:47,5°C						
<b>AIOX CHIP VOLTAGES</b>						
Vavdd CHIP 1 IN VOLT	3x43005 4x43005 l:43004	146,0x0092 B:00 92			UINT16 R/O	
Actual measured voltage Vavdd of CHIPx:14,6V						
Current measured voltage Vavdd for CHIPx in x*10 Volts. Each CHIP supports 4 AIOX channels. This must be >14.5V, if not, there is a severe wiring or other hardware issue!						
Vavdd CHIP 2 IN VOLT	3x43006 4x43006 l:43005	146,0x0092 B:00 92			UINT16 R/O	
Actual measured voltage Vavdd of CHIPx:14,6V						
<b>AIOX CHIP VOLTAGES</b>						
AVERAGE Vavdd CHIP 1 IN VOLT	3x43007 4x43007 l:43006	146,0x0092 B:00 92			UINT16 R/O	
Measured average voltage Vavdd of CHIPx:14,6V						
Current measured voltage Vavdd for CHIPx in x*10 Volts. Each CHIP supports 4 AIOX channels. This must be >14.5V, if not, there is a severe wiring or other hardware issue!						
AVERAGE Vavdd CHIP 2 IN VOLT	3x43008 4x43008 l:43007	146,0x0092 B:00 92			UINT16 R/O	



		Measured average voltage Vavdd of CHIPx:14,6V				
<b>AIOX CHIP VOLTAGES</b>						
Vagnd CHIP 1 IN VOLT	3x43009 4x43009 I:43008	0,0x0000 B:00 00			UINT16 R/O	
		Actual measured voltage Vagnd of CHIPx:0,0V				
Current measured voltage Vagnd for CHIPx in x*10 Volts. Each CHIP supports 4 AIOX channels. This must be 0V, if not, there is a severe wiring or other hardware issue!						
Vagnd CHIP 2 IN VOLT	3x43010 4x43010 I:43009	0,0x0000 B:00 00			UINT16 R/O	
		Actual measured voltage Vagnd of CHIPx:0,0V				
<b>AIOX CHIP VOLTAGES</b>						
AVERAGE Vagnd CHIP 1 IN VOLT	3x43011 4x43011 I:43010	0,0x0000 B:00 00			UINT16 R/O	
		Measured average voltage Vagnd of CHIPx:0,0V				
Current measured voltage Vagnd for CHIPx in x*10 Volts. Each CHIP supports 4 AIOX channels. This must be 0V, if not, there is a severe wiring or other hardware issue!						
AVERAGE Vagnd CHIP 2 IN VOLT	3x43012 4x43012 I:43011	0,0x0000 B:00 00			UINT16 R/O	
		Measured average voltage Vagnd of CHIPx:0,0V				
<b>AIOX CHIP STATUS</b>						
LIVE STATUS CHIP 1	3x43013 4x43013 I:43012	30720,0x7800 B:78 00			UINT16 R/O	
		Actual live status of CHIPx:7800				
Current live status for CHIPx. Each CHIP supports 4 AIOX channels. Each result bit stands for a different state: Bit 0: VI_ERR_CURR_A: Status of channel A:Voltage or current error detected on Channel A. This bit is interpreted differently depending on which of the following IO function selected: Voltage output: short-circuit error. The error condition is debounced for 2 ms before the status bit is set. Current output: open circuit error. The error condition is debounced for 2 ms before the status bit is set. Current input, loop powered: short-circuit error. A short to ground is detected Current input, externally powered: short-circuit error. A current source >25 mA is detected Bit 1: VI_ERR_CURR_B: Status of voltage input B. Same like VI_ERR_CURR_A Bit 2: VI_ERR_CURR_C: Status of voltage input C. Same like VI_ERR_CURR_A Bit 3: VI_ERR_CURR_D: Status of voltage input D. Same like VI_ERR_CURR_A Bit 4: HI_TEMP_STATUS: If the die temperature is typically at or above 115°C, the HI_TEMP_STATUS bit is asserted Bit 5: CHARGE_PUMP_STATUS: Charge pump error detected. Bit 6: ALDO5V_STATUS: ALDO5V Power Supply Monitor Error. This bit is asserted when the ALDO5V pin falls below 4.05 V. Usually ~5V. Bit 7: AVDD_STATUS: AVDD Power Supply Monitor Error. This bit is asserted when the AVDD pin falls below 9.26 V. Usually ~17V. Bit 8: DVCC_STATUS: DVCC Power Supply Monitor Error. This bit is asserted when the DVCC pin falls below 1.93 V. Usually ~3.3V. Bit 9: ALDO1V8_STATUS: ALDO1V8 Power Supply Monitor Error. This bit is asserted when the ALDO1V8 pin falls below 1.35 V. Usually ~1.8V. Bit 10-12: ADC_CH_CURR: Current converted channel of the ADC (0:A, 1:B, 2:C, 3:D, 4:Diagnostic 0, 5:Diagnostic 1, 6:Diagnostic 2, 7:Diagnostic 3) Bit 13: ADC_BUSY: ADC busy status bit. Bit 14: ADC_DATA_RDY:ADC data ready. The ADC_DATA_RDY bit asserts when a conversion cycle has completed. The bit stays asserted until a user writes 1 to clear the bit. In single conversion mode, the ADC_RDY pin follows the ADC_DATA_RDY bit and only deasserts when the ADC_DATA_RDY bit is cleared. In continuous conversion mode, the ADC_RDY pin returns high after 24 µs. Bit 15: RESERVED: Reserved						

LIVE STATUS CHIP 2	3x43014 4x43014 I:43013	24576,0x6000 B:60 00			UINT16 R/O	
Actual live status of CHIPx:6000						
<b>AIOX CHIP STATUS</b>						
ALERT STATUS CHIP 1	3x43015 4x43015 I:43014	33792,0x8400 B:84 00			UINT16 R/O	
Actual alert status of CHIPx:8400						
<p>Current alert status for CHIPx. Each CHIP supports 4 AIOX channels.  Each result bit stands for a different state:  Bit 0: VI_ERR_CURR_A: Status of channel A:Voltage or current error detected on Channel A. This bit is interpreted differently depending on which of the following IO function selected:  Voltage output: short-circuit error. The error condition is debounced for 2 ms before the status bit is set.  Current output: open circuit error. The error condition is debounced for 2 ms before the status bit is set.  Current input, loop powered: short-circuit error. A short to ground is detected  Current input, externally powered: short-circuit error. A current source &gt;25 mA is detected  Bit 1: VI_ERR_CURR_B: Status of voltage input B. Same like VI_ERR_CURR_A  Bit 2: VI_ERR_CURR_C: Status of voltage input C. Same like VI_ERR_CURR_A  Bit 3: VI_ERR_CURR_D: Status of voltage input D. Same like VI_ERR_CURR_A  Bit 4: HI_TEMP_STATUS: If the die temperature is typically at or above 115°C, the HI_TEMP_STATUS bit is asserted  Bit 5: CHARGE_PUMP_STATUS: Charge pump error detected.  Bit 6: ALDO5V_STATUS: ALDO5V Power Supply Monitor Error. This bit is asserted when the ALDO5V pin falls below 4.05 V. Usually ~5V.  Bit 7: AVDD_STATUS: AVDD Power Supply Monitor Error. This bit is asserted when the AVDD pin falls below 9.26 V. Usually ~17V.  Bit 8: DVCC_STATUS: DVCC Power Supply Monitor Error. This bit is asserted when the DVCC pin falls below 1.93 V. Usually ~3.3V.  Bit 9: ALDO1V8_STATUS: ALDO1V8 Power Supply Monitor Error. This bit is asserted when the ALDO1V8 pin falls below 1.35 V. Usually ~1.8V.  Bit 10: ADC_CONV_ERR: ADC Conversion Error. ADC results may be outside the selected measurement range.  Bit 11: ADC_SAT_ERR: ADC Saturation Error. ADC may be outside the user selected measurement range.  Bit 12: SPI_SCLK_CNT_ERR: SPI SCLK count error detected. This bit is asserted if an SPI command is applied but 32 SCLKs are not provided.  Bit 13: SPI_CRC_ERR: SPI CRC error detected. This bit is asserted if an invalid CRC is received.  Bit 14: CAL_MEM_ERR: Calibration Memory Error. This flag asserts under the following two conditions: When a calibration memory CRC error or an uncorrectable error correcting code (ECC) error is detected on the calibration memory upload.  It is not possible to clear this bit if there is a CRC error or uncorrectable ECC error. It is recommended to reset the device and check the supplies in this situation. When there is an attempted SPI access to a register before the calibration memory refresh is complete. Do not address the device until the calibration memory is refreshed. Writing 1 to this bit clears the flag, if the flag is asserted due to this condition.  Bit 15: RESET_OCCURRED: Reset occurred. This bit is asserted after a reset event, which asserts the ALERT pin after the reset. Write a 1 to this bit to clear the flag. Note that a mask bit is not provided for this bit.</p>						
ALERT STATUS CHIP 2	3x43016 4x43016 I:43015	33792,0x8400 B:84 00			UINT16 R/O	
Actual alert status of CHIPx:8400						
<b>AIOX SPI STATUS</b>						
SPI ERRORS CHIP 1	3x43017 4x43017 I:43016	0,0x0000 B:00 00			UINT16 R/O	
Actual SPI error counter of CHIPx:0 error(s)						
<p>Current SPI error counter for CHIPx. Each CHIP supports 4 AIOX channels.  This command shows the actual SPI errors since power up for every chip</p>						
SPI ERRORS CHIP 2	3x43018 4x43018 I:43017	0,0x0000 B:00 00			UINT16 R/O	
Actual SPI error counter of CHIPx:0 error(s)						
<b>AIOX STATE MACHINES</b>						

STATE MACHINE CHIP 1	3x43019 4x43019 I:43018	12070,0x2F26 B:2F 26			UINT16 R/O	
		Actual state of CHIPx:12070				
This command shows the acutal state of the internal communication state machine for CHIPx						
STATE MACHINE CHIP 2	3x43020 4x43020 I:43019	12050,0x2F12 B:2F 12			UINT16 R/O	
		Actual state of CHIPx:12050				
<b>AIOX ONLINE</b>						
IS ONLINE CHIP 1	3x43021 4x43021 I:43020	1,0x0001 B:00 01			UINT16 R/O	
		Is CHIPx online:1=YES				
This command shows the acutal state of the internal communication state machine for CHIPx						
IS ONLINE CHIP 2	3x43022 4x43022 I:43021	1,0x0001 B:00 01			UINT16 R/O	
		Is CHIPx online:1=YES				
<b>AIOX CLEAR ALARM STATE</b>						
CLEAR ALERT STATES CHIP 1	3x43023 4x43023 I:43022	0,0x0000 B:00 00	65535		UINT16 R/W	YES
		0:VI_ERR_A		1:RESET FLAG		
		1:VI_ERR_B		1:RESET FLAG		
		2:VI_ERR_C		1:RESET FLAG		
		3:VI_ERR_D		1:RESET FLAG		
		4:HI_TEMP_ERR		1:RESET FLAG		
		5:CHARGE_PUMP_ERR		1:RESET FLAG		
		6:ALDO5V_ERR		1:RESET FLAG		
		7:AVDD_ERR		1:RESET FLAG		
		8:DVCC_ERR		1:RESET FLAG		
		9:ALDO1V8_ERR		1:RESET FLAG		
		10:ADC_CONV_ERR		1:RESET FLAG		
		11:ADC_SAT_ERR		1:RESET FLAG		
		12:SPI_SCLK_ERR		1:RESET FLAG		
		13:SPI_CRC_ERR		1:RESET FLAG		
		14:CAL_MEM_ERR		1:RESET FLAG		
		15:RESET_OCCURED		1:RESET FLAG		
With this command you can reset individual alert bits in the alert status register of CHIPx						
CLEAR ALERT STATES CHIP 2	3x43024 4x43024 I:43023	0,0x0000 B:00 00	65535		UINT16 R/W	YES
		0:VI_ERR_A		1:RESET FLAG		
		1:VI_ERR_B		1:RESET FLAG		

		2:VI_ERR_C	1:RESET FLAG		
		3:VI_ERR_D	1:RESET FLAG		
		4:HI_TEMP_ERR	1:RESET FLAG		
		5:CHARGE_PUMP_ERR	1:RESET FLAG		
		6:ALDO5V_ERR	1:RESET FLAG		
		7:AVDD_ERR	1:RESET FLAG		
		8:DVCC_ERR	1:RESET FLAG		
		9:ALDO1V8_ERR	1:RESET FLAG		
		10:ADC_CONV_ERR	1:RESET FLAG		
		11:ADC_SAT_ERR	1:RESET FLAG		
		12:SPI_SCLK_ERR	1:RESET FLAG		
		13:SPI_CRC_ERR	1:RESET FLAG		
		14:CAL_MEM_ERR	1:RESET FLAG		
		15:RESET_OCCURED	1:RESET FLAG		

With this command you can reset individual alert bits in the alert status register of CHIPx

#### AIOX RESET STATE MACHINE

RESET CHIP 1 STATE MACHINE	3x43025 4x43025 I:43024	0,0x0000 B:00 00	1	1:RESET STATE MACHINE	UINT16 R/W	YES
-------------------------------	-------------------------------	---------------------	---	-----------------------	---------------	-----

This command restarts the state machine for chip CHIPx . The affected chip will be resetted & initialized completely

RESET CHIP 2 STATE MACHINE	3x43026 4x43026 I:43025	0,0x0000 B:00 00	1	1:RESET STATE MACHINE	UINT16 R/W	YES
-------------------------------	-------------------------------	---------------------	---	-----------------------	---------------	-----

Register NAME Command NAME	MODBUS Register ASCII Command	Register VALUE ASCII Command	NEW REAL VALUE	NEW VALUE	DATA TYPE	DO WRITE
<b>AIOX CONFIG OUTPUT VALUES</b>						
CONFIG OUTPUT VALUE AIOX1	3x44001 4x44001 I:44000	65535,0xFFFF B:FF FF	100	1	UINT16 R/W	YES
Actual config value for AIOx:N/A			ENTER NEW CONFIG VALUE FOR AIOx			
This command sets for all outputs the standard value in Volt*100 or in mA*100, which are used when the controller is restarted or a watchdog condition has occurred and the channel is used as voltage output or current output. For voltage outputs the range is 0 to 1100 (0 to 11,0V). For current outputs the range is 0 to 2500 (0 to 25mA). All IOs with a different usage type will return 65535,0xFFFF.						
CONFIG OUTPUT VALUE AIOX2	3x44002 4x44002 I:44001	65535,0xFFFF B:FF FF	200	2	UINT16 R/W	YES
Actual config value for AIOx:N/A			ENTER NEW CONFIG VALUE FOR AIOx			
CONFIG OUTPUT VALUE AIOX3	3x44003 4x44003 I:44002	65535,0xFFFF B:FF FF	300	3	UINT16 R/W	YES
Actual config value for AIOx:N/A			ENTER NEW CONFIG VALUE FOR AIOx			
CONFIG OUTPUT VALUE AIOX4	3x44004 4x44004 I:44003	65535,0xFFFF B:FF FF	400	4	UINT16 R/W	YES
Actual config value for AIOx:N/A			ENTER NEW CONFIG VALUE FOR AIOx			
CONFIG OUTPUT VALUE AIOX5	3x44005 4x44005 I:44004	65535,0xFFFF B:FF FF	500	5	UINT16 R/W	YES
Actual config value for AIOx:N/A			ENTER NEW CONFIG VALUE FOR AIOx			
CONFIG OUTPUT VALUE AIOX6	3x44006 4x44006 I:44005	65535,0xFFFF B:FF FF	600	6	UINT16 R/W	YES
Actual config value for AIOx:N/A			ENTER NEW CONFIG VALUE FOR AIOx			
CONFIG OUTPUT VALUE AIOX7	3x44007 4x44007 I:44006	65535,0xFFFF B:FF FF	700	7	UINT16 R/W	YES
Actual config value for AIOx:N/A			ENTER NEW CONFIG VALUE FOR AIOx			
CONFIG OUTPUT VALUE AIOX8	3x44008 4x44008 I:44007	65535,0xFFFF B:FF FF	800	8	UINT16 R/W	YES
Actual config value for AIOx:N/A			ENTER NEW CONFIG VALUE FOR AIOx			
<b>INTER PROCESSOR COMMUNICATION</b>						
AIOX IS ONLINE	3x50000 4x50000 I:49999	1,0x0001 B:00 01			UINT16 R/O	

	Actual communication status co-processor to AIOX processor:OK		
This command returns the actual state of the serial communication between the ARM co-processor and the additional processor for the AIOX. =1: Currently the communication is fine =0: There is a mayor problem/hardware fault between the two processors			